



# Alcatel-Lucent 7950

EXTENSIBLE ROUTING SYSTEM | RELEASE 13.0.R4  
BASIC SYSTEM CONFIGURATION GUIDE

Alcatel-Lucent – Proprietary & Confidential  
Contains proprietary/trade secret information which is the property of Alcatel-Lucent. Not to be made available to, or copied or used by anyone who is not an employee of Alcatel-Lucent except when there is a valid non-disclosure agreement in place which covers such information and contains appropriate non-disclosure and limited use obligations.  
Copyright 2015 © Alcatel-Lucent. All rights reserved.

All specifications, procedures, and information in this document are subject to change and revision at any time without notice. The information contained herein is believed to be accurate as of the date of publication. Alcatel-Lucent provides no warranty, express or implied, regarding its contents. Users are fully responsible for application or use of the documentation.

Alcatel, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent. All other trademarks are the property of their respective owners.

Copyright 2015 Alcatel-Lucent.

All rights reserved.

### **Disclaimers**

Alcatel-Lucent products are intended for commercial uses. Without the appropriate network design engineering, they must not be sold, licensed or otherwise distributed for use in any hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life-support machines, or weapons systems, in which the failure of products could lead directly to death, personal injury, or severe physical or environmental damage. The customer hereby agrees that the use, sale, license or other distribution of the products for any such application without the prior written consent of Alcatel-Lucent, shall be at the customer's sole risk. The customer hereby agrees to defend and hold Alcatel-Lucent harmless from any claims for loss, cost, damage, expense or liability that may arise out of or in connection with the use, sale, license or other distribution of the products in such applications.

This document may contain information regarding the use and installation of non-Alcatel-Lucent products. Please note that this information is provided as a courtesy to assist you. While Alcatel-Lucent tries to ensure that this information accurately reflects information provided by the supplier, please refer to the materials provided with any non-Alcatel-Lucent product and contact the supplier for confirmation. Alcatel-Lucent assumes no responsibility or liability for incorrect or incomplete information provided about non-Alcatel-Lucent products.

However, this does not constitute a representation or warranty. The warranties provided for Alcatel-Lucent products, if any, are set forth in contractual documentation entered into by Alcatel-Lucent and its customers.

This document was originally written in English. If there is any conflict or inconsistency between the English version and any other version of a document, the English version shall prevail.

# Table of Contents

<b>Preface</b> .....	11
About This Guide .....	11
Audience .....	11
List of Technical Publications .....	12
Searching for Information .....	13
To search for specific information in this guide .....	13
To search for specific information in multiple documents .....	13
Technical Support .....	15
<b>Getting Started</b>	
In This Chapter .....	17
Alcatel-Lucent 7950 XRS-Series System Configuration Process .....	17
<b>CLI Usage</b>	
In This Chapter .....	19
CLI Structure .....	20
Navigating in the CLI .....	23
CLI Contexts .....	23
Basic CLI Commands .....	24
CLI Environment Commands .....	27
CLI Monitor Commands .....	28
Getting Help in the CLI .....	29
The CLI Command Prompt .....	30
Displaying Configuration Contexts .....	31
EXEC Files .....	32
CLI Script Control .....	33
Entering CLI Commands .....	34
Command Completion .....	34
Unordered Parameters .....	34
Editing Keystrokes .....	35
Absolute Paths .....	36
History .....	37
Entering Numerical Ranges .....	37
Pipe/Match .....	39
Pipe/Count .....	43
Redirection .....	44
VI Editor .....	45
Summary of vi Commands .....	45
Using the vi Commands .....	46
EX Commands .....	48
Configuration Rollback .....	49
Feature Behavior .....	50
Rollback and SNMP .....	56
Rescue Configuration .....	57
Operational Guidelines .....	58

## Table of Contents

Transactional Configuration .....	60
Basic Operation .....	61
Transactions and Rollback .....	62
Authorization .....	63
<b>File System Management</b>	
In This Chapter .....	65
The File System .....	66
Compact Flash Devices .....	66
URLs .....	67
Wildcards .....	69
File Management Tasks .....	71
Modifying File Attributes .....	71
Creating Directories .....	72
Copying Files .....	73
Moving Files .....	74
Deleting Files and Removing Directories .....	74
Displaying Directory and File Information .....	76
Repairing the File System .....	78
File Command Reference .....	79
Command Hierarchy .....	79
Configuration Commands .....	81
Basic Command Reference .....	93
Command Hierarchies .....	93
Basic CLI Commands .....	99
<b>Boot Options</b>	
In This Chapter .....	193
System Initialization .....	194
Configuration and Image Loading .....	198
Persistence .....	200
Lawful Intercept .....	201
FIPS-140-2 Mode .....	202
Initial System Startup Process Flow .....	203
Configuration Notes .....	204
Configuring Boot File Options with CLI .....	205
BOF Configuration Overview .....	206
Basic BOF Configuration .....	207
Common Configuration Tasks .....	208
Searching for the BOF .....	209
Accessing the CLI .....	211
Console Connection .....	211
Configuring BOF Parameters .....	213
Service Management Tasks .....	214
System Administration Commands .....	214
Viewing the Current Configuration .....	214
Modifying and Saving a Configuration .....	216
Deleting BOF Parameters .....	217
Saving a Configuration to a Different Filename .....	218

Rebooting . . . . .	218
BOF Command Reference . . . . .	219
Command Hierarchies . . . . .	219
Configuration Commands . . . . .	221
BOF Processing Control . . . . .	223
Console Port Configuration . . . . .	224
Image and Configuration Management . . . . .	225
Management Ethernet Configuration . . . . .	229
DNS Configuration Commands . . . . .	232
Show Commands . . . . .	235
<b>System Management</b>	
In This Chapter . . . . .	241
System Management Parameters . . . . .	243
System Information . . . . .	243
System Name . . . . .	243
System Contact . . . . .	243
System Location . . . . .	244
System Coordinates . . . . .	244
Naming Objects . . . . .	244
Common Language Location Identifier . . . . .	245
DNS Security Extensions . . . . .	245
System Time . . . . .	246
Time Zones . . . . .	246
Network Time Protocol (NTP) . . . . .	248
SNTP Time Synchronization . . . . .	249
CRON . . . . .	250
High Availability . . . . .	251
HA Features . . . . .	252
Redundancy . . . . .	252
Nonstop Forwarding . . . . .	255
Nonstop Routing (NSR) . . . . .	255
CPM Switchover . . . . .	256
Synchronization . . . . .	257
Synchronization and Redundancy . . . . .	258
Active and Standby Designations . . . . .	259
When the Active CPM Goes Offline . . . . .	261
OOB Management Ethernet Port Redundancy . . . . .	262
Network Synchronization . . . . .	264
Central Synchronization Sub-System . . . . .	265
7950 XRS-40 Extension Chassis Central Clocks . . . . .	266
Synchronization Status Messages (SSM) . . . . .	267
DS1 Signals . . . . .	267
E1 Signals . . . . .	267
Synchronous Ethernet . . . . .	268
Clock Source Quality Level Definitions . . . . .	269
Link Layer Discovery Protocol (LLDP) . . . . .	271
IP Hashing as an LSR . . . . .	274
Administrative Tasks . . . . .	275
Saving Configurations . . . . .	276

## Table of Contents

Specifying Post-Boot Configuration Files .....	277
Network Timing .....	278
Automatic Synchronization .....	279
Boot-Env Option .....	279
Config Option .....	279
Manual Synchronization .....	280
Forcing a Switchover .....	280
System Configuration Process Overview .....	281
Configuration Notes .....	282
General .....	282
Configuring System Management with CLI .....	283
System Management .....	284
Saving Configurations .....	284
Basic System Configuration .....	285
Common Configuration Tasks .....	286
System Information .....	287
System Information Parameters .....	288
Coordinates .....	290
System Time Elements .....	291
ANCP Enhancements .....	311
Configuring Synchronization and Redundancy .....	312
Configuring Synchronization .....	312
Configuring Manual Synchronization .....	313
Forcing a Switchover .....	313
Configuring Synchronization Options .....	314
Configuring Multi-Chassis Redundancy .....	314
Configuring Backup Copies .....	317
Post-Boot Configuration Extension Files .....	318
System Timing .....	321
Edit Mode .....	322
Configuring Timing References .....	323
Using the Revert Command .....	324
Other Editing Commands .....	325
Forcing a Specific Reference .....	326
Configuring System Monitoring Thresholds .....	327
Creating Events .....	327
System Alarm Contact Inputs .....	329
Configuring LLDP .....	330
System Command Reference .....	331
Command Hierarchies .....	331
System Command Reference .....	347
Show Commands .....	443
Debug Commands .....	509
Clear Commands .....	521
<b>Standards and Protocol Support .....</b>	<b>527</b>

# List of Tables

Table 1: List of Technical Publications . . . . .	12
---	----

## Getting Started

Table 2: Configuration Process . . . . .	17
--	----

## CLI Usage

Table 3: Console Control Commands . . . . .	24
Table 4: Command Syntax Symbols . . . . .	26
Table 5: CLI Environment Commands . . . . .	27
Table 6: CLI Monitor Command Contexts . . . . .	28
Table 7: Online Help Commands . . . . .	29
Table 8: Command Editing Keystrokes . . . . .	35
Table 9: CLI Range Use Limitations . . . . .	38
Table 10: Regular Expression Symbols . . . . .	41
Table 11: Special Characters . . . . .	41
Table 12: Cutting and Pasting/Deleting Text in vi . . . . .	46
Table 13: Inserting New Text . . . . .	46
Table 14: Moving the Cursor Around the Screen . . . . .	47
Table 15: Replacing Text . . . . .	47
Table 16: EX commands . . . . .	48

## File System Management

Table 17: URL Types and Syntax . . . . .	67
Table 18: File Command Local and Remote File System Support . . . . .	70
Table 19: Show Alias Output Fields . . . . .	191

## Boot Options

Table 20: Console Configuration Parameter Values . . . . .	211
Table 21: Show BOF Output Fields . . . . .	235

## System Management

Table 22: System-defined Time Zones . . . . .	246
Table 23: CPM LEDs . . . . .	259
Table 24: Revertive, non-Revertive Timing Reference Switching Operation . . . . .	266
Table 25: System-defined Time Zones . . . . .	292

## List of Tables

# List of Figures

## CLI Usage

Figure 1: Root Commands . . . . .	21
Figure 2: Operational Root Commands . . . . .	22
Figure 3: Rollback Operation . . . . .	49
Figure 4: Configuration Rollback . . . . .	52
Figure 5: Router Configuration with Rollback and Transactions . . . . .	60

## File System Management

### Boot Options

Figure 6: System Initialization - Part 1 . . . . .	195
Figure 7: Files on the Compact Flash . . . . .	196
Figure 8: Files on the Compact Flash . . . . .	197
Figure 9: System Initialization - Part 2 . . . . .	199
Figure 10: System Startup Flow . . . . .	203

### System Management

Figure 11: CPM LEDs . . . . .	259
Figure 12: Management Ethernet: Normal Mode . . . . .	262
Figure 13: Management Ethernet: Redundancy Mode (FID 120 placeholder) . . . . .	263
Figure 14: Conventional Network Timing Architecture (North American Nomenclature) . . . . .	264
Figure 15: LLDP Internal Architecture for a Network Node . . . . .	272
Figure 16: Customer Use Example For LLDP . . . . .	273
Figure 17: System Configuration and Implementation Flow . . . . .	281

## List of Figures

# Preface

---

## About This Guide

This guide describes system concepts and provides configuration explanations and examples to configure SR-OS boot option file (BOF), file system and system management functions.

This guide is organized into functional chapters and provides concepts and descriptions of the implementation flow, as well as Command Line Interface (CLI) syntax and command usage.

---

## Audience

This guide is intended for network administrators who are responsible for configuring the 7950 XRS routers. It is assumed that the network administrators have an understanding of networking principles and configurations. Concepts described in this guide include the following:

- CLI concepts
- File system concepts
- Boot option, configuration, image loading, and initialization procedures
- Basic system management functions such as the system name, router location and coordinates, and CLLI code, time zones, Network Time Protocol (NTP), Simple Network Time Protocol (SNTP), and synchronization properties

## List of Technical Publications

The 7950 XRS documentation set is composed of the following guides:

**Table 1: List of Technical Publications**

Guide	Description
7950 XRS Basic System Configuration Guide	This guide describes basic system configurations and operations.
7950 XRS System Management Guide	This guide describes system security and access configurations as well as event logging and accounting logs.
7950 XRS Interface Configuration Guide	This guide describes XMA Control Module (XCM), XRS Media Adaptor (XMA), port and Link Aggregation Group (LAG) provisioning.
7950 XRS Router Configuration Guide	This guide describes logical IP routing interfaces and associated attributes such as an IP address, as well as IP and MAC-based filtering, and VRRP and Cflowd.
7950 XRS Routing Protocols Guide	This guide provides an overview of routing concepts and provides configuration examples for RIP, OSPF, IS-IS, BGP, and route policies.
7950 XRS MPLS Guide	This guide describes how to configure Multiprotocol Label Switching (MPLS) and Label Distribution Protocol (LDP).
7950 XRS Services Guide	This guide describes how to configure service parameters such as service distribution points (SDPs), customer information, and user services.
7950 XRS Layer 2 Services and EVPN Guide: VLL, VPLS, PBB, and EVPN	This guide describes Virtual Leased Lines (VLL), Virtual Private LAN Service (VPLS), Provider Backbone Bridging (PBB), and Ethernet VPN (EVPN).
7950 XRS Layer 3 Services Guide: Internet Enhanced Services and Virtual Private Routed Network Services	This guide describes Internet Enhanced Services (IES) and Virtual Private Routed Network (VPRN) services.
7950 XRS Versatile Service Module Guide	This guide describes how to configure service parameters for the Versatile Service Module (VSM).

**Table 1: List of Technical Publications**

Guide	Description
7950 XRS OAM and Diagnostics Guide	This guide describes how to configure features such as service mirroring and Operations, Administration and Management (OAM) tools.
7950 XRS Quality of Service Guide	This guide describes how to configure Quality of Service (QoS) policy management.

## Searching for Information

You can use Adobe Reader, Release 6.0 or later, to search one or more PDF files for a term.

### To search for specific information in this guide

1. From the Adobe Reader main menu, choose Edit > Search or Advanced Search. The Search panel opens.
2. Click on the In the current document radio button.
3. Enter the term to search for.
4. Select the following search criteria, if required:
  - Whole words only
  - Case-Sensitive
  - Include Bookmarks
  - Include Comments
5. Click on the Search button. Adobe Reader displays the search results.

You can expand the entries by clicking on the + symbol.

### To search for specific information in multiple documents

Note: The PDF files that you search must be in the same folder.

1. From the Adobe Reader main menu, choose Edit > Search or Advanced Search. The Search panel opens.
2. Click on the All PDF Documents in radio button.

3. Choose the folder in which to search using the drop-down menu.
4. Enter the term to search for.
5. Select the following search criteria, if required:
  - Whole words only
  - Case-Sensitive
  - Include Bookmarks
  - Include Comments
6. Click on the Search button. Adobe Reader displays the search results.

You can expand the entries for each file by clicking on the + symbol.

## Technical Support

If you purchased a service agreement for your 7950 SR-Series router and related products from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance. If you purchased an Alcatel-Lucent service agreement, follow this link to contact an Alcatel-Lucent support representative and to access product manuals and documentation updates:

**<https://support2.alcatel-lucent.com/portal/olcsHome.do>**



# Getting Started

---

## In This Chapter

This chapter provides process flow information to configure basic router and system parameters, perform operational functions with directory and file management, and boot option tasks.

---

## Alcatel-Lucent 7950 XRS-Series System Configuration Process

[Table 2](#) lists the tasks necessary to configure boot option files (BOF) and system and file management functions. Each chapter in this book is presented in an overall logical configuration flow. Each section describes a software area and provides CLI syntax and command usage to configure parameters for a functional area. After the hardware installation has been properly completed, proceed with the 7950 XRS configuration tasks in the following order:

**Table 2: Configuration Process**

Area	Task	Chapter
CLI Usage	The CLI structure	<a href="#">CLI Usage on page 19</a>
	Basic CLI commands	<a href="#">Basic CLI Commands on page 24</a>
	Configure environment commands	<a href="#">CLI Environment Commands on page 27</a>
	Configure monitor commands	<a href="#">CLI Monitor Commands on page 28</a>
Operational functions	Directory and file management	<a href="#">File System Management on page 65</a>

**Table 2: Configuration Process**

Area	Task	Chapter (Continued)
Boot options	Configure boot option files (BOF)	<a href="#">Boot Options on page 193</a>
System configuration	Configure system functions, including host name, address, domain name, and time parameters.	<a href="#">System Management on page 241</a>
Reference	List of IEEE, IETF, and other proprietary entities.	<a href="#">Standards and Protocol Support on page 527</a>

**Note:** In SR OS 12.0.R4 any function that displays an IPv6 address or prefix changes to reflect rules described in RFC 5952, *A Recommendation for IPv6 Address Text Representation*. Specifically, hexadecimal letters in IPv6 addresses are now represented in lowercase, and the correct compression of all leading zeros is displayed. This changes visible display output compared to previous SR OS releases. Previous SR OS behavior can cause issues with operator scripts that use standard IPv6 address expressions and with libraries that have standard IPv6 parsing as per RFC 5952 rules. See the section on IPv6 Addresses in the Router Configuration Guide for more information.

## In This Chapter

This chapter provides information about using the command-line interface (CLI).

Topics in this chapter include:

- [CLI Structure on page 20](#)
- [Navigating in the CLI on page 23](#)
- [Basic CLI Commands on page 24](#)
- [CLI Environment Commands on page 27](#)
- [CLI Monitor Commands on page 28](#)
- [Getting Help in the CLI on page 29](#)
- [The CLI Command Prompt on page 30](#)
- [Displaying Configuration Contexts on page 31](#)
- [EXEC Files on page 32](#)
- [CLI Script Control on page 33](#)
- [Entering CLI Commands on page 34](#)

## CLI Structure

Alcatel-Lucent's SR OS CLI is a command-driven interface accessible through the console, Telnet and secure shell (SSH). The CLI can be used for configuration and management of SR OS routers.

The SR OS CLI command tree is a hierarchical inverted tree. At the highest level is the ROOT level. Below this level are other tree levels with the major command groups; for example, **configuration** commands and **show** commands are levels below ROOT.

The CLI is organized so related commands with the same scope are at the same level or in the same context. Sublevels or subcontexts have related commands with a more refined scope.




Figure 1: Root Commands

# CLI Structure




Figure 2: Operational Root Commands

# Navigating in the CLI

The following sections describe additional navigational and syntax information.

- [CLI Contexts on page 23](#)
- [Basic CLI Commands on page 24](#)
- [CLI Environment Commands on page 27](#)
- [CLI Monitor Commands on page 28](#)
- [Entering Numerical Ranges on page 37](#)

---

## CLI Contexts

Use the CLI to access, configure, and manage Alcatel-Lucent's SR OS routers. CLI commands are entered at the command line prompt. Access to specific CLI commands is controlled by the permissions set by your system administrator. Entering a CLI command makes navigation possible from one command context (or level) to another.

When you initially enter a CLI session, you are in the ROOT context. Navigate to another level by entering the name of successively lower contexts. For example, enter either the **configure** or **show** commands at the ROOT context to navigate to the **config** or **show** context, respectively. For example, at the command prompt (**#**), enter **config**. The active context displays in the command prompt.

```
A:ALA-12# config
A:ALA-12>config#
```

In a given CLI context, enter commands at that context level by simply entering the text. It is also possible to include a command in a lower context as long as the command is formatted in the proper command and parameter syntax.

The following example shows two methods to navigate to a service SDP ingress level:  
Method 1:

```
A:ALA-12# configure service epipe 6 spoke-sdp 2:6 ingress
*A:ALA-12>config>service>epipe>spoke-sdp>ingress#
```

Method 2:

```
A:ALA-12>config# service
A:ALA-12>config>service# epipe 6
*A:ALA-12>config>service>epipe# spoke-sdp 2:6
*A:ALA-12>config>service>epipe>spoke-sdp# ingress
*A:ALA-12>config>service>epipe>spoke-sdp>ingress#
```

The CLI returns an error message when the syntax is incorrect.

```
*A:ALA-12>config# router
Error: Bad command.
```

## Basic CLI Commands

The console control commands are the commands that are used for navigating within the CLI and displaying information about the console session. Most of these commands are implemented as global commands. They can be entered at any level in the CLI hierarchy with the exception of the `password` command which must be entered at the ROOT level. The console control commands are listed in [Table 3](#).

**Table 3: Console Control Commands**

Command	Description	Page
<Ctrl-c>	Aborts the pending command.	
<Ctrl-z>	Terminates the pending command line and returns to the ROOT context.	
back	Navigates the user to the parent context.	100
clear	Clears statistics for a specified entity or clears and resets the entity.	100
echo	Echos the text that is typed in. Primary use is to display messages to the screen within an <code>exec</code> file.	101
exec	Executes the contents of a text file as if they were CLI commands entered at the console.	101
exit	Returns the user to the previous higher context.	101
exit all	Returns the user to the ROOT context.	102
help	Displays help in the CLI.	103
?		
history	Displays a list of the most recently entered commands.	104
info	Displays the running configuration for a configuration context.	105
logout	Terminates the CLI session.	107
oam	Provides OAM test suite options. See the OAM section of the SR OS OAM and Diagnostic Guide.	
password	Changes the user CLI login password. The password can only be changed at the ROOT level.	109
ping	Verifies the reachability of a remote host.	110
pwc	Displays the present or previous working context of the CLI session.	112

**Table 3: Console Control Commands (Continued)**

Command	Description	Page
sleep	Causes the console session to pause operation (sleep) for one second or for the specified number of seconds. Primary use is to introduce a pause within the execution of an <code>exec</code> file.	112
ssh	Opens a secure shell connection to a host.	113
telnet	Telnet to a host.	113
traceroute	Determines the route to a destination address.	114
tree	Displays a list of all commands at the current level and all sublevels.	115
write	Sends a console message to a specific user or to all users with active console sessions.	115

The list of all system global commands is displayed by entering `help globals` in the CLI. For example:

```
*A:ALA-12>config>service# help globals
back          - Go back a level in the command tree
echo          - Echo the text that is typed in
enable-admin  - Enable the user to become a system administrator
exec          - Execute a file - use -echo to show the commands and
               prompts on the screen
exit          - Exit to intermediate mode - use option all to exit to
               root prompt
help          - Display help
history       - Show command history
info         - Display configuration for the present node
logout       - Log off this system
mrinfo       - Request multicast router information
mstat        - Trace multicast path from a source to a receiver and
               display multicast packet rate and loss information
mtrace       - Trace multicast path from a source to a receiver
oam          + OAM Test Suite
ping         - Verify the reachability of a remote host
pwc          - Show the present working context
sleep        - Sleep for specified number of seconds
ssh          - SSH to a host
telnet       - Telnet to a host
traceroute   - Determine the route to a destination address
tree         - Display command tree structure from the context of
               execution
write        - Write text to another user
*A:ALA-12>config>service#
```

[Table 4](#) lists describes command syntax symbols.

**Table 4: Command Syntax Symbols**

Symbol	Description
	A vertical line indicates that one of the parameters within the brackets or braces is required. <code>tcp-ack {true false}</code>
[ ]	Brackets indicate optional parameters. <code>redirects [number seconds]</code>
< >	Angle brackets indicate that you must enter text based on the parameter inside the brackets. <code>interface &lt;interface-name&gt;</code>
{ }	Braces indicate that one of the parameters must be selected. <code>default-action {drop forward}</code>
[{ }]	Braces within square brackets indicates that you must choose one of the optional parameters. <ul style="list-style-type: none"> <li>• <code>sdp sdp-id [{gre mpls}]</code></li> </ul>
<b>Bold</b>	Commands in <b>bold</b> indicate commands and keywords.
<i>Italic</i>	Commands in <i>italics</i> indicate command options.

## CLI Environment Commands

The CLI **environment** commands are found in the **root>environment** context of the CLI tree and controls session preferences for a single CLI session. The CLI **environment** commands are listed in [Table 5](#).

**Table 5: CLI Environment Commands**

Command	Description	Page
alias	Enables the substitution of a command line by an alias.	<a href="#">116</a>
create	Enables or disables the use of a create parameter check.	<a href="#">116</a>
more	Configures whether CLI output should be displayed one screen at a time awaiting user input to continue.	<a href="#">116</a>
reduced-prompt	Configures the maximum number of higher-level CLI context nodes to display by name in the CLI prompt for the current CLI session.	<a href="#">117</a>
saved-ind-prompt	Saves the indicator in the prompt.	<a href="#">117</a>
suggest-internal-objects	Enables the suggestion of internally created objects while auto completing.	<a href="#">118</a>
terminal	Configures the terminal screen length for the current CLI session.	<a href="#">118</a>
time-display	Specifies whether time should be displayed in local time or UTC.	<a href="#">118</a>

## CLI Monitor Commands

Monitor commands display specified statistical information related to the monitor subject (such as filter, port, QoS, router, service, and VRRP) at a configurable interval until a count is reached. The CLI **monitor** commands are found in the `root>monitor` context of the CLI tree.

The **monitor** command output displays a snapshot of the current statistics. The output display refreshes with subsequent statistical information at each configured interval and is displayed as a delta to the previous display.

The `<Ctrl-c>` keystroke interrupts a monitoring process. Monitor command configurations cannot be saved. You must enter the command for each monitoring session. Note that if the maximum limits are configured, you can monitor the statistical information for a maximum of 60 \* 999 sec ~ 1000 minutes.

The CLI monitor command contexts are listed in [Table 6](#).

**Table 6: CLI Monitor Command Contexts**

Command	Description	Page
card	Enables monitoring of ingress FP queue groups.	<a href="#">135</a>
cpm-filter	Monitor command output for CPM filters.	<a href="#">121</a>
filter	Enables IP and MAC filter monitoring at a configurable interval until that count is reached.	<a href="#">123</a>
lag	Enables Link Aggregation Group (LAG) monitoring to display statistics for individual port members and the LAG.	<a href="#">128</a>
management-access-filter	Enables management access filter monitoring.	<a href="#">129</a>
port	Enables port traffic monitoring. The specified port(s) statistical information displays at the configured interval until the configured count is reached.	<a href="#">131</a>
qos	Enables arbiter and scheduler statistics monitoring.	<a href="#">133</a>
router	Enables virtual router instance monitoring at a configurable interval until that count is reached.	<a href="#">142</a>
service	Monitors commands for a particular service.	<a href="#">168</a>

## Getting Help in the CLI

The **help** system commands and the `?` key display different types of help in the CLI. [Table 7](#) lists the different help commands.

**Table 7: Online Help Commands**

Command	Description
<code>help ?</code>	List all commands in the current context.
<code>string ?</code>	List all commands available in the current context that start with <i>string</i> .
<code>command ?</code>	Displays the command's syntax and associated keywords.
<code>command keyword ?</code>	List the associated arguments for <i>keyword</i> in <i>command</i> .
<code>string&lt;Tab&gt;</code>	Complete a partial command name (auto-completion) or list available commands that match <i>string</i> .

The **tree** and **tree detail** system commands are help commands useful when searching for a command in a lower-level context.

## The CLI Command Prompt

By default, the CLI command prompt indicates the device being accessed and the current CLI context. For example, the prompt: **A:ALA-1>config>router>if#** indicates the active context, the user is on the device with hostname ALA-1 in the **configure>router>interface** context. In the prompt, the separator used between contexts is the “>” symbol.

At the end of the prompt, there is either a pound sign (“#”) or a dollar sign (“\$”). A “#” at the end of the prompt indicates the context is an existing context. A “\$” at the end of the prompt indicates the context has been newly created. New contexts are newly created for logical entities when the user first navigates into the context.

Since there can be a large number of sublevels in the CLI, the **environment** command **reduced-prompt** *no of nodes in prompt* allows the user to control the number of levels displayed in the prompt.

All special characters (#, \$, etc.) must be enclosed within double quotes, otherwise it is seen as a comment character and all characters on the command line following the # are ignored. For example:

```
*A:ALA-1>config>router# interface "primary#1"
```

When changes are made to the configuration file a “\*” appears in the prompt string ( ) indicating that the changes have not been saved. When an admin save command is executed the “\*” disappears. This behavior is controlled in the **saved-ind-prompt** command in the **environment** context.

## Displaying Configuration Contexts

The `info` and `info detail` commands display configuration for the current level. The `info` command displays non-default configurations. The `info detail` command displays the entire configuration for the current level, including defaults. The following example shows the output that displays using the `info` command and the output that displays using the `info detail` command.

```
*A:ALA-1>config>router# interface system
*A:ALA-1>config>router>if# info
-----
                address 10.10.0.1/32
-----
*A:ALA-1>config>router>if#

*A:ALA-1>config>router>if# info detail
-----
                address 10.10.10.103/32 broadcast host-ones
                no description
                no arp-timeout
                no allow-directed-broadcasts
                tos-marking-state trusted
                no local-proxy-arp
                no proxy-arp
                icmp
                    mask-reply
                    redirects 100 10
                    unreachable 100 10
                    ttl-expired 100 10
                exit
                no mac
                no ntp-broadcast
                no cflowd
                no shutdown
-----
*A:ALA-1>config>router>if#
```

## EXEC Files

The `exec` command allows you to execute a text file of CLI commands as if it were typed at a console device.

The `exec` command and the associated `exec` files can be used to conveniently execute a number of commands that are always executed together in the same order. For example, an `exec` command can be used by a user to define a set of commonly used standard command aliases.

The `echo` command can be used within an `exec` command file to display messages on screen while the file executes.

## CLI Script Control

SR OS provides centralized script management for CLI scripts that are used by CRON and the Event Handling System (EHS). A set of script policies and script objects can be configured to control the following items and more:

- Where scripts are located (local compact flash, remote FTP server)
- Where to store the output of the results
- How long to keep historical script result records
- How long a script may run

If the scripts are located on local compact flash devices then the user must ensure that the scripts are on the compact flash devices of both CPMs so that operation of EHS continues as expected if a CPM switchover occurs.

A single script can be executing at one time. A table (SNMP smRunTable in the DISMAN-SCRIPT-MIB) is used as both an input queue of scripts waiting to be executed as well as for storage of records for completed scripts. If the input queue is full then the script request is discarded.

# Entering CLI Commands

---

## Command Completion

The CLI supports both command abbreviation and command completion. If the keystrokes entered are enough to match a valid command, the CLI displays the remainder of the command syntax when the <Tab> key or space bar is pressed. When typing a command, the <Tab> key or space bar invokes auto-completion. If the keystrokes entered are definite, auto-completion will complete the command. If the letters are not sufficient to identify a specific command, pressing the <Tab> key or space bar will display commands matching the letters entered.

System commands are available in all CLI context levels.

---

## Unordered Parameters

In a given context, the CLI accepts command parameters in any order as long as the command is formatted in the proper command keyword and parameter syntax. Command completion will still work as long as enough recognizable characters of the command are entered.

The following output shows different **static-route** command syntax and an example of the command usage.

```
*A:ALA-12>config>router# static-route ?
- [no] static-route {<ip-prefix/mask>|<ip-prefix> <netmask>} [preference <preference>]
  [metric <metric>] [tag <tag>] [enable|disable] next-hop <ip-address|ip-int-name>
- [no] static-route {<ip-prefix/mask>|<ip-prefix> <netmask>} [preference <preference>]
  [metric <metric>] [tag <tag>] [enable|disable] indirect <ip-address> [ldp
  [disallow-igp]]
- [no] static-route {<ip-prefix/mask>|<ip-prefix> <netmask>} [preference <preference>]
  [metric <metric>] [tag <tag>] [enable|disable] black-hole
*A:ALA-12>config>router# static-route preference 1 10.1.0.0/16 metric
```

## Editing Keystrokes

When entering a command, special keystrokes allow for editing of the command. [Table 8](#) lists the command editing keystrokes.

**Table 8: Command Editing Keystrokes**

Editing Action	Keystrokes
Delete current character	<Ctrl-d>
Delete text up to cursor	<Ctrl-u>
Delete text after cursor	<Ctrl-k>
Move to beginning of line	<Ctrl-a>
Move to end of line	<Ctrl-e>
Get prior command from history	<Ctrl-p>
Get next command from history	<Ctrl-n>
Move cursor left	<Ctrl-b>
Move cursor right	<Ctrl-f>
Move back one word	<Esc><b>
Move forward one word	<Esc><f>
Convert rest of word to uppercase	<Esc><c>
Convert rest of word to lowercase	<Esc><l>
Delete remainder of word	<Esc><d>
Delete word up to cursor	<Ctrl-w>
Transpose current and previous character	<Ctrl-t>
Enter command and return to root prompt	<Ctrl-z>
Refresh input line	<Ctrl-l>

## Absolute Paths

CLI commands can be executed in any context by specifying the full path from the CLI root. To execute an out-of-context command enter a forward slash “/” or backward slash “\” at the beginning of the command line. The forward slash “/” or backward slash “\” cannot be used with the **environment alias** command. The commands are interpreted as absolute path. Spaces between the slash and the first command will return an error. Commands that are already global (such as ping, telnet, exit, back, etc.) cannot be executed with a forward slash “/” or backward slash “\” at the beginning of the command line.

```
*A:ALA-12# configure router
*A:ALA-12>config>router# interface system address 1.2.3.4
*A:ALA-12>config>router# /admin save
*A:ALA-12>config>router# \clear router interface
*A:ALA-12>config>router#
```

The command may or may not change the current context depending on whether or not it is a leaf command. This is the same behavior the CLI performs when CLI commands are entered individually, for example:

```
*A:ALA-12# admin
*A:ALA-12>admin# save
OR
*A:ALA-12# admin save
*A:ALA-12#
```

Note that an absolute path command behaves the same as manually entering a series of command line instructions and parameters.

For example, beginning in an IES context service ID 4 (IES 4),

**CLI Syntax:** config>service>ies> /clear card 1

behaves the same as the following series of commands.

**Example:** config>service>ies>exit all  
clear card 1  
configure service ies 4 (returns you to your starting point)  
config>service>ies

If the command takes you to a different context, the following occurs:

**CLI Syntax:** config>service>ies>/configure service ies 5 create

becomes

**Example:** config>service>ies>exit all  
configure service vpls 5 create  
config>service>vpls>

## History

The CLI maintains a history of the most recently entered commands. The `history` command displays the most recently entered CLI commands.

```
*A:ALA-1# history
 1 environment terminal length 48
 2 environment no create
 3 show version
 4 configure port 1/1/1
 5 info
 6 \configure router isis
 7 \port 1/1/2
 8 con port 1/1/2
 9 \con port 1/1/2
10 \configure router bgp
11 info
12 \configure system login-control
13 info
14 history
15 show version
16 history
*A:ALA-1# !3
```

## Entering Numerical Ranges

The SR OS CLI allows the use of a single numerical range as an argument in the command line. A range in a CLI command is limited to positive integers and is denoted with two numbers enclosed in square brackets with two periods (“.”) between the numbers:

$$[x..y]$$

where  $x$  and  $y$  are positive integers and  $y-x$  is less than 1000.

For example, it is possible to shut down ports 1 through 10 in Slot 1 on XMA/MDA 1. A port is denoted with “*slot/mda/port*”, where *slot* is the slot number, *mda* is the XMA/MDA number and *port* is the port number. To shut down ports 1 through 10 on Slot 1 and XMA/MDA 1, the command is entered as follows:

```
configure port 1/1/[1..10] shutdown
```

<Ctrl-C> can be used to abort the execution of a range command.

Specifying a range in the CLI does have limitations. These limitations are summarized in [Table 9](#).

**Table 9: CLI Range Use Limitations**

Limitation	Description
Only a single range can be specified.	<p>It is not possible to shut down ports 1 through 10 on XMA/MDA 1 and XMA/MDA 2, as the command would look like</p> <pre>configure port 1/[1..2]/[1..10]</pre> <p>and requires two ranges in the command, [1..2] for the XMA/MDA and [1..10] for the port number.</p>
Ranges within quotation marks are interpreted literally.	<p>In the CLI, enclosing a string in quotation marks ("string") causes the string to be treated literally and as a single parameter. For example, several commands in the CLI allow the configuration of a descriptive string. If the string is more than one word and includes spaces, it must be enclosed in quotation marks. A range that is enclosed in quotes is also treated literally. For example,</p> <pre>configure router interface "A[1..10]" no shutdown</pre> <p>creates a single router interface with the name "A[1..10]". However, a command such as:</p> <pre>configure router interface A[1..10] no shutdown</pre> <p>creates 10 interfaces with names A1, A2 .. A10.</p>
The range cannot cause a change in contexts.	<p>Commands should be formed in such a way that there is no context change upon command completion. For example,</p> <pre>configure port 1/1/[1..10]</pre> <p>will attempt to change ten different contexts. When a range is specified in the CLI, the commands are executed in a loop. On the first loop execution, the command changes contexts, but the new context is no longer valid for the second iteration of the range loop. A "Bad Command" error is reported and the command aborts.</p>
Command completion may cease to work when entering a range.	<p>After entering a range in a CLI command, command and key completion, which normally occurs by pressing the &lt;Tab&gt; or spacebar, may cease to work. If the command line entered is correct and unambiguous, the command works properly; otherwise, an error is returned.</p>

## Pipe/Match

The SR OS supports the pipe feature to search one or more files for a given character string or pattern.

**Note:** When using the pipe/match command the variables and attributes must be spelled correctly. The attributes following the command and must come before the expression/pattern. The following displays examples of the pipe/match command to complete different tasks:

- Task: Capture all the lines that include “echo” and redirect the output to a file on the compact flash:  
**admin display-config | match “echo” > cf1:\test\echo\_list.txt**
- Task: Display all the lines that do not include “echo”:  
**admin display-config | match invert-match “echo”**
- Task: Display the first match of “vpls” in the configuration file:  
**admin display-config | match max-count 1 “vpls”**
- Task: Display everything in the configuration after finding the first instance of “interface”:  
**admin display-config | match post-lines 999999 interface**
- Task: Display a count of the total number of lines of output instead of displaying the output itself.  
**admin display-config | match interface | count**

Command syntax:

```
match pattern context {parents | children | all} [ignore-case] [max-count lines-count] [expression]
```

```
match pattern [ignore-case] [invert-match] [pre-lines pre-lines] [post-lines lines-count] [max-count lines-count] [expression]
```

where:

<i>pattern</i>	string or regular expression
<i>context</i>	keyword: display context associated with the matching line
<i>parents</i>	keyword: display parent context information
<i>children</i>	keyword: display child context information
<i>all</i>	keyword: display both parent and child context information
<i>ignore-case</i>	keyword
<i>max-count</i>	keyword: display only a specific number of instances of matching lines
<i>lines-count</i>	1 – 2147483647
<i>expression</i>	keyword: pattern is interpreted as a regular expression
<i>invert-match</i>	keyword
<i>pre-lines</i>	keyword: display some lines prior to the matching line
<i>pre-lines</i>	0 – 100
<i>post-lines</i>	keyword: display some lines after the matching line
<i>lines-count</i>	1 – 2147483647

For example:

```
A:Dut-C# show log log-id 98 | match ignore-case "sdp bind"
"Status of SDP Bind 101:1002 in service 1001 (customer 1) changed to admin=up oper=up
flags="
"Processing of a SDP state change event is finished and the status of all affected SDP
Bindings on SDP 101 has been updated."
```

```
A:Dut-C# show log log-id 98 | match max-count 1 "service 1001"
"Status of service 1001 (customer 1) changed to administrative state: up, operational
state: up"
```

```
A:Dut-C# admin display-config | match post-lines 5 max-count 2 expression "OSPF.*Config"
echo "OSPFv2 Configuration"
```

```
#-----
      ospf
        timers
          spf-wait 1000 1000 1000
        exit
```

```
echo "OSPFv2 (Inst: 1) Configuration"
```

```
#-----
      ospf 1
        asbr
        router-id 1.0.0.1
        export "testall"
```

```
*A:Dut# admin display-config | match debug_mirror
      profile "debug_mirror"
```

```
*A:Dut# admin display-config | match context parent debug_mirror
```

```
#-----
      system
        security
          profile "debug_mirror"
```

```
*A:Dut# admin display-config | match context all debug_mirror
```

```
#-----
      system
        security
          profile "debug_mirror"
          default-action deny-all
          entry 10
          exit
```

```
*A:Dut# show log event-control | match ignore-case pre-lines 10 SyncStatus
```

```
L 2016 tmnxLogOnlyEventThrottled      MA gen      0      0
MCPATH:
  2001 tmnxMcPathSrcGrpBlkHole        MI gen      0      0
  2002 tmnxMcPathSrcGrpBlkHoleClear   MI gen      0      0
  2003 tmnxMcPathAvailBwLimitReached  MI gen      0      0
  2004 tmnxMcPathAvailBwValWithinRange MI gen      0      0
MC_REDUNDANCY:
  2001 tmnxMcRedundancyPeerStateChanged WA gen      0      0
  2002 tmnxMcRedundancyMismatchDetected WA gen      0      0
  2003 tmnxMcRedundancyMismatchResolved WA gen      0      0
  2004 tmnxMcPeerSyncStatusChanged   WA gen      0      0
```

Table 10 describes regular expression symbols and interpretation (similar to what is used for route policy regexp matching). Table 11 describes special characters.

**Table 10: Regular Expression Symbols**

String	Description
.	Matches any single character.
[ ]	Matches a single character that is contained within the brackets. [abc] matches “a”, “b”, or “c”. [a-z] matches any lowercase letter. [A-Z] matches any uppercase letter. [0-9] matches any number.
[^ ]	Matches a single character that is not contained within the brackets. [^abc] matches any character other than “a”, “b”, or “c”. [^a-z] matches any single character that is not a lowercase letter.
^	Matches the start of the line (or any line, when applied in multiline mode)
\$	Matches the end of the line (or any line, when applied in multiline mode)
()	Define a “marked subexpression”. Every matched instance will be available to the next command as a variable.
*	A single character expression followed by “*” matches zero or more copies of the expression.
{m, n}	Matches least m and at most n repetitions of the term
{m}	Matches exactly m repetitions of the term
{m, }	Matches m or more repetitions of the term
?	The preceding item is optional and matched at most once.
+	The preceding item is matched one or more times.
-	Used between start and end of a range.
\	An escape character to indicate that the following character is a match criteria and not a grouping delimiter.
>	Redirect output

**Table 11: Special Characters**

Options	Similar to	Description
[ :upper: ]	[A-Z]	uppercase letters
[ :lower: ]	[a-z]	lowercase letters
[ :alpha: ]	[A-Za-z]	upper- and lowercase letters

**Table 11: Special Characters (Continued)**

<b>Options</b>	<b>Similar to</b>	<b>Description</b>
<code>\w</code>	<code>[A-Za-z_]</code>	word characters
<code>[:alnum:]</code>	<code>[A-Za-z0-9]</code>	digits, upper- and lowercase letters
<code>[:digit:]</code>	<code>[0-9]</code>	digits
<code>\d</code>	<code>[0-9]</code>	digits
<code>[:xdigit:]</code>	<code>[0-9A-Fa-f]</code>	hexadecimal digits
<code>[:punct:]</code>	<code>[.,!?:...]</code>	punctuation
<code>[:blank:]</code>	<code>[ \t]</code>	space and TAB
<code>[:space:]</code>	<code>[ \t\n\r\f\v]</code>	blank characters
<code>\s</code>	<code>[ \t\n\r\f\v]</code>	blank characters

## Pipe/Count

SR OS supports a **pipe/count** command (...| **count**) that provides a count of the number of lines that would have otherwise been displayed. The pipe/count command is particularly useful when used in conjunction with the pipe/match command in order to count the number of output lines that match a specified pattern.

For example:

```
*A:dut-c# show service service-using vprn

=====
Services [vprn]
=====
ServiceId   Type      Adm  Opr  CustomerId Service Name
-----
1           VPRN      Down Down 1
44          VPRN      Up   Up   1
100         VPRN      Down Down 1
102         VPRN      Up   Up   1
235         VPRN      Down Down 1
1000        VPRN      Down Down 1000
-----
Matching Services : 6
-----
*A:dut-c# show service service-using vprn | match Down | count
Count: 4 lines
*A:dut-c#
```

## Redirection

The SR OS supports redirection (“>”) which allows the operator to store the output of a CLI command as a local or remote file. Redirection of output can be used to automatically store results of commands in files (both local and remote).

```
'ping <customer_ip> > cf3cf1:/ping/result.txt'  
'ping <customer_ip> > ftp://ron@ftp.alcatel.com/ping/result.txt'
```

In some cases only part of the output might be applicable. The pipe/match and redirection commands can be combined:

```
ping 10.0.0.1 | match expression "time.\d+" > cf3cf1:/ping/time.txt
```

This records only the RTT portion (including the word “time”).

## VI Editor

Note that “vi”ual editor (vi) is a file editor that can edit any ASCII file. This includes configuration, exec files, BOF and any other ASCII file on the system.

VT100 terminal mode is supported. However, if a different terminal mode is configured there will no noticeable negative effect.

When a configuration file is changed, a validation check is executed to see if the user is allowed to view or perform configuration changes. When a user is modifying the configuration file using the vi editor these checks do not occur. Because of this, the vi editor is only available to a user with administrator privileges. Should others require access to the vi editor, their profile must be modified allow the access. Access permission for the file directory where the file resides must be performed before a user can opens, read, or write a file processing command. If a user does not have permission to access the directory then the operation must be denied.

When opening a file, a resource check verifies that sufficient resources are available to process that file. If there are not enough resources, then the operation is denied and the operator is informed of that event.

Multiple sessions are allowed and are limited only by the memory resources available on the node.

---

## Summary of vi Commands

The vi editor operates in two modes:

- Command mode — This mode causes actions to be taken on the file.  
In the this mode, each character entered is a command that does something to the text file being edited; a character typed in the command mode may even cause the vi editor to enter the insert mode.
- Insert mode — Entered text is inserted into the file.  
In the insert mode, every character typed is added to the text in the file. Hitting the `ESC` (Escape) key turns off the insert mode.

## Using the vi Commands

Use the following commands to start and end **vi** edit sessions, move around in a file, enter new text, modify, move, and delete old text, as well as read from and write to files other files. Although there are numerous **vi** commands, only a few are usually sufficient to **vi** users. The following tables list **vi** commands.

- [Cutting and Pasting/Deleting Text in vi on page 46](#)
- [Inserting New Text on page 46](#)
- [Moving the Cursor Around the Screen on page 47](#)
- [Replacing Text on page 47](#)

**Table 12: Cutting and Pasting/Deleting Text in vi**

<b>vi Command</b>	<b>Description</b>
"	Specify a buffer to be used any of the commands using buffers. Follow the " character with a letter or a number, which corresponds to a buffer.
d	Deletes text. "dd" deletes the current line. A count deletes that many lines. Whatever is deleted is placed into the buffer specified with the " command. If no buffer is specified, then the general buffer is used.
D	Delete to the end of the line from the current cursor position.
p	Paste the specified buffer after the current cursor position or line. If no buffer is specified (with the " command.) then 'p' uses the general buffer.
P	Paste the specified buffer before the current cursor position or line. If no buffer is specified (with the " command.) then P uses the general buffer.
x	Delete character under the cursor. A count tells how many characters to delete. The characters will be deleted after the cursor.
X	Delete the character before the cursor.
y	Yank text, putting the result into a buffer. yy yanks the current line. Entering a number yanks that many lines. The buffer can be specified with the " command. If no buffer is specified, then the general buffer is used.
Y	Yank the current line into the specified buffer. If no buffer is specified, then the general buffer is used.

**Table 13: Inserting New Text**

<b>vi Command</b>	<b>Description</b>
A	Append at the end of the current line.
I	Insert from the beginning of a line.

**Table 13: Inserting New Text (Continued)**

<b>vi Command</b>	<b>Description</b>
O	Enter insert mode in a new line above the current cursor position.
a	Enter insert mode, the characters typed in will be inserted after the current cursor position. A count inserts all the text that was inserted that many times.
i	Enter insert mode, the characters typed in will be inserted before the current cursor position. A count inserts all the text that was inserted that many times.
o	Enter insert mode in a new line below the current cursor position.

**Table 14: Moving the Cursor Around the Screen**

<b>vi Command</b>	<b>Description</b>
^E	Scroll forwards one line. A count scrolls that many lines.
^Y	Scroll backwards one line. A count scrolls that many lines.
z	Redraw the screen with the following options. <code>z&lt;return&gt;</code> puts the current line on the top of the screen; <code>z .</code> puts the current line on the center of the screen; and <code>z -</code> puts the current line on the bottom of the screen. If you specify a count before the <code>z</code> command, it changes the current line to the line specified. For example, <code>16z .</code> puts line 16 on the center of the screen.

**Table 15: Replacing Text**

<b>vi Command</b>	<b>Description</b>
C	Change to the end of the line from the current cursor position.
R	Replace characters on the screen with a set of characters entered, ending with the Escape key.
S	Change an entire line.
c	Change until <code>cc</code> changes the current line. A count changes that many lines.
r	Replace one character under the cursor. Specify a count to replace a number of characters.
s	Substitute one character under the cursor, and go into insert mode. Specify a count to substitute a number of characters. A dollar sign (\$) will be put at the last character to be substituted.

## EX Commands

The `vi` editor is built upon another editor, called EX. The EX editor only edits by line. From the `vi` editor you use the `:` command to start entering an EX command. This list given here is not complete, but the commands given are the more commonly used. If more than one line is to be modified by certain commands (such as `:s` and `:w`) the range must be specified before the command. For example, to substitute lines 3 through 15, the command is `:3,15s/from/this/g`.

**Table 16: EX commands**

vi Command	Description
<code>:ab string strings</code>	Abbreviation. If a word is typed in <code>vi</code> corresponding to <code>string1</code> , the editor automatically inserts the corresponding words. For example, the abbreviation <code>:ab usa United States of America</code> would insert the words, <code>United States of America</code> whenever the word <code>usa</code> is typed in.
<code>:map keys new_seq</code>	Mapping. This lets you map a key or a sequence of keys to another key or a sequence of keys.
<code>:q</code>	Quit <code>vi</code> . If there have been changes made, the editor will issue a warning message.
<code>:q!</code>	Quit <code>vi</code> without saving changes.
<code>:s/pattern/to_pattern/options</code>	Substitute. This substitutes the specified pattern with the string in the <code>to_pattern</code> . Without options, it only substitutes the first occurrence of the pattern. If a 'g' is specified, then all occurrences are substituted. For example, the command <code>:1,\$s/Alcatel/Alcatel-Lucent/g</code> substitutes all occurrences of <code>Alcatel</code> to <code>Alcatel-Lucent</code> .
<code>:set [all]</code>	Sets some customizing options to <code>vi</code> and EX. The <code>:set all</code> command gives all the possible options.
<code>:una string</code>	Removes the abbreviation previously defined by <code>:ab</code> .
<code>:unm keys</code>	Removes the remove mapping defined by <code>:map</code> .
<code>:vi filename</code>	Starts editing a new file. If changes have not been saved, the editor will give you a warning.
<code>:w</code>	Write out the current file.
<code>:w filename</code>	Write the buffer to the filename specified.
<code>:w &gt;&gt; filename</code>	Append the contents of the buffer to the filename.
<code>:wq</code>	Write the buffer and quit.

# Configuration Rollback

The Configuration Rollback feature provides the ability to “undo” configuration and reverts back to previous router configuration states while minimizing impacts to services.

This feature gives the operator better control and visibility over the router configurations and reduces operational risk while increasing flexibility and providing powerful recovery options.

Configuration Rollback is useful in cases where configuration changes are made but the operator later decides to not keep the changes (for example, experimentation or when problems are identified in the configuration during actual network operation).


The advantage of this feature are the following:

- Changes made to router configuration is performed with minimal impact on services being provided by the SR by not having to reboot the router.
- No impact in areas of configuration that did not change.

With the rollback feature, the operator can smoothly revert to previous configurations.

Configuration parameters that changed (or items that changed configuration have dependencies on) are first removed (revert to default), and the previous values are then restored (can be briefly service impacting in changed areas).

A history of changes is preserved (checkpoint ids) that allows rollback to different points, as well as examination of changes made as shown in [Figure 3](#).



**Figure 3: Rollback Operation**

## Feature Behavior

The following list describes detailed behavior and CLI usage of the rollback feature:

- The user can create a rollback checkpoint, and later, revert to this checkpoint with minimal impacts to services:

```
admin>rollback# save [comment <comment-string>]
comment-string: an 255 char comment associated with the checkpoint
```

- Rollback checkpoints include all current operationally active configuration:
  - Changes from direct CLI commands in the configuration branch.
  - SNMP sets
- Rollback checkpoints do not include bof configurations. The BOF file (and bof config) is not part of a rollback-save or rollback. A rollback does not change any of the bof configuration. The BOF contains basic information for the node and does not change frequently (mostly during initial commissioning of the node).
- A rollback save feature can be automatically executed (scheduled, for example, monthly) using the cron facility of SR-OS.
- The latest rollback checkpoint file uses a suffix of “.rb”. The next latest rollback checkpoint file has a suffix of “.rb.1”, the next oldest has a suffix of “.rb.2” etc:

```
file-url.rb <--- latest rollback file
file-url.rb.1
...
file-url.rb.9 <--- oldest rollback file
```

- When a **rollback save** is executed, the system shifts the file suffix of all the previous checkpoints by 1 (new id = old id + 1). If there are already as many checkpoint files as the maximum number supported then the last checkpoint file is deleted.
- The maximum number of rollback checkpoints is configurable and defaults to 10 (“latest” and 1 through 9, where checkpoint file 9 is deleted during the next rollback-save).
- The location and name of the rollback checkpoint files is configurable to be local (on compact flash) or remote. The *file-url* must not contain a suffix (just a path/directory + filename). The suffix for rollback checkpoint files is “.rb” and is automatically appended to rollback checkpoint files.

```
config>system>rollback# rollback-location <file-url>
```

- There is no default rollback-location. If one is not specified (or it is cleared using “no rollback-location”) and a rollback save is attempted, the rollback save will fail and return an error message.
- The entire set of rollback checkpoint files can be copied from the active CPM CF to the inactive CPM CF. This synchronization is done via the following command:

```
admin>redundancy# rollback-sync
```

- The operator can enable automatic synchronization of rollback checkpoint files between the active CPM and inactive CPM. When this automatic synchronization is enabled, a rollback save will cause the new checkpoint file to be saved to both the active and standby. The suffixes of the old checkpoint files on both active and standby CPMs are incremented.

**Note:** The automatic sync only causes the ONE new checkpoint file to be copied to both CFs (the other 9 checkpoints are not automatically copied from active to standby but that can be done manually with `admin red rollback-sync`).

```
config>redundancy# [no] rollback-sync
```


- “**config red sync** {boot-env|config}” and “**admin red sync** {boot-env|config}” do not apply to rollback checkpoint files. These commands do not manually or automatically sync rollback checkpoint files. The dedicated `rollback-sync` commands must be used to sync rollback checkpoint files.

- Rollback files can be deleted using a dedicated rollback checkpoint deletion command.

```
admin>rollback# delete {latest-rb|<checkpoint-id>}
```

- Deleting a rollback checkpoint causes the suffixes to be adjusted (decremented) for all checkpoints older than the one that was deleted (to close the “hole” in the list of checkpoint files and create room to create another checkpoint)
  - If “`config redundancy rollback-sync`” is enabled, a rollback delete will also delete the equivalent checkpoint on the standby CF and shuffle the suffixes on the standby CF.
  - If an operator manually deletes a rollback checkpoint file (using `file delete`) then the suffixes of the checkpoint files are NOT shuffled, nor is the equivalent checkpoint file deleted from the standby CF. This manual deletion creates a “hole” in the checkpoint file list until enough new checkpoints have been created to roll the “hole” off the end of the list.
- As shown in [Figure 4](#), support for rolling back to a previous configuration (a saved rollback checkpoint) with minimal impact on services. The previous configuration will be loaded and take operational effect:

```
admin>rollback# revert [[latest-rb|<checkpoint-id>]
```



**Figure 4: Configuration Rollback**

- A rollback revert does not affect the currently stored rollback checkpoint files (no deletions or renumbering). This means that if an operator issues a “rollback revert 3” and then issues a “rollback-save”, the resulting rollback checkpoint files “file-url.rb” and “file-url.rb.4” will contain the same rollback state/configuration.
- The **boot-good-exec** or **bad-exec** are not automatically executed after a rollback.
- impacts to the running services are minimized during a rollback:
  - no impact in areas of configuration that did not change
  - configuration parameters that changed (or items that changed config have dependencies on) are first removed (revert to default) and the previous values are then restored (can be briefly service impacting in changed areas). Some examples are the following:
    - If the currently active config contains **configure port 5/1/1 dwdm tdc dispersion -1000** and the rollback checkpoint contains **configure port 5/1/1 dwdm tdc dispersion -1010**, then the operational dispersion will transition from -1000, to 0 and then back to -1010 for port 5/1/1 which will cause a traffic interruption.
- A Rollback will undo any SNMP sets or direct CLI config commands that occurred since the last checkpoint creation.
- During the period when an SR-OS node is processing a rollback revert, both CLI commands (from other users) and SNMP commands will continue to be processed. The

only commands that are blocked during a rollback revert are other rollback commands including **revert**, **save**, and **compare** (only one **rollback** command can be executing at a time in one node).

- Commands are available to view and compare the various rollback checkpoints to current operating and candidate configurations.
- Rollback checkpoint files are not guaranteed to be in any particular format. They are not interchangeable with normal config files or exec scripts. A normal config file (from an admin save) cannot be renamed as a rollback checkpoint and then referenced for a rollback revert operation. Only rollback checkpoint files generated with rollback save can be used to rollback revert.
- If a hardware change is made after a rollback-save then:
  - a rollback can be executed as long as the hardware change was an addition of hardware to the node (for example, added a new card into a previously empty slot).
  - a rollback is not guaranteed to work if hardware was removed or changed (for example, XCM was removed, or XMA/MDA was swapped for a different XMA/MDA type).
  - `configure isa application-assurance-group minimum-isa-generation`
- Rollback is supported even after an **admin reboot** is performed (or changes the primary config in the bof is changed and an **admin reboot** is performed). **Admin reboot** does not “break the chain” for rollback.
- The Configuration Rollback feature is incompatible with the use of Time Of Day (ToD) policies and functionality. Rollback save and rollback revert operations are blocked if any ToD policies are active (for example, assigned to objects such as a SAP).
- Lawful Intercept configuration under the **config>li** branch is not affected by a rollback or rescue. LI configuration is not saved in the rollback checkpoint or rescue file, and a rollback revert does not touch any config under the **config>li** branch.
- Any configuration or state change performed under the debug branch of CLI is not saved in the rollback checkpoint file nor impacted by a rollback.
- Rollbacks to a checkpoint created in a more recent release is not supported (for example, node running in 9.0r5 cannot rollback to a checkpoint created in 9.0r7).
- The following list captures some side effects and specific behaviors of a Rollback revert. Some of these side effects are not related purely to configuration (that is, in the CLI config branch) and may have interactions with tools commands, RADIUS, etc.
  - SAA jobs that are running when a rollback revert is initiated, and need configuration changes due to the rollback, will be stopped. If the SAA job is a continuous type then it will be re-started as part of the rollback revert after the config changes have been

applied (just as if the operator had typed “no shutdown” for the continuous SAA job). Non-continuous SAA jobs that were modified by the rollback would need to be manually restarted if they need to be run again.

- If **max-nbr-mac-addr** is reduced as part of the revert and the number of mac addresses in the forwarding database is greater than the max-nbr-mac-addr, then the rollback is aborted (before any actions are taken) and an informative error message is provided. The operator must take actions to remove the mac addresses if they wish to proceed with the rollback.
- After multi-chassis peer shutdown or configuration changes that affect the contents of the distributed database (for example, sync tag creation or deletion), further configuration changes related to that peer may be temporarily refused. The duration of the temporary configuration freeze will depend on the size of the distributed database. A rollback attempting to make those refused configuration changes will fail and an error message will be provided to the CLI user.
- If a **force-switchover** command (for example, **tools perform service id 1 endpoint "x" force-switchover spoke-sdp-fec 1**) has been applied to a spoke-sdp-fec of a dynamic multi-segment pseudo wire, and a rollback revert needs to change the admin state of the spoke-sdp-fec (for example, to modify spoke-sdp-fec parameters that may be dependant on admin state), then the rollback revert will automatically remove the force-switchover and the node will revert to whatever is the best spoke-sdp in the redundant set.
- Rollback impacts the configuration state of the router, and as with normal operator CLI or SNMP configuration changes, additional actions or steps may need to occur before certain configuration changes take operational effect. Some examples include:
  - Configuration changes that require a **shutdown** and then **no-shutdown** to be done by an operator in order to take operational effect also need this manual shut/no-shut to be performed by the operator in order to take operational effect after a rollback if the rollback changes those configuration items. Some examples include:
    - Changes to Autonomous System or Confederation value require a BGP shut/no-shut.
    - Changes to VPRN Max-routes requires a shut/no-shut on the VPRN service.
    - Changes to OSPF/ISIS export-limit require a shut/no-shut on OSPF/ISIS.
    - Configuration changes to an msap-policy that normally requires a **tools perform subscriber-mgmt eval-msap** command to take operational effect on subscribers that are already active. Rollback will change the msap-policy configuration, but if it is required to have the configuration changes applied to the active subscribers then the operator will have to run the eval-msap tools command.
- Any uncommitted changes (that is, the **begin** command was entered, some changes made, but the **commit** command was never entered) in the following areas will be lost/cleared when a rollback revert is initiated:
  - **configure>application-assurance>group policy**
  - **configure>router>policy-options**
  - **configure>system>sync-if-timing**

- Some **card** and **mda** commands require a reboot, remove or rebuild of an entire card or XMA/MDA. When these commands need to be executed as part of a rollback, the impacted cards/mdas will be listed in a warning and the operator will be prompted with a single y/n prompt to decide whether to proceed or not. This prompting will not occur for a rollback initiated via SNMP, nor if the operator uses the **now** keyword with the rollback revert command. Some examples of card and mda commands that may cause a prompt are:
  - **configure>card>card-type**
  - **configure>card>mda**
  - **configure>card>mda>mda-type**
- Although the use of the Control-C key combination is not recommended during a rollback revert, it is supported (via CLI or SNMP). Interrupting a rollback revert may leave the router in a state that is not necessarily something between the old active config and the rollback checkpoint since the rollback processing may have been in the middle of tearing things down or rebuilding configurations. A strong warning is issued in this case to indicate that the operator must examine the config and potentially issue another rollback revert to return to a known (and coherent) configuration.
- An HA CPM switchover during a rollback revert will cause the rollback operation to abort. The newly active CPM will have an indeterminate configuration. When an HA switchover occurs during a rollback (or within a few seconds of a rollback completing), the operator is advised to repeat the rollback revert operation to the same checkpoint.
- A rollback revert operation does not check authorization of each command that is applied during the revert. Permission to execute the revert operation (authorization for the “admin rollback revert” command itself) should only be given to users who are allowed to initiate a rollback revert. It is generally advised to only allow system administrators access to the file system where the rollback files are stored so that they cannot be manually edited.

## Rollback and SNMP

SR OS has SNMP support for Rollback status and control. See the TIMETRA-SYSTEM-MIB for details (for example, items such as tmnxSysRollbackStarted).

When the SR OS router is doing a rollback revert, SNMP managers will see a tmnxSysRollbackStarted trap, then a rapid set of “config change” traps, and then finally, the tmnxSysRollbackStatusChange trap.

During the period when an SR OS router is processing a rollback revert, both CLI commands (from other users) and SNMP commands will continue to be processed.

## Rescue Configuration

A special rescue configuration checkpoint can be created that an operator can rollback revert to at any time. The rescue configuration has its own keyword (**rescue**) and does not use the same rolling suffix indices as the normal rollback checkpoints. This allows the operator to easily return to the rescue configuration state without having to consider a checkpoint index, and ensures that the rescue checkpoint is always available (does not roll off the bottom of the list of checkpoints).

The operator should define a basic rescue configuration that is known to work and give correct management access to the node.

The location and filename of the rescue file are configurable. SR-OS appends an “.rc” suffix to the specified rescue filename.

## Operational Guidelines

The following points offer some operational guidance on the usage of rollback.

- Both **admin save** and **rollback save** should be performed periodically:
- Use **admin save** to backup a complete configuration file that can be used during router reboot.
  - Used with a reboot as a last resort.
  - Do an admin save after any major h/w changes or major service changes.
  - Should be performed after any software upgrade.
- Use **rollback-save** to create a rollback checkpoint.
  - Used for intermediate checkpoints that can be recovered with minimal impacts to services.
  - Should be performed each time that a moderate amount configuration changes have been made.
  - Should be performed after any h/w changes.
  - Should be performed after any s/w upgrade.
  - Could also be scheduled with cron (for example, once every 1 or 2 weeks).
- A new **rescue-save** must be created when hardware is changed.
- Rollback-checkpoint files are not editable nor compatible/interchangeable with config files (generated with **admin save**).
- Do not continue to repeat the **rollback save, rollback save, rollback save** over the course of weeks/months without also doing executing an occasional **admin save**. In a serious situation, use one of the saved configs to use as the primary config for an **admin reboot**.
- Software Upgrade: It is recommended to create a Rollback Checkpoint (**admin rollback save**), in addition to saving the configuration (**admin save**), after an upgrade has been performed and the system is operating as expected. This will ensure a good checkpoint fully compatible with the new release is available at a point shortly after the upgrade.
- An operator could create a set of rollback checkpoints to support busy/quiet days or weekend/weekday and use cron to shift between them.
- It is beneficial to create a rollback checkpoint before a rollback revert is initiated (especially if there have been significant config changes since the last checkpoint was created). If the rollback is especially significant (a lot of major changes) it is also a good practice to do perform an **admin save** in case a full reboot is required to recover from an issue.
- A rollback failure may occur in some limited cases where the node needs a long time to complete one of the resulting configuration changes. Some examples include X and Y. If a rollback (for example, rollback revert 5) fails during execution, it should be attempted again. The second attempt will typically complete the remaining configuration changes required to fully revert to the desired checkpoint.


- When a new backup CPM is commissioned, the user execute the **admin redundancy rollback-sync** command to copy the entire set of rollback files from the active CPM cf to the new standby CPM cf. If the operator wants the system to automatically copy new rollback checkpoints to both cfs whenever a new checkpoint is created, then the **config redundancy rollback-sync** should be configured.
- An HA CPM switchover during a rollback revert will cause the rollback operation to abort. The newly active CPM will have an indeterminate configuration. A log event is created in this case to warn the operator. When an HA switchover occurs during a rollback (or within a few seconds of a rollback completing), the operator is advised to repeat the rollback revert operation to the same checkpoint.
- A rollback checkpoint stores the rollback-location and the local/remote-max-checkpoint values, and as such a rollback revert operation can change those values. If an operator changes the local/remote-max-checkpoint values it is recommended to delete all the existing checkpoints (otherwise a subsequent rollback revert could change the max back to a previous value).
- If a warning prompt (**y/n**) is displayed when a rollback revert is initiated, it is highly suggested to respond **no** to the warning prompt the first time, save a rollback checkpoint before attempting this rollback revert, and then executing the revert again and responding **yes**. If the rollback encounters problems then a revert to the saved checkpoint can be used to go back to the initial configuration state.

# Transactional Configuration

Transactional configuration allows an operator to edit a candidate configuration (a set of configuration changes) without actually causing operational changes in the router (the active or operational configuration). Once the candidate configuration is complete the operator can explicitly commit the changes and cause the entire new configuration to become active.

Transactional configuration gives the operator better control and visibility over their router configurations and reduce operational risk while increasing flexibility.

Transactional Configuration and Configuration Rollback support combine to provide the operational model depicted in [Figure 5](#).



**Figure 5: Router Configuration with Rollback and Transactions**

## Basic Operation

In order to edit the candidate configuration the operator must first enter the candidate edit mode (edit-cfg). The operator can enter and quit the configuration mode as many times as they wish before finally committing the candidate.

In edit-cfg mode the operator builds a set candidate configuration changes using the same CLI tree as standard (line-by-line non-transactional) configuration. Tab completion and keyword syntax checking is available.

Just as there is a single operational active configuration that can be modified simultaneously by multiple users in SR OS, there is also a single global candidate configuration instance. All users make changes in the same global candidate configuration and a commit operation by any user will commit the changes made by all users.

Users have the ability to exclusively create a candidate configuration by blocking other users (and sessions of the same user) from entering edit-cfg mode.

If a commit operation is successful then all of the candidate changes will take operational effect and the candidate is cleared. If there is an error in the processing of the commit, or a 'commit confirmed' is not confirmed and an auto-revert occurs, then the router will return to a configuration state with none of the candidate changes applied. The operator can then continue editing the candidate and try a commit later.

All commands in the candidate configuration must be in the correct order for a commit to be successful. Configuration that depends on other candidate objects must be placed after those objects in the candidate. A set of candidate editing commands (**copy**, **insert**, etc) are available to correct and reorder the candidate configuration.

The edit-cfg mode is primarily intended for building a candidate configuration while navigating the **configure** branch of CLI. Many CLI commands in branches other than **configure** are supported while in edit-cfg mode, but access to some CLI branches and command are blocked including the:

- **exec** command
- **enable-admin** command
- **enable-dynamic-services-config** command
- **admin** branch
- **bof** branch
- **debug** branch
- **tools** branch

The candidate configuration can be saved to a file and subsequently loaded into a candidate configuration. A saved candidate is similar to, but not the same as an SR OS config file generated with an **admin save** command. The saved candidate cannot be used in general as a configuration file and may not **exec** without failures.

## Transactions and Rollback

There is no SNMP access to the candidate configuration and no SNMP management of candidates although any configuration changes done via a transaction are reported via the standard SR OS SNMP change traps and basic candidate status information is available via SNMP.

Failure of a commit may be due to one or more of several reasons including:

- **Misordering:** The candidate configuration has changes that are not in the correct order (an object is referred to before it is actually created).
- **Invalid options and combinations:** Although many syntax errors are eliminated during the candidate editing process, the candidate configuration may contain combinations of configuration and options that are not valid and are rejected when SR OS attempts to have them take operational effect.
- **Out of resources:** The application of the candidate may exhaust various system resources (queues, for example).

Error messages that will help the operator to take necessary actions to correct the candidate are provided for commit failures.

Standard line-by-line (immediate operational effect upon pushing the enter/return key) non-transactional CLI and SNMP commands are not blocked during the creation/editing of a candidate or the processing of a commit. These commands take immediate effect as normal.

---

## Transactions and Rollback

By default, the SR OS will automatically create a new rollback checkpoint after a commit operation. The rollback checkpoint will include the new configuration changes made by the commit. An optional **no-checkpoint** keyword can be used to avoid the auto-creation of a rollback checkpoint after a commit. If the commit fails then no new rollback checkpoint is created.

When the **commit confirmed** option is used then a rollback checkpoint is created after the processing of the commit and will exist whether the commit is automatically reverted or not.

Transactional configuration relies on the rollback mechanism to operate. Any commands and configuration that is not supported in a rollback revert are also not supported in edit-cfg mode (examples include changes to chassis-mode or the existence of time-of-day suites).

## Authorization

Authorization works transparently in edit-cfg mode and no unique/new local profile or TACACS+ permissions rules are required (other than allowing access to the **candidate** branch). For example: if an operator has permissions to access the **configure filter** context then they will automatically also have access to the **configure filter** context when in edit-cfg mode.

The candidate **load** and **save** operations (if the operator's profile allows access to the candidate load and save commands) will load and save only those items that the user is authorized to access.

The candidate view will only display the items that the user is authorized to access.

The various candidate editing commands (such as adding lines, removing lines, delete, etc) only allow operations on items that the user is authorized to access.

The candidate **commit** and **discard** operations (along with **rollback revert**) operate on the entire candidate and impact all items (authorization does not apply).



# File System Management

---

## In This Chapter

This chapter provides information about file system management.

Topics in this chapter include:

- [The File System on page 66](#)
  - [Compact Flash Devices on page 66](#)
  - [URLs on page 67](#)
  - [Wildcards on page 69](#)
- [File Management Tasks on page 71](#)
  - [Modifying File Attributes on page 71](#)
  - [Creating Directories on page 72](#)
  - [Copying Files on page 73](#)
  - [Moving Files on page 74](#)
  - [Deleting Files and Removing Directories on page 74](#)
  - [Displaying Directory and File Information on page 76](#)

## The File System

The SR OS file system is used to store files used and generated by the system, for example, image files, configuration files, logging files and accounting files.

The file commands allow you to copy, create, move, and delete files and directories, navigate to a different directory, display file or directory contents and the image version.

Although some of the storage devices on some SR OS platforms are not actually compact flash devices (i.e., cf1: on the 7950 XRS is an internal SSD), the SR OS User Guides generally refer to all storage devices as “compact flash”.

---

## Compact Flash Devices

The file system is based on a DOS file system (with an optional Reliance filesystem). In the 7950 XRS, each CCM has up to three storage devices numbered one through three. The names for these devices are:

- cf1:
- cf2:
- cf3:

The above device names are *relative* device names as they refer to the devices local to the control processor with the current console session. As in the DOS file system, the colon (“:”) at the end of the name indicates it is a device.

The cf2: and cf3: compact flash devices on the 7950 XRS routers are removable and have an administrative state (shutdown/no shutdown). cf1: is an internal SSD.

NOTE: To prevent corrupting open files in the file system, you should only remove a compact flash that is administratively shutdown. SR OS gracefully closes any open files on the device, so it can be safely removed.

## URLs

The arguments for the SR OS file commands are modeled after standard universal resource locator (URL). A URL refers to a file (a *file-url*) or a directory (a *directory-url*).

The 7950 SR OS supports operations on both the local file system and on remote files. For the purposes of categorizing the applicability of commands to local and remote file operations, URLs are divided into three types of URLs: local, ftp and tftp. The syntax for each of the URL types are listed in [Table 17](#).

**Table 17: URL Types and Syntax**

URL Type	Syntax	Notes
<i>local-url</i>	<i>[cflash-id:\]path</i>	<i>cflash-id</i> is the compact flash device name. Values: cfl:
<i>ftp-url</i>	<b>ftp://</b> <i>[username[:password]@]host/path</i>	An absolute ftp path from the root of the remote file system. <i>username</i> is the ftp user name <i>password</i> is the ftp user password <i>host</i> is the remote host <i>path</i> is the path to the directory or file
	<b>ftp://</b> <i>[username[:password]@]host./path</i>	A relative ftp path from the user's home directory. Note the period and slash ("./") in this syntax compared to the absolute path.
<i>tftp-url</i>	<b>tftp://</b> <i>host[/path]/filename</i>	tftp is only supported for operations on file-urls.

Note that if the host portion of the URL is an IPv6 address, then the address should be enclosed in square brackets. For example:

```
ftp://user:passw@[3ffe::97]/./testfile.txt
```

```
tftp://[1111:2222:3333:4444:5555:6666:7777:8888]/./testfile.txt
```

The system accepts either forward slash ("/") or backslash ("\") characters to delimit directory and/or filenames in URLs. Similarly, the The SR OS SCP client application can use either slash or backslash characters, but not all SCP clients treat backslash characters as equivalent to slash characters. In particular, UNIX systems will often times interpret the backslash character as an "escape" character. This can cause problems when using an external SCP client application to send files to the SCP server. If the external system treats the backslash like an escape character, the backslash delimiter will get stripped by the parser and will not be transmitted to the SCP server.

For example, a destination directory specified as "cfl:\dir1\file1" will be transmitted to the SCP server as "cfl:dir1file1" where the backslash escape characters are stripped by the SCP client

## URLs

system before transmission. On systems where the client treats the backslash like an “escape” character, a double backslash “\\” or the forward slash “/” can typically be used to properly delimit directories and the filename.

## Wildcards

7950 SR OS supports the standard DOS wildcard characters. The asterisk (\*) can represent zero or more characters in a string of characters, and the question mark (?) can represent any one character.

```

Example: A:ALA-1>file cf3:\ # copy test*.cfg siliconvalley
            cf1:\testfile.cfg
            1 file(s) copied.
            A:ALA-1>file cf3:\ # cd siliconvalley
            A:ALA-1>file cf3:\siliconvalley\ # dir
            Volume in drive cf1 on slot A has no label.
            Directory of cf3:\siliconvalley\
            05/10/2006 11:32p      <DIR>          .
            05/10/2006 11:14p      <DIR>          ..
            05/10/2006 11:32p                7597 testfile.cfg
                                1 File(s)          7597 bytes.
                                2 Dir(s)           1082368 bytes free.
            A:ALA-1>file cf3:\siliconvalley\ #
  
```

As in a DOS file system, the wildcard characters can only be used in some of the file commands.

Another example of wildcard usage:

```

A:21# show router mpls lsp 1-63-8*
=====
MPLS LSPs (Originating)
=====
LSP Name                To                Fastfail
Adm  Opr
Config
-----
1-63-8-cc                213.224.245.8    No
Up    Dwn
1-63-8-cw                213.224.245.8    No
Up    Dwn
-----
LSPs : 2
=====
A:21#
  
```

All the commands can operate on the local file system. [Table 18](#) indicates which commands also support remote file operations.

**Table 18: File Command Local and Remote File System Support**

<b>Command</b>	<b>local-url</b>	<b>ftp-url</b>	<b>tftp-url</b>
attrib	X		
cd	X	X	
copy	X	X	X
delete	X	X	
dir	X	X	
md		X	
move	X	X	
rd		X	
scp	source only		
type	X	X	X
version	X	X	X

## File Management Tasks

The following sections are basic system tasks that can be performed.

Note that when a file system operation is performed with the copy, delete, move, rd, or scp commands that can potentially delete or overwrite a file system entry, a prompt appears to confirm the action. The **force** keyword performs the copy, delete, move, rd, and scp actions without displaying the confirmation prompt.

- [Modifying File Attributes on page 71](#)
  - [Creating Directories on page 72](#)
  - [Copying Files on page 73](#)
  - [Moving Files on page 74](#)
  - [Deleting Files and Removing Directories on page 74](#)
  - [Displaying Directory and File Information on page 76](#)
- 

## Modifying File Attributes

The system administrator can change the read-only attribute in the local file. Enter the `attrib` command with no options to display the contents of the directory and the file attributes. Use the CLI syntax displayed below to modify file attributes:

**CLI Syntax:** `file> attrib [+r | -r] file-url`

The following displays an example of the command syntax:

**Example:** `# file`  
`file cf:\ # attrib`  
`file cf:\ # attrib +r BOF.SAV`  
`file cf:\ # attrib`

## Creating Directories

The following displays the file configuration:

```
A:ALA-1>file cf:\ # attrib
cf:\bootlog.txt
cf:\bof.cfg
cf:\boot.ldr
cf:\bootlog_prev.txt
cf:\BOF.SAV
A:ALA-1>file cf:\ # attrib +r BOF.SAV
A:ALA-1>file cf:\ # attrib
cf:\bootlog.txt
cf:\bof.cfg
cf:\boot.ldr
cf:\bootlog_prev.txt
R   cf:\BOF.SAV
```

---

## Creating Directories

Use the `md` command to create a new directory in the local file system, one level at a time.

Enter the `cd` command to navigate to different directories.

Use the CLI syntax displayed below to modify file attributes:

```
CLI Syntax: file>
                md file-url
```

The following displays an example of the command syntax:

```
Example: file cf1:\ # md test1
file cf1:\ # cd test1
file cf1:\test1\ # md test2
file cf1:\test1\ # cd test2
file cf1:\test1\test2\ # md test3
file cf1:\test1\test2\ # cd test3
file cf1:\test1\test2\test3 #
```

## Copying Files

Use the **copy** command to upload or download an image file, configuration file, or other file types to or from a flash card or a TFTP server.

The **scp** command copies files between hosts on a network. It uses SSH for data transfer, and uses the same authentication and provides the same security as SSH.

The source file for the **scp** command must be local. The file must reside on the 7950 XRS router. The destination file has to be of the format: `user@host:file-name`. The destination does not need to be local.

Use the CLI syntax displayed below to copy files:

```
CLI Syntax: file>
               copy source-file-url dest-file-url [force]
               scp local-file-url destination-file-url [router router name | ser-
                  vice-id] [force]
```

The following displays an example of the copy command syntax:

```
Example: A:ALA-1>file cf1:\ # copy 104.cfg cf1:\test1\test2\test3\test.cfg
A:ALA-1>file cf1:\ # scp file1 admin@192.168.x.x:cf1:\file1
A:ALA-1>file cf1:\ # scp file2 user2@192.168.x.x:/user2/file2
A:ALA-1>file cf1:\ # scp cf:/file3 admin@192.168.x.x:cf1:\file3
```

## Moving Files

Use the `move` command to move a file or directory from one location to another.

Use the CLI syntax displayed below to move files:

```
CLI Syntax:  file>
                move old-file-url new-file-url [force]
```

The following displays an example of the command syntax:

```
Example: A:ALA-1>file cf1:\test1\test2\test3\ # move test.cfg cf1:\test1
            cf1:\test1\test2\test3\test.cfg
A:ALA-1>file cf1:\test1\test2\test3\ # cd ..
A:ALA-1>file cf1:\test1\test2\ # cd ..
A:ALA-1>file cf1:\test1\ # dir

Directory of cf1:\test1\
05/04/2006 07:58a      <DIR>          .
05/04/2006 07:06a      <DIR>          ..
05/04/2006 07:06a      <DIR>          test2
05/04/2006 07:58a                25278 test.cfg
1 File(s)                25278 bytes.
3 Dir(s)                  1056256 bytes free.
A:ALA-1>file cf1:\test1\ #
```

## Deleting Files and Removing Directories

Use the `delete` and `rd` commands to delete files and remove directories. Directories can be removed even if they contain files and/or subdirectories. To remove a directory that contains files and/or subdirectories, use the `rd /f` command. When files or directories are deleted, they cannot be recovered.

The `force` option deletes the file or directory without prompting the user to confirm.

Use the CLI syntax displayed below to delete files and then remove directories:

```
CLI Syntax:  file#
                delete file-url [force]
                rd file-url [force]
```

The following displays an example of the command syntax:

```
A:ALA-1>file cf1:\test1\ # delete test.cfg
A:ALA-1>file cf1:\test1\ # delete abc.cfg
A:ALA-1>file cf1:\test1\test2\ # cd test3
A:ALA-1>file cf1:\test1\test2\test3\ # cd ..
A:ALA-1>file cf1:\test1\test2\ # rd test3
```

```
A:ALA-1>file cf1:\test1\test2\ # cd ..
A:ALA-1>file cf1:\test1\ # rd test2
A:ALA-1>file cf1:\test1\ # cd ..
A:ALA-1>file cf1:\ # rd test1
A:ALA-1>file cf1:\ #
```

Use the CLI syntax displayed below to remove a directory without first deleting files or subdirectories:

**CLI Syntax:** `file`  
`rd file-url rf`

## Displaying Directory and File Information

Use the **dir** command to display a list of files on a file system.

The **type** command displays the contents of a file.

The **version** command displays the version of a \*.tim or iom.tim file (iom.tim file is used for the XCM).

Use the CLI syntax displayed below to display directory and file information:

**CLI Syntax:** file>  
           dir [file-url]  
           type file-url  
           version file-url

The following displays an example of the command syntax:

```
A:ALA-1>file cf1:\ # dir
Volume in drive cf1 on slot A has no label.
Directory of cf1:\
01/01/1980  12:00a                7597 test.cfg
01/01/1980  12:00a                 957 b.
08/19/2001  02:14p            230110 BOOTROM.SYS
01/01/1980  12:00a                133 NVRAM.DAT
04/03/2003  05:32a                1709 103.ndx
01/28/2003  05:06a                1341 103.cftg.ndx
01/28/2003  05:06a            20754 103.cftg
04/05/2003  02:20a      <DIR>      test
                15 File(s)                338240 bytes.
                3 Dir(s)                  1097728 bytes free.
A:ALA-1>file cf1:\ # type fred.cfg
# Saved to /cflash1/fred.cfg
# Generated THU FEB 21 01:30:09 2002 UTC
exit all
config
#-----
# Chassis Commands
#-----
card 2 card-type faste-tx-32
exit
#-----
# Interface Commands
#-----
# Physical port configuration
interface faste 2/1
    shutdown
    mode network
exit
interface faste 2/2
    shutdown
exit
```

```
interface faste 2/3
  shutdown
exit
interface faste 2/4
A:ALA-1>file cf1:\ # version boot.tim
TiMOS-L-1.0.B3-8
A:ALA-1>file cf1:\ #
```

## Repairing the File System

Use the repair command to check a compact flash device for errors and repair any errors found.

Use the CLI syntax displayed below to check and repair a compact flash device:

**CLI Syntax:** `file`  
`repair [cflash-id]`

The following displays an example of the command syntax:

```
A:ALA-1>file cf3:\ # repair
Checking drive cf3: on slot A for errors...
Drive cf31: on slot A is OK.
```

---

# File Command Reference

---

## Command Hierarchy

### Configuration Commands

**file**

- **attrib** [+r | -r] *file-url*
- **attrib**
- **cd** [*file-url*]
- **copy** *source-file-url* *dest-file-url* [**force**]
- **delete** *file-url* [**force**]
- **dir** [*file-url*] [**sort-order** {d | n | s}] [**reverse**]
- **format** [*cflash-id*] [**reliable**]
- **md** *file-url*
- **move** *old-file-url* *new-file-url* [**force**]
- **rd** *file-url* **rf**
- **rd** *file-url* [**force**]
- **repair** [*cflash-id*]
- **scp** *local-file-url* *destination-file-url* [**router** *router-instance*] [**force**]
- **scp** *local-file-url* *destination-file-url* [**force**] **service** *service-name*
- [**no**] **shutdown** [**active**] [**standby**]
- [**no**] **shutdown** *cflash-id*
- **type** *file-url*
- **version** *file-url* [**check**]
- **vi** *local-url*



---

# Configuration Commands

---

## File System Commands

### shutdown

**Syntax** [no] shutdown [active] [standby]  
[no] shutdown [cflash-id]

**Context** file

**Description**

This command shuts down (unmounts) the specified CPM(s).

Use the **no shutdown [active] [standby]** command to enable one or both CPM.

Use the **no shutdown [cflash-id]** command to enable a compact flash (cf1:, cf2:, or cf3:) on the CCM card. The **no shutdown** command can be issued for a specific slot when no compact flash is present. When a flash card is installed in the slot, the card will be activated upon detection.

In redundant systems, use the **no shutdown** command on cf3: on both CCMs in order to facilitate synchronization. See the [synchronize](#) command on [page 418](#).

**NOTE:** The **shutdown** command must be issued prior to removing a flash card. If no parameters are specified, then the drive referred to by the current working directory will be shut down.

**LED Status Indicators —** The following states are possible for the compact flash:

Operational:

If a compact flash is present in a drive and operational (**no shutdown**), the respective LED is lit green. The LED flickers when the compact flash is accessed.

**NOTE:** *Do not remove* the compact flash during a read/write operation.

State: admin = up, operational = up, equipped

Flash defective:

If a compact flash is defective, the respective LED blinks amber to reflect the error condition and a trap is raised.

State: admin = up/down, operational = faulty, equipped = no

Flash drive shut down:

When the compact flash drive is shut down and a compact flash present, the LED is lit amber. In this state, the compact flash can be ejected.

State: admin = down, operational = down, equipped = yes

No compact flash present, drive shut down:

If no compact flash is present and the drive is shut down the LED is unlit.

State: admin = down, operational = down, equipped = no

No compact flash present, drive enabled:

If no compact flash is present and the drive is not shut down the LED is unlit.

State: admin = up, operational = down, equipped = no

Ejecting a compact flash:

The compact flash drive should be shut down before ejecting a compact flash card. The LED should turn to solid (not blinking) amber. This is the only mode to safely remove the flash card.

If a compact flash drive is not shut down before a compact flash is ejected, the LED blinks amber for approximately 5 seconds before shutting off.

State: admin = down, operational = down, equipped = yes

The **shutdown** or **no shutdown** state is not saved in the configuration file. Following a reboot all compact flash drives are in their default state.

**Default** **no shutdown** — compact flash device administratively enabled

**Parameters** *cflash-id* — Specifies the compact flash slot ID to be shut down or enabled. If *cflash-id* is specified, the drive is shut down or enabled. If no *cflash-id* is specified, the drive referred to by the current working directory is assumed. If a slot number is not specified, then the active CPMCFM is assumed.

**Default** The current compact flash device

**Values** cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

**active** — If **active** is selected, then all drives on the active CPM are shutdown or enabled.

**standby** — If **standby** is selected, then all drives on the standby CPM are shutdown or enabled.

**Note:** When both **active** and **standby** keywords are specified, then all drives on both CPM are shutdown.

---

## File Commands

### attrib

**Syntax** **attrib** [+r | -r] *file-url*  
**attrib**

**Context** file

**Description** This command sets or clears/resets the read-only attribute for a file in the local file system. To list all files and their current attributes enter **attrib** or **attrib x** where **x** is either the filename or a wildcard (\*).  
 When an **attrib** command is entered to list a specific file or all files in a directory, the file's attributes are displayed with or without an "R" preceding the filename. The "R" implies that the +r is set and that the file is read-only. Files without the "R" designation implies that the -r is set and that the file is read-write-all. For example:

```
ALA-1>file cf3:\ # attrib
:\bootlog.txt
cf3:\bof.cfg
cf3:\boot.ldr
cf3:\sr1.cfg
cf3:\test
cf3:\bootlog_prev.txt
cf3:\BOF.SAV
```

**Parameters** *file-url* — The URL for the local file.

**Values** *local-url* | *remote-url*: 255 chars max  
*local-url*: [cflash-id/][file-path]  
*remote-url* [ftp://login:pswd@remote-locn/][file-path]  
 cf1:,cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

+r — Sets the read-only attribute on the specified file.

-r — Clears/resets the read-only attribute on the specified file.

### cd

**Syntax** **cd** [*file-url*]

**Context** file

**Description** This command displays or changes the current working directory in the local file system.

**Parameters** *file-url* — Syntax: [local-url | remote-url (255 chars max)  
 local-url - [cflash-id/][file-path]  
 remote-url - [{ftp://|tftp://}login:pswd@remote-locn/][file-path]  
 cf1:,cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

<none> — Displays the current working directory.

*..* — Signifies the parent directory. This can be used in place of an actual directory name in a *directory-url*.  
*directory-url* — The destination directory.

## copy

**Syntax** `copy source-file-url dest-file-url [force]`

**Context** file

**Description** This command copies a file or all files in a directory from a source URL to a destination URL. At least one of the specified URLs should be a local URL. The optional wildcard (\*) can be used to copy multiple files that share a common (partial) prefix and/or (partial) suffix.  
When a file is copied to a destination with the same file name, the original file is overwritten by the new file specified in the operation. The following prompt appears if the destination file already exists:

“Overwrite destination file (y/n)?”

For example:

To copy a file named **srcfile** in a directory called *test* on to a file called **destfile** in a directory called *production* on *cf1*, the syntax is:

```
srl>file :\ # copy cf2-/test/srcfile/production/destfile
```

To FTP a file named **121201.cfg** in directory *mydir* stored on *cf1* to a network FTP server with IP address 131.12.31.79 in a directory called *backup* with a destination file name of **121201.cfg**, the FTP syntax is:

```
copy /mydir/121201.cfg 131.12.31.79/backup/121201.cfg
```

**Parameters** *source-file-url* — The location of the source file or directory to be copied.

*dest-file-url* — The destination of the copied file or directory.

**force** — Forces an immediate copy of the specified file(s).

**file copy force** executes the command without displaying a user prompt message.

## delete

**Syntax** `delete file-url [force]`

**Context** file

**Description** This command deletes the specified file.

The optional wildcard “\*” can be used to delete multiple files that share a common (partial) prefix and/or (partial) suffix. When the wildcard is entered, the following prompt displays for each file that matches the wildcard:

“Delete file <filename> (y/n)?”

*file-url* — The file name to delete.

**Values**     *local-url* | *remote-url*:     255 chars max  
*local-url*:             [*cflash-id*/][*file-path*]  
*remote-url*             [ftp://*login:pswd@remote-locn*][*file-path*]  
cf1:,cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

**force** — Forces an immediate deletion of the specified file(s).

**file delete \* force** deletes all the wildcard matching files without displaying a user prompt message.

## dir

**Syntax**     **dir** [*file-url*][**sort-order** { **d** | **n** | **s**}] [**reverse**]

**Context**     file

**Description**     This command displays a list of files and subdirectories in a directory.

**Parameters**     *file-url* — The path or directory name.

Use the *file-url* with the optional wildcard (\*) to reduce the number of files to list.

**Default**     Lists all files in the present working directory

**sort-order** { **d** | **n** | **s** — Specifies the sort order.

**Values**     **d** — date  
**n** — name  
**s** — size

**reverse** — Specifies to reverse the sort order.

### Sample Output

```
A:cses-E12>file cf3:\ # dir
- dir [<file-url>] [sort-order { d | n | s}] [reverse]

<file-url>          : <local-url>|<remote-url>
local-url           - [<cflash-id>/][<file-path>]
                    200 chars max, including cflash-id
                    directory length 99 chars max each
remote-url          - [ftp://<login>:<pswd>@<remote-locn>/
                    ] [<file-path>]
                    255 chars max
                    directory length 99 chars max each
remote-locn         - [ <hostname> | <ipv4-address> |
                    "["<ipv6-address>"]" ]
ipv4-address        - a.b.c.d
ipv6-address        - x:x:x:x:x:x:x[-interface]
                    x:x:x:x:x:d.d.d.d[-interface]
                    x - [0..FFFF]H
                    d - [0..255]D
                    interface - 32 chars max, for link
                    local addresses
```

```

                                cflash-id      - cf1:|cf1-A:|cf1-B:|cf2:|cf2-A:|
                                                cf2-B:|cf3:|cf3-A:|cf3-B:
< d | n | s>                : Sort order: d - date, n - name, s - size
<reverse>                   : keyword - reverse order
A:cses-E12>file cf3:\ # dir

```

## file

**Syntax** file

**Context** root

**Description** The context to enter and perform file system operations. When entering the **file** context, the prompt changes to reflect the present working directory. Navigating the file system with the **cd ..** command results in a changed prompt.

The **exit all** command leaves the file system/file operation context and returns to the <ROOT> CLI context. The state of the present working directory is maintained for the CLI session. Entering the **file** command returns the cursor to the working directory where the **exit** command was issued.

## format

**Syntax** format cflash [*cflash-id*] [**reliable**]

**Context** root>file

**Description** This command formats the compact flash. The compact flash must be shut down before starting the format.

**Parameters** *cflash-id* — The compact flash type.

**Values** cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

**reliable** — Enables the reliance file system and disables the default DOS file system. This option is valid only on compact flashes 1 and 2.

## md

**Syntax** md *file-url*

**Context** file

**Description** This command creates a new directory in a file system. Directories can only be created one level at a time.

**Parameters** *file-url* — The directory name to be created.

**Values** *local-url* | *remote-url*: 255 chars max  
*local-url*: [*cflash-id*]/[*file-path*]

*remote-url* [ftp://login:pswd@remote-locn/][file-path]  
 cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

## move

**Syntax** `move old-file-url new-file-url [force]`

**Context** file

**Description** This command moves a local file, system file, or a directory. If the target already exists, the command fails and an error message displays.

The following prompt appears if the destination file already exists:

“Overwrite destination file (y/n)?”

**Parameters** *old-file-url* — The file or directory to be moved.

**Values** *local-url* | *remote-url*: 255 chars max  
*local-url*: [cflash-id/][file-path]  
*remote-url* [ftp://login:pswd@remote-locn/][file-path]  
 cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

*new-file-url* — The new destination to place the *old-file-url*.

**Values** *local-url* | *remote-url*: 255 chars max  
*local-url*: [cflash-id/][file-path]  
*remote-url* [ftp://login:pswd@remote-locn/][file-path]  
 cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

**force** — Forces an immediate move of the specified file(s).

**file move force** executes the command without displaying a user prompt message.

## rd

**Syntax** `rd file-url rf`  
`rd file-url [force]`

**Context** file

**Description** If the directory is empty, the rd command is used to remove it. The force option executes the command without prompting the user to confirm the action.

If the directory contains files and/or subdirectories, the rf parameter must be used to remove the directory.

Example:

```
A:nE1>file cf1:\ # rd alcateltest
Are you sure (y/n)? y
Deleting directory cf1:\alcateltest .MINOR: CLI Cannot delete cf1:\alcateltest.
A:nE1>file cf1:\ # rd alcateltest force
Deleting directory cf1:\alcateltest .MINOR: CLI Cannot delete cf1:\alcateltest.
```

```
A:nE1>file cf1:\ # rd testbase rf
Deleting all subdirectories and files in specified directory. y/n ?y
Deleting directory cf1:\testbase\testbase1 ..OK
Deleting directory cf1:\alcateltest .OK
```

**Parameters** *file-url* — The directory to be removed.

<b>Values</b>	local-url remote-url
	local-url [cflash-id/] [file-path] 200 chars max, including cflash-id directory length 99 chars max each
	remote-url [ftp://login:pswd@remote-locn/] [file-path] 247 chars max directory length 99 chars max each
	remote-locn [hostname   ipv4-address   "["ipv6-address"]" ]
	ipv4-address a.b.c.d
	ipv6-address x:x:x:x:x:x:x[-interface] x:x:x:x:x:d.d.d.d[-interface] x - [0..FFFF]H d - [0..255]D
	cflash-id interface - 32 chars max, for link local addresses cf1: cf1-A: cf1-B: cf2: cf2-A: cf2-B: cf3: cf3-A: cf3-B:

**rf** — The parameter forces a recursive delete.

**force** — Forces an immediate deletion of the specified directory.

For example, **rd file-url force** executes the command without displaying a user prompt message.

## repair

**Syntax** **repair** [*cflash-id*]

**Context** file

**Description** This command checks a compact flash device for errors and repairs any errors found.

**Parameters** *cflash-id* — Specify the compact flash slot ID to be shut down or enabled. When a specific flash-id is specified, then that drive is shut down. If no flash-id is specified, the drive referred to by the current working directory is assumed. If a slot number is not specified, then the active CSM is assumed.

**Default** The current compact flash device

**Values** cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

## scp

**Syntax** **scp** *local-file-url destination-file-url* [**router** *router-instance*] [**force**]  
**scp** *local-file-url destination-file-url* [**force**] **service** *service-name*

**Context** file

**Description** This command copies a local file to a remote host file system. It uses `ssh` for data transfer, and uses the same authentication and provides the same security as `ssh`. The following prompt appears:

“Are you sure (y/n)?” The destination must specify a user and a host.

**Parameters** *local-file-url* — The local source file or directory.

**Values** [*flash-id*]/[*file-path*]: Up to 256 characters.

*destination-file-url* — The destination file.

**Values** <destination-file-\*> : user@hostname:file-path - [255 chars max]  
user [32 chars max]  
hostname [ <dns-name> | <ipv4-address> | "["<ipv6-address>"]" ]  
ipv4-address a.b.c.d  
ipv6-address x:x:x:x:x:x:x[-interface]  
x:x:x:x:x:x:d.d.d.d[-interface]  
x - [0..FFFF]H  
d - [0..255]D  
interface - 32 chars max, mandatory for link local addresses  
dns-name [128 chars max]  
file-path [200 chars max]

*user* — The SSH user.

*host* — The remote host IP address of DNS name.

*file-path* — The destination path.

*router-instance* — Specify the router name or service ID.

**Values** *router-name:* Base , management  
*service-id:* 1 — 2147483647

**Default** Base

**force** — Forces an immediate copy of the specified file.

**file** **scp** *local-file-url destination-file-url* [**router**] **force** executes the command without displaying a user prompt message.

**service** *service-name* — Specifies the service name up to 64 characters in length.

## type

**Syntax** `type file-url`

**Context** file

**Description** Displays the contents of a text file.

*file-url* — The file contents to display.

**Values**

file-url	<local-url> <remote-url>
local-url	[<cflash-id>/][<file-path> 200 chars max, including cflash-id directory length 99 chars max each
remote-url	[{ftp://tftp://}<login>:<pswd>@<remote-locn>/][<file-path> 255 chars max directory length 99 chars max each
remote-locn	[<hostname>  <ipv4-address>  <ipv6-address> ]
ipv4-address	a.b.c.d
ipv6-address	x:x:x:x:x:x[-interface] x:x:x:x:x.d.d.d[-interface] x - [0..FFFF]H d - [0..255]D interface - 32 chars max, for link local addresses
cflash-id	cf1:, cf1-A:, cf1-B:

## version

**Syntax** `version file-url [check]`

**Context** file

**Description** This command displays the version of an SR OS \*.tim or iom.tim file (iom.tim file is used for the XCM).

**Parameters** *file-url* — The file name of the target file.

**Values**

local-url   remote-url:	255 characters maximum
local-url:	[ <i>cflash-id</i> /][ <i>file-path</i> ]
remote-url:	[{ftp://tftp://} <i>login:pswd@remote-locn</i> ][ <i>file-path</i> ]
cflash-id:	cf1:,

**check** — Validates the .tim file.

### Sample Output

```
A:Redundancy>file cf3:\ # version ftp://test:1234@xxx.xxx.xxx.xx/usr/global/images/6.1/R4/cpm.tim
TiMOS-C-6.1.R4 for 7750
Thu Oct 30 14:21:09 PDT 2008 by builder in /rel6.1/b1/R4/panos/main
```

```
A:Redundancy>file cf3:\ # version check ftp://test:1234@xxx.xxx.xxx.xx/usr/global/images/
6.1/R4/cpm.tim
TiMOS-C-6.1.R4 for 7750
Thu Oct 30 14:21:09 PDT 2008 by builder in /rel6.1/b1/R4/panos/main
Validation successful
A:Redundancy>file cf3:\ #
```

## vi

**Syntax** `vi local-url`

**Context** file

**Description** Edit files using the vi editor.

**Parameters** *local-url* — Specifies the local source file or directory.

**Values** [*flash-id*>/]*file-path*  
 cflash-id: cf1:, cf2:, cf3:



---

# Basic Command Reference

---

## Command Hierarchies

- [Basic CLI Commands](#)
- [Environment Commands](#)
- [Monitor Commands](#)
- [Candidate Commands](#)
- [Rollback Commands](#)
- [Management Infrastructure Control Commands](#)

## Basic CLI Commands

- **back**
- **clear**
- **echo** [*text-to-echo*] [*extra-text-to-echo*] [*more-text*]
- **enable-admin**
- **exec** [-echo] [-syntax] *filename*
- **exit** [all]
- **help**
- **history**
- **info** [detail]
- **logout**
- **mstat** **source** [*ip-address* | *dns-name*] [**group** *grp-ip-address*] [**destination** *dst-ip-address*] [**hop** *hop*] [**router** *router-instance*] [**wait-time** *wait-time*]
- **mtrace** **source** [*ip-address* | *dns-name*] [**group** *grp-ip-address*] [**destination** *dst-ip-address*] [**hop** *hop*] [**router** *router-instance*] [**wait-time** *wait-time*]
- **password**
- **ping** {*ip-address* | *dns-name*} [**rapid** | **detail**] [**ttl** *time-to-live*] [**tos** *type-of-service*] [**size** *bytes*] [**pattern** *pattern*] [**source** *ip-address*] [**interval** *seconds*] [{**next-hop** *ip-address*} | {**interface** *interface-name*} | **bypass-routing**] [**count** *requests*] [**do-not-fragment**] [**router** [*router-instance*]][**timeout** *time-out*]
- **pwc** [previous]
- **sleep** [seconds]
- **ssh** [*ip-addr* | *dns-name*] [*username@ip-addr*] [-l *username*] [-v *SSH-version*] [**router** *router-instance*] [**service-name** *service-name*]
- **telnet** [*ip-address* | *dns-name*] [*port*] [**router** *router-instance*]
- **traceroute** {*ip-address* | *dns-name*} [**ttl** *value*] [**wait** *milliseconds*] [**no-dns**] [**source** *ip-address*] [**tos** *type-of-service*]
- **tree** [detail]
- **write** {*user* | **broadcast**} *message-string*

## Monitor Commands

- monitor**
  - **card** *slot-number* **fp** *fp-number* **ingress** {**access** | **network**} **queue-group** *queue-group-name* **instance** *instance-id* [**interval** *seconds*][**repeat** *repeat*] **policer** *policer-id* [**absolute** | **percent-rate** | *reference-rate*]
  - **ccag** *ccag-id* [**path** {**a** | **b**}] [**type** {**sap-sap** | **sap-net** | **net-sap**}] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
  - **cpm-filter**
    - **ip** **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
    - **ipv6** **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
    - **mac** **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
  - **filter**
    - **ip** *ip-filter-id* **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
    - **ipv6** *ipv6-filter-id* **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
    - **mac** *mac-filter-id* **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
  - **lag** *lag-id* [*lag-id...*(up to 5 max)] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
  - **management-access-filter**
    - **ip** **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
    - **ipv6** **entry** *entry-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
  - **port** *port-id* [*port-id...*(up to 5 max)] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
  - **qos**
    - **arbiter-stats**
      - **card** *slot-number* **fp** *fp-number* **queue-group** *queue-group-name* **instance** *instance-id* [**ingress**] [**access** | **networks**] [**interval** *seconds*][**repeat** *repeat*] [**absolute** | **percent-rate** | *reference-rate*] [**arbiter** *root* | *name*]
      - **customer** *customer-id* **site** *customer-site-name* [**arbiter** *root*|*name*] [**ingress**|**egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]
      - **port** *port-id* **egress** *network* **queue-group** *queue-group-name* **instance** *instance-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**] [**arbiter** *root* | *name*]
      - **sap** *sap-id* [**arbiter** *name* | *root*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
      - **subscriber** *sub-ident-string* [**arbiter** *name*|*root*] [**ingress**|**egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]
    - **port** *port-id* **exp-secondary-shaper** *shaper-name* [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]
    - **port** *port-id* **vport** *name* **monitor-threshold** [**interval** *seconds*] [**repeat** *repeat*]
    - **port** *port-id* **monitor-threshold** [**interval** *seconds*] [**repeat** *repeat*]
    - **scheduler-stats**
      - **customer** *customer-id* **site** *customer-site-name* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
      - **port** *port-id* **queue-group** *queue-group-name* [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**] [**access** | **network**] [**instance** *instance-id*]
      - **port** *port-id* **vport** *name* [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]
      - **sap** *sap-id* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
      - **sap** *sap-id* **encap-group** *group-name* [**member** *encap-id*] [**scheduler** *scheduler-name*] [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]
      - **port** *sub-ident-string* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
      - **subscriber** *sub-ident-string* [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]
      - **sap** *sap-id* **sla-profile** *sla-profile-name*
  - **router** [*router-instance*]
    - **bgp**

- **neighbor** *ip-address* [*ip-address...*(up to 5 max)] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **isis**
  - **statistics** [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **ldp**
  - **session** *ldp-id* [*ldp-id...*(up to 5 max)] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
  - **statistics** [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **mpls**
  - **interface** *interface* [*interface...*(up to 5 max)] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
  - **lsp-egress-statistics** *lsp-name* [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
  - **lsp-ingress-statistics** *ip-address lsp lsp-name* [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **ospf** [*ospf-instance*]
- **ospf3**
  - **interface** *interface* [*interface...*(up to 5 max)] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
  - **virtual-link** *nbr-rtr-id area area-id* [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
  - **virtual-neighbor** *nbr-rtr-id area area-id* [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **pim**
  - **group** *grp-ip-address* [*source ip-address*] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **rip**
  - **neighbor** *neighbor* [*neighbor...*(up to 5 max)] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **rsvp**
  - **interface** *interface* [*interface...*(up to 5 max)] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **vrrp**
  - **instance** *interface interface-name vr-id virtual-router-id* [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
- **service**
  - **id** *service-id*
    - **sap** *sap-id* [*interval seconds*] [**repeat repeat**] [**absolute | rate**]
    - **sdp** *sdp-id* [*far-end ip-address*] [*interval seconds*] [**repeat repeat**] [**absolute | rate**]

## Environment Commands

- <root>
  - **environment**
    - **alias** *alias-name alias-command-name*
    - **no alias** *alias-name*
    - **[no] create**
    - **[no] more**
    - **reduced-prompt** [*no. of nodes in prompt*]
    - **no reduced-prompt**
    - **[no] saved-internal-prompt**
    - **suggest-internal-objects**
    - **terminal**
      - **length** *lines*
      - **width** *width*

- **time-display** {local | utc}

## Candidate Commands

- <root>
  - **candidate**
    - **edit** [exclusive]
    - **commit** [confirmed *timeout*] [**comment** *comment*]
    - **commit no-checkpoint** [confirmed *timeout*]
    - **confirm**
    - **copy** [line]
    - **delete** [line]
    - **discard** [now]
    - **goto** line
    - **insert** [line]
    - **load** file-url [overwrite | insert | append]
    - **quit**
    - **redo** [*count*]
    - **replace** [line]
    - **save** file-url
    - **undo** [*count*]
    - **view** [line]
  - **info operational** operational
- show
  - system
    - **candidate**

## Rollback Commands

```

root
  — admin
    — rollback
      — compare [to source2]
      — compare source1 to source2
      — delete {latest-rb | checkpoint-id | rescue}
      — revert [latest-rb] | checkpoint-id | rescue [now]
      — revert
      — save (rollback) [rescue] [comment comment-string]
      — view [latest-rb | checkpoint-id | rescue]
    — view {latest-cfg | active-cfg | latest-rb | checkpoint-id}
config
  — system
    — rollback
      — [no] rollback-location file-url
      — [no] rescue-location file-url
      — [no] local-max-checkpoints <1...50>
      — [no] remote-max-checkpoints <1...50>

```

## Management Infrastructure Control Commands

```

config
  — system
    — management {cli}
      — configuration
        — immediate

```



---

## Basic CLI Commands

---

### Global Commands

#### enable-admin

**Syntax**    **enable-admin**

**Context**    <global>

**Description**    **NOTE:** See the description for the **admin-password** command. If the **admin-password** is configured in the **config>system>security>password** context, then any user can enter a special administrative mode by entering the **enable-admin** command.

**enable-admin** is in the default profile. By default, all users are given access to this command.

Once the **enable-admin** command is entered, the user is prompted for a password. If the password matches, the user is given unrestricted access to all the commands.

The minimum length of the password is determined by the **minimum-length** command. The complexity requirements for the password is determined by the **complexity** command.

The following displays a password configuration example:

```
A:ALA-1>config>system>security# info
-----
...
      password
      aging 365
      minimum-length 8
      attempts 5 time 5 lockout 20
      admin-password "rUYUz9XMo6I" hash
      exit
...
-----
A:ALA-1>config>system>security#
```

## Global Commands

There are two ways to verify that a user is in the enable-admin mode:

- `show users` – Administrator can know which users are in this mode.
- Enter the `enable-admin` command again at the root prompt and an error message will be returned.

```
A:ALA-1# show users
=====
User Type From Login time Idle time
=====
admin Console -- 10AUG2006 13:55:24 0d 19:42:22
admin Telnet 10.20.30.93 09AUG2004 08:35:23 0d 00:00:00 A
-----
Number of users : 2
'A' indicates user is in admin mode
=====
A:ALA-1#
A:ALA-1# enable-admin
MINOR: CLI Already in admin mode.
A:ALA-1#
```

## back

**Syntax** `back`

**Context** <GLOBAL>

**Description** This command moves the context back one level of the command hierarchy. For example, if the current level is the `config router ospf` context, the `back` command moves the cursor to the `config router` context level.

## clear

**Syntax** `clear`

**Context** <GLOBAL>

**Description** This command clears statistics for a specified entity or clears and resets the entity.

**Parameters**

- `card` — Reinitializes a I/O module in the specified slot.
- `cflowd` — Clears cflowd.
- `cpm-filter` — Clears IP filter entry IDs.
- `cron` — Clears CRON history.
- `filter` — Clears IP, MAC, and log filter counters.
- `lag` — Clears LAG-related entities.
- `log` — Closes and reinitializes the log specified by log-id.
- `mda` — Reinitializes the specified XMA/MDA in a particular slot.
- `port` — Clears port statistics.

**qos** — Clears QoS statistics.

**radius** — Clears the RADIUS server state.

**router** — Clears router commands affecting the router instance in which they are entered.

**Values** arp, authentication, bgp, bfd, forwarding-table, icmp-redirect-route, icmp6, igmp, interface, isis, ldp, mpls, neighbor, ospf, ospf3, pim, rip, outer-advertisement, rsvp

**saa** — Clears the SAA test results.

**screen** — Clears the console or telnet screen.

**service** — Clears service ID and statistical entities.

**system** — Clears (re-enables) a previously failed reference.

**tacplus** — Clears the TACACS+ server state.

**trace** — Clears the trace log.

**vrrp** — Clears and resets the VRRP interface and statistical entities.

## echo

**Syntax** **echo** [*text-to-echo*] [*extra-text-to-echo*] [*more-text*]

**Context** <GLOBAL>

**Description** This command echoes arguments on the command line. The primary use of this command is to allow messages to be displayed to the screen in files executed with the **exec** command.

**Parameters** *text-to-echo* — Specifies a text string to be echoed up to 256 characters.  
*extra-text-to-echo* — Specifies more text to be echoed up to 256 characters.  
*more-text* — Specifies more text to be echoed up to 256 characters.

## exec

**Syntax** **exec** [-**echo**] [-**syntax**] {*filename* | <<[*eof\_string*]}

**Context** <GLOBAL>

**Description** This command executes the contents of a text file as if they were CLI commands entered at the console. Exec commands do not have **no** versions.

**Parameters** -**echo** — Echo the contents of the **exec** file to the session screen as it executes.

**Default** Echo disabled.

-**syntax** — Perform a syntax check of the file without executing the commands. Syntax checking will be able to find invalid commands and keywords, but it will not be able to validate erroneous user-supplied parameters.

**Default** Execute file commands.

## Global Commands

*filename* — The text file with CLI commands to execute.

<< — Stdin can be used as the source of commands for the exec command. When stdin is used as the exec command input, the command list is terminated with <Ctrl-C>, “EOF<Return>” or “*eof\_string*<Return>”.

If an error occurs entering an exec file sourced from stdin, all commands after the command returning the error will be silently ignored. The exec command will indicate the command error line number when the stdin input is terminated with an end-of-file input.

*eof\_string* — The ASCII printable string used to indicate the end of the exec file when stdin is used as the exec file source. <Ctrl-C> and “EOF” can always be used to terminate an exec file sourced from stdin.

**Default** <Ctrl-C>, EOF

### Related Commands

[boot-bad-exec command on page 349](#) — Use this command to configure a URL for a CLI script to exec following a failed configuration boot.

[boot-good-exec command on page 349](#) — Use this command to configure a URL for a CLI script to exec following a successful configuration boot.

## exit

**Syntax** **exit [all]**

**Context** <GLOBAL>

### Description

This command returns to the context from which the current level was entered. For example, if you navigated to the current level on a context by context basis, then the **exit** command only moves the cursor back one level.

```
A:ALA-1# configure
A:ALA-1>config# router
A:ALA-1>config>router# ospf
A:ALA-1>config>router>ospf# exit
A:ALA-1>config>router# exit
A:ALA-1>config# exit
```

If you navigated to the current level by entering a command string, then the **exit** command returns the cursor to the context in which the command was initially entered.

```
A:ALA-1# configure router ospf
A:ALA-1>config>router>ospf# exit
A:ALA-1#
```

The **exit all** command moves the cursor all the way back to the root level.

```
A:ALA-1# configure
A:ALA-1>config# router
A:ALA-1>config>router# ospf
A:ALA-1>config>router>ospf# exit all
A:ALA-1#
```

### Parameters

**all** — Exits back to the root CLI context.

## help

**Syntax**    **help**  
**help edit**  
**help global**  
**help special-characters**  
 <GLOBAL>

**Description**    This command provides a brief description of the help system. The following information displays:

Help may be requested at any point by hitting a question mark '?'.  
 In case of an executable node, the syntax for that node will be displayed with an explanation of all parameters.  
 In case of sub-commands, a brief description is provided.  
 Global Commands:  
     Help on global commands can be observed by issuing "help globals" at any time.  
 Editing Commands:  
     Help on editing commands can be observed by issuing "help edit" at any time.

**Parameters**    **help** — Displays a brief description of the help system.

**help edit** — Displays help on editing.

Available editing keystrokes:

```
Delete current character.....Ctrl-d
Delete text up to cursor.....Ctrl-u
Delete text after cursor.....Ctrl-k
Move to beginning of line.....Ctrl-a
Move to end of line.....Ctrl-e
Get prior command from history.....Ctrl-p
Get next command from history.....Ctrl-n
Move cursor left.....Ctrl-b
Move cursor right.....Ctrl-f
Move back one word.....Esc-b
Move forward one word.....Esc-f
Convert rest of word to uppercase.....Esc-c
Convert rest of word to lowercase.....Esc-l
Delete remainder of word.....Esc-d
Delete word up to cursor.....Ctrl-w
Transpose current and previous character....Ctrl-t
Enter command and return to root prompt.....Ctrl-z
Refresh input line.....Ctrl-l
```

**help global** — Displays help on global commands.

Available global commands:

```
back            - Go back a level in the command tree
echo            - Echo the text that is typed in
exec            - Execute a file - use -echo to show the commands and
                prompts on the screen
exit            - Exit to intermediate mode - use option all to exit to
                root prompt
help            - Display help
history         - Show command history
info            - Display configuration for the present node
logout         - Log off this system
oam             + OAM Test Suite
ping            - Verify the reachability of a remote host
pwc            - Show the present working context
sleep          - Sleep for specified number of seconds
ssh            - SSH to a host
telnet         - Telnet to a host
```

## Global Commands

```
traceroute    - Determine the route to a destination address
tree          - Display command tree structure from the context of
               execution
write         - Write text to another user
```

**help special-characters** — Displays help on special characters.

Use the following CLI commands to display more information about commands and command syntax:

**?** — Lists all commands in the current context.

**string?** — Lists all commands available in the current context that start with the string.

**command ?** — Display command's syntax and associated keywords.

**string<Tab>** or **string<Space>** — Complete a partial command name (auto-completion) or list available commands that match the string.

## history

**Syntax** **history**

**Context** <GLOBAL>

**Description** This command lists the last 30 commands entered in this session.

Re-execute a command in the history with the **!n** command, where **n** is the line number associated with the command in the history output.

For example:

```
A:ALA-1# history
 68 info
 69 exit
 70 info
 71 filter
 72 exit all
 73 configure
 74 router
 75 info
 76 interface "test"
 77 exit
 78 reduced-prompt
 79 info
 80 interface "test"
 81 icmp unreachable exit all
 82 exit all
 83 reduced-prompt
 84 configure router
 85 interface
 86 info
 87 interface "test"
 88 info
 89 reduced-prompt
 90 exit all
 91 configure
 92 card 1
 93 card-type
 94 exit
 95 router
```

```

96 exit
97 history
A:ALA-1# !91
A:ALA-1# configure
A:ALA-1>config#

```

## info

**Syntax** info [detail]

**Context** <GLOBAL>

**Description** This command displays the running configuration for the configuration context.

The output of this command is similar to the output of a **show config** command. This command, however, lists the configuration of the context where it is entered and all branches below that context level.

By default, the command only enters the configuration parameters that vary from the default values. The **detail** keyword causes all configuration parameters to be displayed.

For example,

```

A:ALA-48>config>router>mpls# info
-----
admin-group "green" 15
admin-group "red" 25
admin-group "yellow" 20
interface "system"
exit
interface "to-104"
  admin-group "green"
  admin-group "red"
  admin-group "yellow"
  label-map 35
    swap 36 nexthop 10.10.10.91
    no shutdown
  exit
exit
path "secondary-path"
  hop 1 10.10.0.111 strict
  hop 2 10.10.0.222 strict
  hop 3 10.10.0.123 strict
  no shutdown
exit
path "to-NYC"
  hop 1 10.10.10.104 strict
  hop 2 10.10.0.210 strict
  no shutdown
exit
path "to-104"
  no shutdown
exit
lsp "to-104"
  to 10.10.10.104
  from 10.10.10.103
  rsvp-resv-style ff
  cspf
...
-----

```

## Global Commands

```
A:ALA-48>config>router>mpls#
A:ALA-48>config>router>mpls# info detail
-----
frr-object
no resignal-timer
admin-group "green" 15
admin-group "red" 25
admin-group "yellow" 20
interface "system"
    no admin-group
    no shutdown
exit
interface "to-104"
    admin-group "green"
    admin-group "red"
    admin-group "yellow"
    label-map 35
        swap 36 nexthop 10.10.10.91
    no shutdown
    exit
    no shutdown
exit
path "secondary-path"
    hop 1 10.10.0.111 strict
    hop 2 10.10.0.222 strict
    hop 3 10.10.0.123 strict
    no shutdown
exit
path "to-NYC"
    hop 1 10.10.10.104 strict
    hop 2 10.10.0.210 strict
    no shutdown
exit
path "to-104"
    no shutdown
exit
lsp "to-104"
    to 10.10.10.104
    from 10.10.10.103
    rsvp-resv-style ff
    adaptive
    cspf
    include "red"
    exclude "green"
    adspec
    fast-reroute one-to-one
        no bandwidth
        no hop-limit
        node-protect
    exit
    hop-limit 10
    retry-limit 0
    retry-timer 30
    secondary "secondary-path"
        no standby
        no hop-limit
        adaptive
        no include
        no exclude
        record
        record-label
```

```

        bandwidth 50000
        no shutdown
    exit
    primary "to-NYC"
        hop-limit 50
        adaptive
        no include
        no exclude
        record
        record-label
        no bandwidth
        no shutdown
    exit
    no shutdown
exit
...
-----
A:ALA-48>config>router>mpls#

```

**Parameters** **detail** — Displays all configuration parameters including parameters at their default values.

## logout

**Syntax** **logout**

**Context** <GLOBAL>

**Description** This command logs out of the router session.

When the **logout** command is issued from the console, the login prompt is displayed, and any log IDs directed to the console are discarded. When the console session resumes (regardless of the user), the log output to the console resumes.

When a Telnet session is terminated from a **logout** command, all log IDs directed to the session are removed. When a user logs back in, the log IDs must be re-created.

## mrinfo

<b>Syntax</b>	<b>mrinfo</b> [ <i>ip-address</i>   <i>dns-name</i> ] [ <b>router</b> <i>router-instance</i> ]
<b>Context</b>	<GLOBAL>
<b>Description</b>	This command is used to print relevant multicast information from the target multicast router. Information displayed includes adjacency information, protocol, metrics, thresholds, and flags from the target multicast route
<b>Parameters</b>	<p><i>ip-address</i> — Specify the ip-address of the multicast capable target router.</p> <p><i>dns-name</i> — Specify the DNS name (if DNS name resolution is configured).</p> <p><b>Values</b> 63 characters maximum</p> <p><b>router</b> <i>router-instance</i> — Specify the router name or service ID.</p> <p><b>Values</b> <i>router-name:</i> Base, management <i>service-id:</i> 1 — 2147483647</p> <p><b>Default</b> Base</p>

## mstat

<b>Syntax</b>	<b>mstat source</b> [ <i>ip-address</i>   <i>dns-name</i> ] [ <b>group</b> <i>grp-ip-address</i> ] [ <b>destination</b> <i>dst-ip-address</i> ] [ <b>hop</b> <i>hop</i> ] [ <b>router</b> <i>router-instance</i> ] [ <b>wait-time</b> <i>wait-time</i> ]
<b>Context</b>	<GLOBAL>
<b>Description</b>	This command traces a multicast path from a source to a receiver and displays multicast packet rate and loss information.
<b>Parameters</b>	<p><b>source</b> <i>ip-address</i> — Specify the IP address of the multicast-capable source.</p> <p><i>ip-address</i> — Specify the ip-address of the multicast capable target router.</p> <p><i>dns-name</i> — Specify the DNS name (if DNS name resolution is configured).</p> <p><b>Values</b> 63 characters maximum</p> <p><b>group</b> <i>group-ip-address</i> — Specify the multicast address of the group to be displayed.</p> <p><b>destination</b> <i>dst-ip-address</i> — Specify the unicast destination address.</p> <p><b>hop count</b> — Specify the maximum number of hops that will be traced from the receiver back toward the source.</p> <p><b>Values</b> 1 — 255</p> <p><b>Default</b> 32 hops (infinity for the DVMRP routing protocol).</p> <p><b>router</b> <i>router-instance</i> — Specify the router name or service ID.</p> <p><b>Values</b> <i>router-name:</i> Base, management <i>service-id:</i> 1 — 2147483647</p>

**Default** Base

**wait-time** *wait-time* — Specify the number of seconds to wait for the response.

**Values** 1 — 60

## mtrace

**Syntax** **mtrace source** [*ip-address* | *dns-name*] [**group** *grp-ip-address*] [**destination** *dst-ip-address*] [**hop** *hop*] [**router** *router-instance*] [**wait-time** *wait-time*]

**Context** <GLOBAL>

**Description** This command traces a multicast path from a source to a receiver.

**Parameters** *ip-address* — Specify the ip-address of the multicast capable target router.

*dns-name* — Specify the DNS name (if DNS name resolution is configured).

**Values** 63 characters maximum

**group** *group-ip-address* — Specify the multicast address or DNS name of the group that resolves to the multicast group address that will be used. If the group is not specified, address 224.2.0.1 (the Mbone audio) will be used. This will suffice if packet loss statistics for a particular multicast group are not needed.

**destination** *dst-p-address* — Specify either the IP address or the DNS name of the unicast destination. If this parameter is omitted the IP address of the system where the command is entered will be used. The receiver parameter can also be used to specify a local interface address as the destination address for sending the trace query. The response will also be returned to the address specified as the receiver.

**hop** *hop* — Specify the maximum number of hops that will be traced from the receiver back toward the source.

**Values** 1 — 255

**Default** 32 hops (infinity for the DVMRP routing protocol).

*router-instance* — Specify the router name or service ID.

**Values** *router-name:* Base, management  
*service-id:* 1 — 2147483647

**Default** Base

**wait-time** *wait-time* — Specify the number of seconds to wait for the response.

**Values** 1 — 60

## password

**Syntax** **password**

**Context** <ROOT>

**Description** This command changes a user CLI login password.

## Global Commands

When a user logs in after the administrator forces a **new-password-at-login**, or the password has expired (**aging**), then this command is automatically invoked.

When invoked, the user is prompted to enter the old password, the new password, and then the new password again to verify the correct input.

If a user fails to create a new password after the administrator forces a **new-password-at-login** or after the password has expired, the user is not allowed access to the CLI.

A user cannot configure a non-conformant password for themselves using the global password command. A password value that does not conform to the minimum-length or other password complexity rules can be configured using the **config>system>security>user>password** command (for example, by an administrator), but a warning is provided in the CLI. This allows, for example, an administrator to configure a nonconformant password for a user.

## ping

**Syntax** **ping** *{ip-address | ipv6-address | dns-name}* [**rapid** | **detail**] [**ttl** *time-to-live*] [**tos** *type-of-service*] [**size** *bytes*] [**pattern** *pattern*] [**source** *ip-address*] [**interval** *seconds*] [**{next-hop ip-address}** | **{interface interface-name}**] [**bypass-routing**] [**count** *requests*] [**do-not-fragment**] [**router** *[router-instance]*] [**timeout** *timeout*]

**Context** <GLOBAL>

**Description** This command is the TCP/IP utility to verify IP reachability.

**Parameters** *ip-address | dns-name* — The remote host to ping. The IP address or the DNS name (if DNS name resolution is configured) can be specified.

*ipv6-address* — The IPv6 IP address.

**Values** x:x:x:x:x:x:x (eight 16-bit pieces)  
x:x:x:x:x:d.d.d.d  
x: 0 — FFFF H  
d: 0 — 255 D

**rapid** | **detail** — The **rapid** parameter specifies to send ping requests rapidly. The results are reported in a single message, not in individual messages for each ping request. By default, five ping requests are sent before the results are reported. To change the number of requests, include the **count** option.

The **detail** parameter includes in the output the interface on which the ping reply was received.

Example output:

```
A:ALA-1# ping 192.168.xx.xx4 detail
PING 192.168.xx.xx4: 56 data bytes
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=0 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=1 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=2 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=3 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=4 ttl=64 time=0.000 ms.

---- 192.168.xx.xx4 PING Statistics ----
5 packets transmitted, 5 packets received, 0.00% packet loss
round-trip min/avg/max/stddev = 0.000/0.000/0.000/0.000 ms
A:ALA-1#
```

**tll** *time-to-live* — The IP Time To Live (TTL) value to include in the ping request, expressed as a decimal integer.

**Values** 0 — 128

**tos** *type-of-service* — The type-of-service (TOS) bits in the IP header of the ping packets, expressed as a decimal integer.

**Values** 0 — 255

**size** *bytes* — The size in bytes of the ping request packets.

**Default** 56 bytes (actually 64 bytes because 8 bytes of ICMP header data are added to the packet)

**Values** 0 — 65507

**pattern** *pattern* — A 16-bit pattern string to include in the ping packet, expressed as a decimal integer.

**Values** 0 — 65535

**source** *ip-address* — The source IP address to use in the ping requests in dotted decimal notation.

**Default** The IP address of the egress IP interface.

**Values** 0.0.0.0 — 255.255.255.255

**interval** *seconds* — The interval in seconds between consecutive ping requests, expressed as a decimal integer.

**Default** 1

**Values** 1 — 10000

**next-hop** *ip-address* — This option disregards the routing table and will send this packet to the specified next hop address. This address must be on an adjacent router that is attached to a subnet that is common between this and the next-hop router.

**Default** Per the routing table.

**Values** A valid IP next hop IP address.

**interface** *interface-name* — Specify the interface name.

**bypass-routing** — Send the ping request to a host on a directly attached network bypassing the routing table. The host must be on a directly attached network or an error is returned.

**count** *requests* — The number of ping requests to send to the remote host, expressed as a decimal integer.

**Default** 5

**Values** 1 — 10000

**do-not-fragment** — Specifies that the request frame should not be fragmented. This option is particularly useful in combination with the size parameter for maximum MTU determination.

**router** *router-instance* — Specify the router name or service ID.

**Default** Base

**Values** *router-name:* Base, management  
*service-id:* 1 — 2147483647

**timeout** *timeout* — Specify the timeout in seconds.

## Global Commands

**Default** 5  
**Values** 1 — 10

### pwc

**Syntax** **pwc [previous]**

**Context** <GLOBAL>

**Description** This command displays the present or previous working context of the CLI session. The **pwc** command provides a user who is in the process of dynamically configuring a chassis a way to display the current or previous working context of the CLI session. The **pwc** command displays a list of the CLI nodes that hierarchically define the current context of the CLI instance of the user.

For example,

```
A:ALA-1>config>router>bgp>group# pwc
-----
Present Working Context :
-----
<root>
  configure
  router Base
  bgp
  group test
  ospf
  area 1
-----
A:ALA-1>config>router>bgp>group#
```

For example,

When the **previous** keyword is specified, the previous context displays. This is the context entered by the CLI parser upon execution of the **exit** command. The current context of the CLI is not affected by the **pwc** command.

For example,

```
A:ALA-1>config>router>bgp>group# pwc previous
-----
Previous Working Context :
-----
<root>
  configure
  router Base
  bgp
  ospf
-----
A:ALA-1>config>router>bgp>group#
```

**Parameters** **previous** — Specifies to display the previous present working context.

### sleep

<b>Syntax</b>	<b>sleep</b> [ <i>seconds</i> ]
<b>Context</b>	<GLOBAL>
<b>Description</b>	This command causes the console session to pause operation (sleep) for 1 second (default) or for the specified number of seconds.
<b>Parameters</b>	<i>seconds</i> — The number of seconds for the console session to sleep, expressed as a decimal integer.
	<b>Default</b> 1
	<b>Values</b> 1 — 100

## ssh

<b>Syntax</b>	<b>ssh</b> [ <i>ip-addr</i>   <i>dns-name</i> [ <i>username@ip-addr</i> ] [- <i>I</i> <i>username</i> ] [- <i>v</i> <i>SSH-version</i> ] [ <b>router</b> <i>router-instance</i> ] <b>service-name</b> <i>service-name</i> ]
<b>Context</b>	<GLOBAL>
<b>Description</b>	This command initiates a client SSH session with the remote host and is independent from the administrative or operational state of the SSH server. However, to be the target of an SSH session, the SSH server must be operational.  Quitting SSH while in the process of authentication is accomplished by either executing a ctrl-c or "~." (tilde and dot) assuming the "~" is the default escape character for SSH session.
<b>Parameters</b>	<i>ip-address</i>   <i>host-name</i> — The remote host to which to open an SSH session. The IP address or the DNS name (providing DNS name resolution is configured) can be specified.  - <i>I</i> <i>user</i> — The user name to use when opening the SSH session.  <b>router</b> <i>router-instance</i> — Specify the router name or service ID.
	<b>Values</b> <i>router-name:</i> Base, management <i>service-id:</i> 1 — 2147483647
	<b>Default</b> Base

## telnet

<b>Syntax</b>	<b>telnet</b> [ <i>ip-address</i>   <i>dns-name</i> ] [ <i>port</i> ] [ <b>router</b> <i>router-instance</i> ]
<b>Context</b>	<GLOBAL>
<b>Description</b>	This command opens a Telnet session to a remote host. Telnet servers in 7950 XRSnetworks limit a Telnet clients to three retries to login. The Telnet server disconnects the Telnet client session after three retries. The number of retry attempts for a Telnet client session is not user-configurable.

## Global Commands

**Parameters** *ip-address* — The IP address or the DNS name (providing DNS name resolution is configured) can be specified.

**Values**

ipv4-address	a.b.c.d
ipv6-address	x:x:x:x:x:x:x[-interface] x:x:x:x:x:d.d.d.d[-interface] x: [0 — FFFF]H d: [0 — 255]Dipv6-address

**dns-name** — Specify the DNS name (if DNS name resolution is configured).

**Values** 128 characters maximum

**port** — The TCP port number to use to Telnet to the remote host, expressed as a decimal integer.

**Default** 23

**Values** 1 — 65535

**router** *router-instance* — Specify the router name or service ID.

**Values**

<i>router-name:</i>	Base, management
<i>service-id:</i>	1 — 2147483647

**Default** Base

## traceroute

**Syntax** **traceroute** {*ip-address* | *dns-name*} [**tll** *tll*] [**wait** *milliseconds*] [**no-dns**] [**source** *ip-address*] [**tos** *type-of-service*] [**router** *router-instance*]

**Context** <GLOBAL>

**Description** The TCP/IP traceroute utility determines the route to a destination address. Note that aborting a traceroute with the <Ctrl-C> command could require issuing a second <Ctrl-C> command before the prompt is returned.

```
A:ALA-1# traceroute 192.168.xx.xx4
traceroute to 192.168.xx.xx4, 30 hops max, 40 byte packets
 1 192.168.xx.xx4 0.000 ms 0.000 ms 0.000 ms
A:ALA-1#
```

**Parameters** *ip-address* | *dns-name* — The remote address to traceroute. The IP address or the DNS name (if DNS name resolution is configured) can be specified.

**Values**

ipv4-address	a.b.c.d
ipv6-address	x:x:x:x:x:x:x[-interface] x:x:x:x:x:d.d.d.d[-interface] x: [0 — FFFF]H d: [0 — 255]Dipv6-address
dns-name	128 characters maximum

**tll** *tll* — The maximum Time-To-Live (TTL) value to include in the traceroute request, expressed as a decimal integer.

**Values** 1 — 255

**wait** *milliseconds* — The time in milliseconds to wait for a response to a probe, expressed as a decimal integer.

**Default** 5000

**Values** 1 — 60000

**no-dns** — When the **no-dns** keyword is specified, a DNS lookup for the specified host name will not be performed.

**Default** DNS lookups are performed

**source** *ip-address* — The source IP address to use as the source of the probe packets in dotted decimal notation. If the IP address is not one of the device's interfaces, an error is returned.

**tos** *type-of-service* — The type-of-service (TOS) bits in the IP header of the probe packets, expressed as a decimal integer.

**Values** 0 — 255

**router** *router-instance* — Specifies the router name or service ID.

**Values** *router-name:* Base, management  
*service-id:* 1 — 2147483647

**Default** Base

## tree

**Syntax** **tree** [**detail**]

**Context** <GLOBAL>

**Description** This command displays the command hierarchy structure from the present working context.

**Parameters** **detail** — Includes parameter information for each command displayed in the tree output.

## write

**Syntax** **write** {*user* | **broadcast**} *message-string*

**Context** <GLOBAL>

**Description** This command sends a console message to a specific user or to all users with active console sessions.

**Parameters** *user* — The name of a user with an active console session to which to send a console message.

**Values** Any valid CLI username

**broadcast** — Specifies that the *message-string* is to be sent to all users logged into the router.

*message-string* — The message string to send. Allowed values are any string up to 250 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

---

## CLI Environment Commands

### alias

**Syntax** **alias** *alias-name alias-command-line*  
**no alias** *alias-name*

**Context** environment

**Description** This command enables the substitution of a command line by an alias. Use the **alias** command to create alternative or easier to remember/understand names for an entity or command string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. The special characters | and > can't be used inside environment alias strings. Additionally, the special characters / and \ cannot be used as the first character inside an alias string. Only a single command can be present in the command string. The **alias** command can be entered in any context but must be created in the **root>environment** context.

For example, to create an alias named **soi** to display OSPF interfaces, enter:

```
alias soi "show router ospf interface"
```

**Parameters** *alias-name* — The alias name. Do not use a valid command string for the alias. If the alias specified is an actual command, this causes the command to be replaced by the alias.

*alias-command-line* — The command line to be associated.

### create

**Syntax** [**no**] **create**

**Context** environment

**Description** By default, the **create** command is required to create a new OS entity.  
The **no** form of the command disables requiring the **create** keyword.

**Default** **create** — The create keyword is required.

### more

**Syntax** [**no**] **more**

**Context** environment

**Description** This command enables per-screen CLI output, meaning that the output is displayed on a screen-by-screen basis. The terminal screen length can be modified with the **terminal** command.  
The following prompt appears at the end of each screen of paginated output:

```
Press any key to continue (Q to quit)
```

The **no** form of the command displays the output all at once. If the output length is longer than one screen, the entire output will be displayed, which may scroll the screen.

**Default** **more** — CLI output pauses at the end of each screen waiting for the user input to continue.

## reduced-prompt

**Syntax** **reduced-prompt** [*number of nodes in prompt*]  
**no reduced-prompt**

**Context** environment

**Description** This command configures the maximum number of higher CLI context levels to display in the CLI prompt for the current CLI session. This command is useful when configuring features that are several node levels deep, causing the CLI prompt to become too long.

By default, the CLI prompt displays the system name and the complete context in the CLI.

The number of *nodes* specified indicates the number of higher-level contexts that can be displayed in the prompt. For example, if reduced prompt is set to 2, the two highest contexts from the present working context are displayed by name with the hidden (reduced) contexts compressed into an ellipsis (“...”).

```
A:ALA-1>environment# reduced-prompt 2
A:ALA-1>vonfig>router# interface to-103
A:ALA-1>...router>if#
```

Note that the setting is not saved in the configuration. It must be reset for each CLI session or stored in an **exec** script file.

The **no** form of the command reverts to the default.

**Default** **no reduced-prompt** — Displays all context nodes in the CLI prompt.

**Parameters** *number of nodes in prompt* — The maximum number of higher-level nodes displayed by name in the prompt, expressed as a decimal integer.

**Default** 2

**Values** 0 — 15

## saved-ind-prompt

**Syntax** [**no**] **saved-ind-prompt**

**Context** environment

**Description** This command enables saved indicator in the prompt. When changes are made to the configuration file a “\*” appears in the prompt string indicating that the changes have not been saved. When an admin save command is executed the “\*” disappears.

```
*A:ALA-48# admin save
Writing file to ftp://128.251.10.43/./sim48/sim48-config.cfg
Saving configuration .... Completed.
A:ALA-48#
```

## suggest-internal-objects

**Syntax** [no] suggest-internal-objects

**Context** environment

**Description** This command enables suggesting of internally created objects while auto completing. The **no** form of the command disables the command.

## terminal

**Syntax** terminal  
no terminal

**Context** environment

**Description** This command enables the context to configure the terminal screen length for the current CLI session.

## length

**Syntax** length *lines*

**Context** environment>terminal

**Description** This command sets the number of lines on a screen.

**Default** 24 — Terminal dimensions are set to 24 lines long by 80 characters wide.

**Parameters** *lines* — The number of lines for the terminal screen length, expressed as a decimal integer.

**Values** 1 — 512

## width

**Syntax** width *width*

**Context** environment>terminal

**Description** This command determines display terminal width.

**Default** 80 — Terminal dimensions are set to 24 lines long by 80 characters wide.

**Parameters** *width* — Sets the width of the display terminal.

**Values** 1 — 512

## time-display

**Syntax** `time-display {local | utc}`

**Context** environment

**Description** This command displays time stamps in the CLI session based on local time or Coordinated Universal Time (UTC).

The system keeps time internally in UTC and is capable of displaying the time in either UTC or local time based on the time zone configured.

This configuration command is only valid for times displayed in the current CLI session. This includes displays of event logs, traps and all other places where a time stamp is displayed.

In general all time stamps are shown in the time selected. This includes log entries destined for console/session, memory, or SNMP logs. Log files on compact flash are maintained and displayed in UTC format.

**Default** `time-display local` — Displays time stamps based on the local time.

---

## Monitor CLI Commands

### card

**Syntax** `card slot-number fp fp-number ingress {access | network} queue-group queue-group-name instance instance-id [interval seconds ] [repeat repeat] policer policer-id [absolute | percent-rate | reference-rate]`

**Context** monitor

**Description** This command monitors policer statistics in an ingress FP queue group.

**Parameters** `card slot-number` — Specifies the slot number associated with the queue group, expressed as an integer.

**Values** 1 — 20

`fp fp-number` — Specifies the FP number associated with the queue group, expressed as an integer.

**Values** 1 — 2

`ingress` — Displays policer statistics applied on the ingress FP.

`access` — Displays policer statistics on the FP access.

`network` — Displays policer statistics on the FP network.

`queue-group queue-group-name` — Specifies the name of the queue group up to 32 characters in length.

`instance instance-id` — Specifies the identification of a specific instance of the queue-group.

**Values** 1— 65535

`interval interval` — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

`policer policer-id` — The specified policer-id must exist within the queue-group template applied to the ingress context of the forwarding plane.

**Values** 1 — 8

`absolute` — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

`percent-rate` — When the percent-rate keyword is specified, the rate-per-second for each statistic is displayed based on the reference rate of 10G.

**Default** 10

**Values** 1 — 999

*reference-rate* — When a reference-rate value is specified, the rate-per-second for each statistic is displayed as a percentage based on the reference rate specified.

**Values** 100M, 1G, 10G, 40G, 100G, 400G

## ccag

**Syntax** **ccag** *ccag-id* [**path** {**a** | **b**}] [**type** {**sap-sap** | **sap-net** | **net-sap**}] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context** monitor

**Description** Displays monitor command output of traffic statistics for Cross Connect Aggregation Groups (CCAGs) ports.

**Parameters** *ccag-id* — Specifies the CCAG instance to monitor.

**path** — Specifies the CCA path nodal context where the CCA path bandwidth, buffer and accounting parameters are maintained. The path context must be specified with either the **a** or **b** keyword specifying the CCA path context to be entered.

**type** — Specify cross connect type.

**Values** **sap-sap**, **sap-net**, **net-sap**

**interval** — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## cpm-filter

**Syntax** **cpm-filter**

**Context** monitor

**Description** Displays monitor command output for CPM filters.

## ip

## Monitor CLI Commands

<b>Syntax</b>	<b>ip entry</b> <i>entry-id</i> [ <b>interval</b> <i>seconds</i> ] [ <b>repeat</b> <i>repeat</i> ] [ <b>absolute</b>   <b>rate</b> ]
<b>Context</b>	monitor>cpm-filter
<b>Description</b>	This command displays monitor command statistics for IP filter entries.
<b>Parameters</b>	<b>entry</b> <i>entry-id</i> — Displays information on the specified filter entry ID for the specified filter ID only. <b>Values</b> 1 — 65535 <b>interval</b> <i>seconds</i> — Configures the interval for each display in seconds. <b>Default</b> 5 seconds <b>Values</b> 3 — 60 <b>repeat</b> <i>repeat</i> — Configures how many times the command is repeated. <b>Default</b> 10 <b>Values</b> 1 — 999 <b>absolute</b> — When the <b>absolute</b> keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics. <b>rate</b> — When the <b>rate</b> keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## ipv6

<b>Syntax</b>	<b>ip entry</b> <i>entry-id</i> [ <b>interval</b> <i>seconds</i> ] [ <b>repeat</b> <i>repeat</i> ] [ <b>absolute</b>   <b>rate</b> ]
<b>Context</b>	monitor>cpm-filter
<b>Description</b>	This command displays monitor command statistics for IPv6 filter entries.
<b>Parameters</b>	<b>entry</b> <i>entry-id</i> — Displays information on the specified filter entry ID for the specified filter ID only. <b>Values</b> 1 — 65535 <b>interval</b> <i>seconds</i> — Configures the interval for each display in seconds. <b>Default</b> 5 seconds <b>Values</b> 3 — 60 <b>repeat</b> <i>repeat</i> — Configures how many times the command is repeated. <b>Default</b> 10 <b>Values</b> 1 — 999 <b>absolute</b> — When the <b>absolute</b> keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics. <b>rate</b> — When the <b>rate</b> keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## mac

**Syntax** `mac entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>cpm-filter`

**Description** This command displays monitor command statistics for MAC filter entries.

**Parameters** `entry entry-id` — Displays information on the specified filter entry ID for the specified filter ID only.

**Values** 1 — 65535

`interval seconds` — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## filter

**Syntax** `filter`

**Context** `monitor`

**Description** This command enables the context to configure criteria to monitor IP and MAC filter statistics.

## ip

**Syntax** `ip ip-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>filter`

**Description** This command enables IP filter monitoring. The statistical information for the specified IP filter entry displays at the configured interval until the configured count is reached. The first screen displays the current statistics related to the specified IP filter. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta. Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

## Monitor CLI Commands

### Parameters

*ip-filter-id* — Displays detailed information for the specified filter ID and its filter entries.

**Values** 1 — 65535

*entry entry-id* — Displays information on the specified filter entry ID for the specified filter ID only.

**Values** 1 — 65535

*interval seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

*repeat repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-1>monitor# filter ip 10 entry 1 interval 3 repeat 3 absolute
=====
Monitor statistics for IP filter 10 entry 1
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====
A:ALA-1>monitor#
```

```
A:ALA-1>monitor# filter ip 10 entry 1 interval 3 repeat 3 rate
=====
Monitor statistics for IP filter 10 entry 1
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 3 sec (Mode: Rate)
-----
```

```

Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====
A:ALA-1>monitor#

```

## ipv6

**Syntax** `ipv6 ipv6-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>filter`

**Description** This command enables IPv6 filter monitoring. The statistical information for the specified IPv6 filter entry displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified IPv6 filter. The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *ipv6-filter-id* — Displays detailed information for the specified IPv6 filter ID and its filter entries.

**Values** 1 — 65535

**entry** *entry-id* — Displays information on the specified IPv6 filter entry ID for the specified filter ID only.

**Values** 1 — 65535

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-48# monitor filter ipv6 100 entry 10 interval 3 repeat 3 absolute
```

## Monitor CLI Commands

```
=====
Monitor statistics for IPv6 filter 100 entry 10
-----
At time t = 0 sec (Base Statistics)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 3 sec (Mode: Absolute)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 6 sec (Mode: Absolute)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 9 sec (Mode: Absolute)
-----
Ing. Matches : 0                               Egr. Matches : 01
=====
A:ALA-48#
```

```
A:ALA-48# monitor filter ipv6 100 entry 10 interval 3 repeat 3 rate
=====
Monitor statistics for IPv6 filter 100 entry 10
-----
At time t = 0 sec (Base Statistics)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 3 sec (Mode: Rate)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 6 sec (Mode: Rate)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 9 sec (Mode: Rate)
-----
Ing. Matches : 0                               Egr. Matches : 1
=====
A:ALA-48#
```

## mac

**Syntax** `mac mac-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>filter

**Description** This command enables MAC filter monitoring. The statistical information for the specified MAC filter entry displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified MAC filter. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters**

*mac-filter-id* — The MAC filter policy ID.

**Values** 1 — 65535

**entry** *entry-id* — Displays information on the specified filter entry ID for the specified filter ID only.

**Values** 1 — 65535

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

**Sample Output**

```
A:ALA-1>monitor>filter# mac 50 entry 10 interval 3 repeat 3 absolute
=====
Monitor statistics for Mac filter 50 entry 10
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====

A:ALA-1>monitor>filter# mac 50 entry 10 interval 3 repeat 3 rate
=====
Monitor statistics for Mac filter 50 entry 10
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
```

## Monitor CLI Commands

```
-----  
At time t = 3 sec (Mode: Rate)  
-----  
Ing. Matches: 0                               Egr. Matches : 0  
-----  
At time t = 6 sec (Mode: Rate)  
-----  
Ing. Matches: 0                               Egr. Matches : 0  
-----  
At time t = 9 sec (Mode: Rate)  
-----  
Ing. Matches: 0                               Egr. Matches : 0  
=====
```

```
A:ALA-1>monitor>filter#
```

## lag

**Syntax** `lag lag-id [lag-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor

**Description** This command monitors traffic statistics for Link Aggregation Group (LAG) ports. Statistical information for the specified LAG ID(s) displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified LAG ID. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the “rate per second” for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *lag-id* — The number of the LAG.

**Default** none — The LAG ID value must be specified.

**Values** 1 — 800

*interval seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

*repeat repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12# monitor lag 2
```

```

=====
Monitor statistics for LAG ID 2
=====
Port-id      Input      Input      Output      Output      Input      Output
             Bytes      Packets    Bytes      Packets      Errors     Errors
-----
At time t = 0 sec (Base Statistics)
-----
1/1/1        2168900   26450      64          1            0           0
1/1/2        10677318 125610     2273750     26439        0           0
1/1/3        2168490   26445      0            0            0           0
-----
Totals        15014708 178505     2273814     26440        0           0
-----
At time t = 5 sec (Mode: Delta)
-----
1/1/1         0          0           0            0            0           0
1/1/2        258         3           86            1            0           0
1/1/3        82          1            0            0            0           0
-----
Totals        340         4            86            1            0           0
=====
A:ALA-12#

```

## lsp-egress-stats

**Syntax** **lsp-egress-stats**  
**lsp-egress-stats** *lsp-name*

**Context** show>router>mpls

**Description** This command displays MPLS LSP egress statistics information.

## lsp-ingress-stats

**Syntax** **lsp-ingress-stats**  
**lsp-ingress-stats** *ip-address lsp lsp-name*

**Context** show>router>mpls

**Description** This command displays MPLS LSP ingress statistics information.

## management-access-filter

**Syntax** **management-access-filter**

**Context** monitor

**Description** This command enables the context to monitor management-access filters. These filters are configured in the **config>system>security>mgmt-access-filter** context.

## ip

**Syntax** `ip entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>management-access-filter

**Description** This command monitors statistics for the MAF IP filter entry.

**Parameters** `entry entry-id` — Specifies an existing IP MAF entry ID.

**Values** 1 — 9999

`interval seconds` — Configures the interval for each display in seconds.

**Default** 10

**Values** 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## ipv6

**Syntax** `ipv6 entry-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>management-access-filter

**Description** This command monitors statistics for the MAF IPv6 filter entry.

**Parameters** `entry entry-id` — Specifies an existing IP MAF entry ID.

**Values** 1 — 9999

`interval seconds` — Configures the interval for each display in seconds.

**Default** 10

**Values** 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## mac

- Syntax** `mac entry-id [interval seconds] [repeat repeat] [absolute | rate]`
- Context** monitor>management-access-filter
- Description** This command monitors statistics for the MAF MAC filter entry.
- Parameters** `entry entry-id` — Specifies an existing IP MAF entry ID.
- Values** 1 — 9999
- `interval seconds` — Configures the interval for each display in seconds.
- Default** 10
- Values** 3 — 60
- `repeat repeat` — Configures how many times the command is repeated.
- Default** 10
- Values** 1 — 999
- absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.
- rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## port

- Syntax** `port port-id [port-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`
- Context** monitor
- Description** This command enables port traffic monitoring. The specified port(s) statistical information displays at the configured interval until the configured count is reached.
- The first screen displays the current statistics related to the specified port(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.
- Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.
- Parameters** `port port-id` — Specify up to 5 port IDs.
- Syntax:** `port-id slot/mda/portinterval seconds` — Configures the interval for each display in seconds.
- Default** 5 seconds
- Values** 3 — 60
- `repeat repeat` — Configures how many times the command is repeated.

## Monitor CLI Commands

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor# port 2/1/4 interval 3 repeat 3 absolute
=====
Monitor statistics for Port 2/1/4
=====
                               Input                               Output
-----
At time t = 0 sec (Base Statistics)
-----
Octets                        0                               0
Packets                       39                              175
Errors                        0                               0
-----
At time t = 3 sec (Mode: Absolute)
-----
Octets                        0                               0
Packets                       39                              175
Errors                        0                               0
-----
At time t = 6 sec (Mode: Absolute)
-----
Octets                        0                               0
Packets                       39                              175
Errors                        0                               0
-----
At time t = 9 sec (Mode: Absolute)
-----
Octets                        0                               0
Packets                       39                              175
Errors                        0                               0
=====
A:ALA-12>monitor#
```

```
A:ALA-12>monitor# port interval 3 repeat 3 rate
=====
Monitor statistics for Port 2/1/4
=====
                               Input                               Output
-----
At time t = 0 sec (Base Statistics)
-----
Octets                        0                               0
Packets                       39                              175
Errors                        0                               0
-----
At time t = 3 sec (Mode: Rate)
-----
Octets                        0                               0
```

```

Packets                                0                                0
Errors                                  0                                0
-----
At time t = 6 sec (Mode: Rate)
-----
Octets                                  0                                0
Packets                                  0                                0
Errors                                  0                                0
-----
At time t = 9 sec (Mode: Rate)
-----
Octets                                  0                                0
Packets                                  0                                0
Errors                                  0                                0
=====
A:ALA-12>monitor#

```

## qos

**Syntax**    **qos**

**Context**    monitor

**Description**    This command enables the context to configure criteria to monitor QoS scheduler statistics for specific customers and SAPs.

## arbiter-stats

**Syntax**    **arbiter-stats**

**Context**    monitor>qos

**Description**    This command enables the context to configure monitor commands for arbiter statistics.

## port

**Syntax**    **port**

**Context**    monitor>qos

**Description**    This command enables the context to configure monitor commands for port related statistics.

## port

## Monitor CLI Commands

**Syntax** `port port-id exp-secondary-shaper shaper-name [interval seconds] [repeat repeat] [absolute|rate]`

**Context** `monitor>qos`

**Description** This command monitors expanded secondary shaper statistics.

**Parameters** `port port-id` — Specifies the port ID.

**Values** `slot/mda/port`

`exp-secondary-shaper shaper-name` — Displays statistics for the named exp secondary shaper.

`interval` — `seconds` — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

`absolute` — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

`rate` — When the rate keyword is specified, the rate-per-second for each statistic is displayed.

## port

**Syntax** `port port-id vport name monitor-threshold [interval seconds] [repeat repeat]`

**Context** `monitor>qos`

**Description** This command monitors VPORT statistics.

**Parameters** `port port-id` — Specifies the port ID.

**Values** `slot/mda/port [.channel]`

`vport name` — Displays statistics for the named VPORT.

`monitor-threshold` — Displays the exceed-count for the port-scheduler for the named VPORT.

`interval` — `seconds` — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

## scheduler-stats

**Syntax** **scheduler-stats**

**Context** monitor>qos

**Description** This command enables the context to configure monitor commands for scheduler statistics.

## card

**Syntax** **card** *slot-number* **fp** *fp-number* **queue-group** *queue-group-name* **instance** *instance-id* [**ingress**] [**access** | **networks**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **percent-rate** | *reference-rate*] [**arbiter** *root* | *name*]

**Context** monitor>qos>arbiter-stats

**Description** This command monitors arbiter statistics in an ingress FP queue group.

**Parameters** **card** *slot-number* — Specifies the slot number associated with the queue group, expressed as an integer.

**Values** 1 — 20

**fp** *fp-number* — Specifies the FP number associated with the queue group, expressed as an integer.

**Values** 1 — 2

**queue-group** *queue-group-name* — Specifies the name of the queue group up to 32 characters in length.

**instance** *instance-id* — Specifies the identification of a specific instance of the queue-group.

**Values** 1— 65535

**ingress** — Displays arbiter-name statistics applied on the ingress FP.

**access** — Displays arbiter-name statistics applied on the FP access.

**network** — Displays arbiter-name statistics applied on the FP network.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**percent-rate** — When the percent-rate keyword is specified, the rate-per-second for each statistic is displayed based on the reference rate of 10G.

**reference-rate** — When a reference-rate value is specified, the rate-per-second for each statistic is displayed as a percentage based on the reference rate specified.

**Values** 100M, 1G, 10G, 40G, 100G, 400G

## Monitor CLI Commands

**arbiter** *name* — Specifies the name of the policer control policy arbiter.

**Values** An existing arbiter-name in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

*root* — Specifies the root arbiter.

## customer

**Syntax** **customer** *customer-id* **site** *customer-site-name* [**arbiter** *root*{*name*}] [**ingress**|**egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]

**Context** monitor>qos>arbiter-stats

**Description** This command monitors arbiter statistics for a customer site.

**Parameters** *customer-id* — Specifies the ID number to be associated with the customer, expressed as an integer.

**Values** 1 — 2147483647

**site** *customer-site-name* — Specifies the customer site which is an anchor point for ingress and egress arbiter hierarchy.

**arbiter** *name* — Specify the name of the policer control policy arbiter. This parameter is mandatory if the SAP resides on a LAG in adapt-qos link or port-fair mode.

**Values** Values An existing arbiter-name in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

*root* — Specify the root arbiter.

**ingress** — Displays arbiter-name statistics applied on the site ingress.

**egress** — — Displays arbiter-name statistics applied on the site egress.

**interval** *seconds* — — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the rate keyword is specified, the rate-per-second for each statistic is displayed.

## port

**Syntax** `port port-id egress network queue-group queue-group-name instance instance-id [interval seconds] [repeat repeat] [absolute | rate] [arbiter root | name]`

**Context** monitor>qos>arbiter-stats

**Description** This command monitors arbiter statistics for a customer site.

**Parameters** `port port-id` — Specifies the port ID.

**Values** slot/mda/port

`egress network` — Specifies statistics are for an egress network queue group.

**Values** network

`queue-group queue-group-name` — Specifies the name of the queue group up to 32 characters in length.

`instance instance-id` — Specifies the identification of a specific instance of the queue-group.

**Values** 1— 65535

`interval seconds` — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

`absolute` — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

`rate` — When the rate keyword is specified, the rate-per-second for each statistic is displayed.

`arbiter name` — Specify the name of the policer control policy arbiter.

**Values** An existing arbiter-name in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

`root` — Specify the root arbiter.

## sap

**Syntax** `sap sap-id [arbiter name | root] [ingress | egress] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>qos>arbiter-stats

**Description** This command monitors arbiter statistics for a SAP.

**Parameters** `sap-id` — Specify the physical port identifier portion of the SAP definition.

## Monitor CLI Commands

**arbiter** *name* — Specify the name of the policer control policy arbiter. This parameter is mandatory if the SAP resides on a LAG in adapt-qoslink or port-fair mode.

**Values** An existing *scheduler-name* in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**root** — Specify the scheduler to which this queue would be feeding.

**ingress** — Displays *scheduler-name* statistics applied on the ingress SAP.

**egress** — Displays *scheduler-name* statistics applied on the egress SAP.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## customer

**Syntax** **customer** *customer-id* **site** *customer-site-name* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context** monitor>qos>scheduler-stats

**Description** Use this command to monitor scheduler statistics per customer multi-service-site. The first screen displays the current statistics related to the specified customer ID and customer site name. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta. Monitor commands are similar to **show** commands but only statistical information displays. These commands display selected statistics per the configured number of times at the interval specified.

**Parameters** *customer-id* — Specifies the ID number to be associated with the customer, expressed as an integer.

**Values** 1 — 2147483647

**site** *customer-site-name* — Specify the customer site which is an anchor point for ingress and egress virtual scheduler hierarchy.

**scheduler** *scheduler-name* — Specify an existing *scheduler-name*. Scheduler names are configured in the **config>qos>scheduler-policy>tier level** context. This parameter is mandatory if the customer resides on a LAG in adapt-qoslink or port-fair mode.

**Values** An existing *scheduler-name* is in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**ingress** — Displays the customer's multi-service-site ingress scheduler policy.

**egress** — Displays the customer's multi-service-site egress scheduler policy.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## sap

**Syntax** **sap** *sap-id* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context** monitor>qos>scheduler-stats

**Description** Use this command to monitor scheduler statistics for a SAP at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified SAP. The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *sap-id* — Specifies the physical port identifier portion of the SAP definition.

**scheduler** *scheduler-name* — Specify an existing *scheduler-name*. Scheduler names are configured in the **config>qos>scheduler-policy>tier level** context. This parameter is mandatory if the SAP resides on a LAG in adapt-qoslink or port-fair mode.

**Values** An existing *scheduler-name* in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## Monitor CLI Commands

**ingress** — Displays *scheduler-name* statistics applied on the ingress SAP.

**egress** — Displays *scheduler-name* statistics applied on the egress SAP.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## port

**Syntax** **port** *port-id* **queue-group** *queue-group-name* [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**] [**access** | **network**] [**instance** *instance-id*]

**Context** monitor>qos>scheduler-stats

**Description** This command monitors scheduler statistics in a port queue group.

**Parameters** **port** *port-id* — Specifies the port ID.

**Values** slot/mda/port

**queue-group** *queue-group-name* — Specifies the name of the queue group up to 32 characters in length.

**instance** *instance-id* — Specifies the identification of a specific instance of the queue-group.

**Values** 1— 65535

**ingress** — Specifies statistics are for an ingress queue group.

**egress** — Specifies statistics are for an egress queue group.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed.

**access** — Displays scheduler statistics applied on an access port.

**network** — Displays scheduler statistics applied on a network port.

## port

**Syntax** **port** *port-id* **vport** *name* [**interval** *seconds*] [**repeat** *repeat*][**absolute**|**rate**]

**Context** monitor>qos>scheduler-stats

**Description** This command monitors scheduler statistics in a VPORT.

**Parameters** **port** *port-id* — Specifies the port ID.

**Values** slot/mda/port

**vport** *name* — Displays statistics for the named VPORT.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the rate keyword is specified, the rate-per-second for each statistic is displayed.

## sap

**Syntax** **sap** *sap-id* **encap-group** *group-name* [**member** *encap-id*] [**scheduler** *scheduler-name*] [**interval** *seconds*] [**repeat** *repeat*] [**absolute**|**rate**]

**Context** monitor>qos>scheduler-stats

**Description** This command monitors scheduler statistics for a SAP encap-group.

**Parameters** **sap** *sap-id* — Specify the physical port identifier portion of the SAP definition.

**encap-group** *group-name* — Displays statistics for the encap group.

**member** *encap-id* — The value of the encap-id to be displayed.

**Values** 0 - 16777215

## Monitor CLI Commands

**scheduler** *scheduler-name* — Specify an existing scheduler-name. Scheduler names are configured in the `config>qos>scheduler-policy>tier` level context. This parameter is mandatory if the SAP resides on a LAG in `adapt-qoslink` or `port-fair` mode

**Values** An existing scheduler-name is in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the rate keyword is specified, the rate-per-second for each statistic is displayed.

## subscriber

**Syntax** **subscriber** *sub-ident-string* [**interval** *seconds*] [**repeat** *repeat*] [**absolute|rate**] **sap** *sap-id* **sla-profile** *sla-profile-name*

**Context** `monitor>qos>scheduler-stats`

**Description** This command monitors scheduler statistics for an SLA profile.

**Parameters** **subscriber** *sub-ident-string* — Specifies an existing subscriber a identification policy name.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the rate keyword is specified, the rate-per-second for each statistic is displayed.

**sap** *sap-id* — Specify the physical port identifier portion of the SAP definition.

**sla-profile** *sla-profile-name* — Specifies the SLA profile belonging to the subscriber host.

## router

**Syntax** `router router-instance`

**Context** monitor

**Description** This command enables the context to configure criteria to monitor statistical information for BGP, LDP, MPLS, OSPF, OSPF3, PIM, RIP, and RSVP protocols.

**Parameters** *router-instance* — Specify the router name or service ID.

<b>Values</b>	<i>router-name:</i>	Base, management
	<i>service-id:</i>	1 — 2147483647
<b>Default</b>		Base

## neighbor

**Syntax** `neighbor ip-address [ip-address...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>router>bgp

**Description** This command displays statistical BGP neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** **neighbor** *ip-address* — Displays damping information for entries received from the BGP neighbor. Up to 5 IP addresses can be specified.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor>router>bgp# neighbor 180.0.0.10 interval 3 repeat 3 absolute
=====
```

## Monitor CLI Commands

```
Monitor statistics for BGP Neighbor 180.0.0.10
=====
At time t = 0 sec
-----
Recd. Prefixes   : 2                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages     : 916              o/p Messages    : 916
i/p Octets       : 17510            o/p Octets      : 17386
i/p Updates      : 2                o/p Updates     : 0
-----
At time t = 3 sec
-----
Recd. Prefixes   : 0                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages     : 0                o/p Messages    : 0
i/p Octets       : 0                o/p Octets      : 0
i/p Updates      : 0                o/p Updates     : 0
-----
At time t = 6 sec
-----
Recd. Prefixes   : 0                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages     : 0                o/p Messages    : 0
i/p Octets       : 0                o/p Octets      : 0
i/p Updates      : 0                o/p Updates     : 0
-----
At time t = 9 sec
-----
Recd. Prefixes   : 0                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages     : 0                o/p Messages    : 0
i/p Octets       : 6                o/p Octets      : 0
i/p Updates      : 0                o/p Updates     : 0
=====
A:ALA-12>monitor>router>bgp#
```

## statistics

**Syntax** `statistics [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>router>isis`

**Description** This command displays statistical IS-IS traffic information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified router statistics. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** `interval seconds` — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat repeat** — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor>router>isis# statistics interval 3 repeat 2 absolute
=====
ISIS Statistics
=====
At time t = 0 sec (Base Statistics)
-----
ISIS Instance      : 1                SPF Runs          : 2
Purge Initiated   : 0                LSP Regens.      : 11

CSPF Statistics

Requests          : 0                Request Drops    : 0
Paths Found       : 0                Paths Not Found  : 0
-----
PDU Type   Received   Processed   Dropped    Sent       Retransmitted
-----
LSP        0           0           0           0           0
IIH        0           0           0           74          0
CSNP       0           0           0           0           0
PSNP       0           0           0           0           0
Unknown    0           0           0           0           0
-----
At time t = 3 sec (Mode: Absolute)
-----
ISIS Instance      : 1                SPF Runs          : 2
Purge Initiated   : 0                LSP Regens.      : 11

CSPF Statistics

Requests          : 0                Request Drops    : 0
Paths Found       : 0                Paths Not Found  : 0
-----
PDU Type   Received   Processed   Dropped    Sent       Retransmitted
-----
LSP        0           0           0           0           0
IIH        0           0           0           74          0
CSNP       0           0           0           0           0
PSNP       0           0           0           0           0
Unknown    0           0           0           0           0
-----
At time t = 6 sec (Mode: Absolute)
-----
```

## Monitor CLI Commands

```

ISIS Instance      : 1          SPF Runs          : 2
Purge Initiated   : 0          LSP Regens.      : 11
  
```

### CSPF Statistics

```

Requests          : 0          Request Drops    : 0
Paths Found       : 0          Paths Not Found  : 0
  
```

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	74	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

```
A:ALA-12>monitor>router>isis# statistics interval 3 repeat 2 rate
```

### ISIS Statistics

```
At time t = 0 sec (Base Statistics)
```

```

ISIS Instance      : 1          SPF Runs          : 2
Purge Initiated   : 0          LSP Regens.      : 11
  
```

### CSPF Statistics

```

Requests          : 0          Request Drops    : 0
Paths Found       : 0          Paths Not Found  : 0
  
```

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	76	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

```
At time t = 3 sec (Mode: Rate)
```

```

ISIS Instance      : 1          SPF Runs          : 0
Purge Initiated   : 0          LSP Regens.      : 0
  
```

### CSPF Statistics

```

Requests          : 0          Request Drops    : 0
Paths Found       : 0          Paths Not Found  : 0
  
```

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	0	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

```
At time t = 6 sec (Mode: Rate)
```

```

ISIS Instance      : 1          SPF Runs          : 0
  
```

```

Purge Initiated   : 0                      LSP Regens.      : 0

CSPF Statistics

Requests          : 0                      Request Drops    : 0
Paths Found       : 0                      Paths Not Found  : 0
-----
PDU Type   Received   Processed   Dropped    Sent       Retransmitted
-----
LSP        0           0           0           0           0
IIH        0           0           0           1           0
CSNP       0           0           0           0           0
PSNP       0           0           0           0           0
Unknown    0           0           0           0           0
-----
A:ALA-12>monitor>router>isis#

```

## session

**Syntax** `session ldp-id [ldp-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>router>ldp

**Description** This command displays statistical information for LDP sessions at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified LDP session(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *ldp-id* — Specify the IP address of the LDP session to display.

**Values** *ip-address[:label-space]*  
*ip-address* — a.b.c.d  
*label-space* — [0..65535]

**interval seconds** — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat repeat** — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

**Sample Output**

```
A:ALA-103>monitor>router>ldp# session 10.10.10.104 interval 3 repeat 3 absolute
=====
Monitor statistics for LDP Session 10.10.10.104
=====
```

	Sent	Received
-----		
At time t = 0 sec (Base Statistics)		
-----		
FECs	1	2
Hello	5288	5289
Keepalive	8225	8225
Init	1	1
Label Mapping	1	4
Label Request	0	0
Label Release	0	0
Label Withdraw	0	0
Label Abort	0	0
Notification	0	0
Address	1	1
Address Withdraw	0	0
-----		
At time t = 3 sec (Mode: Absolute)		
-----		
FECs	1	2
Hello	5288	5289
Keepalive	8226	8226
Init	1	1
Label Mapping	1	4
Label Request	0	0
Label Release	0	0
Label Withdraw	0	0
Label Abort	0	0
Notification	0	0
Address	1	1
Address Withdraw	0	0
-----		
At time t = 6 sec (Mode: Absolute)		
-----		
FECs	1	2
Hello	5288	5290
Keepalive	8226	8226
Init	1	1
Label Mapping	1	4
Label Request	0	0
Label Release	0	0
Label Withdraw	0	0
Label Abort	0	0
Notification	0	0
Address	1	1
Address Withdraw	0	0
-----		
At time t = 9 sec (Mode: Absolute)		
-----		
FECs	1	2
Hello	5288	5290
Keepalive	8226	8226
Init	1	1
Label Mapping	1	4

```

Label Request          0          0
Label Release          0          0
Label Withdraw         0          0
Label Abort            0          0
Notification           0          0
Address                1          1
Address Withdraw       0          0

```

```

=====
A:ALA-12>monitor>router>ldp#

```

```

A:ALA-12>monitor>router>ldp# session 10.10.10.104 interval 3 repeat 3 rate

```

```

=====
Monitor statistics for LDP Session 10.10.10.104

```

```

=====
                          Sent          Received
-----
At time t = 0 sec (Base Statistics)
-----
FECs                      1          2
Hello                    5289        5290
Keepalive                 8227        8227
Init                      1          1
Label Mapping             1          4
Label Request             0          0
Label Release             0          0
Label Withdraw            0          0
Label Abort               0          0
Notification              0          0
Address                   1          1
Address Withdraw          0          0
-----
At time t = 3 sec (Mode: Rate)
-----
FECs                      0          0
Hello                     0          0
Keepalive                  0          0
Init                       0          0
Label Mapping              0          0
Label Request              0          0
Label Release              0          0
Label Withdraw             0          0
Label Abort                0          0
Notification               0          0
Address                    0          0
Address Withdraw           0          0
-----
At time t = 6 sec (Mode: Rate)
-----
FECs                      0          0
Hello                     0          0
Keepalive                  0          0
Init                       0          0
Label Mapping              0          0
Label Request              0          0
Label Release              0          0
Label Withdraw             0          0
Label Abort                0          0
Notification               0          0
Address                    0          0
Address Withdraw           0          0

```

## Monitor CLI Commands

```
-----  
At time t = 9 sec (Mode: Rate)  
-----  
FECs                0                0  
Hello               0                0  
Keepalive           0                0  
Init                0                0  
Label Mapping       0                0  
Label Request       0                0  
Label Release       0                0  
Label Withdraw      0                0  
Label Abort         0                0  
Notification        0                0  
Address             0                0  
Address Withdraw    0                0  
=====
```

```
A:ALA-12>monitor>router>ldp#
```

## statistics

**Syntax** `statistics [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>router>ldp

**Description** Monitor statistics for LDP instance at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the LDP statistics. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** `interval seconds` — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor>router>ldp# statistics interval 3 repeat 3 absolute  
=====
```

```
Monitor statistics for LDP instance  
=====
```

```

At time t = 0 sec (Base Statistics)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 3 sec (Mode: Absolute)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 6 sec (Mode: Absolute)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 9 sec (Mode: Absolute)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
=====
A:ALA-12>monitor>router>ldp#

A:ALA-12>monitor>router>ldp# statistics interval 3 repeat 3 rate
=====
Monitor statistics for LDP instance
=====
At time t = 0 sec (Base Statistics)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 3 sec (Mode: Rate)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 0                Serv FECs Recv      : 0
-----
At time t = 6 sec (Mode: Rate)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 0                Serv FECs Recv      : 0
-----
At time t = 9 sec (Mode: Rate)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 0                Serv FECs Recv      : 0
=====
A:ALA-12>monitor>router>ldp#

```

## interface

**Syntax** `interface interface [interface...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>router>mpls`

**Description** This command displays statistics for MPLS interfaces at the configured interval until the configured count is reached.

## Monitor CLI Commands

The first screen displays the current statistics related to the MPLS interface(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

### Parameters

**interface** — Specify the interface's IP address (*ip-address*) or interface name (*ip-int-name*). Up to 5 interfaces can be specified. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**interval seconds** — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat repeat** — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor>router>mpls# interface system interval 3 repeat 3 absolute
=====
Monitor statistics for MPLS Interface "system"
=====
At time t = 0 sec (Base Statistics)
-----
Transmitted  : Pkts - 0                Octets - 0
Received     : Pkts - 0                Octets - 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Transmitted  : Pkts - 0                Octets - 0
Received     : Pkts - 0                Octets - 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Transmitted  : Pkts - 0                Octets - 0
Received     : Pkts - 0                Octets - 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Transmitted  : Pkts - 0                Octets - 0
Received     : Pkts - 0                Octets - 0
=====
A:ALA-12>monitor>router>mpls#
```

```
A:ALA-12>monitor>router>mpls# interface system interval 3 repeat 3 rate
```

```

=====
Monitor statistics for MPLS Interface "system"
=====
-----
Transmitted  : Pkts - 0                Octets - 0
Received    : Pkts - 0                Octets - 0
-----
At time t = 3 sec (Mode: Rate)
-----
Transmitted  : Pkts - 0                Octets - 0
Received    : Pkts - 0                Octets - 0
-----
At time t = 6 sec (Mode: Rate)
-----
Transmitted  : Pkts - 0                Octets - 0
Received    : Pkts - 0                Octets - 0
-----
At time t = 9 sec (Mode: Rate)
-----
Transmitted  : Pkts - 0                Octets - 0
Received    : Pkts - 0                Octets - 0
=====
A:ALA-12>monitor>router>mpls#

```

## lsp-egress-statistics

**Syntax** `lsp-egress-stats lsp-name [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor>router>mpls

**Description** This command displays egress statistics for LSP interfaces at the configured interval until the configured count is reached.

**Default** no lsp-egress-statistics

**Parameters** `repeat repeat` — Specifies how many times the command is repeated.

**Values** 10

**Values** 1 — 999

`interval seconds` — Specifies the interval for each display, in seconds.

**Values** 10

**Values** 3 — 60

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample

```

B:Dut-C-cpm2# monitor router mpls lsp-egress-stats sample repeat 3 interval 10 absolute
=====
Monitor egress statistics for MPLS LSP "sample"

```

## Monitor CLI Commands

-----  
At time t = 0 sec (Base Statistics)  
-----

LSP Name : sample  
-----

Collect Stats	: Enabled	Accting Plcy.	: 5
Adm State	: Up	PSB Match	: True
FC BE			
InProf Pkts	: 0	OutProf Pkts	: 551
InProf Octets	: 0	OutProf Octets	: 560918
FC L2			
InProf Pkts	: 0	OutProf Pkts	: 551
InProf Octets	: 0	OutProf Octets	: 560918
FC AF			
InProf Pkts	: 551	OutProf Pkts	: 0
InProf Octets	: 560918	OutProf Octets	: 0
FC L1			
InProf Pkts	: 551	OutProf Pkts	: 0
InProf Octets	: 560918	OutProf Octets	: 0
FC H2			
InProf Pkts	: 0	OutProf Pkts	: 551
InProf Octets	: 0	OutProf Octets	: 560918
FC EF			
InProf Pkts	: 0	OutProf Pkts	: 551
InProf Octets	: 0	OutProf Octets	: 560918
FC H1			
InProf Pkts	: 0	OutProf Pkts	: 551
InProf Octets	: 0	OutProf Octets	: 560918
FC NC			
InProf Pkts	: 551	OutProf Pkts	: 0
InProf Octets	: 560918	OutProf Octets	: 0

-----

At time t = 10 sec (Mode: Absolute)  
-----

LSP Name : sample  
-----

Collect Stats	: Enabled	Accting Plcy.	: 5
Adm State	: Up	PSB Match	: True
FC BE			
InProf Pkts	: 0	OutProf Pkts	: 580
InProf Octets	: 0	OutProf Octets	: 590440
FC L2			
InProf Pkts	: 0	OutProf Pkts	: 580
InProf Octets	: 0	OutProf Octets	: 590440
FC AF			
InProf Pkts	: 580	OutProf Pkts	: 0
InProf Octets	: 590440	OutProf Octets	: 0
FC L1			
InProf Pkts	: 580	OutProf Pkts	: 0
InProf Octets	: 590440	OutProf Octets	: 0
FC H2			
InProf Pkts	: 0	OutProf Pkts	: 580
InProf Octets	: 0	OutProf Octets	: 590440
FC EF			
InProf Pkts	: 0	OutProf Pkts	: 580
InProf Octets	: 0	OutProf Octets	: 590440
FC H1			
InProf Pkts	: 0	OutProf Pkts	: 580
InProf Octets	: 0	OutProf Octets	: 590440
FC NC			
InProf Pkts	: 580	OutProf Pkts	: 0

```
InProf Octets : 590440                               OutProf Octets: 0
```

```
-----
At time t = 20 sec (Mode: Absolute)
-----
```

```
LSP Name      : sample
-----
```

```
Collect Stats : Enabled                               Accting Plcy. : 5
Adm State     : Up                                   PSB Match     : True
FC BE
InProf Pkts  : 0                                    OutProf Pkts  : 609
InProf Octets : 0                                    OutProf Octets: 619962
FC L2
InProf Pkts  : 0                                    OutProf Pkts  : 609
InProf Octets : 0                                    OutProf Octets: 619962
FC AF
InProf Pkts  : 609                                  OutProf Pkts  : 0
InProf Octets : 619962                              OutProf Octets: 0
FC L1
InProf Pkts  : 609                                  OutProf Pkts  : 0
InProf Octets : 619962                              OutProf Octets: 0
FC H2
InProf Pkts  : 0                                    OutProf Pkts  : 609
InProf Octets : 0                                    OutProf Octets: 619962
FC EF
InProf Pkts  : 0                                    OutProf Pkts  : 609
InProf Octets : 0                                    OutProf Octets: 619962
FC H1
InProf Pkts  : 0                                    OutProf Pkts  : 609
InProf Octets : 0                                    OutProf Octets: 619962
FC NC
InProf Pkts  : 609                                  OutProf Pkts  : 0
InProf Octets : 619962                              OutProf Octets: 0
-----
```

```
At time t = 30 sec (Mode: Absolute)
-----
```

```
LSP Name      : sample
-----
```

```
Collect Stats : Enabled                               Accting Plcy. : 5
Adm State     : Up                                   PSB Match     : True
FC BE
InProf Pkts  : 0                                    OutProf Pkts  : 638
InProf Octets : 0                                    OutProf Octets: 649484
FC L2
InProf Pkts  : 0                                    OutProf Pkts  : 638
InProf Octets : 0                                    OutProf Octets: 649484
FC AF
InProf Pkts  : 638                                  OutProf Pkts  : 0
InProf Octets : 649484                              OutProf Octets: 0
FC L1
InProf Pkts  : 638                                  OutProf Pkts  : 0
InProf Octets : 649484                              OutProf Octets: 0
FC H2
InProf Pkts  : 0                                    OutProf Pkts  : 638
InProf Octets : 0                                    OutProf Octets: 649484
FC EF
InProf Pkts  : 0                                    OutProf Pkts  : 638
InProf Octets : 0                                    OutProf Octets: 649484
FC H1
InProf Pkts  : 0                                    OutProf Pkts  : 638
InProf Octets : 0                                    OutProf Octets: 649484
FC NC
```

## Monitor CLI Commands

```
InProf Pkts   : 638                               OutProf Pkts   : 0
InProf Octets : 649484                           OutProf Octets : 0
=====
B:Dut-C-cpm2#
```

## lsp-ingress-statistics

**Syntax** **lsp-ingress-stats** **lsp** *lsp-name* **sender** *sender-address* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context** monitor>router>mpls

**Description** This command displays ingress statistics for LSP interfaces at the configured interval until the configured count is reached.

**Parameters** **repeat** *repeat* — Specifies how many times the command is repeated.

**Values** 10

**Values** 1 — 999

**interval** *seconds* — Specifies the interval for each display, in seconds.

**Values** 10

**Values** 3 — 60

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
B:Dut-C-cpm2# monitor router mpls lsp-ingress-stats lsp sample 1.1.1.1 repeat 3 interval 10
absolute
=====
Monitor ingress statistics for MPLS LSP "sample"
-----
At time t = 0 sec (Base Statistics)
-----
LSP Name       : sample
Sender        : 1.1.1.1
-----
Collect Stats : Enabled                Accting Plcy. : None
Adm State     : Up                     PSB Match    : True
FC BE
InProf Pkts   : 539                    OutProf Pkts : 0
InProf Octets : 548702                 OutProf Octets: 0
FC L2
InProf Pkts   : 0                      OutProf Pkts : 539
InProf Octets : 0                      OutProf Octets: 548702
FC AF
InProf Pkts   : 0                      OutProf Pkts : 0
InProf Octets : 0                      OutProf Octets: 0
FC L1
```

```

InProf Pkts   : 1078                OutProf Pkts   : 0
InProf Octets : 1097404            OutProf Octets : 0
FC H2
InProf Pkts   : 0                  OutProf Pkts   : 539
InProf Octets : 0                  OutProf Octets : 548702
FC EF
InProf Pkts   : 539                OutProf Pkts   : 0
InProf Octets : 548702            OutProf Octets : 0
FC H1
InProf Pkts   : 539                OutProf Pkts   : 0
InProf Octets : 548702            OutProf Octets : 0
FC NC
InProf Pkts   : 0                  OutProf Pkts   : 539
InProf Octets : 0                  OutProf Octets : 548702

```

-----  
At time t = 10 sec (Mode: Absolute)  
-----

```

LSP Name      : sample
Sender        : 1.1.1.1

```

```

-----
Collect Stats : Enabled                Accting Plcy. : None
Adm State     : Up                    PSB Match     : True
FC BE
InProf Pkts   : 568                  OutProf Pkts   : 0
InProf Octets : 578224              OutProf Octets : 0
FC L2
InProf Pkts   : 0                    OutProf Pkts   : 568
InProf Octets : 0                    OutProf Octets : 578224
FC AF
InProf Pkts   : 0                    OutProf Pkts   : 0
InProf Octets : 0                    OutProf Octets : 0
FC L1
InProf Pkts   : 1136                 OutProf Pkts   : 0
InProf Octets : 1156448              OutProf Octets : 0
FC H2
InProf Pkts   : 0                    OutProf Pkts   : 568
InProf Octets : 0                    OutProf Octets : 578224
FC EF
InProf Pkts   : 568                  OutProf Pkts   : 0
InProf Octets : 578224              OutProf Octets : 0
FC H1
InProf Pkts   : 568                  OutProf Pkts   : 0
InProf Octets : 578224              OutProf Octets : 0
FC NC
InProf Pkts   : 0                    OutProf Pkts   : 568
InProf Octets : 0                    OutProf Octets : 578224

```

-----  
At time t = 20 sec (Mode: Absolute)  
-----

```

LSP Name      : sample
Sender        : 1.1.1.1

```

```

-----
Collect Stats : Enabled                Accting Plcy. : None
Adm State     : Up                    PSB Match     : True
FC BE
InProf Pkts   : 597                  OutProf Pkts   : 0
InProf Octets : 607746              OutProf Octets : 0
FC L2
InProf Pkts   : 0                    OutProf Pkts   : 597
InProf Octets : 0                    OutProf Octets : 607746
FC AF

```

## Monitor CLI Commands

```
InProf Pkts : 0
InProf Octets : 0
FC L1
InProf Pkts : 1194
InProf Octets : 1215492
FC H2
InProf Pkts : 0
InProf Octets : 0
FC EF
InProf Pkts : 597
InProf Octets : 607746
FC H1
InProf Pkts : 597
InProf Octets : 607746
FC NC
InProf Pkts : 0
InProf Octets : 0
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 597
OutProf Octets : 607746
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 597
OutProf Octets : 607746
```

-----  
At time t = 30 sec (Mode: Absolute)  
-----

```
LSP Name : sample
Sender : 1.1.1.1
```

```
-----
Collect Stats : Enabled
Adm State : Up
FC BE
InProf Pkts : 627
InProf Octets : 638286
FC L2
InProf Pkts : 0
InProf Octets : 0
FC AF
InProf Pkts : 0
InProf Octets : 0
FC L1
InProf Pkts : 1254
InProf Octets : 1276572
FC H2
InProf Pkts : 0
InProf Octets : 0
FC EF
InProf Pkts : 627
InProf Octets : 638286
FC H1
InProf Pkts : 627
InProf Octets : 638286
FC NC
InProf Pkts : 0
InProf Octets : 0
Accting Plcy. : None
PSB Match : True
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 627
OutProf Octets : 638286
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 627
OutProf Octets : 638286
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 0
OutProf Octets : 0
OutProf Pkts : 627
OutProf Octets : 638286
```

=====  
B:Dut-C-cpm2#

ospf

**Syntax** `ospf [ospf-instance]`

**Context** `monitor>router>ospf`

**Description** This command enables the context to configure monitor commands for the OSPF instance.

**Parameters** *ospf-instance* — Specifies the OSPF instance.

**Values** 1 — 31

## ospf3

**Syntax** `ospf3`

**Context** `monitor>router`

**Description** This command enables the context to configure monitor commands for the OSPF3 instance.

## interface

**Syntax** `interface interface [interface...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

**Context**  
`monitor>router>ospf`  
`monitor>router>ospf3`  
`monitor>router>ospf3`

**Description** This command displays statistics for OSPF interfaces at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the OSPF interface(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the “rate per second” for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *interface* — Specify the interface's IP address (*ip-address*) or interface name (*ip-int-name*). Up to 5 interfaces can be specified. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

**Sample Output**

```
A:ALA-12>monitor>router>ospf# interface to-104 interval 3 repeat 3 absolute
=====
Monitor statistics for OSPF Interface "to-104"
=====
At time t = 0 sec (Base Statistics)
-----
Tot Rx Packets : 8379                Tot Tx Packets : 8528
Rx Hellos      : 8225                Tx Hellos      : 8368
Rx DBDs        : 6                  Tx DBDs        : 12
Rx LSRs        : 2                  Tx LSRs        : 1
Rx LSUs        : 55                 Tx LSUs        : 95
Rx LS Acks     : 91                 Tx LS Acks     : 52
Retransmits    : 2                  Discards       : 0
Bad Networks   : 0                  Bad Virt Links : 0
Bad Areas      : 0                  Bad Dest Adrs : 0
Bad Auth Types : 0                  Auth Failures  : 0
Bad Neighbors  : 0                  Bad Pkt Types  : 0
Bad Lengths    : 0                  Bad Hello Int. : 0
Bad Dead Int.  : 0                  Bad Options    : 0
Bad Versions   : 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Tot Rx Packets : 8379                Tot Tx Packets : 8528
Rx Hellos      : 8225                Tx Hellos      : 8368
Rx DBDs        : 6                  Tx DBDs        : 12
Rx LSRs        : 2                  Tx LSRs        : 1
Rx LSUs        : 55                 Tx LSUs        : 95
Rx LS Acks     : 91                 Tx LS Acks     : 52
Retransmits    : 2                  Discards       : 0
Bad Networks   : 0                  Bad Virt Links : 0
Bad Areas      : 0                  Bad Dest Adrs : 0
Bad Auth Types : 0                  Auth Failures  : 0
Bad Neighbors  : 0                  Bad Pkt Types  : 0
Bad Lengths    : 0                  Bad Hello Int. : 0
Bad Dead Int.  : 0                  Bad Options    : 0
Bad Versions   : 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Tot Rx Packets : 8380                Tot Tx Packets : 8529
Rx Hellos      : 8226                Tx Hellos      : 8369
Rx DBDs        : 6                  Tx DBDs        : 12
Rx LSRs        : 2                  Tx LSRs        : 1
Rx LSUs        : 55                 Tx LSUs        : 95
Rx LS Acks     : 91                 Tx LS Acks     : 52
Retransmits    : 2                  Discards       : 0
Bad Networks   : 0                  Bad Virt Links : 0
Bad Areas      : 0                  Bad Dest Adrs : 0
Bad Auth Types : 0                  Auth Failures  : 0
Bad Neighbors  : 0                  Bad Pkt Types  : 0
Bad Lengths    : 0                  Bad Hello Int. : 0
Bad Dead Int.  : 0                  Bad Options    : 0
Bad Versions   : 0
```

```
-----
At time t = 9 sec (Mode: Absolute)
-----
```

Tot Rx Packets	: 8380	Tot Tx Packets	: 8529
Rx Hellos	: 8226	Tx Hellos	: 8369
Rx DBDs	: 6	Tx DBDs	: 12
Rx LSRs	: 2	Tx LSRs	: 1
Rx LSUs	: 55	Tx LSUs	: 95
Rx LS Acks	: 91	Tx LS Acks	: 52
Retransmits	: 2	Discards	: 0
Bad Networks	: 0	Bad Virt Links	: 0
Bad Areas	: 0	Bad Dest Addrs	: 0
Bad Auth Types	: 0	Auth Failures	: 0
Bad Neighbors	: 0	Bad Pkt Types	: 0
Bad Lengths	: 0	Bad Hello Int.	: 0
Bad Dead Int.	: 0	Bad Options	: 0
Bad Versions	: 0		

```
=====
A:ALA-12>monitor>router>ospf#
```

```
A:ALA-12>monitor>router>ospf# interface to-104 interval 3 repeat 3 rate
```

```
=====
Monitor statistics for OSPF Interface "to-104"
=====
```

```
At time t = 0 sec (Base Statistics)
-----
```

Tot Rx Packets	: 8381	Tot Tx Packets	: 8530
Rx Hellos	: 8227	Tx Hellos	: 8370
Rx DBDs	: 6	Tx DBDs	: 12
Rx LSRs	: 2	Tx LSRs	: 1
Rx LSUs	: 55	Tx LSUs	: 95
Rx LS Acks	: 91	Tx LS Acks	: 52
Retransmits	: 2	Discards	: 0
Bad Networks	: 0	Bad Virt Links	: 0
Bad Areas	: 0	Bad Dest Addrs	: 0
Bad Auth Types	: 0	Auth Failures	: 0
Bad Neighbors	: 0	Bad Pkt Types	: 0
Bad Lengths	: 0	Bad Hello Int.	: 0
Bad Dead Int.	: 0	Bad Options	: 0
Bad Versions	: 0		

```
-----
At time t = 3 sec (Mode: Rate)
-----
```

Tot Rx Packets	: 0	Tot Tx Packets	: 0
Rx Hellos	: 0	Tx Hellos	: 0
Rx DBDs	: 0	Tx DBDs	: 0
Rx LSRs	: 0	Tx LSRs	: 0
Rx LSUs	: 0	Tx LSUs	: 0
Rx LS Acks	: 0	Tx LS Acks	: 0
Retransmits	: 0	Discards	: 0
Bad Networks	: 0	Bad Virt Links	: 0
Bad Areas	: 0	Bad Dest Addrs	: 0
Bad Auth Types	: 0	Auth Failures	: 0
Bad Neighbors	: 0	Bad Pkt Types	: 0
Bad Lengths	: 0	Bad Hello Int.	: 0
Bad Dead Int.	: 0	Bad Options	: 0
Bad Versions	: 0		

```
-----
At time t = 6 sec (Mode: Rate)
-----
```

## Monitor CLI Commands

```
Tot Rx Packets : 0
Rx Hellos      : 0
Rx DBDs        : 0
Rx LSRs        : 0
Rx LSUs        : 0
Rx LS Acks     : 0
Retransmits    : 0
Bad Networks   : 0
Bad Areas      : 0
Bad Auth Types : 0
Bad Neighbors  : 0
Bad Lengths    : 0
Bad Dead Int.  : 0
Bad Versions   : 0

Tot Tx Packets : 0
Tx Hellos      : 0
Tx DBDs        : 0
Tx LSRs        : 0
Tx LSUs        : 0
Tx LS Acks     : 0
Discards       : 0
Bad Virt Links : 0
Bad Dest Adrs : 0
Auth Failures  : 0
Bad Pkt Types  : 0
Bad Hello Int. : 0
Bad Options    : 0
```

-----  
At time t = 9 sec (Mode: Rate)

```
Tot Rx Packets : 0
Rx Hellos      : 0
Rx DBDs        : 0
Rx LSRs        : 0
Rx LSUs        : 0
Rx LS Acks     : 0
Retransmits    : 0
Bad Networks   : 0
Bad Areas      : 0
Bad Auth Types : 0
Bad Neighbors  : 0
Bad Lengths    : 0
Bad Dead Int.  : 0
Bad Versions   : 0

Tot Tx Packets : 0
Tx Hellos      : 0
Tx DBDs        : 0
Tx LSRs        : 0
Tx LSUs        : 0
Tx LS Acks     : 0
Discards       : 0
Bad Virt Links : 0
Bad Dest Adrs : 0
Auth Failures  : 0
Bad Pkt Types  : 0
Bad Hello Int. : 0
Bad Options    : 0
```

=====  
A:ALA-12>monitor>router>ospf#

## neighbor

**Syntax** **neighbor** *ip-address* [*ip-address...*(up to 5 max)] [*interval seconds*] [*repeat repeat*] [*absolute | rate*]

**Context** monitor>router>ospf

**Description** This command displays statistical OSPF or OSPF3 neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified OSPF neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** **neighbor** *ip-address* — The IP address to display information for entries received from the specified OSPF neighbor. Up to 5 IP addresses can be specified.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat repeat** — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor>router# ospf neighbor 10.0.0.104 interval 3 repeat 3 absolute
=====
Monitor statistics for OSPF Neighbor 10.0.0.104
=====
At time t = 0 sec (Base Statistics)
-----
Bad Nbr States      : 0                LSA Inst fails    : 0
Bad Seq Nums       : 0                Bad MTUs          : 0
Bad Packets        : 0                LSA not in LSDB  : 0
Option Mismatches : 0                Nbr Duplicates   : 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Bad Nbr States      : 0                LSA Inst fails    : 0
Bad Seq Nums       : 0                Bad MTUs          : 0
Bad Packets        : 0                LSA not in LSDB  : 0
Option Mismatches : 0                Nbr Duplicates   : 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Bad Nbr States      : 0                LSA Inst fails    : 0
Bad Seq Nums       : 0                Bad MTUs          : 0
Bad Packets        : 0                LSA not in LSDB  : 0
Option Mismatches : 0                Nbr Duplicates   : 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Bad Nbr States      : 0                LSA Inst fails    : 0
Bad Seq Nums       : 0                Bad MTUs          : 0
Bad Packets        : 0                LSA not in LSDB  : 0
Option Mismatches : 0                Nbr Duplicates   : 0
=====
A:ALA-12>monitor>router#

A:ALA-12>monitor>router# ospf neighbor 10.0.0.104 interval 3 repeat 3 absolute
=====
Monitor statistics for OSPF Neighbor 10.0.0.104
=====
-----
At time t = 0 sec (Base Statistics)
-----
```

## Monitor CLI Commands

```
Bad Nbr States      : 0          LSA Inst fails    : 0
Bad Seq Nums       : 0          Bad MTUs          : 0
Bad Packets        : 0          LSA not in LSDB  : 0
Option Mismatches: 0          Nbr Duplicates   : 0
-----
At time t = 3 sec (Mode: Rate)
-----
Bad Nbr States      : 0          LSA Inst fails    : 0
Bad Seq Nums       : 0          Bad MTUs          : 0
Bad Packets        : 0          LSA not in LSDB  : 0
Option Mismatches: 0          Nbr Duplicates   : 0
-----
At time t = 6 sec (Mode: Rate)
-----
Bad Nbr States      : 0          LSA Inst fails    : 0
Bad Seq Nums       : 0          Bad MTUs          : 0
Bad Packets        : 0          LSA not in LSDB  : 0
Option Mismatches: 0          Nbr Duplicates   : 0
-----
At time t = 9 sec (Mode: Rate)
-----
Bad Nbr States      : 0          LSA Inst fails    : 0
Bad Seq Nums       : 0          Bad MTUs          : 0
Bad Packets        : 0          LSA not in LSDB  : 0
Option Mismatches: 0          Nbr Duplicates   : 0
=====
A:ALA-12>monitor>router#
```

## neighbor

**Syntax** `neighbor [router-id] [interface-name] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>router>ospf3`

**Description** This command displays statistical OSPF or OSPF3 neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified OSPF neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** **neighbor** *ip-address* — The IP address to display information for entries received from the specified OSPF neighbor. Up to 5 IP addresses can be specified.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

*router-id* — The router ID for an existing IP interface.

## virtual-link

**Syntax** **virtual-link** *nbr-rtr-id* **area** *area-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context**  
monitor>router>ospf  
monitor>router>ospf3  
monitor>router>ospf3

**Description** This command displays statistical OSPF virtual link information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *nbr-rtr-id* — The IP address to uniquely identify a neighboring router in the autonomous system.  
**area** *area-id* — The OSPF area ID, expressed in dotted decimal notation or as a 32-bit decimal integer.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## virtual-neighbor

## Monitor CLI Commands

**Syntax** `virtual-neighbor nbr-rtr-id area area-id [interval seconds] [repeat repeat] [absolute | rate]`

**Context**  
monitor>router>ospf  
monitor>router>ospf3  
monitor>router>ospf3

**Description** This command displays statistical OSPF virtual neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified OSPF virtual neighbor router. The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *nbr-rtr-id* — The IP address to uniquely identify a neighboring router in the autonomous system.

*area area-id* — The OSPF area ID, expressed in dotted decimal notation or as a 32-bit decimal integer.

*interval seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

*repeat repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## group

**Syntax** `group grp-ip-address [source ip-address] [interval interval] [repeat repeat] [absolute | rate]`

**Context**  
monitor>router>pim

**Description** This command monitors statistics for a PIM source group.

**Parameters** *grp-ip-address* — The IP address of an multicast group that identifies a set of recipients that are interested in a particular data stream.

*source ip-address* — The source IP address to use in the ping requests in dotted decimal notation.

**Default** The IP address of the egress IP interface.

**Values** 0.0.0.0 — 255.255.255.255

*interval interval* — Configures the interval for each display in seconds.

**Default** 10 seconds

**Values** 10|20|30|40|50|60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## neighbor

**Syntax** **neighbor** *neighbor* [*neighbor...*(up to 5 max)] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context** monitor>router>rip

**Description** This command displays statistical RIP neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified RIP neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** **neighbor** *ip-address* — The IP address to display information for entries received from the specified RIP neighbor. Up to 5 IP addresses can be displayed.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 5 seconds

**Values** 3 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## interface

## Monitor CLI Commands

<b>Syntax</b>	<b>interface</b> <i>interface</i> [ <i>interface...</i> (up to 5 max)][ <b>interval</b> <i>seconds</i> ] [ <b>repeat</b> <i>repeat</i> ] [ <b>absolute</b>   <b>rate</b> ]								
<b>Context</b>	monitor>router>rsvp								
<b>Description</b>	<p>This command displays statistics for RSVP interfaces at the configured interval until the configured count is reached.</p> <p>The first screen displays the current statistics related to the RSVP interface(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword <b>rate</b> is specified, the "rate per second" for each statistic is displayed instead of the delta.</p> <p>Monitor commands are similar to <b>show</b> commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.</p>								
<b>Parameters</b>	<p><i>interface</i> — Specify the interface's IP address (<i>ip-address</i>) or interface name (<i>ip-int-name</i>). Up to 5 interfaces can be specified. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.</p> <p><b>interval</b> <i>seconds</i> — Configures the interval for each display in seconds.</p> <table><tr><td><b>Default</b></td><td>5 seconds</td></tr><tr><td><b>Values</b></td><td>3 — 60</td></tr></table> <p><b>repeat</b> <i>repeat</i> — Configures how many times the command is repeated.</p> <table><tr><td><b>Default</b></td><td>10</td></tr><tr><td><b>Values</b></td><td>1 — 999</td></tr></table> <p><b>absolute</b> — When the <b>absolute</b> keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.</p> <p><b>rate</b> — When the <b>rate</b> keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.</p>	<b>Default</b>	5 seconds	<b>Values</b>	3 — 60	<b>Default</b>	10	<b>Values</b>	1 — 999
<b>Default</b>	5 seconds								
<b>Values</b>	3 — 60								
<b>Default</b>	10								
<b>Values</b>	1 — 999								

## service

<b>Syntax</b>	<b>service</b>
<b>Context</b>	monitor
<b>Description</b>	This command enables the context to configure criteria to monitor specific service SAP criteria.

## id

<b>Syntax</b>	<b>id</b> <i>service-id</i>
<b>Context</b>	monitor>service
<b>Description</b>	This command displays statistics for a specific service, specified by the <i>service-id</i> , at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the *service-id*. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *service-id* — The unique service identification number which identifies the service in the service domain.

## sap

**Syntax** **sap** *sap-id* [**interval seconds**] [**repeat repeat**] [**absolute | rate**]

**Context** monitor>service>id *service-id*

**Description** This command monitors statistics for a SAP associated with this service.

This command displays statistics for a specific SAP, identified by the *port-id* and encapsulation value, at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the SAP. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** *sap-id* — Specifies the physical port identifier portion of the SAP definition.

```

sap-id:          null    [port-id | lag-id]
                  dot1q   [port-id | lag-id]:qtag1
                  qinq    [port-id | lag-id]:qtag1.qtag2

                  port-id slot/mda/port
                  lag-id   lag-id
                  lag      keyword
                  id        1 — 800

```

*port-id* — Specifies the physical port ID in the *slot/mda/port* format.

If the card in the slot has XMA/MDAs installed, the *port-id* must be in the *slot\_number/MDA\_number/port\_number* format. For example 6/2/3 specifies port 3 on XMA/MDA 2 in slot 6.

The *port-id* must reference a valid port type.

*qtag1*, *qtag2* — Specifies the encapsulation value used to identify the SAP on the port or sub-port. If this parameter is not specifically defined, the default value is 0.

**Values** *qtag1*: 0 — 4094  
*qtag2*: \* | 0 — 4094

## Monitor CLI Commands

The values depends on the encapsulation type configured for the interface. The following table describes the allowed values for the port and encapsulation types.

Port Type	Encap-Type	Allowed Values	Comments
Ethernet	Null	0	The SAP is identified by the port.
Ethernet	Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the port. Note that a 0 qtag1 value also accepts untagged packets on the dot1q port.
Ethernet	QinQ	qtag1: 0 — 4094 qtag2: 0 — 4094	The SAP is identified by two 802.1Q tags on the port. Note that a 0 qtag1 value also accepts untagged packets on the dot1q port.

**interval** *seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the absolute rate-per-second value for each statistic is displayed.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
*A:cses-A13# monitor service id 88 sap 1/1/2:0
=====
Monitor statistics for Service 88 SAP 1/1/2:0
=====
-----
At time t = 0 sec (Base Statistics)
-----
-----
Sap Statistics
-----
Last Cleared Time      : N/A
                        Packets                Octets
Forwarding Engine Stats
Dropped                : 0                      0
Off. HiPrio            : 0                      0
Off. LowPrio           : 0                      0
Off. Uncolor           : 0                      0

Queueing Stats(Ingress QoS Policy 1)
Dro. HiPrio            : 0                      0
Dro. LowPrio           : 0                      0
For. InProf            : 0                      0
For. OutProf           : 0                      0
```

```

Queueing Stats(Egress QoS Policy 1)
Dro. InProf          : 0                0
Dro. OutProf         : 0                0
For. InProf          : 0                0
For. OutProf         : 0                0
-----
Sap per Queue Stats
-----
                Packets                Octets

Ingress Queue 1 (Unicast) (Priority)
Off. HiPrio         : 0                0
Off. LoPrio         : 0                0
Dro. HiPrio         : 0                0
Dro. LoPrio         : 0                0
For. InProf         : 0                0
For. OutProf        : 0                0

```

## sdp

**Syntax** `sdp {sdp-id | far-end ip-address} [interval seconds] [repeat repeat] [absolute | rate]`

**Context** `monitor>service>id service-id`

**Description** This command monitors statistics for a SDP binding associated with this service.

**Parameters** *sdp-id* — Specify the SDP identifier.

**Values** 1 — 17407

*far-end ip-address* — The system address of the far-end SR OS router for the SDP in dotted decimal notation.

*interval seconds* — Configures the interval for each display in seconds.

**Default** 11 seconds

**Values** 11 — 60

*repeat repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the absolute rate-per-second value for each statistic is displayed.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```

A:ALA-12# monitor service id 100 sdp 10 repeat 3
=====
Monitor statistics for Service 100 SDP binding 10

```

## Monitor CLI Commands

```
=====
At time t = 0 sec (Base Statistics)
-----
I. Fwd. Pkts.   : 0                I. Dro. Pkts.   : 0
E. Fwd. Pkts.   : 0                E. Fwd. Octets  : 0
-----
At time t = 11 sec (Mode: Delta)
-----
I. Fwd. Pkts.   : 0                I. Dro. Pkts.   : 0
E. Fwd. Pkts.   : 0                E. Fwd. Octets  : 0
-----
At time t = 22 sec (Mode: Delta)
-----
I. Fwd. Pkts.   : 0                I. Dro. Pkts.   : 0
E. Fwd. Pkts.   : 0                E. Fwd. Octets  : 0
-----
At time t = 33 sec (Mode: Delta)
-----
I. Fwd. Pkts.   : 0                I. Dro. Pkts.   : 0
E. Fwd. Pkts.   : 0                E. Fwd. Octets  : 0
=====
A:ALA-12#
```

## vrrp

**Syntax** vrrp

**Context** monitor>router

**Description** This command enables the context to configure criteria to monitor VRRP statistical information for a VRRP enabled on a specific interface.

## instance

**Syntax** instance interface *interface-name* vr-id *virtual-router-id* [*interval seconds*] [*repeat repeat*] [*absolute | rate*]

**Context** monitor>router>vrrp

**Description** Monitor statistics for a VRRP instance.

**Parameters**

- interface-name* — The name of the existing IP interface on which VRRP is configured.
- vr-id *virtual-router-id* — The virtual router ID for the existing IP interface, expressed as a decimal integer.
- interval seconds* — Configures the interval for each display in seconds.
  - Default** 5 seconds
  - Values** 3 — 60
- repeat repeat* — Configures how many times the command is repeated.
  - Default** 10
  - Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

## subscriber

**Syntax** **subscriber** *sub-ident-string* **sap** *sap-id* **sla-profile** *sla-profile-name* [**base** | **ingress-queue-id** *ingress-queue-id* | **egress-queue-id** *egress-queue-id*] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

**Context** monitor>service

**Description** This command monitors statistics for a subscriber.

**Parameters** **sub-ident-string** — Specifies an existing subscriber identification profile to monitor.

**sap** *sap-id* — Specifies the physical port identifier portion of the SAP definition.

**Values** dlcI 16 — 1022

**sla-profile** *sla-profile-name* — Specifies an existing SLA profile.

**interval** *seconds* — Configures the interval for each display in seconds

**Default** 11

**Values** 11 — 60

**repeat** *repeat* — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**Default** mode delta

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

**base** — Monitor base statistics.

**ingress-queue-id** *ingress-queue-id* — Monitors statistics for this queue.

**Values** 1 — 32

**egress-queue-id** *egress-queue-id* — Monitors statistics for this queue.

**Values** 1 — 8

### Sample Output

```
A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default
=====
Monitor statistics for Subscriber alcatel_100
```

## Monitor CLI Commands

```
=====
At time t = 0 sec (Base Statistics)
-----
SLA Profile Instance statistics
-----
                Packets                Octets
Off. HiPrio      : 0                    0
Off. LowPrio     : 94531                30704535
Off. Uncolor     : 0                    0

Queueing Stats (Ingress QoS Policy 1000)
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 7332                2510859
For. InProf      : 0                    0
For. OutProf     : 87067                28152288

Queueing Stats (Egress QoS Policy 1000)
Dro. InProf      : 880                  127660
Dro. OutProf     : 0                    0
For. InProf      : 90862                12995616
For. OutProf     : 0                    0
-----
SLA Profile Instance per Queue statistics
-----
                Packets                Octets
Ingress Queue 1 (Unicast) (Priority)
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0

Ingress Queue 2 (Unicast) (Priority)
Off. HiPrio      : 0                    0
Off. LowPrio     : 94531                30704535
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 7332                2510859
For. InProf      : 0                    0
For. OutProf     : 87067                28152288

Ingress Queue 3 (Unicast) (Priority)
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0

Ingress Queue 11 (Multipoint) (Priority)
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0
```

```
Egress Queue 1
Dro. InProf      : 880          127660
Dro. OutProf     : 0           0
For. InProf      : 90862       12995616
For. OutProf     : 0           0
```

```
Egress Queue 2
Dro. InProf      : 0           0
Dro. OutProf     : 0           0
For. InProf      : 0           0
For. OutProf     : 0           0
```

```
Egress Queue 3
Dro. InProf      : 0           0
Dro. OutProf     : 0           0
For. InProf      : 0           0
For. OutProf     : 0           0
```

=====  
A:Dut-A#

```
A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default base
rate
```

=====  
Monitor statistics for Subscriber alcatel\_100

=====  
At time t = 0 sec (Base Statistics)

-----  
SLA Profile Instance statistics

```
-----
Packets      Octets
Off. HiPrio  : 0          0
Off. LowPrio : 109099       35427060
Off. Uncolor : 0          0
Queueing Stats (Ingress QoS Policy 1000)
Dro. HiPrio  : 0          0
Dro. LowPrio : 8449       2894798
For. InProf  : 0          0
For. OutProf : 100523       32489663
Queueing Stats (Egress QoS Policy 1000)
Dro. InProf  : 880       127660
Dro. OutProf : 0          0
For. InProf  : 105578    15104553
For. OutProf : 0          0
-----
```

At time t = 11 sec (Mode: Rate)

-----  
SLA Profile Instance statistics

```
-----
Packets      Octets      % Port
              Util.
Off. HiPrio  : 0          0          0.00
Off. LowPrio : 1469       477795     0.38
Off. Uncolor : 0          0          0.00
Queueing Stats (Ingress QoS Policy 1000)
Dro. HiPrio  : 0          0          0.00
Dro. LowPrio : 119       40691     0.03
For. InProf  : 0          0          0.00
For. OutProf : 1349       437350    0.34
Queueing Stats (Egress QoS Policy 1000)
Dro. InProf  : 0          0          0.00
-----
```

## Monitor CLI Commands

```
Dro. OutProf      : 0                0                0.00
For. InProf      : 1469             209129           0.16
For. OutProf     : 0                0                0.00
=====
```

A:Dut-A#

```
A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default
ingress-queue-id 1
```

```
=====
Monitor statistics for Subscriber alcatel_100
=====
```

```
At time t = 0 sec (Base Statistics)
```

```
-----
                          Packets                Octets
Ingress Queue 1 (Unicast) (Priority)
Off. HiPrio      : 0                0
Off. LowPrio    : 0                0
Off. Uncolor    : 0                0
Dro. HiPrio     : 0                0
Dro. LowPrio    : 0                0
For. InProf     : 0                0
For. OutProf    : 0                0
=====
```

A:Dut-A#

```
A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default
egress-queue-id 1
```

```
=====
Monitor statistics for Subscriber alcatel_100
=====
```

```
At time t = 0 sec (Base Statistics)
```

```
-----
                          Packets                Octets
Egress Queue 1
Dro. InProf     : 880              127660
Dro. OutProf    : 0                0
For. InProf     : 164366           23506178
For. OutProf    : 0                0
=====
```

A:Dut-A#

---

## Candidate Commands

### candidate

**Syntax** `candidate`

**Context** `<root>`

**Description** This command enables the context to edit candidate configurations.  
Commands in the **candidate** CLI branch, except **candidate edit**, are available only when in edit-cfg mode.

### edit

**Syntax** `edit [exclusive]`

**Context** `candidate`

**Description** This command enables the edit-cfg mode where changes can be made to the candidate configuration and sets the edit-point to the end of the candidate. In edit-cfg mode the CLI prompt contains **edit-cfg** near the root of the prompt. Commands in the **candidate** CLI branch, except **candidate edit**, are available only when in edit-cfg mode.

**Parameters** **exclusive** — Allows a user to exclusively create a candidate configuration by blocking other users (and other sessions of the same user) from entering edit-cfg mode. Exclusive edit-cfg mode can only be entered if the candidate configuration is empty and no user is in edit-cfg mode. Once a user is in exclusive edit-cfg mode no other users/sessions are allowed in edit-cfg mode. The user must either commit or discard the exclusive candidate before leaving exclusive edit-cfg mode. If the CLI session times out while a user is in exclusive edit-cfg mode then the contents of the candidate are discarded. The **admin disconnect** command can be used to force a user to disconnect (and to clear the contents of the candidate) if they have the candidate locked.

### commit

**Syntax** `commit [confirmed timeout] [comment comment]`  
`commit no-checkpoint [confirmed timeout]`

**Context** `candidate`

**Description** This command applies the changes in the candidate configuration to the active running configuration. The candidate changes will take operational effect.  
If a commit operation is successful then all of the candidate changes will take operational effect and the candidate is cleared. If there is an error in the processing of the commit, or a 'commit confirmed' is not confirmed and an auto-revert occurs, then the router will return to a configuration state with none of the candidate changes applied. The operator can then continue editing the candidate and try a commit later.

## Candidate Commands

By default SR OS will automatically create a new rollback checkpoint after a commit operation. The rollback checkpoint will contain the new configuration changes made by the commit. An optional **no-checkpoint** keyword can be used to avoid the auto-creation of a rollback checkpoint after a commit.

A commit operation is blocked if a rollback revert is currently being processed.

**Parameters** **confirmed** — Specifies that the commit operation (if successful) should be automatically reverted (undone) at the end of the timeout period unless the operator issues the confirm command before the timeout period expires. A rollback checkpoint is created after the commit operation (if successful) and will remain available whether the commit is auto-reverted or not. The contents of the candidate will remain visible (candidate view) and changes to the candidate are blocked until the timeout is completed or the candidate confirm command is executed. If the timeout expires and an auto-revert occurs, then the original candidate config will be available in edit-cfg mode.

Standard line-by-line non-transactional configuration commands (including via SNMP) are not blocked during the countdown period and any changes made to the configuration during the countdown period will be rolled back if the timeout expires. The confirmed option is useful when changes are being made that could impact management reachability to the router.

A rollback revert is blocked during the countdown period until the commit has been confirmed.

*timeout* — The auto-revert timeout period in minutes.

**Values** 1 — 168

**no-checkpoint** — Used to avoid the automatic creation of a rollback checkpoint for a successful commit.

**comment** *comment* — Adds a comment up to 255 characters in length to the automatic rollback checkpoint.

## confirm

**Syntax** **confirm**

**Context** candidate

**Description** This command is used to stop an automatic reversion to the previous configuration after the **candidate commit confirmed** command was used. If the confirm command is not executed before the commit confirmed timeout period expires then the previous commit changes will be undone and the previous candidate configuration will be available for editing and a subsequent commit.

During the countdown the contents of the candidate will remain visible (candidate view) and changes to the candidate are blocked until the timeout is completed or the candidate confirm command is executed. Executing the confirm command clears the contents of the candidate and allows editing of the candidate.

## copy

**Syntax** **copy** [*line*]

**Context** candidate

**Description** This command copies the selected CLI node (which includes all sub-branches) into a temporary buffer that can be used for a subsequent insert. The contents of the temporary buffer are deleted when the operator exits the candidate edit mode.

<b>Parameters</b>	<b>line</b> —
	<b>Values</b> line, offset, first, edit-point last
	line Absolute line number.
	offset Relative line number to current edit point. Prefixed with '+' or '-'
	first Keyword - first line
	edit-point Keyword - current edit point
	last Keyword - last line that is not 'exit'

## delete

<b>Syntax</b>	<b>delete [line]</b>
<b>Context</b>	candidate
<b>Description</b>	This command deletes the selected CLI node (which includes all sub-branches). The deleted lines are also copied into a temporary buffer that can be used for a subsequent insert.

<b>Parameters</b>	<b>line</b> —
	<b>Values</b> line, offset, first, edit-point last
	line Absolute line number.
	offset Relative line number to current edit point. Prefixed with '+' or '-'.
	first Keyword - first line
	edit-point Keyword - current edit point
	last Keyword - last line that is not 'exit'

## discard

<b>Syntax</b>	<b>discard [now]</b>
<b>Context</b>	candidate
<b>Description</b>	This command deletes the entire contents of the candidate configuration and exits the edit-cfg mode. Undo cannot be used to recover a candidate that has been discarded with <b>candidate discard</b> .
<b>Parameters</b>	<b>now</b> — Avoids a confirmation prompt for the discard.

## goto

<b>Syntax</b>	<b>goto line</b>
<b>Context</b>	candidate
<b>Description</b>	This command changes the edit point of the candidate configuration. The edit point is the point after which new commands are inserted into the candidate configuration as an operator navigates the CLI and issues commands in edit-cfg mode.

## Candidate Commands

**Parameters** line —

**Values** line, offset, first, edit-point last  
line Absolute line number.  
offset Relative line number to current edit point. Prefixed with '+' or '-'.  
first Keyword - first line  
edit-point Keyword - current edit point  
last Keyword - last line that is not 'exit'

## insert

**Syntax** insert [line]

**Context** candidate

**Description** This command inserts the contents of the temporary buffer (populated by a previous copy or delete command) into the candidate configuration. The contents are inserted by default after the current edit point. Optional parameters allow the insertion after some other point of the candidate. The contents of the temporary buffer are deleted when the operator exits candidate edit mode.

Insertions are context-aware. The temporary buffer always stores the CLI context (such as the current CLI branch) for each line deleted or copied. If the lines to be inserted are supported at the context of the insertion point then the lines are simply inserted into the configuration. If the lines to be inserted are not supported at the context of the insertion point, then the context at the insertion point is first closed using multiple exit statements, the context of the lines to be inserted is built (added) into the candidate at the insertion point, then the lines themselves are added, the context of the inserted lines is closed using exit statements and finally the context from the original insertion point is built again leaving the context at the same point as it was before the insertion.

**Parameters** line —

**Values** line, offset, first, edit-point last  
line Absolute line number.  
offset Relative line number to current edit point. Prefixed with '+' or '-'.  
first Keyword - first line  
edit-point Keyword - current edit point  
last Keyword - last line that is not 'exit'

## load

**Syntax** load file-url [overwrite | insert | append]

**Context** candidate

**Description** This command loads a previously saved candidate configuration into the current candidate. The edit point will be set to the end of the loaded configuration lines. The candidate configuration cannot be modified while a load is in progress.

**Default** If the candidate is empty then a load without any of the optional parameters (such as overwrite, etc) will simply load the file-url into the candidate. If the candidate is not empty then one of the options, such as overwrite, insert, etc., must be specified.

**Parameters**

- file-url** — The directory and filename to load.
- overwrite** — Discards the contents of the current candidate and replace it with the contents of the file.
- insert** — Inserts the contents of the file at the current edit point.
- append** — Inserts the contents of the file at the end of the current candidate.

## quit

**Syntax** **quit**

**Context** candidate

**Description** This command exits the edit-cfg mode. The contents of the current candidate will not be deleted and the operator can continue editing the candidate later.

## redo

**Syntax** **redo** [*count*]

**Context** candidate

**Description** This command reapplies the changes to the candidate that were removed using a previous undo. All undo/redo history is lost when the operator exists edit-cfg mode.

A **redo** command is blocked if another user has made changes in the same CLI branches that would be impacted during the redo.

**Parameters**

- count** — The number of previous changes to reapply.

**Values** 1 — 50

**Default** 1

## replace

**Syntax** **replace** [*line*]

**Context** candidate

**Description** This command displays the specified line (a single line only) and allows it to be changed.

**Parameters** **line** —

**Values** line, offset, first, edit-point last

- line Absolute line number.
- offset Relative line number to current edit point. Prefixed with '+' or '-'.
- first Keyword - first line
- edit-point Keyword - current edit point
- last Keyword - last line that is not 'exit'

## Candidate Commands

### save

**Syntax** `save file-url`

**Context** candidate

**Description** This command saves the current candidate to a file.

**Parameters** *file-url* — The directory and filename,

### undo

**Syntax** `undo [count]`

**Context** candidate

**Description** This command removes the most recent change(s) done to the candidate. The changes can be reapplied using the redo command. All undo/redo history is lost when the operator exists edit-cfg mode. Undo can not be used to recover a candidate that has been discarded with **candidate discard**.

An undo command is blocked if another user has made changes in the same CLI branches that would be impacted during the undo.

**Parameters** **count** — The number of previous changes to remove.

**Values** 1 — 50

**Default** 1

### view

**Syntax** `view [line]`

**Context** candidate

**Description** This command displays the candidate configuration along with line numbers that can be used for editing the candidate configuration.

**Parameters** **line** — displays the candidate starting at the point indicated by the following options (the display is not limited to the current CLI context/branch)

**Values** line, offset, first, edit-point last

- line Absolute line number.
- offset Relative line number to current edit point. Prefixed with '+' or '-'.
- first Keyword - first line
- edit-point Keyword - current edit point
- last Keyword - last line that is not 'exit'

## info operational

**Syntax** `info {operational}`

**Context** `<root>`

**Description** In edit-cfg mode, the operational keyword is mandatory when using the **info** command.

## candidate

**Syntax** `candidate`

**Context** `show>system`

**Description** This command shows candidate configuration information.

**Output** **Candidate Output** — The following table describes the candidate output fields.

Label	Description
Candidate configuration state	<ul style="list-style-type: none"> <li>• empty — Indicates there are no uncommitted changes in the candidate config.</li> <li>• modified — Indicates there are uncommitted changes in the candidate config.</li> <li>• unconfirmed — Indicates there are no uncommitted changes in the candidate config but the result of the last commit will be auto-reverted unless it is confirmed before the timeout expires.</li> </ul>
Num editors/viewers	The number of CLI sessions currently in edit-cfg mode.
Candidate cfg exclusive locked	Indicates if a user has exclusively locked the candidate using the <b>candidate edit exclusive</b> command.
Last commit state	<ul style="list-style-type: none"> <li>• none , — Indicates there have been no commits since the last reboot of the node.</li> <li>• in-progress — Indicates the system is currently committing the candidate config.</li> <li>• success — Indicates the last commit finished successfully.</li> <li>• revert-pending — Indicates the last commit finished successfully but has not been confirmed yet, and will be auto-reverted if it is not confirmed before the timeout expires.</li> <li>• failed — Indicates the last commit failed and has been undone.</li> <li>•revert-in-progress — Indicates the last commit finished successfully but was not confirmed in time and is currently being reverted.</li> <li>• reverted — Indicates the last commit finished successfully but was not confirmed in time and has been reverted.</li> <li>• revert-failed — Indicates the last commit finished successfully but was not confirmed in time and the system attempted to revert it but failed.</li> </ul>
Last commit time	The time at which the last commit attempt was started.

Label	Description (Continued)
Checkpoint created with last commit	indicates if a rollback checkpoint was created after the previous commit completed.
Scheduled revert time	Used to indicate the currently scheduled auto-revert time based on the confirmed option being used with a candidate commit.
Last commit revert time	The time the commit was last reverted.
Users in edit-cfg mode	Lists all the user sessions that are currently in edit-cfg mode.
Type (from)	Indicates the type of session (such as Console, Telnet, etc.) and also the source of the session (such as the the source IP address of the remote host).

**Sample Output**

```
*A:bksim3107# show system candidate
=====
Candidate Config Information
=====
Candidate configuration state           : modified
Num editors/viewers                   : 0
Candidate cfg exclusive locked        : no
Last commit state                     : revert-failed
Last commit time                      : 10/23/2012 17:21:47
Checkpoint created with last commit   : yes
Scheduled revert time                 : N/A
Last commit revert time               : 10/23/2012 17:22:47

=====
Users in edit-cfg mode
=====
Username      Type (from)
=====
admin        Console
Joris       Telnet (172.31.117.239)
=====
```

## Rollback Commands

### compare

**Syntax**    **compare** [**to** *source2*]  
**compare** *source1 to source2*

**Context**    admin  
 admin>rollback  
 config>*xx* (where *xx* is any sub-branch at any level below config, but not at the config context itself)

**Description**    This command displays the differences between rollback checkpoints and the active operational configuration, with *source1* as the base/first file to which *source2* is compared.

A compare operation does not check authorization of each line of output. Permission to execute the compare operation from the “admin” branch of CLI (authorization for the **admin rollback compare** or **admin compare** command itself) should only be given to users who are allowed to view the entire configuration, similar to permissions for **admin display-config**.

**Parameters**    *source1, source2* — Specifies comparison information.

**Values**        **active-cfg** — The currently operational configuration that is active in the node.

**latest-rb** — The most recent rollback checkpoint (the checkpoint file at the configured rollback-location with “\*.rb” as the suffix).

**rescue** — The rescue configuration (at the configured rescue-location).

**checkpoint-id** — An id from [1 ..max] indicating a specific rollback checkpoint (where max is the highest checkpoint allowed/configured). A checkpoint-id of 1 indicates the rollback checkpoint file (at the configured rollback-location) with “\*.rb.1” as the suffix, 2 for file “\*.rb.2”, etc.

**Default**        The defaults for *source1* and *source2* are context aware and differ based on the branch in which the command is executed. In general, the default for *source1* matches the context from which the command is issued.

- In the admin node: No defaults. *source1* and *source2* must be specified.
- In the admin>rollback node:
  - source1 default = active-cfg, source2 default = latest-rb
  - compare: Equivalent to “compare active-cfg to latest-rb”
  - compare to source2: Equivalent to “compare active-cfg to source2”
- In a config>*xx* node:
  - compare to source2: Equivalent to “compare active-cfg to source2”

### delete

## Rollback Commands

**Syntax** `delete {latest-rb| checkpoint-id | rescue}`

**Context** admin>rollback

**Description** This command deletes a rollback checkpoint and causes the suffixes to be adjusted (decremented) for all checkpoints older than the one that was deleted (to close the “hole” in the list of checkpoint files and create room to create another checkpoint).

If “**config redundancy rollback-sync**” is enabled, a rollback delete will also delete the equivalent checkpoint on the standby CF and shuffle the suffixes on the standby CF.

It is not advised to manually delete a rollback checkpoint (for example, using a "file delete" command). If a rollback checkpoint file is manually deleted without using the "admin rollback delete" command then the suffixes of the checkpoint files are NOT shuffled, nor is the equivalent checkpoint file deleted from the standby CF. This manual deletion creates a “hole” in the checkpoint file list until enough new checkpoints have been created to roll the “hole” off the end of the list.

**Default** none

**Parameters** **latest-rb** — Specifies the most recently created rollback checkpoint (corresponds to the file-url.rb rollback checkpoint file).

*checkpoint-id* — An id from [1 ..max] indicating a specific rollback checkpoint (where max is the highest checkpoint allowed/configured). A checkpoint-id of 1 indicates the rollback checkpoint file (at the configured rollback-location) with “\*.rb.1” as the suffix, 2 for file “\*.rb.2”, etc.

**rescue** — Deletes the rescue checkpoint. No checkpoint suffix numbers are changed.

## revert

**Syntax** `revert [latest-rb| checkpoint-id | rescue] [now]`

**Context** admin>rollback

**Description** This command initiates a configuration rollback revert operation that will return the configuration state of the node to a previously saved checkpoint. The rollback revert minimizes impacts to running services. There are no impacts in areas of configuration that did not change since the checkpoint. Configuration parameters that changed (or items on which changed configuration have dependencies) are first removed (revert to default) and the previous values are then restored (can be briefly service impacting in changed areas).

**Parameters** **latest-rb** — Specifies the most recently created rollback checkpoint (corresponds to the file-url.rb rollback checkpoint file).

*checkpoint-id* — >Indicates the configuration to return to (which rollback checkpoint file to use).

Checkpoint-id of “1” corresponds to the file-url.rb.1 rollback checkpoint file. The higher the id, the older the checkpoint. Max is the highest rollback checkpoint supported or configured.

**Values** 1—max, where max is the number of configured checkpoints minus 1 (since, for example, the 10th checkpoint has an id of 9)

**rescue** — Revert to the rescue checkpoint.

**now** — Forces a rollback revert without any interactive confirmations (assumes ‘y’ for any confirmations that would have occurred).

## save (rollback)

**Syntax** **save** [**rescue**] [**comment** *comment-string*]

**Context** admin>rollback

**Description** If the optional “rescue” keyword is not used, this command saves a rollback checkpoint at the location and with the filename specified by the rollback-location with a suffix of “.rb”. The previously saved checkpoints will have their suffixes incremented by one (.rb.1 becomes .rb.2, etc). If there are already as many checkpoint files as the maximum number supported, then the last checkpoint file is deleted.

If the “rescue” keyword is used, then this command saves the current operational configuration as a rescue configuration at the location and with the filename specified by the rescue-location. The filename will have the suffix “.rc” appended.

**Default** none

**Parameters** *comment-string* — A comment of up to 255 characters in length that is associated with the checkpoint.

**rescue** — Save the rescue checkpoint instead of a normal rollback checkpoint.

## view

**Syntax** **view** [**latest-rb** | *checkpoint-id* | **rescue**]

**Context** admin>rollback

**Description** This command displays checkpoint..

**Default** none

**Parameters** **latest-rb** — Specifies the most recently created rollback checkpoint (corresponds to the file-url.rb rollback checkpoint file).

*checkpoint-id* — >Indicates rollback checkpoint file to be viewed. Checkpoint-id of “1” corresponds to the file-url.rb.1 rollback checkpoint file. The higher the id, the older the checkpoint. Max is the highest rollback checkpoint supported or configured.

**Values** 1..max

**rescue** — View the rescue configuration.

## view

**Syntax** **view** {**bootup-cfg**|**active-cfg**|**candidate-cfg**|**latest-rb**| *checkpoint-id*|**rescue**}

**Context** <ROOT>

**Description** The context to configure administrative system viewing parameters. Only authorized users can execute the commands in the **admin** context.

**Default** none

**Parameters** **bootup-cfg** — Specifies the bootup configuration.

## Rollback Commands

**active-cfg** — Specifies current running configuration.

**candidate-cfg** — Specifies candidate configuration.

**latest-rb** — Specifies the latest configuration.

*checkpoint-id* — Specifies a specific checkpoint file configuration.

**Values** 1 — 9

**rescue** — Specifies a rescue checkpoint configuration.

## rollback-location

**Syntax** **rollback-location** *file-url/rollback filename*

**Context** config>system>rollback

**Description** The location and name of the rollback checkpoint files is configurable to be local (on compact flash) or remote. The file-url must not contain a suffix (just a path/directory + filename). The suffixes for rollback checkpoint files are “.rb”, “.rb.1”, ..., “.rb.9” and are automatically appended to rollback checkpoint files.

**Default** None. A valid rollback-location must be configured before a rollback save is executed.

**Values** <file-url>

<local-url>|<remote-url>

local-url [*<cflash-id>/*][*<file-path>*] 200 chars max, including cflash-id  
directory length 99 chars max each

remote-url [ {ftp://} <login>: <pswd>@ <remote-locn> } ][*<file-path>*]  
255 chars max directory length 99 chars max each

remote-locn [ <hostname> | <ipv4-address> | <ipv6-address> ]

ipv4-address a.b.c.d

ipv6-address x:x:x:x:x:x[-interface]

x:x:x:x:x:d.d.d.d[-interface]

x - [0..FFFF]H

d - [0..255]D

interface - 32 chars max, for link local addresses

cflash-id cf1:|cf1-A:|cf1-B:|cf2:|cf2-A:|cf2-B:| cf3:|cf3-A:|cf3-B:

<rollback filename> suffixed with .rb, .rb.1 up to .9 during rollback checkpoint creation

## rescue-location

**Syntax** **no rescue-location** *file-url*

**Context** config>system>rollback

**Description** The location and filename of the rescue configuration is configurable to be local (on compact flash) or remote. The suffix “.rc” will be automatically appended to the filename when a rescue configuration file is saved. Trivial FTP (tftp) is not supported for remote locations.

**Default** None. A valid rescue-location must be configured before a rescue configuration is saved.

**Parameters** *file-url* — Specifies the URL.

<b>Values</b>	<file-url>
	<local-url> <remote-url>
local-url	[<cflash-id>/][<file-path>] 200 chars max, including cflash-id directory length 99 chars max each
remote-url	[ {ftp://} <login>:<pswd>@ <remote-locn>/ ][<file-path>] 255 chars max directory length 99 chars max each
remote-locn	[ <hostname>   <ipv4-address>   <ipv6-address> ]
ipv4-address	a.b.c.d
ipv6-address	x:x:x:x:x:x:x[-interface] x:x:x:x:x:d.d.d.d[-interface] x - [0..FFFF]H d - [0..255]D interface - 32 chars max, for link local addresses
cflash-id	cf1: cf1-A: cf1-B: cf2: cf2-A: cf2-B:  cf3: cf3-A: cf3-B:
<rescue filename>	suffixed with .rc during rescue file creation

## local-max-checkpoints

**Syntax** `local-max-checkpoints <1..50>`

**Context** `config>system>rollback`

**Description** Configures the maximum number of rollback checkpoint files when the rollback-location is on local compact flash.

**Default** 10

## remote-max-checkpoints

**Syntax** `remote-max-checkpoints <1..200>`

**Context** `config>system>rollback`

**Description** Configures the maximum number of rollback checkpoint files when the rollback-location is remote (e.g. ftp).

**Default** 10

## Management Infrastructure Control Commands

### management

<b>Syntax</b>	<b>management {cli}</b>
<b>Context</b>	config>system
<b>Description</b>	This command enables the context to configure management interface parameters.
<b>Default</b>	No default
<b>Parameters</b>	<b>cli</b> — Allows configuration of parameters related to basic CLI commands for datastore infrastructure operation and behavior.

### configuration

<b>Syntax</b>	<b>configuration</b>
<b>Context</b>	config>system>management
<b>Description</b>	This command enables the context to configure parameters related to configuration data.

### immediate

<b>Syntax</b>	<b>[no] immediate</b>
<b>Context</b>	config>system>management>configuration
<b>Description</b>	<p>This command enables writeable access in the <b>configure</b> CLI branch.</p> <p>The <b>no</b> form of this command, when configured under the <b>management cli</b> context, blocks writeable access and configuration changes in the <b>configure</b> CLI branch. This causes the running configuration datastore from the <b>configure</b> CLI branch to be read-only.</p> <p>This command can be used to enforce the use of candidate configuration and the <b>commit</b> command, instead of allowing immediate mode line-by-line configuration changes.</p>
<b>Default</b>	<b>immediate</b> (configuration changes are allowed in the <b>configure</b> CLI branch)

---

## Show Commands

### alias

**Syntax**    **alias**

**Context**    <root>

**Description**    This command displays a list of existing aliases.

**Output**    **Show Alias Fields** — The following table describes alias output fields.

**Table 19: Show Alias Output Fields**

Label	Description
Alias-Name	Displays the name of the alias.
Alias-command-name	The command and parameter syntax that define the alias.
Number of aliases	The total number of aliases configured on the router.

### Sample Output

```
A:ALA-103>config>system# show alias
=====
Alias-Name                Alias-command-name
=====
sri                       show router interface
sse                       show service service-using epipe
ssvpls                   show service service-using vpls
ssi                       show service service-using ies
-----
Number of aliases : 5
=====
A:ALA-103>config>system#
```

Show Commands

# Boot Options

---

## In This Chapter

This chapter provides information about configuring boot option parameters.

Topics in this chapter include:

- [System Initialization on page 194](#)
  - [Configuration and Image Loading on page 198](#)
    - [Persistence on page 200](#)
    - [Lawful Intercept on page 201](#)
    - [FIPS-140-2 Mode on page 202](#)
- [Initial System Startup Process Flow on page 203](#)
- [Configuration Notes on page 204](#)

## System Initialization

The primary copy of SR OS software is located on a compact flash card. The removable media is shipped with each 7950 XRS-Series router and contains a copy of the OS image.

Starting a 7950 XRS-Series router begins with hardware initialization (a reset or power cycle). By default, the system searches Compact Flash Slot #3 (*cf3*) for the `boot.ldr` file (also known as the bootstrap file). The `boot.ldr` file is the image that reads and executes the system initialization commands configured in the boot option file (BOF). The default value to initially search for the `boot.ldr` file on *cf3* cannot be modified.

The following is an example of console display output when the `boot.ldr` file cannot be located on *cf3*.

```
...
(memory test messages)
(serial number information)
Searching for boot.ldr on local drives:
No disk in cf3
No disk in cf3
No disk in cf3
Error - file boot.ldr not found on any drive
Please insert CF containing boot.ldr. Rebooting in 5 seconds.
```

When the bootstrap image is loaded, the BOF is read to obtain the location of the image and configuration files. The BOF must be located on the same compact flash drive as the `boot.ldr` file.

[Figure 6](#) displays the system initialization sequence.





Figure 6: System Initialization - Part 1

Figure 7 displays the compact flash directory structure and file names.




**Figure 7: Files on the Compact Flash**

Files on the compact flash are:

- bof.cfg — Boot option file
- boot.ldr — Bootstrap image
- config.cfg — Default configuration file
- TIMOS-m.n.Yz:
  - m — Major release number
  - n — minor release number
  - Y: A — Alpha release
  - B — Beta release
  - M — Maintenance release
  - R — Released software
  - z — Version number
  - cpm.tim — CPM image file
  - iom.tim — XCM image file
  - support.tim — required data for SR OS .tim files
  - hmac-sha1.txt (in FIPS-140-2 mode only)

Figure 8 displays the compact flash directory structure and file names .



**Figure 8: Files on the Compact Flash**

Files on the compact flash are:

- bof.cfg — Boot option file
- boot.ldr — Bootstrap image
- config.cfg — Default configuration file
- TIMOS-m.n.Yz:
  - m — Major release number
  - n — Minor release number
  - Y: A — Alpha release
  - B — Beta release
  - M — Maintenance release
  - R — Released software
  - z — Version number
  - both.tim — CPM and IOM image file
  - support.tim — required data for SR OS .tim files
  - hmac-sha1.txt (in FIPS-140-2 mode only)

The 7750 SR-Series router includes a boot option for running the node in a FIPS-140-2 mode. This mode limits the use of cryptographic algorithms on the CPM to only those that are in accordance with the FIPS-140-2 certifications associated with the 7750 SR-Series router.

## Configuration and Image Loading

When the system executes the `boot.ldr` file, the initialization parameters from the BOF are processed. Three locations can be configured for the system to search for the files that contains the runtime image. The locations can be local or remote. The first location searched is the primary image location. If not found, the secondary image location is searched, and lastly, the tertiary image location is searched.

If the BOF cannot be found or loaded, then the system enters a console message dialog session prompting the user to enter alternate file locations and file names.

The **boot.ldr** can be interrupted during the boot sequence by pressing any key on the CPM console port. The operator must then type **sros** and press **ENTER** within 30 seconds or the **boot.ldr** will continue trying to boot the system. This key sequence ensures that noise or misconfiguration does not inadvertently interrupt the boot sequence. If the operator types **sros** and presses **ENTER** within 30 seconds, they are brought to a console message dialog session prompting the user to enter file locations and other boot information.

When the runtime image is successfully loaded, control is passed from the bootstrap loader to the image. The runtime image attempts to locate the configuration file as configured in the BOF. Like the runtime image, three locations can be configured for the system to search for the configuration file. The locations can be local or remote. The first location searched is the primary configuration location. If not found, the secondary configuration location is searched, and lastly, the tertiary configuration location is searched. The configuration file include chassis, XCM (card), XMA (mda), and port configurations, as well as system, routing, and service configurations.

[Figure 9](#) displays the boot sequence.




Figure 9: System Initialization - Part 2

The following displays an example of BOF output.

```
A:ALA-1>bof# show bof
=====
Memory BOF
=====
no autonegotiate
duplex          full
speed           100
address         10.10.xx.xx/20 active
wait           3
primary-image   cf3:\both.tim
primary-config  cf3:\test123.cfg
primary-dns     192.168.xx.xx
persist         on
dns-domain      test.alcatel.com
=====
A:ALA-1>bof#
```

## Persistence

Optionally, the BOF `persist` parameter can specify whether the system should preserve system indexes when a **save** command is executed. During a subsequent boot, the index file is read along with the configuration file. As a result, a number of system indexes are preserved between reboots, including the interface indexLSP IDs, path IDs, etc. If persistence is not required and the configuration file is successfully processed, then the system becomes operational. If `persist` is required, then a matching `x.ndx` file must be located and successfully processed before the system can become operational. Matching files (configuration and index files) must have the same filename prefix such as `test123.cfg` and `test123.ndx` and are created at the same time when a **save** command is executed. Note that the persistence option must be enabled to deploy the Network Management System (NMS). The default is off.

Traps, logs, and console messages are generated if problems occur and SNMP shuts down for all SNMP gets and sets, however, traps are issued.

## Lawful Intercept

Lawful Intercept (LI) describes a process to intercept telecommunications by which law enforcement authorities can un-obtrusively monitor voice and data communications to combat crime and terrorism with higher security standards of lawful intercept capabilities in accordance with local law and after following due process and receiving proper authorization from competent authorities. The interception capabilities are sought by various telecommunications providers.

As lawful interception is subject to national regulation, requirements vary from one country to another. Alcatel-Lucent's implementation satisfies most national standard's requirements. LI is configurable for all service types.

## FIPS-140-2 Mode

The 7750 SR-Series router includes a configurable parameter in the `bof.cfg` file to make the node run in FIPS-140-2 mode. When the node boots in FIPS-140-2 mode, the following behaviors are enabled on the node:

- The node performs an HMAC-SHA1 integrity test on the software images `.tim` files.
- The node limits the use of encryption and authentication algorithms to only those allowed for the associated FIPS-140-2 certification of the 7750-SR Series routers.
- Cryptographic module startup tests are executed on the CPM when the node boots to ensure the associated approved FIPS-140-2 algorithms are operating correctly.
- Cryptographic module conditional tests are executed when required during normal operation of associated when using FIPS-140-2 approved algorithms.
- When configuring user-defined encryption or authentication keys, CLI will prompt for the key to be re-entered. If the re-entered key does not match the original, the CLI command will be canceled. This affects several protocols and applications.

To support FIPS-140-2, an HMAC-SHA-1 integrity check is performed to verify the integrity of the software images. The following file is included in the TIMOS-m.n.Yz software bundle containing the `hmac-sha-1` signature:

- `hmac-sha1.txt`

During the loading of the `cpm.tim` or `both.tim`, a HMAC-SHA-1 check is performed to ensure that the calculated HMAC-SHA-1 of the loaded image matches that stored in the `hmac-sha1.txt` file.

The HMAC-SHA-1 check is performed on the data loaded from the `.tim` file. Note that when configuring the `primary-image`, `secondary-image` and `tertiary-image`, the `hmac-sha1.txt` file must exist in the same directory as the `.tim` files. If the load has been verified correctly from the HMAC-SHA-1 integrity check, the load continues to bootup as normal. If the load is not verified by the HMAC-SHA-1 integrity check, the image load will fail.

After the HMAC-SHA-1 integrity check passes, the nodes continues its normal bootup sequence including reading the `config.cfg` file and loading the configuration. The `config.cfg` file used to boot the node in FIPS-140-2 mode must not contain any configuration that is not supported in FIPS-140-2 mode. If such configuration is present in the `config.cfg` file when the node boots, the node will load the `config.cfg` file until the location of the offending configuration and then halt the configuration at that point. Upon a failure to load the `config.cfg` file, a failure message is printed on the console.

# Initial System Startup Process Flow

Figure 10 displays the process start your system. Note that this example assumes that the boot loader and BOF image and configuration files are successfully located.




Figure 10: System Startup Flow

## Configuration Notes

This section describes BOF configuration caveats.

- For router initialization, the compact flash card must be installed in the Compact Flash #3 slot.
- The loading sequence is based on the order in which it is placed in the configuration file. It is loaded as it is read in at boot time.

## Configuring Boot File Options with CLI

This section provides information to configure BOF parameters with CLI.

Topics in this section include:

- [Configuring Boot File Options with CLI on page 205](#)
- [BOF Configuration Overview on page 206](#)
- [Basic BOF Configuration on page 207](#)
- [Common Configuration Tasks on page 208](#)
- [Configuring BOF Parameters on page 213](#)
- [Service Management Tasks on page 214](#)
  - [Viewing the Current Configuration on page 214](#)
  - [Modifying and Saving a Configuration on page 216](#)
  - [Saving a Configuration to a Different Filename on page 218](#)
  - [Rebooting on page 218](#)

## BOF Configuration Overview

Alcatel-Lucent 7950 XRS routers do not contain a boot EEPROM. The boot loader code is loaded from the boot. file. The BOF file performs the following tasks:

1. Sets up the CPM/CCM Ethernet port (speed, duplex, auto).
2. Assigns the IP address for the CPM/CCM Ethernet port.
3. Creates static routes for the CPM/CCM Ethernet port.
4. Sets the console port speed.
5. Configures the Domain Name System (DNS) name and DNS servers.
6. Configures the primary, secondary, tertiary configuration source.
7. Configures the primary, secondary, and tertiary image source.
8. Configures operational parameters.

## Basic BOF Configuration

The parameters which specify location of the image filename that the router will try to boot from and the configuration file are in the BOF.

The most basic BOF configuration should have the following:

- Primary address
- Primary image location
- Primary configuration location

Following is a sample of a basic BOF configuration.

```
A:SR-45# show bof
=====
BOF (Memory)
=====
primary-image      cf3:/4.0.R20
primary-config     cf3:/ospf_default.cfg
address            138.120.189.53/24 active
static-route       138.120.0.0/16 next-hop 138.120.189.1
static-route       172.0.0.0/8 next-hop 138.120.189.1
autonegotiate
duplex             full
speed              100
wait               3
persist            on
console-speed      115200
=====
A:SR-45#
```

## Common Configuration Tasks

The following sections are basic system tasks that must be performed.

- [Searching for the BOF on page 209](#)
  - [Accessing the CLI on page 211](#)
    - [Console Connection on page 211](#)
- [Configuring BOF Parameters on page 213](#)

For details about hardware installation and initial router connections, refer to the specific 7950 XRS-Series hardware installation guide.

## Searching for the BOF

The BOF should be on the same drive as theboot loader file. If the system cannot load or cannot find the BOF then the system checks whether the boot sequence was manually interrupted. The system prompts for a different image and configuration location.

The following example displays an example of the output when the boot sequence is interrupted.

```

...

Hit a key within 3 seconds to change boot parms...

You must supply some required Boot Options. At any prompt, you can type:
  "restart" - restart the query mode.
  "reboot"  - reboot.
  "exit"    - boot with with existing values.

Press ENTER to begin, or 'flash' to enter firmware update...

Software Location
-----
  You must enter the URL of the TiMOS software.
  The location can be on a Compact Flash device,
  or on the network.

  Here are some examples
    cf3:/timos1.0R1
    ftp://user:passwd@192.168.xx.xxx/./timos1.0R1
    tftp://192.168.xx.xxx/./timos1.0R1

The existing Image URL is 'ftp://vxworks:vxw0rks@192.168.xx.xxx/./rel/0.0/xx'
Press ENTER to keep it.
Software Image URL:
Using: 'ftp://vxworks:vxw0rks@192.168.xx.xxx/./rel/0.0/xx'

Configuration File Location
-----
  You must enter the location of configuration
  file to be used by TiMOS. The file can be on
  a Compact Flash device, or on the network.

  Here are some examples
    cf1:/config.cfg
    ftp://user:passwd@192.168.xx.xxx/./config.cfg
    tftp://192.168.xx.xxx/./config.cfg

The existing Config URL is 'cf3:/config.cfg'
Press ENTER to keep it, or the word 'none' for no Config URL.
Config File URL:
Using: 'cf3:/config.cfg'

Network Configuration
-----
  You specified a network location for either the
  software or the configuration file. You need to

```

## Searching for the BOF

assign an IP address for this system.

The IP address should be entered in standard dotted decimal form with a network length.

example: 192.168.xx.xxx/24

### Display on Redundant models

The existing **Active** IP address is 192.168.xx.xxx/20. Press ENTER to keep it.

Enter Active IP Address:

Using: 192.168.xx.xxx/20

The existing **Standby** IP address is 192.168.xx.xxx/20. Press ENTER to keep it.

Enter Standby IP Address (Type 0 if none desired):

Using: 192.168.xx.xxx/20

Would you like to add a static route? (yes/no) y

Static Routes

-----

You specified network locations which require static routes to reach. You will be asked to enter static routes until all the locations become reachable.

Static routes should be entered in the following format:

prefix/mask next-hop ip-address

example: 192.168.xx.xxx/16 next-hop 192.168.xx.xxx

Enter route: 1.x.x.0/24 next-hop 192.168.xx.xxx

OK

Would you like to add another static route? (yes/no) n

New Settings

-----

primary-image	ftp://vxworks:vxw0rks@192.168.xx.xx/./rel/0.0/xx
primary-config	cf3:/config.cfg
address	192.168.xx.xx/20 active
primary-dns	192.168.xx.xx
dns-domain	xxx.xxx.com
static-route	1.x.x.0/24 next-hop 192.168.xx.xxx
autonegotiate	
duplex	full
speed	100
wait	3
persist	off

Do you want to overwrite cf3:/bof.cfg with the new settings? (yes/no): y

Successfully saved the new settings in cf3:/bof.cfg

## Accessing the CLI

To access the CLI to configure the software for the first time, follow these steps:

- When the power to the chassis is turned on, the 7950 XRS software automatically begins the boot sequence.
  - When the boot loader and BOF image and configuration files are successfully located, establish a router connection (console session).
- 

## Console Connection

To establish a console connection, you will need the following:

- An ASCII terminal or a PC running terminal emulation software set to the parameters shown in the table below.
- A standard serial cable with a male DB9.

**Table 20: Console Configuration Parameter Values**

<b>Parameter</b>	<b>Value</b>
Baud Rate	115,200
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	None

To establish a console connection:

- Step 1** Connect the terminal to the Console port using the serial cable.
- Step 2** Power on the terminal.
- Step 3** Establish the connection by pressing the <Enter> key a few times on your terminal keyboard.
- Step 4** At the router prompt, enter the login and password.  
The default login is `admin`.  
The default password is `admin`.

## Configuring BOF Parameters

The following output displays a BOF configuration:

```
A:ALA-1>bof# show bof
=====
Memory BOF
=====
no autonegotiate
duplex      full
speed      100
address    10.10.xx.xx/20 active
wait       3
primary-image cf3:\both.tim
primary-config cf3:\test123.cfg
primary-dns 192.168.xx.xx
persist     on
dns-domain  test.alcatel.com
=====
A:ALA-1>bof#
```

## Service Management Tasks

This section discusses the following service management tasks:

- [System Administration Commands on page 214](#)
  - [Viewing the Current Configuration on page 214](#)
  - [Modifying and Saving a Configuration on page 216](#)
  - [Deleting BOF Parameters on page 217](#)
  - [Saving a Configuration to a Different Filename on page 218](#)

## System Administration Commands

Use the following administrative commands to perform management tasks.

**CLI Syntax:** A:ALA-1# admin  
 display-config  
 reboot [active|standby] [now]  
 save [file-url] [detail] [index]

## Viewing the Current Configuration

Use one of the following CLI commands to display the current configuration. The *detail* option displays all default values. The *index* option displays only the persistent indices. The *info* command displays context-level information.

**CLI Syntax:** admin# display-config [detail|index]  
 info *detail*

The following displays an example of a configuration file:

```
exit all
configure
#-----
echo "System Configuration"
#-----
system
  name "-3"
  contact "Fred Information Technology"
  location "Bldg.1-floor 2-Room 201"
  clli-code "abcdefg1234"
  coordinates "N 45 58 23, W 34 56 12"
  ccm 1
  exit
```

```

snmp
exit
login-control
    idle-timeout 1440
    motd text "-3"
exit
time
    sntp
        shutdown
    exit
    zone UTC
exit
thresholds
    rmon
    exit
exit
exit...
...
#-----
echo "Redundancy Configuration"
#-----
    redundancy
        synchronize boot-env
    exit
...exit all

# Finished FRI Nov 21 15:06:16 2008 UTC
A:#

```

## Modifying and Saving a Configuration

If you modify a configuration file, the changes remain in effect only during the current power cycle unless a `save` command is executed. Changes are lost if the system is powered down or the router is rebooted without saving.

- Specify the file URL location to save the running configuration. If a destination is not specified, the files are saved to the location where the files were found for that boot sequence. The same configuration can be saved with different file names to the same location or to different locations.
- The **detail** option adds the default parameters to the saved configuration.
- The **index** option forces a save of the index file.
- Changing the active and standby addresses without reboot standby CPM may cause a boot-env sync to fail.

The following command saves a configuration:

**CLI Syntax:** `bof# save [cflash-id]`

**Example:**

```
A:ALA-1# bof
A:ALA-1>bof# save cf:
A:ALA-1>bof#
```

The following command saves the system configuration:

**CLI Syntax:** `admin# save [file-url] [detail] [index]`

**Example:**

```
A:ALA-1# admin save cf:\test123.cfg
Saving config.# Saved to cf:\test123.cfg
... complete
A:ALA-1#
```

**NOTE:** If the `persist` option is enabled and the `admin save file-url` command is executed with an FTP path used as the `file-url` parameter, two FTP sessions simultaneously open to the FTP server. The FTP server must be configured to allow multiple sessions from the same login, otherwise, the configuration and index files will not be saved correctly.

## Deleting BOF Parameters

You can delete specific BOF parameters. The **no** form of these commands removes the parameter from configuration. The changes remain in effect only during the current power cycle unless a `save` command is executed. Changes are lost if the system is powered down or the router is rebooted without saving.

Deleting a BOF address entry is not allowed from a Telnet session.

Use the following CLI syntax to save and remove BOF configuration parameters:

**CLI Syntax:** `bof# save [cflash-id]`

**Example:**

```
A:ALA-1# bof
A:ALA-1>bof# save cf:
A:ALA-1>bof#
```

## Saving a Configuration to a Different Filename

Save the current configuration with a unique filename to have additional backup copies and to edit parameters with a text editor. You can save your current configuration to an ASCII file.

Use either of the following CLI syntax to save a configuration to a different location:

**CLI Syntax:** bof# save [*cflash-id*]

**Example:** A:ALA-1# bof  
A:ALA-1>bof# save cf:  
A:ALA-1>bof#

or

**CLI Syntax:** admin# save [*file-url*] [detail] [index]

**Example:** A:ALA-1>admin# save cf:\testABC.cfg  
Saving config.# Saved to cf:\testABC.cfg  
... complete  
A:ALA-1#

---

## Rebooting

When an **admin>reboot** command is issued, CPM are rebooted as well as the XMA's and XCM's. Changes are lost unless the configuration is saved. Use the **admin>save file-url** command to save the current configuration. If no command line options are specified, the user is prompted to confirm the reboot operation.

Use the following CLI syntax to reboot:

**CLI Syntax:** admin# reboot [active|standby] [now]

**Example:** A:ALA-1>admin# reboot  
A:DutA>admin# reboot  
  
Are you sure you want to reboot (y/n)? y  
  
Resetting...OK  
  
Alcatel 7xxx Boot ROM. Copyright 2000-2007 Alcatel-Lucent.  
  
All rights reserved. All use is subject to applicable  
license agreements.  
....

---

# BOF Command Reference

---

## Command Hierarchies

### Configuration Commands

```

bof
  — [no] address ip-prefix/ip-prefix-length [active | standby]
  — [no] autonegotiate
  — console-speed baud-rate
  — no console-speed
  — dns-domain dns-name
  — no dns-domain
  — duplex {full | half}
  — fips-140-2
  — no fips-140-2
  — [no] li-local-save
  — [no] li-separate
  — persist {on | off}
  — primary-config file-url
  — no primary-config
  — primary-dns ip-address
  — no primary-dns
  — primary-image file-url
  — no primary-image
  — save [cflash-id ]
  — secondary-config file-url
  — no secondary-config
  — [no] secondary-dns ip-address
  — secondary-image file-url
  — no secondary-image
  — speed speed
  — [no] static-route ip-prefix/ip-prefix-length next-hop ip-address
  — tertiary-config file-url
  — no tertiary-config
  — [no] tertiary-dns ip-address
  — tertiary-image file-url
  — no tertiary-image
  — wait seconds

```

## Command Hierarchies

### Show Commands

- show**
- **bof** [*cf**flash-id* | *booted*]
- **boot-messages**

---

## Configuration Commands

---

### File Management Commands

#### bof

**Syntax**    **bof**

**Context**    <ROOT>

**Description**    This command creates or edits the boot option file (BOF) for the specified local storage device. A BOF file specifies where the system searches for runtime images, configuration files, and other operational parameters during system initialization.

BOF parameters can be modified. Changes can be saved to a specified compact flash. The BOF must be located in the root directory of either an internal or external compact flash local to the system and have the mandatory filename of *bof.cfg*.

When modifications are made to in-memory parameters that are currently in use or operating, the changes are effective immediately. For example, if the IP address of the management port is changed, the change takes place immediately.

Only one entry of the BOF configuration command statement can be saved once the statement has been found to be syntactically correct.

When opening an existing BOF that is not the BOF used in the most recent boot, a message is issued notifying the user that the parameters will not affect the operation of the node.

No default boot option file exists. The router boots with the factory default boot sequence and options.

**Default**        **none**

#### save

**Syntax**    **save [cflash-id]**

**Context**    bof

**Description**    This command uses the boot option parameters currently in memory and writes them from the boot option file to the specified compact flash.

The BOF must be located in the root directory of the internal or external compact flash drive local to the system and have the mandatory filename of *bof.cfg*.

If a location is not specified, the BOF is saved to the default compact flash drive (cf3:) on the active CPM (typically the CPM in slot A, but the CPM in slot B could also be acting as the active). The slot name is not case-sensitive. You can use upper or lowercase “A” or “B”.

Command usage:

## File Management Commands

- **bof save** — Saves the BOF to the default drive (cf3:) on the active CPM(either in slot A or B).
- **bof save cf:** — Saves the BOF to cf3: on the active CPM (either in slot A or B).

To save the BOF to a compact flash drive on the standby CPM (for example, the redundant (standby) CPM is installed in slot B), specify -A or -B option.

Command usage:

- **bof save cf3-A:** — Saves the BOF to cf3: on CPM in in slot A whether it is active or standby.
- **bof save cf3-B:** — Saves the BOF to cf3: on CPM in in slot B whether it is active or standby.

The slot name is not case-sensitive. You can use upper or lowercase “A” or “B”.

The **bof save** and **show bof** commands allow you to save to or read from the compact flash of the standby. Use the **show card** command to determine the active and standby CPM(A or B).

**Default** Saves must be explicitly executed. The BOF is saved to cf: if a location is not specified.

**Parameters** *flash-id* — The compact flash ID where the *bof.cfg* is to be saved.

**Values** cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

**Default** cf3:

---

## BOF Processing Control

### wait

**Syntax**    `wait seconds`

**Context**    bof

**Description**    This command configures a pause, in seconds, at the start of the boot process which allows system initialization to be interrupted at the console.

When system initialization is interrupted the operator is allowed to manually override the parameters defined in the boot option file (BOF).

Only one **wait** command can be defined in the BOF.

**Default**    3

**Parameters**    *seconds* — The time to pause at the start of the boot process, in seconds.

**Values**    1 — 10

---

## Console Port Configuration

### console-speed

**Syntax**    **console-speed** *baud-rate*  
              **no console-speed**

**Context**    bof

**Description**    This command configures the console port baud rate.  
                    When this command is issued while editing the BOF file used for the most recent boot, both the BOF file and the active configuration are changed immediately.  
                    The **no** form of the command reverts to the default value.

**Default**        **115200** — console configured for 115,200 bps operation

**Parameters**    *baud-rate* — The console port baud rate, expressed as a decimal integer.

**Values**        9600, 19200, 38400, 57600, 115200

---

## Image and Configuration Management

### persist

**Syntax** `persist {on | off}`

**Context** bof

**Description** This command specifies whether the system will preserve system indexes when a **save** command is executed. During a subsequent boot, the index file is read along with the configuration file. As a result, a number of system indexes are preserved between reboots, including the interface index, LSP IDs, path IDs, etc. This reduces resynchronizations of the Network Management System (NMS) with the affected network element.

In the event that **persist** is **on** and the reboot with the appropriate index file fails, SNMP is operationally shut down to prevent the management system from accessing and possibly synchronizing with a partially booted or incomplete network element. To enable SNMP access, enter the **config>system>snmp>no shutdown** command.

If **persist** is enabled and the **admin save <url/>** command is executed with an FTP path used as the **<url/>** parameter, two FTP sessions simultaneously open to the FTP server. The FTP server must be configured to allow multiple sessions from the same login, otherwise, the configuration and index files will not be saved correctly.

Notes:

- Persistency files (.ndx) are saved on the same disk as the configuration files and the image files.
- When an operator sets the location for the persistency file, the system will check to ensure that the disk has enough free space. If this there is not enough free space, the persistency will not become active and a trap will be generated. Then, it is up to the operator to free adequate disk space. In the meantime, the system will perform a space availability check every 30 seconds. As soon as the space is available the persistency will become active on the next (30 second) check.

**Default** off

**Parameters** *on* — Create when saving the configuration.  
*off* — Disables the system index saves between reboots.

## primary-config

<b>Syntax</b>	<b>primary-config</b> <i>file-url</i> <b>no primary-config</b>								
<b>Context</b>	bof								
<b>Description</b>	<p>This command specifies the name and location of the primary configuration file.</p> <p>The system attempts to use the configuration specified in <b>primary-config</b>. If the specified file cannot be located, the system automatically attempts to obtain the configuration from the location specified in <b>secondary-config</b> and then the <b>tertiary-config</b>.</p> <p>Note that if an error in the configuration file is encountered, the boot process aborts.</p> <p>The <b>no</b> form of the command removes the <b>primary-config</b> configuration.</p>								
<b>Default</b>	none								
<b>Parameters</b>	<i>file-url</i> — The primary configuration file location, expressed as a file URL.								
<b>Values</b>	<table> <tr> <td>file-url</td> <td>[<i>local-url</i>   <i>remote-url</i>] (up to 180 characters)</td> </tr> <tr> <td>local-url</td> <td>[<i>cflash-id</i>]/[<i>file-path</i>]</td> </tr> <tr> <td>remote-url</td> <td>[{ftp:// tftp://} <i>login:pswd@remote-locn</i>]/[<i>file-path</i>]</td> </tr> <tr> <td>cflash-id</td> <td>cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:</td> </tr> </table>	file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)	local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]	remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]	cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:
file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)								
local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]								
remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]								
cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:								

## primary-image

<b>Syntax</b>	<b>primary-image</b> <i>file-url</i> <b>no primary image</b>								
<b>Context</b>	bof								
<b>Description</b>	<p>This command specifies the primary directory location for runtime image file loading.</p> <p>The system attempts to load all runtime image files configured in the <b>primary-image</b> first. If this fails, the system attempts to load the runtime images from the location configured in the <b>secondary-image</b>. If the secondary image load fails, the tertiary image specified in <b>tertiary-image</b> is used.</p> <p>All runtime image files (*.tim files) must be located in the same directory.</p> <p>The <b>no</b> form of the command removes the <b>primary-image</b> configuration.</p>								
<b>Default</b>	none								
<b>Parameters</b>	<i>file-url</i> — The <i>location-url</i> can be either local (this CPM) or a remote FTP server.								
<b>Values</b>	<table> <tr> <td>file-url</td> <td>[<i>local-url</i>   <i>remote-url</i>] (up to 180 characters)</td> </tr> <tr> <td>local-url</td> <td>[<i>cflash-id</i>]/[<i>file-path</i>]</td> </tr> <tr> <td>remote-url</td> <td>[{ftp:// tftp://} <i>login:pswd@remote-locn</i>]/[<i>file-path</i>]</td> </tr> <tr> <td>cflash-id</td> <td>cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:</td> </tr> </table>	file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)	local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]	remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]	cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:
file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)								
local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]								
remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]								
cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:								

## secondary-config

**Syntax**    **secondary-config** *file-url*  
**no secondary-config**

**Context**    bof

**Description**    This command specifies the name and location of the secondary configuration file. The system attempts to use the configuration as specified in **secondary-config** if the primary config cannot be located. If the **secondary-config** file cannot be located, the system attempts to obtain the configuration from the location specified in the **tertiary-config**.

Note that if an error in the configuration file is encountered, the boot process aborts.

The **no** form of the command removes the **secondary-config** configuration.

**Default**    **none**

**Parameters**    *file-url* — The secondary configuration file location, expressed as a file URL.

<b>Values</b>	file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)
	local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]
	remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]
	cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

## secondary-image

**Syntax**    **secondary-image** *file-url*  
**no secondary-image**

**Context**    bof

**Description**    This command specifies the secondary directory location for runtime image file loading. The system attempts to load all runtime image files configured in the **primary-image** first. If this fails, the system attempts to load the runtime images from the location configured in the **secondary-image**. If the secondary image load fails, the tertiary image specified in **tertiary-image** is used.

All runtime image files (\*.tim files) must be located in the same directory.

The **no** form of the command removes the **secondary-image** configuration.

**Default**    **none**

**Parameters**    *file-url* — The *file-url* can be either local (this CPM) or a remote FTP server.

<b>Values</b>	file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)
	local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]
	remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]
	cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

## tertiary-config

<b>Syntax</b>	<b>tertiary-config</b> <i>file-url</i> <b>no tertiary-config</b>		
<b>Context</b>	bof		
<b>Description</b>	<p>This command specifies the name and location of the tertiary configuration file.</p> <p>The system attempts to use the configuration specified in <b>tertiary-config</b> if both the primary and secondary config files cannot be located. If this file cannot be located, the system boots with the factory default configuration.</p> <p>Note that if an error in the configuration file is encountered, the boot process aborts.</p> <p>The <b>no</b> form of the command removes the <b>tertiary-config</b> configuration.</p>		
<b>Default</b>	none		
<b>Parameters</b>	<i>file-url</i> — The tertiary configuration file location, expressed as a file URL.		
	<b>Values</b>	local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]
		cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:
		remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]

## tertiary-image

<b>Syntax</b>	<b>tertiary-image</b> <i>file-url</i> <b>no tertiary-image</b>		
<b>Context</b>	bof		
<b>Description</b>	<p>This command specifies the tertiary directory location for runtime image file loading.</p> <p>The system attempts to load all runtime image files configured in the <b>primary-image</b> first. If this fails, the system attempts to load the runtime images from the location configured in the <b>secondary-image</b>. If the secondary image load fails, the tertiary image specified in <b>tertiary-image</b> is used.</p> <p>All runtime image files (*.tim files) must be located in the same directory.</p> <p>The <b>no</b> form of the command removes the <b>tertiary-image</b> configuration.</p>		
<b>Default</b>	none		
<b>Parameters</b>	<i>file-url</i> — The location-url can be either local (this CPM) or a remote FTP server.		
	<b>Values</b>	file-url	[ <i>local-url</i>   <i>remote-url</i> ] (up to 180 characters)
		local-url	[ <i>cflash-id</i> ]/[ <i>file-path</i> ]
		remote-url	[{ftp:// tftp://} <i>login:pswd@remote-locn</i> ]/[ <i>file-path</i> ]
		cflash-id	cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

## Management Ethernet Configuration

### address

**Syntax** [no] address *ip-prefix/ip-prefix-length* [active | standby]

**Context** bof

**Description** This command assigns an IP address to the management Ethernet port on the active CPM in the running configuration and the Boot Option File (BOF) or the standby CPM for systems using redundant CPMs. Deleting a BOF address entry is not allowed from a remote session.

Note that changing the active and standby addresses without reboot standby CPM may cause a boot-env sync to fail.

The **no** form of the command deletes the IP address from the CPM Ethernet port.

**Default** **no address** — There are no IP addresses assigned to Ethernet ports.

**Parameters** *ip-prefix/ip-prefix-length* — The destination address of the aggregate route in dotted decimal notation.

<b>Values</b>	ipv4-prefix	a.b.c.d (host bits must be 0)
	ipv4-prefix-length	0 — 32
	ipv6-prefix	x:x:x:x:x:x:x:x (eight 16-bit pieces)
		x:x:x:x:x:d.d.d.d
		x: [0 — FFFF]H
		d: [0 — 255]D
	ipv6-prefix-length	0 — 128

**active | standby** — Specifies which CPM Ethernet address is being configured: the active CPM Ethernet or the standby CPM Ethernet.

**Default** active

### autonegotiate

**Syntax** [no] autonegotiate [limited]

**Context** bof

**Description** This command enables speed and duplex autonegotiation on the management Ethernet port in the running configuration and the Boot Option File (BOF).

When autonegotiation is enabled, the link attempts to automatically negotiate the link speed and duplex parameters. If autonegotiation is enabled, then the configured duplex and speed parameters are ignored.

The **no** form of the command disables the autonegotiate feature on this port.

**autonegotiate** — Autonegotiation is enabled on the management Ethernet port.

## Management Ethernet Configuration

**Parameters** **limited** — Specifies ethernet ports to be configurable to use link autonegotiation but with only a single speed/duplex combination advertised. This allows a specific speed/duplex to be guaranteed without having to turn off autonegotiation, which is not allowed for 1000BASE-T.

### duplex

**Syntax** **duplex {full | half}**

**Context** bof

**Description** This command configures the duplex mode of the CPM management Ethernet port when autonegotiation is disabled in the running configuration and the Boot Option File (BOF).

This configuration command allows for the configuration of the duplex mode of the CPM Ethernet interface. If the port is configured to autonegotiate this parameter will be ignored.

**Default** **duplex full** — Full duplex operation.

**Parameters** **full** — Sets the link to full duplex mode.

**half** — Sets the link to half duplex mode.

### fips-140-2

**Syntax** **fips-140-2**  
**no fips-140-2**

**Context** bof

**Description** This command is used to configure the node in FIPS-140-2 mode. Before using this command, the operator must ensure that no current configuration exists in the config file that is not supported in FIPS-140-2 mode. Failing to remove unsupported configuration will result in the node being unable to boot up. The node must be rebooted after executing this command in order for the node to begin operating in FIPS-140-2 mode.

**Default** no fips-140-2

### li-local-save

**Syntax** **[no] li-local-save**

**Context** bof

**Description** This command enables the lawful intercept (LI) configuration to be saved locally.

## li-separate

**Syntax** [no] **li-separate**

**Context** bof

**Description** This command enables separate access to lawful intercept (LI) information.

## speed

**Syntax** **speed** *speed*

**Context** bof

**Description** This command configures the speed for the CPM management Ethernet port when autonegotiation is disabled in the running configuration and the Boot Option File (BOF).

If the port is configured to autonegotiate this parameter is ignored.

**Default** **speed 100** — 100 M/bps operation.

**Parameters** **10** — Sets the link to 10 M/bps speed.

**100** — Sets the link to 100 M/bps speed.

## static-route

**Syntax** [no] **static-route** *ip-prefix/ip-prefix-length next-hop ip-address*

**Context** bof

This command creates a static route entry for the CPM management Ethernet port in the running configuration and the Boot Option File (BOF).

This command allows manual configuration of static routing table entries. These static routes are only used by traffic generated by the CPM Ethernet port. To reduce configuration, manual address aggregation should be applied where possible.

A static default (0.0.0.0/0 or ::/0) route cannot be configured on the CPM Ethernet port. A maximum of 10 static routes can be configured on the CPM port.

The **no** form of the command deletes the static route.

**Default** No default routes are configured.

**Parameters** *ip-prefix/ip-prefix-length* — The destination address of the static route in dotted decimal notation.

<b>Values</b>	ip-prefix/ip-prefix-length: ipv4-prefix	a.b.c.d (host bits must be 0)
	ipv4-prefix-le	0 — 32
	ipv6-prefix	x:x:x:x:x:x:x (eight 16-bit pieces)
		x:x:x:x:x:d.d.d.d
		x: [0..FFFF]H

## DNS Configuration Commands

	ip-address:	ipv6-prefix-le	d: [0..255]D
		ipv4-address	0 — 128
		ipv6-address	a.b.c.d
			x:x:x:x:x:x:x (eight 16-bit pieces)
			x:x:x:x:x:d.d.d.d
			x: [0..FFFF]H
			d: [0..255]D

*mask* — The subnet mask, expressed as an integer or in dotted decimal notation.

**Values** 1 — 32 (mask length), 128.0.0.0 — 255.255.255.255 (dotted decimal)

**next-hop** *ip-address* — The next hop IP address used to reach the destination.

---

## DNS Configuration Commands

### dns-domain

**Syntax** **dns-domain** *dns-name*  
**no dns-domain**

**Context** bof

**Description** This command configures the domain name used when performing DNS address resolution. This is a required parameter if DNS address resolution is required. Only a single domain name can be configured. If multiple domain statements are configured, the last one encountered is used.

The **no** form of the command removes the domain name from the configuration.

**Default** **no dns-domain** — No DNS domain name is configured.

**Parameters** *dns-name* — Specifies the DNS domain name up to 32 characters in length.

### primary-dns

**Syntax** **primary-dns** *ip-address*  
**no primary-dns**

**Context** bof

**Description** This command configures the primary DNS server used for DNS name resolution. DNS name resolution can be used when executing ping, traceroute, and service-ping, and also when defining file URLs. DNS name resolution is not supported when DNS names are embedded in configuration files.

The **no** form of the command removes the primary DNS server from the configuration.

**Default** **no primary-dns** — No primary DNS server is configured.

<b>Parameters</b>	<i>ip-address</i> — The IP or IPv6 address of the primary DNS server.
<b>Values</b>	ipv4-address - a.b.c.d ipv6-address: x:x:x:x:x:x:x[-interface] x:x:x:x:x:d.d.d.d[-interface] x: [0..FFFF]H d: [0..255]D interface - 32 chars max, for link local addresses

## secondary-dns

	<b>[no] secondary-dns</b> <i>ip-address</i>
<b>Context</b>	bof
<b>Description</b>	<p>This command configures the secondary DNS server for DNS name resolution. The secondary DNS server is used only if the primary DNS server does not respond.</p> <p>DNS name resolution can be used when executing ping, traceroute, and service-ping, and also when defining file URLs. DNS name resolution is not supported when DNS names are embedded in configuration files.</p> <p>The <b>no</b> form of the command removes the secondary DNS server from the configuration.</p>
<b>Default</b>	<b>no secondary-dns</b> — No secondary DNS server is configured.
<b>Parameters</b>	<i>ip-address</i> — The IP or IPv6 address of the secondary DNS server.
<b>Values</b>	ipv4-address - a.b.c.d ipv6-address: x:x:x:x:x:x:x[-interface] x:x:x:x:x:d.d.d.d[-interface] x: [0..FFFF]H d: [0..255]D interface - 32 chars max, for link local addresses

## tertiary-dns

<b>Syntax</b>	<b>[no] tertiary-dns</b> <i>ip-address</i>
<b>Context</b>	bof
<b>Description</b>	<p>This command configures the tertiary DNS server for DNS name resolution. The tertiary DNS server is used only if the primary DNS server and the secondary DNS server do not respond.</p> <p>DNS name resolution can be used when executing ping, traceroute, and service-ping, and also when defining file URLs. DNS name resolution is not supported when DNS names are embedded in configuration files.</p> <p>The <b>no</b> form of the command removes the tertiary DNS server from the configuration.</p>
<b>Default</b>	<b>no tertiary-dns</b> — No tertiary DNS server is configured.

## DNS Configuration Commands

**Parameters**    *ip-address* — The IP or IPv6 address of the tertiary DNS server.

**Values**

- ipv4-address - a.b.c.d
- ipv6-address:    x:x:x:x:x:x:x[-interface]  
                  x:x:x:x:x:d.d.d.d[-interface]  
                  x: [0..FFFF]H  
                  d: [0..255]D  
                  interface - 32 chars max, for link local addresses

---

## Show Commands

### bof

**Syntax** `bof [cflash-id | booted]`

**Context** show

**Description** This command displays the Boot Option File (BOF) executed on last system boot or on the specified device. If no device is specified, the BOF used in the last system boot displays. If the BOF has been modified since the system boot, a message displays.

**Parameters** *cflash-id*. The cflash directory name. The slot name is not case-sensitive. Use upper or lowercase “A” or “B” for the slot name.

**Values** `cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:`

*booted* — Displays the boot option file used to boot the system.

**Output** **Show BOF Fields** — The following table describes BOF output fields.

**Table 21: Show BOF Output Fields**

Label	Description
<code>primary-image</code>	The primary location of the directory that contains the runtime images of both CPM and XCM.
<code>primary-config</code>	The primary location of the file that contains the configuration.
<code>primary-dns</code>	The primary DNS server for resolution of host names to IP addresses.
<code>secondary-image</code>	The secondary location of the directory that contains the runtime images of both CPM and XCM.
<code>secondary-config</code>	The secondary location of the file that contains the configuration.
<code>secondary-dns</code>	The secondary DNS server for resolution of host names to IP addresses.
<code>tertiary-image</code>	The tertiary location of the directory that contains the runtime images of both CPM and XCM.
<code>tertiary-config</code>	The tertiary location of the file that contains the configuration.
<code>address</code>	The IP address and mask associated with the CPM Ethernet port or the secondary CPM port.
<code>tertiary-dns</code>	The tertiary DNS server for resolution of host names to IP addresses.
<code>persist</code>	<code>on</code> — Persistent indexes between system reboots is enabled. <code>off</code> — Persistent indexes between system reboots is disabled.

**Table 21: Show BOF Output Fields (Continued)**

Label	Description
wait	The time configured for the boot to pause while waiting for console input.
autonegotiate	No autonegotiate – Autonegotiate not enabled. autonegotiate – Autonegotiate is enabled.
duplex	half – Specifies that the system uses half duplex. full – Specifies that the system uses full duplex.
speed	The speed of the CPM Ethernet interface.
console speed	The console port baud rate.
dns domain	The domain name used when performing DNS address resolution.
uplinkA-address	Displays the Uplink-A IP address.
uplinkA-port	Displays the primary port to be used for auto-boot.
uplinkA-route	Displays the static route associated with Uplink-A.
uplinkA-vlan	Displays the VLAN ID to be used on Uplink-A.
uplinkB-address	Displays the Uplink-B IP address.
uplinkB-port	Displays the secondary port to be used for auto-boot.
uplinkB-route	Displays the static route associated with Uplink-B.
uplinkB-vlan	Displays the VLAN ID to be used on Uplink-B.
uplink-mode	This parameter displays the uplink mode of the device.
no-service-ports	Displays the ports on which service traffic is not processed.
use-expansion-card-type	Displays the expansion card type.

**Sample Output**

```
A:ALA-1# show bof cf3:
=====
BOF on cf3:
=====
autonegotiate
  primary-image    ftp://test:test@192.168.xx.xx/./both.tim
  primary-config   ftp://test:test@192.168.xx.xx/./lxx.cfg
  secondary-image  cf1:/i650/
  secondary-config cf1:/config.cfg
  address          192.168.xx.xxx/20 active
  address          192.168.xx.xxx/20 standby
  primary-dns      192.168.xx.xxx
```

```

dns-domain      test.test.com
autonegotiate
duplex          full
speed          100
wait           2
persist        off
console-speed  115200
=====
A:ALA-1#
A:ALA-1# show bof booted
=====
System booted with BOF
=====
primary-image   ftp://test:test@192.168.xx.xx/./both.tim
primary-config  ftp://test:test@192.168.xx.xx/./103.cfg
secondary-image cf1:/i650/
secondary-config cf1:/config.cfg
address         192.168.xx.xxx/20 active
address         192.168.xx.xxx/20 standby
primary-dns     192.168.xx.xxx
dns-domain      test.test.com
autonegotiate
duplex          full
speed          100
wait           2
persist        off
console-speed  115200
=====
A:ALA-1#

```

## Show Commands

### boot-messages

**Syntax** boot-messages

**Context** show

**Description** This command displays boot messages generated during the last system boot.

**Output** **Show Boot Messages Fields** — The following output shows boot message output fields.

#### Sample Output

```
ALA-## show boot-messages
Boot log started on CPU#0
  Build: X-1.2.B1-7 on Thurs Jan 13 14:49:23 201 by builder
  CPUCTL FPGA version: 2A
Forcing BDB controller to HwSlot 0
Performing Power on Diagnostics
>>>Testing mainboard FPGA chain...
JTAG chain length = 2
All requested FPGAs on chain programmed
>>>Validating SDRAM from 0x21f00000 to 0x22000000
>>>Testing SDRAM from 0x02200000 to 0x21f00000
>>>Testing Compact Flash 1... Slot Empty
>>>Testing Compact Flash 2... Slot Empty
>>>Testing Compact Flash 3... OK (TOSHIBA THNCF128MBA)
Wales peripheral FPGA version is 0x13
Hardware Slot 31
Card type in EEPROM is 0x6, 'england_r1'
MDA #1: HwType 0x02, 'denmark_r1', Serial Number 'de3-52'
MDA #2: HwType 0x16, 'hungary_ds3_e3_12_r1', Serial Number 'hun01-02'
Board Serial Number is 'eng02-15'
Chassis type 4 (sr1) found in BP 1 EEPROM
Chassis Serial Number is '0203210096'
JTAG chain length = 2
All requested FPGAs on chain programmed
Searching for boot.ldr on local drives:
Searching cf3 for boot.ldr...
*****
  Loaded 0x001bc191 bytes from cf3 to 0x80400000
  Decompressing to address 0x0a000000
Starting code...

Total Memory: 512MB Chassis Type: sr1 Card Type: england_r1
TiMOS-L-1.2.B1-7 boot/hops/T2.02 Copyright (c) 2000-2011 Alcatel, Inc.
Built on Thurs Jan 13 15:15:25 2003 by builder in /rel1.2/b1/B1-7/panos/main

TiMOS BOOT LOADER
Time from clock is Thurs Jan 13 08:39:03 2011 UTC
Error: could not open boot messages file.
Boot messages will not be stored.

Looking for cf3:/bof.cfg ... OK, reading

Contents of Boot Options File on cf3:
  primary-image ftp://vxworks:vxw0rks@192.168.15.1/./rel/0.0/I129
  primary-config cf3:/config.cfg
```

```

address          192.168.13.48/20 active
primary-dns      192.168.1.254
dns-domain       eng.timetra.com
autonegotiate
duplex           full
speed            100
wait             3
persist          off
  
```


Hit a key within 1 second to change boot parms...

```

Primary image location: ftp://vxworks:vxw0rks@192.168.15.1/./rel/0.0/I129
Initializing management port tme0 using IP address 192.168.13.48.
Loading image ftp://vxworks:vxw0rks@192.168.15.1/./rel/0.0/I129/both.tim
Version B-0.0.I129, Thurs Jan 13 21:24:57 2011 by builder in /rel0.0/I129/panos/main
text:(8906865-->21711576) + data:(587508-->5418992)
Executing TiMOS image at 0x2800000
  
```

```

Total Memory: 512MB Chassis Type: srl Card Type: england_r1
TiMOS-B-0.0.I129 both/hops/T2.02 Copyright (c) 2000-2011 Alcatel.
All rights reserved. All use subject to applicable license agreements.
Built on Thurs Jan 13 21:24:57 2011 by builder in /rel0.0/I129/panos/main
  
```



```

Time from clock is THU JAN 13 08:39:11 2011 UTC
Attempting to exec configuration file:
'cf3:/config.cfg' ...
System Configuration
Log Configuration
Card Configuration
Port Configuration
Router (Network Side) Configuration
Service Configuration
Router (Service Side) Configuration
Executed 232 lines in 0.0 seconds from file cf3:\config.cfg
ALA-1#
  
```

Show Commands

# System Management

---

## In This Chapter

This chapter provides information about configuring basic system management parameters.

Topics in this chapter include:

- [System Management Parameters on page 243](#)
  - [System Information on page 243](#)
    - [System Name on page 243](#)
    - [System Contact on page 243](#)
    - [System Location on page 244](#)
    - [System Coordinates on page 244](#)
    - [Naming Objects on page 244](#)
    - [Naming Objects on page 244](#)
    - [Common Language Location Identifier on page 245](#)
    - [DNS Security Extensions on page 245](#)
  - [System Time on page 246](#)
    - [Time Zones on page 246](#)
    - [Network Time Protocol \(NTP\) on page 248](#)
    - [SNTP Time Synchronization on page 249](#)
    - [CRON on page 250](#)
- [High Availability on page 251](#)
  - [HA Features on page 252](#)
    - [HA Features on page 252](#)
      - [Redundancy on page 252](#)
      - [Nonstop Forwarding on page 255](#)
      - [Nonstop Routing \(NSR\) on page 255](#)

## In This Chapter

- CPM Switchover on page 256
- Synchronization on page 257
- Synchronization and Redundancy on page 258
  - Synchronous Ethernet on page 268
  - Config Option on page 279
  - When the Active CPM Goes Offline on page 261
- Network Synchronization on page 264
  - Synchronous Ethernet on page 268
  - Synchronous Ethernet on page 268
  - Clock Source Quality Level Definitions on page 269
  - DS1 Signals on page 267
  - E1 Signals on page 267

## System Management Parameters

System management commands allow you to configure basic system management functions such as the system name, the router's location and coordinates, and CLI code as well as time zones, Network Time Protocol (NTP), Simple Network Time Protocol (SNTP) properties, CRON and synchronization properties.

It is possible to query the DNS server for IPv6 addresses. By default the DNS names are queried for A-records only (address-preference is IPv4-only). If the address-preference is set to IPv6 first, the DNS server will be queried for AAAA-records first, and if there is no successful reply, then A-records.

---

## System Information

System information components include:

- [System Name on page 243](#)
  - [System Contact on page 243](#)
  - [System Location on page 244](#)
  - [System Coordinates on page 244](#)
  - [Naming Objects on page 244](#)
- 

## System Name

The system name is the MIB II (RFC 1907, *Management Information Base for Version 2 of the Simple Network Management Protocol (SNMPv2)*) sysName object. By convention, this text string is the node's fully-qualified domain name. The system name can be any ASCII printable text string of up to 32 characters.

---

## System Contact

The system contact is the MIB II sysContact object. By convention, this text string is a textual identification of the contact person for this managed node, together with information on how to contact this person. The system contact can be any ASCII printable text string of up to 80 characters.

## System Location

The system location is the MIB II sysLocation object which is a text string conventionally used to describe the node's physical location, for example, "Bldg MV-11, 1st Floor, Room 101". The system location can be any ASCII printable text string of up to 80 characters.

---

## System Coordinates

The system coordinates is the Alcatel-Lucent Chassis MIB tmnxChassisCoordinates object. This text string indicates the Global Positioning System (GPS) coordinates of the location of the chassis.

Two-dimensional GPS positioning offers latitude and longitude information as a four dimensional vector:

*<direction, hours, minutes, seconds>*

where *direction* is one of the four basic values: N, S, W, E, *hours* ranges from 0 to 180 (for latitude) and 0 to 90 for longitude, and minutes and seconds range from 0 to 60.

<W, 122, 56, 89> is an example of longitude and <N, 85, 66, 43> is an example of latitude.

System coordinates can be expressed in different notations, examples include:

- N 45 58 23, W 34 56 12
- N37 37' 00 latitude, W122 22' 00 longitude
- N36\*39.246' W121\*40.121

The system coordinates can be any ASCII printable text string up to 80 characters.

---

## Naming Objects

It is discouraged to configure named objects with a name that starts with “\_tmnx\_” and with “\_” in general.

## Common Language Location Identifier

A Common Language Location Identifier (CLLI) code string for the device is an 11-character standardized geographic identifier that uniquely identifies the geographic location of places and certain functional categories of equipment unique to the telecommunications industry. The CLLI code is stored in the Alcatel-Lucent Chassis MIB `tmnxChassisCLLICode` object.

The CLLI code can be any ASCII printable text string of up to 11 characters.

---

## DNS Security Extensions

DNS Security (DNSSEC) Extensions are now implemented in SR OS, allowing operators to configure DNS behavior of the router to evaluate whether the Authenticated Data bit was set in the response received from the recursive name server and to trust the response, or ignore it.

## System Time

7950 SR-Series routers are equipped with a real-time system clock for time keeping purposes. When set, the system clock always operates on Coordinated Universal Time (UTC), but the 7950 XRS software has options for local time translation as well as system clock synchronization.

System time parameters include:

- [Time Zones on page 246](#)
- [Network Time Protocol \(NTP\) on page 248](#)
- [SNTP Time Synchronization on page 249](#)
- [CRON on page 250](#)

## Time Zones

Setting a time zone in SR OS allows for times to be displayed in the local time rather than in UTC. The SR OS has both user-defined and system defined time zones.

A user-defined time zone has a user assigned name of up to four printable ASCII characters in length and unique from the system-defined time zones. For user-defined time zones, the offset from UTC is configured as well as any summer time adjustment for the time zone.

The SR OS system-defined time zones are listed in [Table 22](#) which includes both time zones with and without summer time correction.

**Table 22: System-defined Time Zones**

Acronym	Time Zone Name	UTC Offset
Europe:		
GMT	Greenwich Mean Time	UTC
BST	British Summer Time	UTC +1
IST	Irish Summer Time	UTC +1*
WET	Western Europe Time	UTC
WEST	Western Europe Summer Time	UTC +1
CET	Central Europe Time	UTC +1
CEST	Central Europe Summer Time	UTC +2
EET	Eastern Europe Time	UTC +2
EEST	Eastern Europe Summer Time	UTC +3

**Table 22: System-defined Time Zones (Continued)**

<b>Acronym</b>	<b>Time Zone Name</b>	<b>UTC Offset</b>
MSK	Moscow Time	UTC +3
MSD	Moscow Summer Time	UTC +4
US and Canada		
AST	Atlantic Standard Time	UTC -4
ADT	Atlantic Daylight Time	UTC -3
EST	Eastern Standard Time	UTC -5
EDT	Eastern Daylight Saving Time	UTC -4
ET	Eastern Time	Either as EST or EDT, depending on place and time of year
CST	Central Standard Time	UTC -6
CDT	Central Daylight Saving Time	UTC -5
CT	Central Time	Either as CST or CDT, depending on place and time of year
MST	Mountain Standard Time	UTC -7
MDT	Mountain Daylight Saving Time	UTC -6
MT	Mountain Time	Either as MST or MDT, depending on place and time of year
PST	Pacific Standard Time	UTC -8
PDT	Pacific Daylight Saving Time	UTC -7
PT	Pacific Time	Either as PST or PDT, depending on place and time of year
HST	Hawaiian Standard Time	UTC -10
AKST	Alaska Standard Time	UTC -9
AKDT	Alaska Standard Daylight Saving Time	UTC -8
<b>Australia</b>		
AWST	Western Standard Time (e.g., Perth)	UTC +8
ACST	Central Standard Time (e.g., Darwin)	UTC +9.5
AEST	Eastern Standard/Summer Time (e.g., Canberra)	UTC +10

## Network Time Protocol (NTP)

NTP is the Network Time Protocol defined in RFC 1305, *Network Time Protocol (Version 3) Specification, Implementation and Analysis* and RFC 5905, *Network Time Protocol Version 4: Protocol and Algorithms Specification*. It allows for the participating network nodes to keep time more accurately and more importantly they can maintain time in a more synchronized fashion between all participating network nodes.

NTP uses stratum levels to define the number of hops from a reference clock. The reference clock is considered to be a stratum-0 device that is assumed to be accurate with little or no delay. Stratum-0 servers cannot be used in a network. However, they can be directly connected to devices that operate as stratum-1 servers. A stratum-1 server is an NTP server with a directly-connected device that provides Coordinated Universal Time (UTC), such as a GPS or atomic clock.

The higher stratum levels are separated from the stratum-1 server over a network path, thus, a stratum-2 server receives its time over a network link from a stratum-1 server. A stratum-3 server receives its time over a network link from a stratum-2 server.

The following NTP elements are supported:

- Server mode — In this mode, the node advertises the ability to act as a clock source for other network elements. In this mode, the node will, by default, transmit NTP packets in NTP version 4 mode.
- Authentication keys — Increased security support in carrier and other network has been implemented. Both DES and MD5 authentication are supported as well as multiple keys.
- Operation in symmetric active mode — This capability requires that NTP be synchronized with a specific node that is considered more trustworthy or accurate than other nodes carrying NTP in the system. This mode requires that a specific peer is set.
- Server and peer addressing using IPv6 — Both external servers and external peers may be defined using IPv6 or IPv4 addresses. Other features (such as multicast, broadcast) use IPv4 addressing only.
- Broadcaster multicastmodes — When operating in these modes, the node will receive or send using either a multicast (default 224.0.1.1) or a broadcast address. Multicast is supported on the MGMT port.
- Alert when NTP server is not available — When none of the configured servers are reachable on the node, the system reverts to manual timekeeping and issues a critical alarm. When a server becomes available, a trap is issued indicating that standard operation has resumed.
- NTP and SNTP — If both NTP and SNTP are enabled on the node, then SNTP transitions to an operationally down state. If NTP is removed from the configuration or shut down, then SNTP resumes an operationally up state.
- Gradual clock adjustment — As several applications (such as Service Assurance Agent

(SAA) can use the clock, and if determined that a major (128 ms or more) adjustment needs to be performed, the adjustment is performed by programmatically stepping the clock. If a minor (less than 128 ms) adjustment must be performed, then the adjustment is performed by either speeding up or slowing down the clock.

- In order to avoid the generation of too many events/trap the NTP module will rate limit the generation of events/traps to three per second. At that point a single trap will be generated that indicates that event/trap squashing is taking place.

---

## SNTP Time Synchronization

For synchronizing the system clock with outside time sources, the SR OS includes a Simple Network Time Protocol (SNTP) client. As defined in RFC 2030, SNTP Version 4 is an adaptation of the Network Time Protocol (NTP). SNTP typically provides time accuracy within 100 milliseconds of the time source. SNTP can only receive the time from NTP servers; it cannot be used to provide time services to other systems. SNTP is a compact, client-only version of NTP. SNTP does not authenticate traffic.

SNTP can be configured in both unicast client modes (point-to-point) and broadcast client modes (point-to-multipoint). SNTP should be used only at the extremities of the synchronization subnet. SNTP clients should operate only at the highest stratum (leaves) of the subnet and in configurations where no NTP or SNTP client is dependent on another SNTP client for synchronization. SNTP time servers should operate only at the root (stratum 1) of the subnet and then only in configurations where no other source of synchronization other than a reliable radio clock is available. External servers may only be specified using IPv4 addresses.

In the SR OS, the SNTP client can be configured for either broadcast or unicast client mode.

## CRON

The CRON feature supports periodic and date and time-based scheduling in SR OS. CRON can be used, for example, to schedule Service Assurance Agent (SAA) functions or to schedule turning on and off policies to meet "Time of Day" (TOD) requirements. CRON functionality includes the ability to specify scripts that need to be run, when they will be scheduled, including one-time only functionality (one-shot), interval and calendar functions. Scheduled reboots, peer turn ups, service assurance agent tests and more can all be scheduled with CRON, as well as OAM events, such as connectivity checks, or troubleshooting runs.

The following CRON elements are supported:

- **Schedule** — The schedule function configures the type of schedule to run, including one-time only (one-shot), periodic, or calendar-based runs. All runs are determined by month, day of month or weekday, hour, minute, and interval (seconds).
- **Time Range** — Filter (ACL) policy configurations may be enhanced to support time-based matching by referring to a time-range policy.
- **Time of Day** — Time of Day (TOD) suites are useful when configuring many types of time-based policies or when a large number of SAPs require the same type of TOD changes. The TOD suite may be configured while using specific ingress or egress ACLs or QoS policies, and is an enhancement of the ingress and egress CLI trees.

## High Availability

This section discusses the high availability (HA) routing options and features available to service providers that help diminish vulnerability at the network or service provider edge and alleviate the effect of a lengthy outage on IP networks.

High availability is an important feature in service provider routing systems. High availability is gaining momentum due to the unprecedented growth of IP services and applications in service provider networks driven by the demand from the enterprise and residential communities. Downtime can be very costly, and, in addition to lost revenue, customer information and business-critical communications can be lost. High availability is the combination of continuous uptime over long periods (Mean Time Between Failures (MTBF)) and the speed at which failover or recovery occurs (Mean Time To Repair (MTTR)).

The popularity of high availability routing is evident at the network or service provider edge where thousands of connections are hosted and rerouting options around a failed piece of equipment can often be limiting. Or, a single access link exists to a customer because of additional costs for redundant links. As service providers converge business-critical services such as real-time voice (VoIP), video, and VPN applications over their IP networks, high availability becomes much more stringent compared to the requirements for best-effort data. Network and service availability become critical aspects when offering advanced IP services which dictates that IP routers that are used to construct the foundations of these networks be resilient to component and software outages.

For high availability configuration information, refer to [Synchronization and Redundancy on page 258](#).

## HA Features

As more and more critical commercial applications move onto the IP/MPLS networks, providing high availability services becomes increasingly important. This section describes high availability features for routers. Control Processor Modules .

- [Redundancy on page 252](#)
    - [Software Redundancy on page 252](#)
    - [Configuration Redundancy on page 253](#)
    - [Component Redundancy on page 253](#)
    - [Service Redundancy on page 254](#)
    - [Accounting Configuration Redundancy on page 254](#)
  - [Nonstop Forwarding on page 255](#)
  - [Nonstop Routing \(NSR\) on page 255](#)
  - [CPM Switchover on page 256](#)
  - [Synchronization on page 257](#)
    - [Configuration and boot-env Synchronization on page 257](#)
    - [State Database Synchronization on page 257](#)
- 

## Redundancy

The redundancy features enable the duplication of data elements and software functionality to maintain service continuation in case of outages or component failure.

---

## Software Redundancy

Software outages are challenging even when baseline hardware redundancy is in place. There should be a balance to provide high availability routing otherwise router problems typically propagate not only throughout the service provider network, but also externally to other connected networks possibly belonging to other service providers. This could affect customers on a broad scale. Presently, there are several software availability features that contribute to the percentage of time that a router is available to process and forward traffic.

To fully appreciate high availability you should realize that all routing protocols specify minimum time intervals in which the peer device must receive an acknowledgement before it disconnects the session.

- OSPF default session timeout is approximately 40 seconds. The timeout intervals are

configurable.

- BGP default session timeout is approximately 120 seconds. The timeout intervals are configurable.

Therefore, router software has to recover faster than the specified time interval to maintain up time.

---

## Configuration Redundancy

Features configured on the active device CPM are saved on the standby CPM as well. When the active device CPM fails, these features are brought up on the standby device CPM that takes over the mastership.

Even with modern modular and stable software, the failure of route processor hardware or software can cause the router to reboot or cause other service impacting events. In the best circumstances, failure leads to the initialization of a redundant route processor, which hosts the standby software configuration, to become the active processor. The following options are available.

- Warm standby — The router image and configuration is already loaded on the standby route processor. However, the standby could still take a few minutes to become effective since it must first re-initialize connections by bringing up Layer 2 connections and Layer 3 routing protocols and then rebuild routing tables.
  - Hot standby — The router image, configuration, and network state is already loaded on the standby and it receives continual updates from the active route processor and the sw takeover is immediate. However, hot standby affects conventional router performance as more frequent synchronization increases consumption of system resources. Newer generation service routers, like the SR OS routers, address this issue because they already have extra processing built into the system.
- 

## Component Redundancy

7950 SR-Series component redundancy is critical to reduce MTTR for the system and primarily consists of the following router features:

- Dual route processor modules — For a highly available architecture, redundant route processors (RPs) or Control Processor Modules (CPMs) are essential. The route processor calculates the most efficient route to an Internet destination and communicates the best path information to peer routers. Rapid information synchronization between the primary and secondary route processor is crucial to minimize recovery time.
- switch fabric (SFM) redundancy — Failover to the backup switch fabric within a minimum time interval, preferably with no loss of traffic.

- Redundant line cards — Failover to the backup within a minimum time interval, preferably with no loss of traffic.
- Redundant power supply — A power module can be removed without impact on traffic.
- Redundant fan — Failure of a fan module without impacting traffic.
- Hot swap — Components in a live system can be replaced or become active without taking the system down or affecting traffic flow to/from other modules.

Router hardware architecture plays a key role in the availability of the system. The principle router architecture styles are centralized and distributed. In these architectures, both active and standby route processors, XCMs and XMAs (also called line cards), fans, and power supplies maintain a low MTTR for the routing system.

However, in a centralized architecture, packet processing and forwarding is performed in a central shared route processor and the individual line cards are relatively simple. The cards rely solely on the route processor for routing and forwarding intelligence and, should the centralized route processor fail, there is greater impact to the system overall, as all routing and packet forwarding will stop.

In a distributed system, the packet forwarding functionality is situated on each line card. Distributing the forwarding engines off the central route processor and positioning one on each line card lowers the impact of route processor failure as the line cards can continue to forward traffic during an outage.

The distributed system is better suited to enable the convergence of business critical services such as real-time voice (VoIP), Video, and VPN applications over IP networks with superior performance and scalability. The centralized architecture can be prone to performance bottleneck issues and limits service offerings through poor scalability which may lead to customer and service SLA violations.

---

### **Service Redundancy**

All service-related statistics are kept during a switchover. Services, SDPs, and SAPs will remain up with a minimum loss of forwarded traffic during a CPM switchover.

---

### **Accounting Configuration Redundancy**

When there is a switchover and the standby CPM becomes active, the accounting servers will be checked and if they are administratively up and capable of coming online (media present, etc.), the standby will be brought online and new accounting files will be created at that point. Users must manually copy the accounting records from the failed CPM.

## Nonstop Forwarding

In a control plane failure or a forced switchover event, the router continues to forward packets using the existing stale forwarding information. Nonstop forwarding requires clean control plane and data plane separation. Usually the forwarding information is distributed to the XCMs/XMAs.

Nonstop forwarding is used to notify peer routers to continue forwarding and receiving packets, even if the route processor (control plane) is not working or is in a switch-over state. Nonstop forwarding requires clean control plane and data plane separation and usually the forwarding information is distributed to the line cards. This method of availability has both advantages and disadvantages. Nonstop forwarding continues to forward packets using the existing stale forwarding information during a failure. This may cause routing loops and black holes, and also requires that surrounding routers adhere to separate extension standards for each protocol. Every router vendor must support protocol extensions for interoperability.

---

## Nonstop Routing (NSR)

With NSR on the 7950 XRS-Series routers devices, routing neighbors are unaware of a routing process fault. If a fault occurs, a reliable and deterministic activity switch to the inactive control complex occurs such that routing topology and reachability are not affected, even in the presence of routing updates. NSR achieves high availability through parallelization by maintaining up to date routing state information, at all times, on the standby route processor. This capability is achieved independently of protocols or protocol extensions, providing a more robust solution than graceful restart protocols between network routers.

The NSR implementation on the 7950 XRS-Seriesrouters supports all routing protocols. NSR makes it possible to keep the existing sessions (BGP,LDP, OSPF, etc.) during a CPM switchover, including support for MPLS signaling protocols. Peers will not see any change.

Protocol extensions are not required. There are no interoperability issues and there is no need to define protocol extensions for every protocol. Unlike nonstop forwarding and graceful restart, the forwarding information in NSR is always up to date, which eliminates possible blackholes or forwarding loops.

Traditionally, addressing high availability issues have been patched through non-stop forwarding solutions. With the implementation of NSR, these limitations are overcome by delivering an intelligent hitless failover solution. This enables a carrier-class foundation for transparent networks, required to support business IP services backed by stringent SLAs. This level of high availability poses a major issue for conventional routers whose architectural design limits or prevents them from implementing NSR.

## CPM Switchover

During a switchover, system control and routing protocol execution are transferred from the active to the standby CPM

An automatic switchover may occur under the following conditions:

- A fault condition that causes the active CPM to crash or reboot.
- The active CPM is declared down (not responding).
- Online removal of the active CPM

A manual switchover can occur under the following conditions:

- To force a switchover from an active CPM to a standby, use the `admin redundancy force-switchover` command. You can configure a batch file that executes after failover by using the **config system switchover-exec** and **admin redundancy force-switchover now** CLI commands.

## Synchronization

Synchronization between the CPMs includes the following:

- [Configuration and boot-env Synchronization on page 257](#)
  - [State Database Synchronization on page 257](#)
- 

### Configuration and boot-env Synchronization

Configuration and boot-env synchronization are supported in **admin>redundancy> synchronize and config>redundancy>synchronize** contexts.

---

### State Database Synchronization

If a new standby CPM is inserted into the system, it synchronizes with the active CPM upon a successful boot process.

If the standby CPM is rebooted, it synchronizes with the active CPM upon a successful boot process.

When configuration or state changes occur, an incremental synchronization is conducted from the active CPM to the standby CPM.

If the synchronization fails, the standby does not reboot automatically. The **show redundancy synchronization** command displays synchronization output information.

If the active and standby are not synchronized for some reason, users can manually synchronize the standby CPM by rebooting the standby by issuing the **admin reboot standby** command on the active or the standby CPM.

## Synchronization and Redundancy

7950 SR-Series routers supporting redundancy use a 1:1 redundancy scheme. Redundancy methods facilitate system synchronization between the active and standby Control Processor Modules (CPMs) so they maintain identical operational parameters to prevent inconsistencies in the event of a CPM failure.

When automatic system synchronization is enabled for an entity, any save or delete file operations configured on the primary, secondary or tertiary choices on the active CPM file system are mirrored in the standby CPM file system.

Although software configurations and images can be copied or downloaded from remote locations, synchronization can only occur locally between compact flash drives (cf1:, cf2:, and cf3:).

Synchronization can occur either:

- Automatically — Automatic synchronization is disabled by default. To enable automatic synchronization, the **config>redundancy>synchronization** command must be specified with either the **boot-env** parameter or the `config` parameter.

When the **boot-env** parameter is specified, the BOF, boot.ldr, config, and image files are automatically synchronized. When the `config` parameter is specified, only the config files are automatically synchronized.

Automatic synchronization also occurs whenever the BOF is modified and when an `admin>save` command is entered with no filename specified.

- Manually — To execute synchronization manually, the **admin>redundancy>synchronization** command must be entered with the **boot-env** parameter or the **config** parameter.

When the **boot-env** parameter is specified, the BOF, boot.ldr, config, and image files are synchronized. When the **config** parameter is specified, only the config files are synchronized.

The following shows the output displayed during a manual synchronization of configuration files.

```
A:ALA-12>admin>redundancy# synchronize config
Syncing configuration.....

Syncing configuration.....Completed.
A:ALA-12#
```

## Active and Standby Designations

Typically, the first CPM card installed in a 7950 XRS chassis assumes the role as active, regardless of being inserted in Slot A or B. The next CPM installed in the same chassis then assumes the role as the standby CPM. If two CPM are inserted simultaneously (or almost simultaneously) and are booting at the same time, then preference is given to the CPM installed in Slot A.

If only one CPM is installed in a redundant router device, then it becomes the active CPM regardless of the slot it is installed in.

Status The Status LED on the second CPM faceplate is lit amber to indicate the standby designation. To visually determine the active and standby designations, see the LED displays on the CPM front panel as shown in [Figure 11](#).



**Figure 11: CPM LEDs**

For status and detailed description of CPM LEDs, see [Table 23](#).

**Table 23: CPM LEDs**

Key	Label	Color/State	Description
1	Status	Green (solid)	Completed boot/load process and operating as the <i>Primary</i> CPM.
		Blue (solid)	Completed boot/load process and operating as the <i>Secondary</i> CPM.
		Blue (slow blinking)	Running CPU diagnostics and loading firmware
		Blue (rapid blinking)	running full POST/Diagnostics
		Red (solid)	Card failure

**Table 23: CPM LEDs (Continued)**

Key	Label	Color/State	Description
2	Esata port	Blue	
3	Link/Act	Green (solid)	Valid communications link established
		Green (blinking)	Port active and receiving or transmitting data
		Amber (fast blinking)	Loopback
		Amber (slow blinking)	Administratively up, but no optic module installed
		Amber (solid)	Optics installed, but no link present or LOS
		Unlit	Laser disabled or port shut down

The following output shows that the CPM installed in Slot A is acting as the active CPM and the CPM installed in Slot B is acting as the standby.

```
*A:7950 XRS-20# show card
=====
Card Summary
=====
Slot   Provisioned Type           Admin Operational  Comments
       Equipped Type (if different) State State
-----
1      xcm-x20                    up   provisioned
A      cpm-x20                    up   up/active
B      cpm-x20                    up   up/standby
=====
```

The following console message displays when a CPM boots, sees an active CPM, and becomes the standby CPM.

```
...
Slot A contains the Active CPM

This CPM (Slot B) is the Standby CPM
```

## When the Active CPM Goes Offline

When an active CPM goes offline (due to reboot, removal, or failure), the standby CPM takes control without rebooting or initializing itself. It is assumed that the CPMs are synchronized, therefore, there is no delay in operability. When the CPM that went offline boots and then comes back online, it becomes the standby CPM.

When the standby CPM comes online, the following output displays:

```
Active CPM in Slot A has stopped  
Slot B is now active CPM
```

```
Attempting to exec configuration file:  
'cf3:/config.cfg' ...
```

```
...
```


```
Executed 49,588 lines in 8.0 seconds from file cf3:\config.cfg
```

## OOB Management Ethernet Port Redundancy

The SR OS platform provides a resilient out-of-band (OOB) management Ethernet redundancy mode for system management.


When the management Ethernet port is down on the active CPM, the OOB Ethernet redundancy feature allows the active CPM to use the management Ethernet port of the standby CPM, as shown in [Figure 13](#) and [Figure 14](#)

OOB management Ethernet port redundancy is enabled using the **configure>redundancy>mgmt-ethernet-redundancy** command.



25169

**Figure 12: Management Ethernet: Normal Mode**



25168


**Figure 13: Management Ethernet: Redundancy Mode (FID 120 placeholder)**

# Network Synchronization

This section describes network synchronization capabilities available on SR OS platforms. These capabilities involve multiple approaches to network timing; namely Synchronous Ethernet, and BITS. These features address barriers to entry by:

- Providing synchronization quality required by the mobile space; such as radio operations and circuit emulation services (CES) transport.
- Augmenting and potentially replacing the existing (SONET/SDH) timing infrastructure and delivering high quality network timing for time sensitive applications in the wireline space.

Network synchronization is commonly distributed in a hierarchical master-slave topology at the physical layer as shown in [Figure 14](#).



**Figure 14: Conventional Network Timing Architecture (North American Nomenclature)**

The architecture shown in [Figure 14](#) provides the following benefits:

- Limits the need for high quality clocks at each network element and only requires that they reliably replicate input to remain traceable to its reference.
- Uses reliable physical media to provide transport of the timing signal; it doesn't consume any bandwidth and requires limited additional processing.

The synchronization network is designed so a clock always receives timing from a clock of equal or higher stratum or quality level. This ensures that if an upstream clock has a fault condition (for example, loses its reference and enters a holdover or free-run state) and begins to drift in frequency, the downstream clock will be able to follow it. For greater reliability and robustness, most offices and nodes have at least two synchronization references that can be selected in priority order (such as primary and secondary).

Further levels of resiliency can be provided by designing a capability in the node clock that will operate within prescribed network performance specifications without any reference for a specified time-frame. A clock operating in this mode is said to hold the last known state over (or holdover) until the reference lock is once again achieved. Each level in the timing hierarchy is associated with minimum levels of network performance.

Each synchronization capable port can be independently configured to transmit data using the node reference timing or loop timing. In addition, some TDM channels can use adaptive timing.

Transmission of a reference clock through a chain of Ethernet equipment requires that all equipment supports Synchronous Ethernet. A single piece of equipment that is not capable of performing Synchronous Ethernet breaks the chain. Ethernet frames will still get through but downstream devices should not use the recovered line timing as it will not be traceable to an acceptable stratum source.

---

## Central Synchronization Sub-System

The timing subsystem for the platforms has a central clock located on the CPM (motherboard). The timing subsystem performs many of the duties of the network element clock as defined by Telcordia (GR-1244-CORE) and ITU-T G.781.

The system can select from up to three timing inputs to train the local oscillator. The priority order of these references must be specified. This is a simple ordered list of inputs: {bits, ref1, ref2}. The CPM clock output shall have the ability to drive the clocking for all line cards in the system. The routers support selection of the node reference using Quality Level (QL) indications. The recovered clock will be able to derive its timing from any of the following:

- Synchronous Ethernet ports
- BITS port on the CCM module
- 10GE ports in WAN PHY mode

The BITS ports accept T1 or E1 signal formats.

BITS input port on CCM A is used by the central clock module on CPM A and BITS input port on CCM B is used by the central clock module on CPM B.

All settings of the signal characteristics for the BITS input applies to both ports.

The BITS output ports can be configured to provided either the unfiltered recovered line clock from a SR/ESS port or the output of the central clock of the 7750 SR. The first case would be used if the port was connected to deliver an input reference directly to dedicated timing device in the facility (BITS or SASE device). The second case would be used to test the quality of the clocking used by the 7750 SR.

When QL selection mode is disabled, then the reversion setting controls when the central clock can re-select a previously failed reference.

The [Table 24](#) shows the selection followed for two reference in both revertive and non-revertive modes:

**Table 24: Revertive, non-Revertive Timing Reference Switching Operation**

Status of Reference A	Status of Reference B	Active Reference Non-revertive Case	Active Reference Revertive Case
OK	OK	A	A
Failed	OK	B	B
OK	OK	B	A
OK	Failed	A	A
OK	OK	A	A
Failed	Failed	holdover	holdover
OK	Failed	A	A
Failed	Failed	holdover	holdover
Failed	OK	B	B
Failed	Failed	holdover	holdover
OK	OK	A or B	A

## 7950 XRS-40 Extension Chassis Central Clocks

The central clock architecture described above applies to each chassis of the 7950 XRS-40. There is a central clock located on each of the CPMs present in the extension chassis. However, there is no configuration for the central clocks on the CPMs of the extension chassis. The central clocks only use the BITS input ports of the extension chassis for their input reference. It is assumed that the quality of the reference provided into the BITS input ports of the extension chassis CPMs is equal to the quality of the Master chassis central clocks. See the installation guide for appropriate physical cabling to support this architecture.

## Synchronization Status Messages (SSM)

SSM provides a mechanism to allow the synchronization distribution network to both determine the quality level of the clock sourcing a given synchronization trail and to allow a network element to select the best of multiple input synchronization trails. Synchronization Status messages have been defined for various transport protocols including T1/E1, and Synchronous Ethernet, for interaction with office clocks, such as BITS or SSUs and embedded network element clocks.

SSM allows equipment to autonomously provision and reconfigure (by reference switching) their synchronization references, while helping to avoid the creation of timing loops. These messages are particularly useful to allow synchronization reconfigurations when timing is distributed in both directions around a ring.

---

### DS1 Signals

DS1 signals can carry an indication of the quality level of the source generating the timing information using the SSM transported within the 1544 Kbit/s signal's Extended Super Frame (ESF) Data Link (DL) as specified in Recommendation G.704. No such provision is extended to SF formatted DS1 signals.

The format of the data link messages in ESF frame format is "0xxx xxx0 1111 1111", transmitted rightmost bit first. The six bits denoted "xxx xxx" contain the actual message; some of these messages are reserved for synchronization messaging. It takes 32 frames (such as 4 ms) to transmit all 16 bits of a complete DL.

---

### E1 Signals

E1 signals can carry an indication of the quality level of the source generating the timing information using the SSM as specified in Recommendation G.704.

One of the Sa4 to Sa8 bits, (the actual Sa bit is for operator selection), is allocated for Synchronization Status Messages. To prevent ambiguities in pattern recognition, it is necessary to align the first bit (San1) with frame 1 of a G.704 E1 multi-frame.

The numbering of the San (n = 4, 5, 6, 7, 8) bits. A San bit is organized as a 4-bit nibble San1 to San4. San1 is the most significant bit; San4 is the least significant bit.

The message set in San1 to San4 is a copy of the set defined in SDH bits 5 to 8 of byte S1.

## Synchronous Ethernet

Traditionally, Ethernet-based networks employ the physical layer transmitter clock to be derived from an inexpensive +/-100ppm crystal oscillator and the receiver locks onto it. There is no need for long term frequency stability because the data is packetized and can be buffered. For the same reason there is no need for consistency between the frequencies of different links. However, you can derive the physical layer transmitter clock from a high quality frequency reference by replacing the crystal with a frequency source traceable to a primary reference clock. This would not effect the operation of any of the Ethernet layers, for which this change would be transparent. The receiver at the far end of the link would lock onto the physical layer clock of the received signal, and thus itself gain access to a highly accurate and stable frequency reference. Then, in a manner analogous to conventional hierarchical master-slave network synchronization, this receiver could lock the transmission clock of its other ports to this frequency reference and a fully time synchronous network could be established.

The advantage of using Synchronous Ethernet, compared with methods that rely on sending timing information in packets over an unlocked physical layer, is that it is not influenced by impairments introduced by the higher levels of the networking technology (packet loss, packet delay variation). Hence, the frequency accuracy and stability may be expected to exceed those of networks with unsynchronized physical layers.

Synchronous Ethernet allows operators to gracefully integrate existing systems and future deployments into conventional industry-standard synchronization hierarchy. The concept behind synchronous Ethernet is analogous to SONET/SDH system timing capabilities. It allows the operator to select any (optical) Ethernet port as a candidate timing reference. The recovered timing from this port will then be used to time the system (for example, the CPM will lock to this provisioned reference selection). The operator then could ensure that any of system output would be locked to a stable traceable frequency source.

If the port is a fixed copper Ethernet port and in 1000BASE-T mode of operation, there is a dependency on the 802.3 link timing for the Synchronous Ethernet functionality (refer to ITU-T G.8262). The 802.3 link Master-Slave timing states must align with the desired direction of Synchronous Ethernet timing flow. When a fixed copper Ethernet port is specified as an input reference for the node or when it is removed as an input reference for the node, an 802.3 link auto-negotiation is triggered to ensure the link timing aligns properly.

The SSM of Synchronous Ethernet uses an Ethernet OAM PDU that uses the slow protocol subtype. For a complete description of the format and processing see ITU-T G.8264

## Clock Source Quality Level Definitions

The following clock source quality levels have been identified for the purpose of tracking network timing flow. These levels make up all of the defined network deployment options given in Recommendation G.803 and G.781. The Option I network is a network developed on the original European SDH model; whereas, the Option II network is a network developed on the North American SONET model.

In addition to the QL values received over SSM of an interface, the standards also define additional codes for internal use. These include the following:


- QL INV<sub>x</sub> is generated internally by the system if and when an unallocated SSM value is received, where x represents the binary value of this SSM. Within the all these independent values are assigned as the singled value of QL-INVALID.
- QL FAILED is generated internally by the system if and when the terminated network synchronization distribution trail is in the signal fail state.

Within the , there is also an internal quality level of QL-UNKNOWN. This is used to differentiate from a received QL-STU code but is equivalent for the purposes of QL selection.

the external clocks are labeled 'peers'. There shows the relationship of various neighbor clocks using unicast IP sessions to communicate with a 7750 SR configured as a boundary clock with two configured peers.

## Clock Source Quality Level Definitions

shows the relationship of various neighbor clocks using multicast Ethernet sessions to a 7750 SR



configured as a boundary clock. The 7750 SR has three ports configured for multicast Ethernet communications. Port 1/2/1 of the 7750 SR shows a connection where there are two neighbor clocks connecting to one port of the 7750 SR through an end-to-end transparent clock.

## Link Layer Discovery Protocol (LLDP)

The IEEE 802.1ab Link Layer Discovery Protocol (LLDP) is a uni-directional protocol that uses the MAC layer to transmit specific information related to the capabilities and status of the local device. Separately from the transmit direction, the LLDP agent can also receive the same kind of information for a remote device which is stored in the related MIBs.

LLDP itself does not contain a mechanism for soliciting specific information from other LLDP agents, nor does it provide a specific means of confirming the receipt of information. LLDP allows the transmitter and the receiver to be separately enabled, making it possible to configure an implementation so the local LLDP agent can either transmit only or receive only, or can transmit and receive LLDP information.

The information fields in each LLDP frame are contained in a LLDP Data Unit (LLDPDU) as a sequence of variable length information elements, that each include type, length, and value fields (known as TLVs), where:

- Type identifies what kind of information is being sent.
- Length indicates the length of the information string in octets.
- Value is the actual information that needs to be sent (for example, a binary bit map or an alphanumeric string that can contain one or more fields).

Each LLDPDU contains four mandatory TLVs and can contain optional TLVs as selected by network management:

- Chassis ID TLV
- Port ID TLV
- Time To Live TLV
- Zero or more optional TLVs, as allowed by the maximum size of the LLDPDU
- End Of LLDPDU TLV

The chassis ID and the port ID values are concatenated to form a logical identifier that is used by the recipient to identify the sending LLDP agent/port. Both the chassis ID and port ID values can be defined in a number of convenient forms. Once selected however, the chassis ID/port ID value combination remains the same as long as the particular port remains operable.

A non-zero value in the TTL field of the time-to-live TLV tells the receiving LLDP agent how long all information pertaining to this LLDPDU's identifier will be valid so that all the associated information can later be automatically discarded by the receiving LLDP agent if the sender fails to update it in a timely manner. A zero value indicates that any information pertaining to this LLDPDU's identifier is to be discarded immediately.


## Link Layer Discovery Protocol (LLDP)

Note that a TTL value of zero can be used, for example, to signal that the sending port has initiated a port shutdown procedure.

The end of a LLDPDU TLV marks the end of the LLDPDU.

The IEEE 802.1ab standard defines a protocol that:


- Advertises connectivity and management information about the local station to adjacent stations on the same IEEE 802 LAN.
- Receives network management information from adjacent stations on the same IEEE 802 LAN.
- Operates with all IEEE 802 access protocols and network media.
- Establishes a network management information schema and object definitions that are suitable for storing connection information about adjacent stations.
- Provides compatibility with a number of MIBs as depicted in [Figure 15](#).



**Figure 15: LLDP Internal Architecture for a Network Node**

Network operators must be able to discover the topology information in order to detect and address network problems and inconsistencies in the configuration. Moreover, standard-based

tools can address the complex network scenarios where multiple devices from different vendors are interconnected using Ethernet interfaces.



**Figure 16: Customer Use Example For LLDP**

The example displayed in [Figure 16](#) depicts a MPLS network that uses Ethernet interfaces in the core or as an access/hand off interfaces to connect to different kind of Ethernet enabled devices such as service gateway/routers, QinQ switches, DSLAMs or customer equipment.

IEEE 802.1ab LLDP running on each Ethernet interfaces in between all the above network elements may be used to discover the topology information.

## IP Hashing as an LSR

It is now possible to include IP header in the hash routine at an LSR for the purpose of spraying labeled-IPv4 and labeled-IPv6 packets over multiple equal cost paths in ECMP in an LDP LSP and/or over multiple links of a LAG group in all types of LSPs.

A couple of configurable options are supported. The first option is referred to as the "Label-IP Hash" option and is designated in the CLI as the "lbl-ip" option. When enabled, the hash algorithm parses down the label stack and once it hits the bottom of the stack, it checks the next nibble. If the nibble value is four (4) or six (6) then it will assume it is an IPv4 or IPv6 packet. The result of the hash of the label stack, along with the incoming port and system IP address, is fed into another hash along with source and destination address fields in the IP packet's header. The second option is referred to as "IP-only hash" and is enabled in CLI by entering the "iponly" keyword. It operates the same way as the "Label-IP Hash" method except the hash is performed exclusively on the source and destination address fields in the IP packet header. This method supports both IPv4 and IPv6 payload and operates on packets received on an IP interface on an IOM3-XP/IMM port only.

By default, MPLS packet hashing at an LSR is based on the whole label stack, along with the incoming port and system IP address. This method is referred to as "Label-Only Hash" option and is enabled in CLI by entering the "lbl-only" keyword.

The "lbl-only", "lbl-ip" and "ip-only" hashing options can be configured system-wide and can also be overridden on a per IP interface basis. They are supported on 7750 SR-7/12 and 7450 ESS-6/6v/7/12 with all chassis modes as well as in 7750 SR-c4/c12.

**Note:** The "ip-only" option and the IPv6 payload support with the "lbl-ip" option can only be enabled on IP interfaces on IOM3/IMM ports.

## Administrative Tasks

This section contains information to perform administrative tasks.

- [Saving Configurations on page 276](#)
- [Network Timing on page 278](#)



**NOTE:** The iom-20g is not supported from 5.0R and later but chassis mode A is described for backwards compatibility purposes.

## Saving Configurations

Whenever configuration changes are made, the modified configuration must be saved so they will not be lost when the system is rebooted.

Configuration files are saved by executing explicit command syntax which includes the file URL location to save the configuration file as well as options to save both default and non-default configuration parameters. Boot option file (BOF) parameters specify where the system should search for configuration and image files as well as other operational parameters during system initialization.

For more information about boot option files, refer to the *Boot Option Files* section of this manual.

## Specifying Post-Boot Configuration Files

Two post-boot configuration extension files are supported and are triggered when either a successful or failed boot configuration file is processed. The **boot-bad-exec** and **boot-good-exec** commands specify URLs for the CLI scripts to be run following the completion of the boot-up configuration. A URL must be specified or no action is taken.

For example, after a configuration file is successfully loaded, the specified URL can contain a nearly identical configuration file with certain commands enabled or disabled, or particular parameters specified and according to the script which loads that file.

## Network Timing

In Time Domain Multiplexed (TDM)-based networks (for example, SONET or SDH circuit-switched networks), the concept of network timing is used to prevent over-run or under-run issues where circuits are groomed (rebundled) and switched. Hardware exists in each node that takes a common clock derived from an internal oscillator, a specific receive interface and provides it to each synchronous interface in the system. Usually, each synchronous interface is allowed to choose between using the chassis-provided clock or the clocking recovered from the received signal on the interface. The clocking is used to drive the transmit side of the interface. The appropriate configuration at each node which defines how interface clocking is handled must be considered when designing a network that has a centralized timing source so each interface is operating in a synchronous manner.

The effect of timing on a network is dependent on the nature of the type of traffic carried on the network. With bit-wise synchronous traffic (traditional circuit-based voice or video), non-synchronous transmissions cause a loss of information in the streams affecting performance. With packet-based traffic, the applications expect and handle jitter and latency inherent to packet-based networks. When a packet-based network is used to carry voice or video traffic, the applications use data compression and elasticity buffering to compensate for jitter and latency. The network itself relies on appropriate Quality of Service (QoS) definitions and network provisioning to further minimize the jitter and latency the application may experience.

## Automatic Synchronization

Use the CLI syntax displayed below to configure synchronization components relating to active-to-standby CPM switchover. In redundant systems, synchronization ensures that the active and standby CPMs have identical operational parameters, including the active configuration, CPM, and XCM images in the event of a failure or reset of the active CPM.

The **force-switchover** command forces a switchover to the standby CPM. To enable automatic synchronization, either the **boot-env** parameter or the **config** parameter must be specified. The synchronization occurs when the **admin save** or **bof save** commands are executed.

When the **boot-env** parameter of the **synchronize** command is specified, the bof.cfg, primary/secondary/tertiary configuration files (.cfg and .ndx), li, and ssh files are automatically synchronized. When the **config** parameter is specified, only the configuration files are automatically synchronized.

Synchronization also occurs whenever the BOF is modified and when an **admin>save** command is entered with no filename specified.

---

### Boot-Env Option

The **boot-env** option enables a synchronization of all the files used in system initialization.

When configuring the system to perform this synchronization, the following occurs:

1. The BOF used during system initialization is copied to the same compact flash on the standby CPM (in redundant systems).  
**Note:** The synchronization parameters on the standby CPM are preserved.
  2. The primary, secondary, and tertiary images, (provided they are locally stored on the active CPM) are copied to the same compact flash on the standby CPM.
  3. The primary, secondary, and tertiary configuration files, (provided they are locally stored on the active CPM) are copied to the same compact flash on the standby CPM.
- 

### Config Option

The **config** option synchronizes configuration files by copying the files specified in the active CPM BOF file to the same compact flash on the standby CPM

## Manual Synchronization

The **admin redundancy synchronize** command performs manual CPM synchronizations. The **boot-env** parameter synchronizes the BOF, image, and configuration files in redundant systems. The **config** parameter synchronizes only the configuration files in redundant systems.

---

## Forcing a Switchover

The **force-switchover now** command forces an immediate switchover to the standby CPMcard.

If the active and standby are not synchronized for some reason, users can manually synchronize the standby CPM by rebooting the standby by issuing the **admin reboot standby** command on the active or the standby CPM.

# System Configuration Process Overview

Figure 17 displays the process to provision basic system parameters.




Figure 17: System Configuration and Implementation Flow

## Configuration Notes

This section describes system configuration caveats.

---

### General

The system must be properly initialized and the boot loader and BOF files successfully executed in order to access the CLI.

# Configuring System Management with CLI

This section provides information about configuring system management features with CLI.

Topics in this chapter include:

- [Basic System Configuration on page 285](#)
- [Common Configuration Tasks on page 286](#)
- [System Information on page 287](#)
  - [System Information Parameters](#)
    - [Name on page 288](#)
    - [Contact on page 288](#)
    - [Location on page 289](#)
    - [CLLI Code on page 289](#)
    - [Coordinates on page 290](#)
  - [System Time Elements on page 291](#)
    - [Zone on page 291](#)
    - [Summer Time Conditions on page 293](#)
    - [NTP on page 294](#)
    - [SNTP on page 300](#)
    - [CRON on page 302](#)
  - [Configuring Synchronization and Redundancy on page 312](#)
    - [Configuring Synchronization on page 312](#)
    - [Configuring Manual Synchronization on page 313](#)
    - [Forcing a Switchover on page 313](#)
    - [Configuring Synchronization Options on page 314](#)
- [Post-Boot Configuration Extension Files on page 318](#)
- [System Timing on page 321](#)
  - [Edit Mode on page 322](#)
  - [Configuring Timing References on page 323](#)
  - [Using the Revert Command on page 324](#)
  - [Other Editing Commands on page 325](#)
  - [Forcing a Specific Reference on page 326](#)
- [Configuring System Monitoring Thresholds on page 327](#)
- [Configuring LLDP on page 330](#)

# System Management

---

## Saving Configurations

Whenever configuration changes are made, the modified configuration must be saved so the changes will not be lost when the system is rebooted. The system uses the configuration and image files, as well as other operational parameters necessary for system initialization, according to the locations specified in the boot option file (BOF) parameters. For more information about boot option files, refer to the *Boot Option Files* section of this manual.

Configuration files are saved by executing *implicit* or *explicit* command syntax.

- An *explicit* save writes the configuration to the location specified in the `save` command syntax (the *file-url* option).
- An *implicit* save writes the configuration to the file specified in the primary configuration location.

If the *file-url* option is not specified in the `save` command syntax, the system attempts to save the current configuration to the current BOF primary configuration source. If the primary configuration source (path and/or filename) changed since the last boot, the new configuration source is used.

The `save` command includes an option to save both default and non-default configuration parameters (the *detail* option).

The *index* option specifies that the system preserves system indexes when a save command is executed, regardless of the persistent status in the BOF file. During a subsequent boot, the index file is read along with the configuration file. As a result, a number of system indexes are preserved between reboots, including the interface index, LSP IDs, path IDs, etc. This reduces resynchronizations of the Network Management System (NMS) with the affected network element.

If the save attempt fails at the destination, an error occurs and is logged. The system does not try to save the file to the secondary or tertiary configuration sources unless the path and filename are explicitly named with the `save` command.

## Basic System Configuration

This section provides information to configure system parameters and provides configuration examples of common configuration tasks. The minimal system parameters that should be configured are:

- [System Information Parameters on page 288](#)
  - [System Time Elements on page 291](#)
- 

The following example displays a basic system configuration:

```
A:ALA-12>config>system# info
#-----
echo "System Configuration "
#-----
      name "ALA-12"
      coordinates "Unknown"
      snmp
      exit
      security
          snmp
              community "private" rwa version both
          exit
      exit
      time
          ntp
              server 192.168.15.221
              no shutdown
          exit
          sntp
              shutdown
          exit
          zone GMT
      exit
#-----
A:ALA-12>config>system#
```

## Common Configuration Tasks

This section provides a brief overview of the tasks that must be performed to configure system parameters and provides the CLI commands.

- [System Information on page 287](#)
  - [Name on page 288](#)
  - [Contact on page 288](#)
  - [Location on page 289](#)
  - [CLLI Code on page 289](#)
  - [Coordinates on page 290](#)
- [System Time Elements on page 291](#)
  - [Zone on page 291](#)
  - [Summer Time Conditions on page 293](#)
  - [NTP on page 294](#)
  - [SNTP on page 300](#)
  - [CRON on page 302](#)
    - [Schedule on page 302](#)
    - [Time Range on page 302](#)
    - [Time of Day on page 306](#)
- [Synchronization and Redundancy on page 258](#)
  -
- [System Timing on page 321](#)
  - [Configuring Timing References on page 323](#)

## System Information

This section covers the basic system information parameters to configure the physical location of the SR-Series, contact information, location information such as the place the router is located such as an address, floor, room number, etc., global positioning system (GPS) coordinates, and system name.

Use the CLI syntax displayed below to configure the following system components:

- [System Information Parameters on page 288](#)
- [System Time Elements on page 291](#)

General system parameters include:

- [Name on page 288](#)
- [Contact on page 288](#)
- [Location on page 289](#)
- [CLLI Code on page 289](#)
- [Coordinates on page 290](#)

## System Information Parameters

---

### Name

Use the **system** command to configure a name for the device. The name is used in the prompt string. Only one system name can be configured, if multiple system names are configured the last one encountered overwrites the previous entry. Use the following CLI syntax to configure the system name:

**CLI Syntax:** `config>system  
                  name system-name`

**Example:** `alcatel>config>system# name ALA-12`

The following example displays the system name:

```
sysName@domain>config>system# info
#-----
echo "System Configuration "
#-----
          name "ALA-12"
. . . .
          exit
#-----
sysName@domain>config>system#
```

---

### Contact

Use the **contact** command to specify the name of a system administrator, IT staff member, or other administrative entity.

**CLI Syntax:** `config>system  
                  contact contact-name`

**Example:** `config>system# contact "Fred Information Technology"`

## Location

Use the **location** command to specify the system location of the device. For example, enter the city, building address, floor, room number, etc., where the router is located.

Use the following CLI syntax to configure the location:

**CLI Syntax:** `config>system  
                  location location`

**Example:** `config>system# location "Bldg.1-floor 2-Room 201"`

---

## CLLI Code

The Common Language Location Code (CLLI code) is an 11-character standardized geographic identifier that is used to uniquely identify the geographic location of a 7950 SR router.

Use the following CLI command syntax to define the CLLI code:

**CLI Syntax:** `config>system  
                  clli-code clli-code`

**Example:** `config>system# clli-code abcdefg1234`

## Coordinates

Use the optional **coordinates** command to specify the GPS location of the device. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

Use the following CLI syntax to configure the location:

**CLI Syntax:** `config>system  
                  coordinates coordinates`

**Example:** `config>system# coordinates "N 45 58 23, W 34 56 12"`

The following example displays the configuration output of the general system commands:

```
sysName@domain>config>system# info
#-----
echo "System Configuration "
#-----
      name "ALA-12"
      contact "Fred Information Technology"
      location "Bldg.1-floor 2-Room 201"
      clli-code "abcdefg1234"
      coordinates "N 45 58 23, W 34 56 12"

. . .
      exit
-----
A:ALA-12>config>system#
```

## System Time Elements

The system clock maintains time according to Coordinated Universal Time (UTC). Configure information time zone and summer time (daylight savings time) parameters to correctly display time according to the local time zone.

Time elements include:

- [Zone on page 291](#)
- [Summer Time Conditions on page 293](#)
- [NTP on page 294](#)
- [SNTP on page 300](#)
- [CRON on page 302](#)
  - [Time Range on page 302](#)
  - [Time of Day on page 306](#)

## Zone

The **zone** command sets the time zone and/or time zone offset for the router. The router supports system-defined and user-defined time zones. The system-defined time zones are listed in [Table 25](#).

**CLI Syntax:** `config>system>time`  
`zone std-zone-name | non-std-zone-name [hh [:mm]]`

**Example:** `config>system>time#`  
`config>system>time# zone GMT`

The following example displays the zone output:

```
A:ALA-12>config>system>time# info
-----
ntp
    server 192.168.15.221
    no shutdown
exit
sntp
    shutdown
exit
zone UTC
-----
A:ALA-12>config>system>time#
```

**Table 25: System-defined Time Zones**

<b>Acronym</b>	<b>Time Zone Name</b>	<b>UTC Offset</b>
Europe:		
GMT	Greenwich Mean Time	UTC
WET	Western Europe Time	UTC
WEST	Western Europe Summer Time	UTC +1 hour
CET	Central Europe Time	UTC +1 hour
CEST	Central Europe Summer Time	UTC +2 hours
EET	Eastern Europe Time	UTC +2 hours
EEST	Eastern Europe Summer Time	UTC +3 hours
MSK	Moscow Time	UTC +3 hours
MSD	Moscow Summer Time	UTC +4 hours
US and Canada:		
AST	Atlantic Standard Time	UTC -4 hours
ADT	Atlantic Daylight Time	UTC -3 hours
EST	Eastern Standard Time	UTC -5 hours
EDT	Eastern Daylight Saving Time	UTC -4 hours
CST	Central Standard Time	UTC -6 hours
CDT	Central Daylight Saving Time	UTC -5 hours
MST	Mountain Standard Time	UTC -7 hours
MDT	Mountain Daylight Saving Time	UTC -6 hours
PST	Pacific Standard Time	UTC -8 hours
PDT	Pacific Daylight Saving Time	UTC -7 hours
HST	Hawaiian Standard Time	UTC -10 hours
AKST	Alaska Standard Time	UTC -9 hours
AKDT	Alaska Standard Daylight Saving Time	UTC -8 hours
Australia and New Zealand:		
AWST	Western Standard Time (e.g., Perth)	UTC +8 hours
ACST	Central Standard Time (e.g., Darwin)	UTC +9.5 hours
AEST	Eastern Standard/Summer Time (e.g., Canberra)	UTC +10 hours
NZT	New Zealand Standard Time	UTC +12 hours
NZDT	New Zealand Daylight Saving Time	UTC +13 hours

## Summer Time Conditions

The **config>system>time>dst-zone** context configures the start and end dates and offset for summer time or daylight savings time to override system defaults or for user defined time zones.

When configured, the time will be adjusted by adding the configured offset when summer time starts and subtracting the configured offset when summer time ends.

**CLI Syntax:**

```
config>system>time
  dst-zone zone-name
    end {end-week} {end-day} {end-month} [hours-minutes]
    offset offset
    start {start-week} {start-day} {start-month} [hours-minutes]
```

**Example:**

```
config>system# time
config>system>time# dst-zone pt
config>system>time>dst-zone# start second sunday april 02:00
end first sunday october 02:00
config>system>time>dst-zone# offset 0
```

If the time zone configured is listed in [Table 25](#), then the starting and ending parameters and offset do not need to be configured with this command unless there is a need to override the system defaults. The command will return an error if the start and ending dates and times are not available either in [Table 25](#) or entered as optional parameters in this command.

The following example displays the configured parameters.

```
A:ALA-48>config>system>time>dst-zone# info
-----
start second sunday april 02:00
end first sunday october 02:00
offset 0
-----
A:ALA-48>config>system>time>dst-zone# offset 0
```

### NTP

Network Time Protocol (NTP) is defined in RFC 1305, *Network Time Protocol (Version 3) Specification, Implementation and Analysis* and RFC 5905, *Network Time Protocol Version 4: Protocol and Algorithms Specification*. It allows for participating network nodes to keep time more accurately and maintain time in a synchronized manner between all participating network nodes.

NTP time elements include:

- [Authentication-check on page 294](#)
- [Authentication-key on page 295](#)
- [Broadcast on page 295](#)
- [Broadcastclient on page 296](#)
- [Multicast on page 296](#)
- [Multicastclient on page 297](#)
- [NTP-Server on page 297](#)
- [Peer on page 298](#)
- [Server on page 299](#)

---

### Authentication-check

NTP supports an authentication mechanism to provide some security and access control to servers and clients. The default behavior when any authentication keys are configured is to reject all NTP protocol PDUs that have a mismatch in either the authentication key-id, type, or key. The authentication-check command provides for the options to skip or maintain this rejection of NTP PDUs that do not match the authentication requirements.

When authentication-check is configured, NTP PDUs are authenticated on receipt. However, mismatches cause a counter to be increased, one counter for key-id, one for type, and one for key value mismatches.

**CLI Syntax:** `config>system>time>ntp  
                  authentication-check`

**Example:** `config>system>time>ntp#  
config>system>time>ntp# authentication-check  
config>system>time>ntp# no shutdown`

## Authentication-key

The **authentication-key** command configures an authentication key-id, key type, and key used to authenticate NTP PDUs sent to and received from other network elements participating in the NTP protocol. For authentication to work, the authentication key-id, authentication type and authentication key value must match.

**CLI Syntax:** `config>system>time>ntp  
authentication-key key-id {key key} [hash | hash2] type  
{des|message-digest}`

**Example:** `config>system>time>ntp#  
config>system>time>ntp# authentication-key 1 key A type des  
config>system>time>ntp# no shutdown`

The following example shows NTP disabled with the `authentication-key` parameter enabled.

```
A:sim1>config>system>time>ntp# info
-----
                shutdown
                authentication-key 1 key "OAwgNULbZgI" hash2 type des
-----
A:sim1>config>system>time>ntp#
```

---

## Broadcast

The **broadcast** command is used to transmit broadcast packets on a given interface. Interfaces in the base routing context or the management interface may be specified. Due the relative ease of spoofing of broadcast messages, it is strongly recommended to use authentication with broadcast mode. The messages are transmitted using a destination address that is the NTP Broadcast address.

**CLI Syntax:** `config>system>time>ntp  
broadcast [router router-name] {interface  
ip-int-name} [key-id key-id] [version version]  
[ttl ttl]`

**Example:** `config>system>time>ntp#  
config>system>time>ntp# broadcast interface int11 version 4  
ttl 127  
config>system>time>ntp# no shutdown`

The following example in the `system>time` context shows NTP enabled with the `broadcast` command configured.

```
A:sim1>config>system>time# info detail
-----
                ntp
```

```
no shutdown
authentication-check
ntp-server
broadcast interface int11 version 4 ttl 127
exit
A:sim1>config>system>time#
```

---

## Broadcastclient

The **broadcastclient** command enables listening to NTP broadcast messages on the specified interface. Interfaces in the base routing context or the management interface may be specified. Due to the relative ease of spoofing of broadcast messages, it is strongly recommended to use authentication with broadcast mode. The messages must have a destination address of the NTP Broadcast address.

**CLI Syntax:** `config>system>time>ntp`  
`broadcastclient [router router-name] {interface`  
`ip-int-name} [authenticate]`

**Example:** `config>system>time>ntp#`  
`config>system>time>ntp# broadcastclient interface int11`  
`config>system>time>ntp# no shutdown`

The following example shows NTP enabled with the `broadcastclient` parameter enabled.

```
A:ALA-12>config>system>time# info
-----
ntp
  broadcastclient interface int11
  no shutdown
exit
-----
A:ALA-12>config>system>time#
```

---

## Multicast

When configuring NTP the node can be configured to transmit or receive multicast packets on the MGMT port. Broadcast & Multicast messages can easily be spoofed, therefore, authentication is strongly recommended. Multicast is used to configure the transmission of NTP multicast messages. The `no` construct of this command removes the transmission of multicast packets on the management port.

When transmitting multicast NTP messages the default address of 224.0.1.1 is used.

**CLI Syntax:** `config>system>time>ntp`  
`multicast [version version] [key-id key-id]`

**Example:** config>system>time>ntp#  
 config>system>time>ntp# multicast  
 config>system>time>ntp# no shutdown

The following example shows NTP enabled with the `multicast` command configured.

```
A:ALA-12>config>system>time# info
-----
server 192.168.15.221
multicast
no shutdown
-----
A:ALA-12>config>system>time#
```

---

## Multicastclient

The **multicastclient** command is used to configure an address to receive multicast NTP messages on the MGMT port. Broadcast & Multicast messages can easily be spoofed, therefore, authentication is strongly recommended. The `no` construct of this command removes the multicast client. If `multicastclient` is not configured, all NTP multicast traffic will be ignored.

**CLI Syntax:** config>system>time>ntp  
 multicastclient [authenticate]

**Example:** config>system>time>ntp#  
 config>system>time>ntp# multicastclient authenticate  
 config>system>time>ntp# no shutdown

The following example shows NTP enabled with the `multicastclient` command configured.

```
A:ALA-12>config>system>time# info
-----
server 192.168.15.221
multicastclient
no shutdown
-----
A:ALA-12>config>system>time##
```

---

## NTP-Server

The **ntp-server** command configures the node to assume the role of an NTP server. Unless the `server` command is used this node will function as an NTP client only and will not distribute the time to downstream network elements. If authentication is specified in this command, the NTP server requires client packets to be authenticated based on the key received in the client request.

**CLI Syntax:** config>system>time>ntp  
 ntp-server [authenticate]

## System Information

**Example:** config>system>time>ntp#  
config>system>time>ntp# ntp-server  
config>system>time>ntp# no shutdown

The following example shows NTP enabled with the `ntp-server` command configured.

```
A:sim1>config>system>time>ntp# info
-----
no shutdown
ntp-server
-----
A:sim1>config>system>time>ntp#
```

---

## Peer

Configuration of an NTP peer configures symmetric active mode for the configured peer. Although any system can be configured to peer with any other NTP node, it is recommended to configure authentication and to configure known time servers as their peers. Use the **no** form of the command to remove the configured peer.

**CLI Syntax:** config>system>time>ntp  
peer *ip-address* [*version version*] [*key-id key-id*]  
[*prefer*]

**Example:** config>system>time>ntp#  
config>system>time>ntp# peer 192.168.1.1 key-id 1  
config>system>time>ntp# no shutdown

The following example shows NTP enabled with the `peer` command configured.

```
A:sim1>config>system>time>ntp# info
-----
no shutdown
peer 192.168.1.1 key-id 1
-----
A:sim1>config>system>time>ntp#
```

## Server

The **server** command is used when the node should operate in client mode with the NTP server specified in the address field. Use the **no** form of this command to remove the server with the specified address from the configuration.

Up to ten NTP servers can be configured.

**CLI Syntax:** `config>system>time>ntp  
server ip-address [key-id key-id] [version version]  
[prefer]`

**Example:** `config>system>time>ntp#  
config>system>time>ntp# server 192.168.1.1 key-id 1  
config>system>time>ntp# no shutdown`

The following example shows NTP enabled with the `server` command configured.

```
A:sim1>config>system>time>ntp# info
-----
no shutdown
server 192.168.1.1 key 1
-----
A:sim1>config>system>time>ntp#
```

## SNTP

SNTP is a compact, client-only version of the NTP. SNTP can only receive the time from SNTP/NTP servers; it cannot be used to provide time services to other systems. SNTP can be configured in either broadcast or unicast client mode.

SNTP time elements include:

- [Broadcast-client on page 300](#)
- [Server-address on page 301](#)

---

**CLI Syntax:** config>system  
time  
sntp  
broadcast-client  
server-address *ip-address* [version *version-number*]  
[normal|preferred] [interval *seconds*]  
no shutdown

---

## Broadcast-client

The **broadcast-client** command enables listening at the global device level to SNTP broadcast messages on interfaces with broadcast client enabled.

**CLI Syntax:** config>system>time>sntp  
broadcast-client

**Example:** config>system>time>sntp#  
config>system>time>sntp# broadcast-client  
config>system>time>sntp# no shutdown

The following example shows SNTP enabled with the **broadcast-client** command enabled.

```
A:ALA-12>config>system>time# info
-----
sntp
  broadcast-client
  no shutdown
exit
dst-zone PT
  start second sunday april 02:00
  end first sunday october 02:00
  offset 0
exit
zone GMT
-----
A:ALA-12>config>system>time#
```

## Server-address

The **server-address** command configures an SNTP server for SNTP unicast client mode.

**CLI Syntax:** `config>system>time>sntp#`  
`config>system>time>sntp# server-address ip-address version version-`  
`number] [normal|preferred] [interval seconds]`

**Example:** `config>system>time>sntp#`  
`config>system>time# server-address 10.10.0.94 version`  
`1 preferred interval 100`

The following example shows SNTP enabled with the **server-address** command configured.

```
A:ALA-12>config>system>time# info
-----
      sntp
        server-address 10.10.0.94 version 1 preferred interval 100
        no shutdown
      exit
      dst-zone PT start-date 2006/04/04 12:00 end-date 2006/10/25 12:00
      zone GMT
-----
A:ALA-12>config>system>time#
```

## CRON

CRON provides various time and date scheduling functions. Configuration notes for the CRON schedule, time range, and time of day are provided below.

---

### Schedule

The schedule function configures the type of schedule to run, including one-time only (oneshot), periodic or calendar-based runs. All runs are determined by month, day of month or weekday, hour, minute and interval (seconds). If end-time and interval are both configured, whichever condition is reached first is applied.

**Example:**

```
config>system>cron# schedule test2
config>system>cron>sched# day-of-month 17
config>system>cron>sched# end-time 2007/07/17 12:00
config>system>cron>sched# minute 0 15 30 45
config>system>cron>sched# weekday friday
config>system>cron>sched# shut
```

The following example schedules a script named “test2” to run every 15 minutes on the 17th of each month and every Friday until noon on July 17, 2007:

```
*A:SR-3>config>system>cron# info
-----
    schedule "test2"
      shutdown
      day-of-month 17
      minute 0 15 30 45
      weekday friday
      end-time 2007/07/17 12:00
    exit
-----
*A:SR-3>config>system>cron#
```

---

### Time Range

Filter (ACL) policy configurations may be enhanced to support time-based matching by referring to a time-range policy.

Time range elements include:

- [Create on page 303](#)
- [Absolute on page 303](#)
- [Daily on page 303](#)
- [Weekdays on page 304](#)

- [Weekend on page 304](#)
- [Weekly on page 305](#)

## Create

Use the **create** command to enable the time-range context.

The following example creates a time-range called test1.

**Example:** `config>system>cron# time-range test1 create`

## Absolute

The **absolute** command configures a start and end time that will not repeat.

**Example:** `config>system>cron>time-range$ absolute start 2006/05/05,11:00  
end 2006/05/06,11:01`

The following example shows an absolute time range beginning on May 5, 2006 at 11:00 and ending May 6, 2006 at 11:01:

```
A:sim1>config>system>cron>time-range# show cron time-range detail
=====
Cron time-range details
=====
Name       : test1
Triggers   : 0
Status     : Inactive
Absolute   : start 2006/05/05,11:00 end 2006/05/06,11:01
=====
A:sim1>config>system>cron>time-range#
```

## Daily

The **daily** command configures the start and end of a periodic schedule for every day of the week (Sunday through Saturday).

**Example:** `config>system>cron>time-range$ daily start 11:00 end 12:00`

The following example shows a daily time range beginning at 11:00 and ending at 12:00.

```
A:sim1>config>system>cron>time-range# show cron time-range detail
```

```
=====  
Cron time-range details  
=====  
Name       : 1  
Triggers   : 0  
Status     : Inactive  
Periodic   : daily   Start 11:00 End 12:00  
=====  
A:sim1>config>system>cron>time-range#
```

---

## Weekdays

The **weekdays** command configures the start and end of a periodic schedule for weekdays (Monday through Friday).

**Example:** `config>system>cron>time-range$ weekdays start 11:00 end 12:00`

The following command shows a time range beginning at 11:00 and ending at 12:00. This schedule runs all weekdays during this time period.

```
A:sim1>config>system>cron>time-range# show cron time-range detail  
=====  
Cron time-range details  
=====  
Name       : 1  
Triggers   : 0  
Status     : Inactive  
Periodic   : weekdays Start 11:00 End 12:00  
=====  
A:sim1>config>system>cron>time-range#
```

---

## Weekend

The **weekend** command configures the start and end of a periodic schedule for weekends (Saturday and Sunday). The resolution must be at least one minute apart, for example, start at 11:00 and end at 11:01. A start time and end time of 11:00 is invalid.

**Example:** `config>system>cron>time-range$ weekend start 11:00 end 12:00`

The following command shows a weekend time range beginning at 11:00am and ending at 12:00pm, both Saturday and Sunday.

To specify 11:00am to 12:00pm on Saturday or Sunday only, use the [Absolute](#) parameter for one day, or the [Weekly](#) parameter for every Saturday or Sunday accordingly. In addition, see the [Schedule](#) parameter to schedule oneshot or periodic events in the `config>cron>` context.

```
A:sim1>config>system>cron>time-range# show cron time-range detail  
=====  
Cron time-range details  
=====  
A:sim1>config>system>cron>time-range#
```

```
Name       : 1
Triggers   : 0
Status     : Inactive
Periodic   : weekend Start 11:00 End 12:00
```

---

## Weekly

The **weekly** command configures the start and end of a periodic schedule for the same day every week, for example, every Friday. The start and end dates must be the same. The resolution must be at least one minute apart, for example, start at 11:00 and end at 11:01. A start time and end time of 11:00 is invalid.

**Example:** `config>system>cron>time-range$ start fri,01:01 end fri,01:02`

The following command shows a weekly time range beginning on Friday at 1:01am ending Friday at 1:02am.

```
A:sim1>config>system>cron>time-range$ info
-----
        weekly start fri,01:01 end fri,01:02
-----
A:sim1>config>system>cron>time-range$
```

---

## Time of Day

Time of Day (TOD) suites are useful when configuring many types of time-based policies or when a large number of SAPs require the same type of TOD changes. The TOD suite may be configured while using specific ingress or egress ACLs or QoS policies, and is an enhancement of the ingress and egress CLI trees.

---

## SAPs

- If a TOD Suite is assigned to a SAP, statistics collection are not collected for that SAP and scheduler overrides cannot be collected on the SAP. If the SAP has an egress aggregate rate limit configured, an egress scheduler policy assignment cannot be applied.
  - When an item is configured both on SAP level and in the TOD suite assigned to the SAP, the TOD-suite defined value takes precedence. If a SAP belongs to an IES Interface, TOD Suites are allowed only with generic interfaces.
  - A policy or filter assignment configured directly on a SAP has a lower priority than any assignment in a TOD Suite. Hence, it is possible that a new direct configuration has no immediate effect. If the configuration is made by CLI, a warning is given.
- 

## Multiservice Site

When applying a TOD Suite to a multi-service-site, only the scheduler policy assignment is active. If the multi-service-site has an egress aggregate rate limit configured, any egress scheduler policy assignment cannot be applied. While a TOD Suite is assigned to a multi-service-site, it is not possible to configure a scheduler to override it.

## ANCP (Access Node Control Protocol)

Static ANCP string mapping and TOD suites must be configured on separate SAPs or multiservice sites.

Time of day elements include:

- [Egress on page 307](#)
  - [Ingress on page 309](#)
- 

## Egress

The **egress** command is an enhancement for specific egress policies including filter lists, schedulers and QoS. Use this command to create time-range based associations of previously created filter lists, QoS and scheduler policies. Multiple policies may be included and each must be assigned a different priority; in case time-ranges overlap, the priority will be used to determine the prevailing policy. Only a single reference to a policy may be included without a time-range.

---

## Egress Aggregate Rate Limit

Having an egress aggregate rate limit is incompatible with having a scheduler policy. If a SAP or multi-service-site has a configured egress aggregate rate limit, and the TOD suite assigns a scheduler policy to it, that assignment cannot be applied: the configured aggregate rate limit takes precedence over the TOD suite's scheduler policy assignment.

---

## Egress Multicast Group

SAPs may not have a TOD suite while belonging to an egress multicast group (EMG). Since all SAPs that belong to the same EMG must have the same egress filter, it is imperative to ensure that the TOD Suite does not modify the egress filter assignment.

## Filters

In a TOD suite, filters that have entries with time-ranges may not be selected. Similarly, filter entries with a time-range may not be created while a TOD suite refers to that filter. QoS policies and filters referred to by a TOD suite must have scope “template” (default).

The following syntax is used to configure TOD-suite egress parameters.

**Example:** `config>system>cron>tod-suite$ egress filter ip 100`

The following command shows an egress IP filter association with filter ID 100.

```
sim1>config>filter# ip-filter 100 create
A:sim1>config>filter>ip-filter$ entry 10 create
A:sim1>config>filter>ip-filter>entry$
A:sim1>config>system>cron>tod-suite# egress filter ip 100
A:sim1>config>system>cron>tod-suite# info detail
-----
          no description
          egress
              filter ip 100
          exit
-----
A:sim1>config>cron>tod-suite#
```

**Example:** `config>system>cron>tod-suite$ egress qos 101`

The following command shows an association with egress QoS-SAP policy 101.

```
A:sim1>config>qos# sap-egress 101 create
...
A:sim1>config>system>cron>tod-suite# egress qos 101
A:sim1>config>system>cron>tod-suite# info detail
-----
          no description
          egress
              qos 101
          exit
-----
A:sim1>config>system>cron>tod-suite#
```

**Example:** `config>system>cron>tod-suite$ egress scheduler-policy test1`

The following command shows an association with an egress scheduler-policy called test1.

```
A:sim1>config# qos scheduler-policy test1 create
A:sim1>config>qos>scheduler-policy#
...
A:sim1# configure system cron tod-suite test1 create
A:sim1>config>system>cron>tod-suite# egress scheduler-policy test1
A:sim1>config>system>cron>tod-suite# info detail
-----
          no description
          egress
              scheduler-policy test1
-----
```

```

        exit
-----
A:sim1>config>system>cron>tod-suite$

```

## Ingress

This command is an enhancement for specific ingress policies including filter lists, schedulers and QoS policies. Use this command to create time-range based associations of previously created filter lists QoS and scheduler policies. Multiple policies may be included and each must be assigned a different priority; in case time-ranges overlap, the priority will be used to determine the prevailing policy. Only a single reference to a policy may be included without a time-range. To configure a daily time-range across midnight, use a combination of two entries. An entry that starts at hour zero will take over from an entry that ends at hour 24.

**Example:** `config>system>cron>tod-suite$ ingress filter ip 100`  
`config>system>cron>tod-suite$`

The following command shows an ingress IP filter association with filter ID 100.

```

sim1>config>filter# ip-filter 100 create
A:sim1>config>filter>ip-filter$ entry 10 create
A:sim1>config>filter>ip-filter>entry$
...
A:sim1>config>system>cron>tod-suite# ingress filter ip 100
A:sim1>config>system>cron>tod-suite# info detail
-----
        no description
        ingress
            filter ip 100
        exit
-----
A:sim1>config>system>cron>tod-suite#

```

**Example:** `config>system>cron>tod-suite$ ingress qos 101`  
`config>system>cron>tod-suite$`

The following command shows an association with ingress QoS-SAP policy 101.

```

A:sim1>config>qos# sap-egress 101 create
...
A:sim1>config>system>cron>tod-suite# ingress qos 101
A:sim1>config>system>cron>tod-suite# info detail
-----
        no description
        ingress
            qos 101
        exit
-----
A:sim1>config>system>cron>tod-suite#

```

## System Information

**Example:** config>system>cron>tod-suite\$ ingress scheduler-policy test1  
config>system>cron>tod-suite\$

The following command shows an association with an ingress scheduler-policy named test1.

```
A:sim1>config# qos scheduler-policy test1 create
A:sim1>config>qos>scheduler-policy#
...
A:sim1# configure cron tod-suite test1 create
A:sim1>config>system>cron>tod-suite#ingress scheduler-policy test1
A:sim1>config>system>cron>tod-suite# info detail
-----
          no description
          ingress
             scheduler-policy test1
          exit
-----
A:sim1>config>system>cron>tod-suite#
```

## ANCP Enhancements

Persistency is available for subscriber's ANCP attributes and is stored on the on-board compact flash card. ANCP data will stay persistence during an ISSU as well as nodal reboots. During recovery, ANCP attributes are first restored fully from the persistence file, and incoming ANCP sessions are temporarily on hold. Afterwards, new ANCP data can overwrite any existing values. This new data is then stored into the compact flash in preparation for the next event.

## Configuring Synchronization and Redundancy

- [Configuring Synchronization on page 312](#)
  - [Configuring Manual Synchronization on page 313](#)
  - [Forcing a Switchover on page 313](#)
  - [Configuring Synchronization Options on page 314](#)
- 

### Configuring Synchronization

The **switchover-exec** command specifies the location and name of the CLI script file executed following a redundancy switchover from the previously active card.

**CLI Syntax:** admin>redundancy  
                  synchronize {boot-env|config}

**CLI Syntax:** config>system  
                  switchover-exec *file-url*

## Configuring Manual Synchronization

Note that automatic synchronization can be configured in the **config>system> synchronization** context.

**CLI Syntax:** admin  
                   redundancy  
                   synchronize {boot-env|config}

**Example:** admin>redundancy# synchronize config

The following shows the output which displays during a manual synchronization:

```
A:ALA-12>admin# synchronize config
Syncing configuration.....
Syncing configuration.....Completed.
A:ALA-12#
```

---

## Forcing a Switchover

The **force-switchover now** command forces an immediate switchover to the standby CPM card.

**CLI Syntax:** admin>redundancy  
                   force-switchover [now]

**Example:** admin>redundancy# force-switchover now

```
A:ALA-12# admin redundancy force-switchover now
A:ALA-12#
Resetting...
?
```

If the active and standby are not synchronized for some reason, users can manually synchronize the standby CPM by rebooting the standby by issuing the **admin reboot standby** command on the active or the standby CPM.

## Configuring Synchronization Options

Network operators can specify the type of synchronization operation to perform between the primary and secondary CPMs after a change has been made to the configuration files or the boot environment information contained in the boot options file (BOF).

Use the following CLI to configure the boot-env option:

**CLI Syntax:** config>system  
                  synchronize {boot-env|config}

**Example:** config>system# synchronize boot-env

The following displays the configuration:

```
A:ALA-12>config>system# synchronize boot-env
A:ALA-12>config>system# show system synchronization
=====
Synchronization Information
=====
Synchronize Mode       : Boot Environment
Synchronize Status    : No synchronization
Last Config Sync Time  : 2006/06/27 06:19:47
Last Boot Env Sync Time : 2006/06/27 06:19:47
=====
A:ALA-12>config>system#
```

Use the following CLI to configure the config option:

**CLI Syntax:** config>system  
                  synchronize {boot-env|config}

**Example:** config>system# synchronize config

The following example displays the configuration.

```
A:ALA-12>config>system# synchronize config
A:ALA-12>config>system# show system synchronization
=====
Synchronization Information
=====
Synchronize Mode       : Configuration
Synchronize Status    : No synchronization
Last Config Sync Time  : 2006/06/27 09:17:15
Last Boot Env Sync Time : 2006/06/24 07:16:37
=====
A:ALA-12>config>system#
```

## Configuring Multi-Chassis Redundancy

Note: When configuring associated LAG ID parameters, the LAG must be in access mode and LACP must be enabled.

Use the CLI syntax displayed below to configure multi-chassis redundancy features.

```
CLI Syntax: admin>redundancy
                multi-chassis
                  peer ip-address
                    authentication-key [authentication-key | hash-key]
                      [hash | hash2]
                    description description-string
                  mc-lag
                    hold-on-neighbor-failure duration
                    keep-alive-interval interval
                    lag lag-id lacp-key admin-key system-id system-id [remote-
                      lag lag-id] system-priority system-priority
                    no shutdown
                  no shutdown
                  source-address ip-address
                  sync
                    igmp
                    igmp-snooping
                    port [port-id | lag-id] [sync-tag]
                      range encap-range sync-tag
                    no shutdown
                  srrp
```

```
Example: admin>redundancy#
            config>redundancy# multi-chassis
            config>redundancy>multi-chassis# peer 10.10.10.2 create
            config>redundancy>multi-chassis>peer# description "Mc-Lag peer
10.10.10.2"
            config>redundancy>multi-chassis>peer# mc-lag
            config>redundancy>mc>peer>mc-lag# lag 1 lacp-key 32666 system-
id 00:00:00:33:33:33 system-priority 32888
            config>redundancy>mc>peer>mc-lag# no shutdown
            config>redundancy>mc>peer>mc-lag# exit
            config>redundancy>multi-chassis>peer# no shutdown
            config>redundancy>multi-chassis>peer# exit
            config>redundancy>multi-chassis# exit
            config>redundancy#
```

The following displays the configuration:

```
A:ALA-48>config>redundancy# info
-----
                multi-chassis
                  peer 10.10.10.2 create
                    description "Mc-Lag peer 10.10.10.2"
                  mc-lag
                    no shutdown
```

## Configuring Multi-Chassis Redundancy

```
        exit
      no shutdown
    exit
  exit
-----
A:ALA-48>config>redundancy#
```

## Configuring Backup Copies

The `config-backup` command allows you to specify the maximum number of backup versions of configuration and index files kept in the primary location.

For example, assume the **config-backup count** is set to **5** and the configuration file is called `xyz.cfg`. When a **save** command is executed, the file `xyz.cfg` is saved with a `.1` extension. Each subsequent **config-backup** command increments the numeric extension until the maximum count is reached. The oldest file (**5**) is deleted as more recent files are saved.

```
xyz.cfg
xyz.cfg.1
xyz.cfg.2
xyz.cfg.3
xyz.cfg.4
xyz.cfg.5
xyz.ndx
```

Each persistent index file is updated at the same time as the associated configuration file. When the index file is updated, then the save is performed to `xyz.cfg` and the index file is created as `xyz.ndx`. Synchronization between the active and standby CPM is performed for all configurations and their associated persistent index files.

**CLI Syntax:** `config>system`  
`config-backup count`

**Example:** `config>system#`  
`config>system# config-backup 7`

The following example shows the `config-backup` configuration.

```
A:ALA-12>config>system>time# info
#-----
echo "System Configuration"
#-----
      name "ALA-12"
      contact "Fred Information Technology"
      location "Bldg.1-floor 2-Room 201"
      clli-code "abcdefg1234"
      coordinates "N 45 58 23, W 34 56 12"
      config-backup 7
...
#-----
A:ALA-12>config>system>time#
```

## Post-Boot Configuration Extension Files

Two post-boot configuration extension files are supported and are triggered when either a successful or failed boot configuration file is processed. The commands specify URLs for the CLI scripts to be run following the completion of the boot-up configuration. A URL must be specified or no action is taken. The commands are persistent between router (re)boots and are included in the configuration saves (admin>save).

**CLI Syntax:** config>system  
                  boot-bad-exec *file-url*  
                  boot-good-exec *file-url*

**Example:** config>system# boot-bad-exec ftp://test:test@192.168.xx.xxx/./fail.cfg  
            config>system# boot-good-exec ftp://test:test@192.168.xx.xxx/./ok.cfg

The following example displays the command output:

```
A:ALA-12>config>system# info
#-----
echo "System Configuration"
#-----
      name "ALA-12"
      contact "Fred Information Technology"
      location "Bldg.1-floor 2-Room 201"
      clli-code "abcdefg1234"
      coordinates "N 45 58 23, W 34 56 12"
      config-backup 7
      boot-good-exec "ftp://test:test@192.168.xx.xxx/./ok.cfg"
      boot-bad-exec "ftp://test:test@192.168.xx.xxx/./fail.cfg"
      lacp-system-priority 1
      sync-if-timing
      begin
      ref-order ref1 ref2 bits
      ..
#-----
A:ALA-12>config>system#
```

## Show Command Output and Console Messages

The `show>system>information` command displays the current value of the bad/good exec URLs and indicates whether a post-boot configuration extension file was executed when the system was booted. If an extension file was executed, the `show>system>information` command also indicates if it completed successfully or not.

```
ALA-12>config>system# show system information
=====
System Information
=====
System Name           : ALA-12
System Contact        : Fred Information Technology
System Location       : Bldg.1-floor 2-Room 201
System Coordinates    : N 45 58 23, W 34 56 12
System Up Time        : 1 days, 04:59:33.56 (hr:min:sec)

SNMP Port             : 161
SNMP Engine ID        : 0000197f000000000467ff00
SNMP Max Message Size : 1500
SNMP Admin State      : Disabled
SNMP Oper State       : Disabled
SNMP Index Boot Status : Not Persistent

BOF Source            : cfl:
Image Source          : primary
Config Source         : primary
Last Booted Config File: ftp://test:test@192.168.xx.xxx/./12.cfg
Last Boot Cfg Version : THU MAR 04 22:39:03 2004 UTC
Last Boot Config Header: # TiMOS B-0.0.I323 - Copyright (c) 2000-2004 Alcatel.
                        # All rights reserved. All use subject to applicable l
                        # license agreements. # Built on Sun Feb 29 21:43:13 PST
                        # 2004 by builder in /rel0.0/I323/panos/main # Generated
                        THU MAR 04 22:39:03 2004 UTC

Last Boot Index Version: N/A
Last Boot Index Header : N/A
Last Saved Config      : N/A
Time Last Saved        : N/A
Changes Since Last Save: Yes
Time Last Modified     : 2004/03/06 03:30:45
Max Cfg/BOF Backup Rev : 7
Cfg-OK Script          : ftp://test:test@192.168.xx.xxx/./ok.cfg
Cfg-OK Script Status   : not used
Cfg-Fail Script        : ftp://test:test@192.168.xx.xxx/./fail.cfg
Cfg-Fail Script Status : not used

Management IP Addr     : 192.168.xx.xxx/20
DNS Server             : 192.168.1.254
DNS Domain             : eng.timetra.com
BOF Static Routes      :
  To                   Next Hop
  172.22.184.0/22      192.168.1.251
ICMP Vendor Enhancement: Disabled
=====
ALA-12>config>system#
```

When executing a post-boot configuration extension file, status messages are output to the CONSOLE screen prior to the “Login” prompt.

Following is an example of a failed boot-up configuration that caused a boot-bad-exec file containing another error to be executed:

```
Attempting to exec configuration file:
'ftp://test:test@192.168.xx.xxx/./12.cfg' ...
System Configuration
Log Configuration
MAJOR: CLI #1009 An error occurred while processing a CLI command -
File ftp://test:test@192.168.xx.xxx/./12.cfg, Line 195: Command "log" failed.
CRITICAL: CLI #1002 An error occurred while processing the configuration file.
The system configuration is missing or incomplete.
MAJOR: CLI #1008 The SNMP daemon is disabled.
If desired, enable SNMP with the 'config>system>snmp no shutdown' command.
Attempting to exec configuration failure extension file:
'ftp://test:test@192.168.xx.xxx/./fail.cfg' ...
Config fail extension
Enabling SNMP daemon
MAJOR: CLI #1009 An error occurred while processing a CLI command -
File ftp://test:test@192.168.xx.xxx/./fail.cfg, Line 5: Command "abc log" failed.
TiMOS-B-x.0.Rx both/hops ALCATEL Copyright (c) 2000-2009 Alcatel-Lucent.
All rights reserved. All use subject to applicable license agreements.
Built on Thu Nov 20 19:19:11 PST 2008 by builder in /rel5x.0/b1/Rx/panos/main
```

Login:

## System Timing

When synchronous Ethernet is enabled, the operator can select an Ethernet port as a candidate for timing reference. The timing information recovered from this port is used by the central clock.

Note: In the current release the derived timing is distributed only through other Ethernet ports.

CLI Syntax:

```
config>system>sync-if-timing
  abort
  begin
  commit
  ref-order ref1 ref2
  ref1
    source-port port-id
    no shutdown
  ref2
    source-port port-id
    no shutdown
  no revert
```

In the event that network timing is required for the synchronous interfaces in the router, a timing subsystem is utilized to provide a clock to all synchronous interfaces within the system.

This section describes the commands used to configure and control the timing subsystem.

Use the CLI syntax displayed below to:

- [Edit Mode on page 322](#)
- [Configuring Timing References on page 323](#)
- [Using the Revert Command on page 324](#)
- [Other Editing Commands on page 325](#)
- [Forcing a Specific Reference on page 326](#)

## Edit Mode

To enter the mode to edit timing references, you must enter the **begin** keyword at the **config>system>sync-if-timing#** prompt.

Use the following CLI syntax to enter the edit mode:

**CLI Syntax:** config>system>sync-if-timing  
begin

The following error message displays when the you try to modify **sync-if-timing** parameters without entering the keyword **begin**.

```
A:ALA-12>config>system>sync-if-timing>ref1# source-port 2/1/1
MINOR: CLI The sync-if-timing must be in edit mode by calling begin before any changes can
be made.
MINOR: CLI Unable to set source port for ref1 to 2/1/1
A:ALA-12>config>system>sync-if-timing>ref1#
```

## Configuring Timing References

Use the following CLI syntax to configure timing reference parameters. Note that the source port specified for **ref1** and **ref2** cannot both be from the same slot. The following displays a timing reference configuration example:

```
ALA-12>config>system>sync-if-timing# info
-----
ref-order ref2 ref1 bits
ref1
  source-port 3/1/1
  no shutdown
exit
ref2
  source-port 6/1/2
  no shutdown
exit
bits
  interface-type ds1 esf
  no shutdown
exit
-----
ALA-12>config>system>sync-if-timing#
```

## Using the Revert Command

The **revert** command allows the clock to revert to a higher priority reference if the current reference goes offline or becomes unstable. When the failed reference becomes operational, it is eligible for selection.

When mode is non-revertive, a failed clock source is not selected again. If a node would enter holdover due to the references being in previous failed state, then the node will select one of the previously failed references rather than going into holdover.

**CLI Syntax:** `config>system>sync-if-timing  
revert`

If the current reference goes offline or becomes unstable the revert command allows the clock to **revert** to a higher-priority reference.

When revert is switching enabled a valid timing reference of the highest priority is used. If a reference with a higher priority becomes valid, a reference switch over to that reference is initiated. If a failure on the current reference occurs, the next highest reference takes over.

If non-revertive switching is enabled, the valid active reference always remains selected even if a higher priority reference becomes available. If the active reference becomes invalid, a reference switch over to a valid reference with the highest priority is initiated. The failed reference is eligible for selection once it becomes operational.

**CLI Syntax:** `config>system>sync-if-timing  
no revert`

## Other Editing Commands

Other editing commands include:

- `commit` — This command saves changes made to the timing references during a session. Modifications are not persistent across system boots unless this command is entered.
- `abort` — This command discards changes that have been made to the timing references during a session.

**CLI Syntax:** `config>system>sync-if-timing`  
`abort`  
`commit`

## Forcing a Specific Reference

Note: The debug sync-if-timing force-reference command should only be used to test and debug problems. Network synchronization problems may appear if network elements are left with this manual override setting. Once the system timing reference input has been forced, it may be cleared using the no force-reference command.

You can force the CPM clock to use a specific input reference using the force-reference command.

When the command is executed, the CPM clock on the active CPM immediately switches its input reference to that specified by the command. If the specified input is not available (shutdown), or in a disqualified state, the CPM clock shall use the next qualified input reference based on the selection rules.

This command also affects the BITS output port. If the BITS output port selection is set to line-reference and the reference being forced is not the BITS input port, then the system uses the forced reference to generate the signal out the BITS output port. If the BITS output port selection is set to internal-clock, then the system uses the output of the CPM clock to generate the signal for the BITS output port.

On a CPM activity switch, the force command is cleared and normal reference selection is determined.

Debug configurations are not saved between reboots.

**CLI Syntax:** debug>sync-if-timing  
force-reference {ref1 | ref2 | bits}

**Example:** debug>sync-if-timing# force-reference

# Configuring System Monitoring Thresholds

---

## Creating Events

The **event** command controls the generation and notification of threshold crossing events configured with the **alarm** command. When a threshold crossing event is triggered, the **rmon event** configuration optionally specifies whether an entry in the RMON-MIB log table be created to record the occurrence of the event. It can also specify whether an SNMP notification (trap) be generated for the event. There are two notifications for threshold crossing events, a rising alarm and a falling alarm.

Creating an event entry in the RMON-MIB log table does not create a corresponding entry in the event logs. However, when the event is set to trap the generation of a rising alarm or falling alarm notification creates an entry in the event logs and that is distributed to whatever log destinations are configured: console, session, memory, file, syslog, or SNMP trap destination. The logger message includes a rising or falling threshold crossing event indicator, the sample type (absolute or delta), the sampled value, the threshold value, the *rmon-alarm-id*, the associated *rmon-event-id* and the sampled SNMP object identifier.

The **alarm** command configures an entry in the RMON-MIB alarm table. The **alarm** command controls the monitoring and triggering of threshold crossing events. In order for notification or logging of a threshold crossing event to occur there must be at least one associated **rmon event** configured.

The agent periodically takes statistical sample values from the MIB variable specified for monitoring and compares them to thresholds that have been configured with the **alarm** command. The **alarm** command configures the MIB variable to be monitored, the polling period (interval), sampling type (absolute or delta value), and rising and falling threshold parameters. If a sample has crossed a threshold value, the associated 'event' is generated.

Preconfigured CLI threshold commands are available. Preconfigured commands hide some of the complexities of configuring RMON alarm and event commands and perform the same function. In particular, the preconfigured commands do not require the user to know the SNMP object identifier to be sampled. The preconfigured threshold configurations include memory warnings and alarms and compact flash usage warnings and alarms.

To create events, use the following CLI:

```
Example:  config>system>thresholds# cflash-cap-warn cf1-B: rising-  
threshold 2000000 falling-threshold 1999900 interval 240 trap startup-  
alarm either
```

## Creating Events

**Example:** config>system>thresholds# memory-use-alarm rising-threshold 50000000 falling-threshold 45999999 interval 500 both startup-alarm either

**Example:** config>system>thresh# rmon

**Example:** config>system>thresh>rmon# event 5 both description "alarm testing" owner "Timos CLI"

The following example displays the command output:

```
A:ALA-49>config>system>thresholds# info
-----
      rmon
        event 5 description "alarm testing" owner "Timos CLI"
      exit
      cflash-cap-warn cf1-B: rising-threshold 2000000 falling-threshold 1999900
interval 240 trap
      memory-use-alarm rising-threshold 50000000 falling-threshold 45999999 interval
500
-----
A:ALA-49>config>system>thresholds#
```

## System Alarm Contact Inputs

The hardware supports alarm contact inputs that allow an operator to monitor and report changes in the external environmental conditions. In a remote or outdoor deployment, alarm contact inputs allow an operator to detect conditions, for example, air conditioner fault, open door.

An operator can configure generation of events when alarm contact inputs transition between the open and close states. For each generated event, the operator can specify the:

- Action associated with each state transition.
- Severity associated with each state transition.
- Log message associated with each state transition.

## Configuring LLDP

The following output displays LLDP defaults:

```
A:testSrl>config>system>lldp# info detail
-----
      no tx-interval
      no tx-hold-multiplier
      no reinit-delay
      no notification-interval
      no tx-credit-max
      no message-fast-tx
      no message-fast-tx-init
      no shutdown
-----
A:testSrl>config>system>lldp#
```

The following example shows an LLDP port configuration.

```
*A:ALA-48>config>port>ethernet>lldp# info
-----
      dest-mac nearest-bridge
      admin-status tx-rx
      tx-tlvs port-desc sys-cap
      tx-mgmt-address system
      exit
-----
*A:ALA-48>config>port>ethernet>lldp#
```

The following example shows a global system LLDP configuration.

```
A:ALA-48>config>system>lldp# info
-----
      tx-interval 10
      tx-hold-multiplier 2
      reinit-delay 5
      notification-interval 10
-----
A:ALA-48>config>system>lldp#
```

---

# System Command Reference

---

## Command Hierarchies

### Configuration Commands

- [System Information Commands on page 331](#)
- [System Alarm Commands on page 333](#)
- [System Time Commands on page 334](#)
- [Cron Commands on page 335](#)
- [Script Control Commands on page 336](#)
- [System Synchronization Commands on page 337](#)
- [System Administration \(Admin\) Commands on page 337](#)
- [High Availability \(Redundancy\) Commands on page 339](#)
- [Show Commands on page 343](#)
- [Debug Commands on page 344](#)
- [Clear Commands on page 344](#)
- [Tools Commands on page 345](#)

### System Information Commands

```

config
  — system
    — boot-bad-exec file-url
    — no boot-bad-exec
    — boot-bad-exec file-url
    — no boot-bad-exec
    — cli-code cli-code
    — no cli-code
    — config-backup count
    — no config-backup
    — contact contact-name
    — no contact
    — coordinates coordinates
    — no coordinates
    — dns
      — address-pref {ipv4-only | ipv6-first}
      — no address-pref
      — dnssec
        — ad-validation fall-through|drop
    — [no] ad-validation
    — lACP-system-priority lACP-system-priority
    — no lACP-system-priority
    — load-balancing

```

## Command Hierarchies

- [no] **l4-load-balancing**
- **lsr-load-balancing** {lbl-only|lbl-ip|ip-only|eth-encap-ip}
- **no lsr-load-balancing**
- [no] **mc-enh-load-balancing**
- [no] **service-id-lag-hashing**
- [no] **system-ip-load-balancing**
- **location** *location*
- **no location**
- **name** *system-name*
- **no name**

## System Alarm Commands

- ```

config
  — system
    — thresholds
      — cflash-cap-alarm cflash-id rising-threshold threshold [falling-threshold threshold]
         interval seconds [rmon-event-type] [startup-alarm alarm-type]
      — no cflash-cap-alarm cflash-id
      — cflash-cap-warn cflash-id rising-threshold threshold [falling-threshold threshold]
         interval seconds [rmon-event-type] [startup-alarm alarm-type]
      — no cflash-cap-warn cflash-id
      — kb-memory-use-alarm rising-threshold threshold [falling-threshold threshold] inter-
         val seconds [rmon-event-type] [startup-alarm alarm-type]
      — no kb-memory-use-alarm
      — kb-memory-use-warn rising-threshold threshold [falling-threshold threshold] interval
         seconds [rmon-event-type] [startup-alarm alarm-type]
      — no kb-memory-use-warn
      — memory-use-alarm rising-threshold threshold [falling-threshold threshold] interval
         seconds [rmon-event-type] [startup-alarm alarm-type]
      — no memory-use-alarm
      — memory-use-warn rising-threshold threshold [falling-threshold threshold] interval
         seconds [rmon-event-type] [startup-alarm alarm-type]
      — no memory-use-warn
      — [no] rmon
         — alarm rmon-alarm-id variable-oid oid-string interval seconds [sample-type]
            [startup-alarm alarm-type] [rising-event rmon-event-id rising-threshold
            threshold] [falling event rmon-event-id falling-threshold threshold] [owner
            owner-string]
         — no alarm rmon-alarm-id
         — event rmon-event-id [event-type] [description description-string] [owner
            owner-string]
         — no event rmon-event-id
      —
      —
      —
      —
  
```

## System Time Commands

```

root
  — admin
    — set-time [date] [time]
config
  — system
    — time
      — [no] ntp
        — [no] authentication-check
        — authentication-key key-id key key [hash | hash2] type {des | message-digest}
        — no authentication-key key-id
        — [no] broadcast [router router-name] {interface ip-int-name} [key-id key-id]
          [version version] [ttl ttl]
        — broadcastclient [router router-name] {interface ip-int-name} [authenticate]
        — [no] multicast [version version] [key-id key-id]
        — [no] multicastclient [authenticate]
        — [no] ntp-server [authenticate]
        — [no] peer {ip-address | ipv6-address} [version version] [key-id key-id] [prefer]
        — [no] server {ip-address | ipv6-address} [key-id key-id] [version version] [prefer]
        — [no] shutdown
      — [no] sntp
        — [no] broadcast-client
        — server-address ip-address [version version-number] [normal | preferred]
          [interval seconds]
        — no server-address ip-address
        — [no] shutdown
      — [no] dst-zone [std-zone-name | non-std-zone-name]
        — end {end-week} {end-day} {end-month} [hours-minutes]
        — offset offset
        — start {start-week} {start-day} {start-month} [hours-minutes]
      — zone std-zone-name | non-std-zone-name [hh [:mm]]
      — no zone

```

## Cron Commands

```

config
  — system
    — [no] cron
      — [no] schedule schedule-name [owner owner-name]
        — [no] action action-name [owner owner-name]
        — [no] day-of-month {day-number [..day-number]} all}
        — count number
        — [no] description description-string
        — [no] end-time [date|day-name] time
        — [no] hour {..hour-number [..hour-number]} all}
        — [no] interval seconds
        — [no] minute {minute-number [..minute-number]} all}
        — [no] month {month-number [..month-number]} month-name [..month-name]} all}
        — script-policy policy-name [owner policy-owner]
        — [no] shutdown
        — type {schedule-type}
        — [no] weekday {weekday-number [..weekday-number]} day-name [..day-name]} all}
      — [no] time-range name
        — absolute start start-absolute-time end end-absolute-time
        — no absolute start start-absolute-time
        — daily start start-time-of-day end end-time-of-day
        — no daily start start-time-of-day
        — weekdays start start-time-of-day end end-time-of-day
        — no weekdays start start-time-of-day
        — weekend start start-time-of-day end end-time-of-day
        — no weekend start start-time-of-day
        — weekly start start-time-in-week end end-time-in-week
        — no weekly start start-time-in-week
      — [no] tod-suite
        — egress
          — filter ip ip-filter-id [time-range time-range-name] [priority priority]
          — filter ipv6 ipv6-filter-id [time-range time-range-name] [priority priority]
          — filter mac mac-filter-id [time-range time-range-name] [priority priority]
          — no filter ip ip-filter-id [time-range time-range-name]
          — filter ipv6 ipv6-filter-id [time-range time-range-name]
          — no filter mac mac-filter-id [time-range time-range-name]
          — qos policy-id [time-range time-range-name] [priority priority]
          — no qos policy-id [time-range time-range-name]
          — scheduler-policy scheduler-policy-name [time-range time-range-name] [priority priority]
          — no scheduler-policy scheduler-policy-name [time-range time-range-name]
        — ingress
          — filter ip ip-filter-id [time-range time-range-name] [priority priority]
          — filter ipv6 ipv6-filter-id [time-range time-range-name] [priority priority]
          — filter mac mac-filter-id [time-range time-range-name] [priority priority]
          — no filter ip ip-filter-id [time-range time-range-name]
          — no filter ipv6 ipv6-filter-id [time-range time-range-name]
          — no filter mac mac-filter-id [time-range time-range-name]

```

- **qos** *policy-id* [**time-range** *time-range-name*] [**priority** *priority*]
- **no qos** *policy-id* [**time-range** *time-range-name*]
- **scheduler-policy** *scheduler-policy-name* [**time-range** *time-range-name*] [**priority** *priority*]
- **no scheduler-policy** *scheduler-policy-name* [**time-range** *time-range-name*]

## Script Control Commands

- config**
  - **system**
    - **script-control**
      - **script-policy** *policy-name* [**owner** *policy-owner*]
        - **expire-time** {*seconds* | **forever**}
        - **lifetime** {*seconds* | **forever**}
        - **max-completed** *unsigned*
        - **results** *file-url*
        - **no results**
        - **script** *script-name* [**owner** *script-owner*]
        - **no script**
        - [**no**] **shutdown**
      - **script** *script-name* [**owner** *script-owner*]
        - **description** *description-string*
        - **no description**
        - **location** *file-url*
        - **no location**
        - [**no**] **shutdown**

## System Administration (Admin) Commands

```

root
  — admin
    — clear-policy-lock
    — debug-save file-url
    — disconnect {address ip-address | username user-name | console | telnet | ftp | ssh}
    — display-config [detail | index]
    — [no] enable-tech
    — radius-discovery
    — force-discover [svc-id service-id]
    — reboot [active | standby] [now]
    — redundancy
    — synchronize {boot-env|config}
    — no synchronize
    — save [file-url] [detail] [index]
    — synchronize [boot-env | config]
    — tech-support [file-url]

```

## System Synchronization Commands

```

config
  — system
    — sync-if-timing
      — abort
      — begin
      — bits
      — input
        — [no] shutdown
      — interface-type {ds1 [{esf | sf}] | e1 [{pcm30crc | pcm31crc}] 2048khz-g703}
      — no interface-type
      — output
        — line-length {110, 220, 330, 440, 550, 660}
        — [no] shutdown
        — source {line-ref|internal-clock}
      — ql-override {prs | stu | st2 | tnc | st3e | st3 | eec1 | sec | prc | ssu-a | ssu-b | eec2}
      — no ql-override
      — ssm-bit sa-bit
    — commit
    — ref-order first second [third [fourth]]
    — no ref-order
    — refl
      — ql-override {prs | stu | st2 | tnc | st3e | st3 | eec1 | sec | prc | ssu-a | ssu-b | eec2}
      — no ql-override
      — [no] shutdown
      — source-port port-id
      — no source-port
    — ref2
      — ql-override {prs | stu | st2 | tnc | st3e | st3 | eec1 | sec | prc | ssu-a | ssu-b | eec2}
      — no ql-override
      — [no] shutdown
      — source-port port-id
      — no source-port
    — [no] ql-selection

```

## Command Hierarchies

```
config
  — [no] revert
  — system
    — sync-if-timing
      — abort
      — begin
      — commit
      — ref-order first second [third]
      — no ref-order
      — ref1
        — ql-override {prs | stu | st2 | tnc | st3e | st3 | eec1 | sec | prc | ssu-a | ssu-b |
          eec2}
        — no ql-override
        — [no] shutdown
        — source-bits slot/mda
        — no source-bits
        — source-port port-id
        — no source-port
        — ssm-bit sa-bit
      — ref2
        — ql-override {prs | stu | st2 | tnc | st3e | st3 | eec1 | sec | prc | ssu-a | ssu-b |
          eec2}
        — no ql-override
        — [no] shutdown
        — source-bits slot/mda
        — no source-bits
        — source-port port-id
        — no source-port
        — ssm-bit sa-bit
      — [no] ql-selection
      — [no] revert
```

## High Availability (Redundancy) Commands

```

root
  — admin
    — display-config [detail |index]
    — redundancy
      — force-switchover [now] [force-switchover]
      — rollback-sync
      — synchronize {boot-env | config}

config
  — system
    — switchover-exec file-url
    — no switchover-exec
  — redundancy
    — mgmt-ethernet
  — redundancy
    — multi-chassis
      — [no] peer ip-address
        — authentication-key [authentication-key | hash-key] [hash | hash2]
        — no authentication-key
        — description description-string
        — no description
        — [no] mc-endpoint
          — [no] bfd-enable
          — boot-timer interval
          — no boot-timer
          — hold-on-neighbor-failure multiplier
          — no hold-on-neighbor-failure
          — keep-alive-interval interval
          — no keep-alive-interval
          — [no] passive-mode
          — [no] shutdown
          — system-priority value
          — no system-priority
        — [no] mc-lag
          — hold-on-neighbor-failure multiplier
          — no hold-on-neighbor-failure
          — keep-alive-interval interval
          — no keep-alive-interval
          — lag lag-id lacp-key admin-key system-id system-id [remote-lag
            remote-lag-id] system-priority system-priority source-bmac-lsb use-
            lacp-key
          — lag lag-id lacp-key admin-key system-id system-id [remote-lag
            remote-lag-id] system-priority system-priority source-bmac-lsb
            MAC-Lsb
          — lag lag-id lacp-key admin-key system-id system-id [remote-lag
            remote-lag-id] system-priority system-priority
          — lag lag-id [remote-lag remote-lag-id]
          — no lag lag-id
          — [no] shutdown
        — [no] mc-mobile
          — bfd-enable [service service-id] interface interface-name
          — no bfd-enable
          — hold-on-neighbor-failure multiplier
          — no hold-on-neighbor-failure

```

- **keep-alive-interval** *interval*
- **no keep-alive-interval**
- **ring** *sync-tag* [**create**]
- **no ring** *sync-tag*
  - **in-band-control-path**
    - **dst-ip** *ip-address*
    - **no dst-ip**
    - **interface** *ip-int-name*
    - **no interface**
    - **service-id** *service-id*
    - **no service-id**
  - [no] **path-b**
    - [no] **range** *vlan-range*
  - [no] **path-excl**
    - [no] **range** *vlan-range*
  - **ring-node** *ring-node-name* [**create**]
  - **no ring-node** *ring-node-name*
    - **connectivity-verify**
      - **dst-ip** *ip-address*
      - **no dst-ip**
      - **interval** *interval*
      - **no interval**
      - **service-id** *service-id*
      - **no service-id**
      - [no] **shutdown**
      - **src-ip** *ip-address*
      - **no src-ip**
      - **src-mac** *ieee-address*
      - **no src-mac**
      - **vlan** [0..4094]
      - **no vlan**
    - [no] **shutdown**
- **peer-name** *name*
- **no peer-name**
- [no] **shutdown**
- **source-address** *ip-address*
- **no source-address**
- [no] **sync**
  - [no] **igmp**
  - [no] **igmp-snooping**
  - [no] **mc-ring**
  - [no] **mld-snooping**
  - **port** [*port-id* | *lag-id*] [**sync-tag** *sync-tag*]
  - **no port** [*port-id* | *lag-id*]
    - **range** *encap-range* [**sync-tag** *sync-tag*]
    - **no range** *encap-range*
  - [no] **python**
  - [no] **shutdown**
- **bgp-multi-homing**
  - **boot-timer** *seconds*
  - **no boot-timer**
  - **site-activation-timer** *seconds*
  - **no site-activation-timer**
  - **site-min-down-timer** *min-down-time*
  - **no site-min-down-timer**

- **[no] rollback-sync**
- **synchronize** {boot-env | config}

## LLDP System Commands

```
configure
  — system
    — lldp
      — message-fast-tx time
      — no message-fast-tx
      — message-fast-tx-init count
      — no message-fast-tx-init
      — notification-interval time
      — no notification-interval
      — reinit-delay time
      — no reinit-delay
      — [no] shutdown
      — tx-credit-max count
      — no tx-credit-max
      — tx-hold-multiplier multiplier
      — no tx-hold-multiplier
      — tx-interval interval
      — no tx-interval
```

## LLDP Ethernet Port Commands

```
configure
  — port port-id
    — ethernet
      — lldp
        — dest-mac {nearest-bridge | nearest-non-tpmr | nearest-customer}
        — admin-status {rx | tx | tx-rx | disabled}
        — [no] notification
        — tx-mgmt-address [system]
        — no tx-mgmt-address
        — tx-tlvs [port-desc] [sys-name] [sys-desc] [sys-cap]
        — no tx-tlvs
```

## Show Commands

```

show
  — redundancy
    — mgmt-ethernet
    — multi-chassis
      — all [detail]
      — mc-endpoint statistics
      — mc-endpoint peer [ip-address] statistics
      — mc-endpoint endpoint [mcep-id] statistics
      — mc-endpoint peer [ip-address]
      — mc-mobile peer [ip-address | ipv6-address]
      — mc-lag [lag lag-id]
        — peer [peer ip-address [lag lag-id]] mc-lag
        — statistics
      — mc-ring peer ip-address statistics
      — mc-ring peer ip-address [ring sync-tag [detail | statistics] ]
      — mc-ring peer ip-address ring sync-tag ring-node [ring-node-name [detail | statistics] ]
      — mc-ring global-statistics
      — sync [port port-id | lag-id]
        — peer [port port-id]
        — detail
    — synchronization
  — time
  — system
    — card
      — cpu [sample-period seconds]
      — memory-pools
    — connections [address ip-address [interface interface-name]] [port port-number] [detail]
    — cpu [sample-period seconds]
    — cron
      — action
      — schedule
      — tod-suite tod-suite-name [detail]
      — tod-suite tod-suite-name associations
      — tod-suite tod-suite-name failed-associations
      — time-range name associations [detail]
    — information
    — lldp neighbor
    — load-balancing-alg [detail]
    — memory-pools
    — ntp
    — rollback
    — script-control
      — script [script-name] [owner script-owner]
      — script-policy script-policy-name [owner owner-name]
      — script-policy run-history [run-state]
    — sntp
    — sync-if-timing
    — thresholds
    — time
  — uptime

```

## Clear Commands

- clear
  - **redundancy**
    - **multi-chassis**
      - **mc-endpoint** endpoint [*mcep-id*] statistics
      - **mc-endpoint** statistics
      - **mc-endpoint** peer [*ip-address*] statistics
      - **mc-mobile** statistics peer {*ip-address* | *ipv6-address*}
      - **mc-lag** [peer *ip-address* [*lag lag-id*]]
      - **mc-ring**
        - **debounce** peer *ip-address* ring *sync-tag*
        - **ring-nodes** peer *ip-address* ring *sync-tag*
        - **statistics**
          - **global**
          - **peer** *ip-address*
          - **ring peer** *ip-address* ring *sync-tag*
          - **ring-node** peer *ip-address* ring *sync-tag* node *ring-node-name*
      - **sync-database** peer *ip-address* all application *application*
      - **sync-database** peer *ip-address* {port *port-id* | *lag-id* | *sync-tag sync-tag*} application *application*
      - **sync-database** peer *ip-address* port *port-id* | *lag-id sync-tag sync-tag* application *application*
  - **screen** *action-name* [**owner** *owner-name*]
  - **system**
    - **script-control**
      - **script-policy**
        - **completed** [*script-policy-name*] [**owner** *owner-name*]
    - **statistics**
      - **xmpp server** *xmpp-server-name*
    - **sync-if-timing** {*ref1* | *ref2* | *bits*}
  - **trace**
    - **log**

## Debug Commands

- debug
  - **sync-if-timing**
    - **force-reference** {*ref1* | *ref2* | *bits*}
    - **no force-reference**
  - [**no**] **system**
    - **http-connections** [*host-ip-address/mask*]
    - **no http-connections**
    - **ntp** [**router** *router-name*] [**interface** *ip-int-name*]

## Tools Commands

```

tools
  — dump
    — redundancy
      — multi-chassis
        — mc-endpoint peer ip-address
        — mc-ring
        — mc-ring peer ip-address [ring sync-tag]
        — sync-database [instance instance-id] [peer ip-address]
        — sync-database [peer ip-address] [port port-id | lag-id] [sync-tag sync-tag]
          [application application] [detail] [type type]
      — perform
        — redundancy
          — mgmt-ethernet
        — chassis
          — set-role{standalone | master | extension}
        — system
          — inter-chassis
            — sfm-interco-test [sfm x]
      — perform
        — system
          — script-control
            — script-policy
              — stop [script-policy-name] [owner script-policy-owner] [all]
          — cron
            — tod
              — re-evaluate
                — customer
                — filter
                — service
                — tod-suite

```



---

## System Command Reference

---

### Generic Commands

#### shutdown

**Syntax** [no] shutdown

**Context** config>system>cron>sched  
 config>system>time>ntp  
 config>system>time>sntp  
 config>system>script-control>script-policy  
 config>system>script-control>script  
 config>system>sync-if-timing>ref1  
 config>system>sync-if-timing>ref2  
 config>system>sync-if-timing>bits>input  
 config>system>sync-if-timing>bits>output  
 config>system>persistence>nat-port-forward  
 config>system>persistence>python-policy-cache  
 config>system>persistence>subscriber-mgmt  
 config>redundancy>multi-chassis>peer  
 config>redundancy>multi-chassis>peer>mc-lag  
 config>redundancy>multi-chassis>peer>sync  
 config>redundancy>mc>peer>mcr>node>cv  
 config>system>lldp  
 config>redundancy>multi-chassis>peer>mc-ep

**Description** This command administratively disables the entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics.

The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.

The **no** form of this command places the entity into an administratively enabled state.

**Default** no shutdown

#### description

**Syntax** **description** *description-string*  
**no description**

**Context** config>system>cron>sched  
 config>system>script-control>script  
 config>system>persistence>ancp

## Generic Commands

```
config>system>persistence>app-assure
config>system>persistence>dhcp-server
config>system>persistence>nat-fwd
config>system>persistence>sub-mgmt
config>system>persistence>dhcp-server
config>redundancy>multi-chassis>peer
```

- Description** This command creates a text description stored in the configuration file for a configuration context.
- The **description** command associates a text string with a configuration context to help identify the content in the configuration file.
- The **no** form of this command removes the string from the configuration.
- Default** No description associated with the configuration context.
- Parameters** *string* — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## System Information Commands

### boot-bad-exec

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>          | <b>boot-bad-exec</b> <i>file-url</i><br><b>no boot-bad-exec</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Context</b>         | config>system                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Description</b>     | Use this command to configure a URL for a CLI script to exec following a failure of a boot-up configuration. The command specifies a URL for the CLI scripts to be run following the completion of the boot-up configuration. A URL must be specified or no action is taken.<br><br>The commands are persistent between router (re)boots and are included in the configuration saves ( <b>admin&gt;save</b> ).                                                                                                                               |
| <b>Default</b>         | no boot-bad-exec                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Parameters</b>      | <i>file-url</i> — Specifies the location and name of the CLI script file executed following failure of the boot-up configuration file execution. When this parameter is not specified, no CLI script file is executed.                                                                                                                                                                                                                                                                                                                       |
| <b>Values</b>          | file url: local-url   remote-url: 255 chars max<br>local-url: [ <i>cflash-id</i> ]/[ <i>file-path</i> ]<br>remote-url: [{ftp://}; login:pswd@remote-locn/][ <i>file-path</i> ]<br>remote-locn [ <i>hostname</i>   <i>ipv4-address</i>   [ <i>ipv6-address</i> ] ]<br>ipv4-address a.b.c.d ipv6-address - x:x:x:x:x:x:x[-<br>interface]<br><br>x:x:x:x:x:d.d.d.d[-interface]<br>x - [0..FFFF]H<br>d - [0..255]D<br>interface - 32 chars max, for link local addresses<br>cflash-id: cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B: |
| <b>Related Command</b> | <b>exec command on page 101</b> — This command executes the contents of a text file as if they were CLI commands entered at the console.                                                                                                                                                                                                                                                                                                                                                                                                     |

### boot-good-exec

|                    |                                                                                                                |
|--------------------|----------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>boot-good-exec</b> <i>file-url</i><br><b>no boot-good-exec</b>                                              |
| <b>Context</b>     | config>system                                                                                                  |
| <b>Description</b> | Use this command to configure a URL for a CLI script to exec following the success of a boot-up configuration. |
| <b>Default</b>     | no boot-good-exec                                                                                              |

## System Information Commands

**Parameters** *file-url* — Specifies the location and name of the file executed following successful completion of the boot-up configuration file execution. When this parameter is not specified, no CLI script file is executed.

**Values**

|              |                                                                                                                                                       |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| file url:    | local-url   remote-url: 255 chars max                                                                                                                 |
| local-url:   | [ <i>cflash-id</i> ]/[ <i>file-path</i> ]                                                                                                             |
| remote-url:  | [{ftp://} login:pswd@remote-locn]/[ <i>file-path</i> ]                                                                                                |
| remote-locn  | [ <i>hostname</i>   <i>ipv4-address</i>   [ <i>ipv6-address</i> ] ]                                                                                   |
| ipv4-address | a.b.c.d                                                                                                                                               |
| ipv6-address | - x:x:x:x:x:x:x[-interface]<br>x:x:x:x:x:d.d.d.d[-interface]<br>x - [0..FFFF]H<br>d - [0..255]D<br>interface - 32 chars max, for link local addresses |
| cflash-id:   | cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:                                                                                             |

**Related Command** **exec command on page 101** — This command executes the contents of a text file as if they were CLI commands entered at the console.

## cli-code

**Syntax** **cli-code** *cli-code*  
**no cli-code**

**Context** config>system

**Description** This command creates a Common Language Location Identifier (CLLI) code string for the 7950 XRS-Series router. A CLLI code is an 11-character standardized geographic identifier that uniquely identifies geographic locations and certain functional categories of equipment unique to the telecommunications industry.

No CLLI validity checks other than truncating or padding the string to eleven characters are performed.

Only one CLLI code can be configured, if multiple CLLI codes are configured the last one entered overwrites the previous entry.

The **no** form of the command removes the CLLI code.

**Default** none — No CLLI codes are configured.

**Parameters** *cli-code* — The 11 character string CLLI code. Any printable, seven bit ASCII characters can be used within the string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. If more than 11 characters are entered, the string is truncated. If less than 11 characters are entered the string is padded with spaces.

## config-backup

**Syntax** **config-backup** *count*  
**no config-backup**

**Context** config>system

**Description** This command configures the maximum number of backup versions maintained for configuration files and BOF.

For example, assume the **config-backup** *count* is set to 5 and the configuration file is called *xyz.cfg*. When a **save** command is executed, the file *xyz.cfg* is saved with a .1 extension. Each subsequent **config-backup** command increments the numeric extension until the maximum count is reached.

```
xyz.cfg
xyz.cfg.1
xyz.cfg.2
xyz.cfg.3
xyz.cfg.4
xyz.cfg.5
xyz.ndx
```

Each persistent index file is updated at the same time as the associated configuration file. When the index file is updated, then the save is performed to *xyz.cfg* and the index file is created as *xyz.ndx*. Synchronization between the active and standby CPM is performed for all configurations and their associated persistent index files.

The **no** form of the command returns the configuration to the default value.

**Default** 5

**Parameters** *count* — The maximum number of backup revisions.

**Values** 1 — 9

## contact

**Syntax** **contact** *contact-name*  
**no contact**

**Context** config>system

**Description** This command creates a text string that identifies the contact name for the device.

Only one contact can be configured, if multiple contacts are configured the last one entered will overwrite the previous entry.

The **no** form of the command reverts to default.

**Default** none — No contact name is configured.

**Parameters** *contact-name* — The contact name character string. The string can be up to 80 characters long. Any printable, seven-bit ASCII characters can be used within the string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## coordinates

**Syntax** **coordinates** *coordinates*  
**no coordinates**

## System Information Commands

**Context** config>system

**Description** This command creates a text string that identifies the system coordinates for the device location. For example, the command **coordinates** "37.390 -122.0550" is read as latitude 37.390 north and longitude 122.0550 west.

Only one set of coordinates can be configured. If multiple coordinates are configured, the last one entered overwrites the previous entry.

The **no** form of the command reverts to the default value.

**Default** none — No coordinates are configured.

**Parameters** *coordinates* — The coordinates describing the device location character string. The string may be up to 80 characters long. Any printable, seven-bit ASCII characters can be used within the string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. If the coordinates are subsequently used by an algorithm that locates the exact position of this node then the string must match the requirements of the algorithm.

## dns

**Syntax** dns

**Context** config>system

**Description** This command configures DNS settings.

## address-pref

**Syntax** address-pref {ipv4-only| ipv6-first}  
no address-pref

**Context** config>system>dns

**Description** This command configures the DNS address resolving order preference. By default DNS names are queried for A-records only (address-preference is IPv4-only).

If the address-preference is set to IPv6-first, the DNS server will be queried for AAAA-records (IPv6) first and if a successful replied is not received, then the DNS server is queried for A-records.

## ad-validation

**Syntax** ad-validation fall-through|drop  
no ad-validation

**Context** config>system>dns>dnssec

**Description** This command enables validation of the presence of the AD-bit in responses from the DNS servers, and reports a warning to the SECURITY log if DNSSEC validation was not possible.

This command requires either the `fall-through` or `drop` parameters be configured. When the `fall-through` parameter is supplied, the system will allow DNS responses that do not pass DNSSEC validation to be accepted and logged. When the `drop` parameter is specified, the system will reject and log DNS responses that do not pass DNSSEC validation and the resolution will appear to fail.

**Default** disabled

**Parameters** *fall-through* — Specifies that the DNSSEC validator should allow non-DNSSEC responses to fall-through to permit resolution in case of validation failure.

*drop* — Specifies that the DNSSEC validator should drop non-DNSSEC responses in case of validation failure.

## enable-icmp-vse

**Syntax** `[no] enable-icmp-vse`

**Context** `config>system`

**Description** This command enables vendor specific extensions to ICMP.

## load-balancing

**Syntax** `load-balancing`

**Context** `config>system>`

**Description** This command enables the load-balancing context to configure the interface per-flow load balancing options that will apply to traffic entering this interface and egressing over a LAG/ECMP on system-egress. This is a per interface setting. For load-balancing options that can also be enabled on the system level, the options enabled on the interface level overwrite system level configurations.

**Default** not applicable

## I4-load-balancing

**Syntax** `[no] I4-load-balancing`

**Context** `config>system>load-balancing`

**Description** This command configures system-wide Layer 4 load balancing. The configuration at the system level can enable or disable load balancing based on Layer 4 fields. If enabled, the Layer 4 source and destination port fields will be included in hashing calculation for TCP/UDP packets.

The hashing algorithm addresses finer spraying granularity where many hosts are connected to the network.

To address more efficient traffic distribution between network links (forming a LAG group), a hashing algorithm extension takes into account L4 information (that is, src/dst L4-protocol port).

## System Information Commands

The hashing index can be calculated according to the following algorithm:

```
If [(TCP or UDP traffic) & enabled]
    hash (<TCP/UDP ports>, <IP addresses>)
else if (IP traffic)
    hash (<IP addresses>)
else
    hash (<MAC addresses>)
endif
```

This algorithm will be used in all cases where IP information in per-packet hashing is included (see [LAG and ECMP Hashing in the Interfaces Guide](#)). However, the Layer 4 information (TCP/UDP ports) will not be used in the following cases:

- Fragmented packets

**Default** no l4-load-balancing

## lsr-load-balancing

**Syntax** **lsr-load-balancing {lbl-only|lbl-ip|ip-only|eth-encap-ip}**  
**no lsr-load-balancing**

**Context** config>system>load-balancing

**Description** This command configures system-wide LSR load balancing. Hashing can be enabled on the IP header at an LSR for spraying labeled IP packets over multiple equal cost paths in ECMP in an LDP LSP and/or over multiple links of a LAG group in all types of LSPs.

The LSR hash routine operates on the label stack and the IP header if a packet is IPv4. An LSR will consider a packet to be IPv4 if the first nibble following the bottom of the label stack is 4. IPv4 is supported only and on IOM-3 and IMMs. IPv6 packets are hashed on label stack only. The hash on label and IPv4 header can be enabled or disabled at the system level only.

**Default** disabled

**Parameters** **lbl-only** — Only the label is used in the hashing algorithm.

**lbl-ip** — The IP header is included in the hashing algorithm.

**ip-only** — the IP header is used exclusively in the hashing algorithm

**eth-encap-ip** — The hash algorithm parses down the label stack (up to 3 labels supported) and once it hits the bottom, the stack assumes Ethernet II non-tagged header follows. At the expected Ethertype offset location, the algorithm checks whether the value present is IPv4/v6 (0x0800 or 0x86DD). If the check passes, the hash algorithm checks the first nibble at the expected IP header location for IPv4/IPv6 (0x0100/0x0110). If the secondary check passes, the hash is performed using IP SA/DA fields in the expected IP header; if any of the checks fail, the label-stack hash is performed.

## mc-enh-load-balancing

**Syntax** [no] mc-enh-load-balancing

**Context** config>system>load-balancing

**Description** This command enables enhanced egress multicast load balancing behavior for Layer 3 multicast. When enabled, the router will spray the multicast traffic using as hash inputs from the packet based on lsr-load-balancing, l4-load-balancing and system-ip-load-balancing configurations. That is, an ingress LER or IP PE will spray traffic based on the IP hash criteria: SA/DA + optional Layer 4 port + optional system IP egress LER or LSR - will spray traffic based on label or IP hash criteria outlined above or both based on configuration of lsr-load-balancing, l4-load-balancing, and system-ip-load-balancing.

The **no** form of the command preserves the default behavior for per flow hashing of multicast traffic.

## service-id-lag-hashing

**Syntax** [no] service-id-lag-hashing

**Context** config>system>load-balancing

**Description** This command enables enhanced VLL LAG service ID hashing. This command improves the LAG spraying of VLL service packets and is applied only when both ECMP and LAG hashing are performed by the same router. By default, the ECMP interface and LAG link for all packets on the VLL service are selected based on a direct modulo operation of the service ID. This command enhances distribution and hashes the service ID prior to the LAG link modulo operation when an ECMP link modulo operation is performed.

The **no** form of the command preserves the default behavior of VLL LAG service ID hashing.

## system-ip-load-balancing

**Syntax** system-ip-load-balancing  
no system-ip-load-balancing

**Context** config>system>load-balancing

**Description** This command enables the use of the system IP address in the ECMP hash algorithm to add a per system variable. This can help guard against cases where multiple routers, in series, will end up hashing traffic to the same ECMP/LAG path.

This command is set at a system wide basis. By default, the IPv4 system IP address is used in the hash algorithm. When no IPv4 system IP address is configured, the IPv6 system IP address, when configured, is used in the hash algorithm.

The **no** form of the command resets the system wide algorithm to default.

**Default** no system-ip-load-balancing

## lACP-system-priority

## System Information Commands

**Syntax** **lacp-system-priority** *lacp-system-priority*  
**no lacp-system-priority**

**Context** config>system

**Description** This command configures the Link Aggregation Control Protocol (LACP) system priority on aggregated Ethernet interfaces. LACP allows the operator to aggregate multiple physical interfaces to form one logical interface.

**Default** 32768

**Parameters** *lacp-system-priority* — Specifies the LACP system priority.

**Values** 1 — 65535

## location

**Syntax** **location** *location*  
**no location**

**Context** config>system

**Description** This command creates a text string that identifies the system location for the device.  
Only one location can be configured. If multiple locations are configured, the last one entered overwrites the previous entry.

The **no** form of the command reverts to the default value.

**Default** **none** — No system location is configured.

**Parameters** *location* — Enter the location as a character string. The string may be up to 80 characters long. Any printable, seven-bit ASCII characters can be used within the string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## name

**Syntax** **name** *system-name*  
**no name**

**Context** config>system

**Description** This command creates a system name string for the device.  
For example, system-name parameter ALA-1 for the **name** command configures the device name as ALA-1.

```
ABC>config>system# name "ALA-1"  
ALA-1>config>system#
```

Only one system name can be configured. If multiple system names are configured, the last one encountered overwrites the previous entry.

The **no** form of the command reverts to the default value.

**Default** The default system name is set to the chassis serial number which is read from the backplane EEPROM.

**Parameters** *system-name* — Enter the system name as a character string. The string may be up to 32 characters long. Any printable, seven-bit ASCII characters can be used within the string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## switchover-exec

**Syntax** **switchover-exec** *file-url*  
**no switchover-exec**

**Context** config>system

**Description** This command specifies the location and name of the CLI script file executed following a redundancy switchover from the previously active CPM card. A switchover can happen because of a fatal failure or by manual action.

The CLI script file can contain commands for environment settings, debug (excluding mirroring settings), and other commands not maintained by the configuration redundancy.

The following commands are not supported in the switchover-exec file: clear, configure, candidate, oam, tools, oam, ping, traceroute, mstat, mtrace and mrinfo.

When the *file-url* parameter is not specified, no CLI script file is executed.

**Default** none

**Parameters** *file-url* — Specifies the location and name of the CLI script file.

|               |             |                                                                  |
|---------------|-------------|------------------------------------------------------------------|
| <b>Values</b> | file url:   | local-url   remote-url: 255 chars max                            |
|               | local-url:  | [ <i>flash-id</i> ]/[ <i>file-path</i> ]                         |
|               | remote-url: | [{ftp:// tftp://} login:pswd@remote-locn/][ <i>file-path</i> ]   |
|               | flash-id:   | cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B: |

---

## System Alarm Commands

### alarm

**Syntax** **alarm** *rmon-alarm-id* **variable-oid** *oid-string* **interval** *seconds* [*sample-type*] [**startup-alarm** *alarm-type*] [**rising-event** *rmon-event-id* **rising-threshold** *threshold*] [**falling-event** *rmon-event-id* **falling threshold** *threshold*] [**owner** *owner-string*]  
**no alarm** *rmon-alarm-id*

**Context** config>system>thresholds>rmon

**Description** The alarm command configures an entry in the RMON-MIB alarmTable. The alarm command controls the monitoring and triggering of threshold crossing events. In order for notification or logging of a threshold crossing event to occur there must be at least one associated rmon>event configured.

The agent periodically takes statistical sample values from the MIB variable specified for monitoring and compares them to thresholds that have been configured with the alarm command. The alarm command configures the MIB variable to be monitored, the polling period (interval), sampling type (absolute or delta value), and rising and falling threshold parameters. If a sample has crossed a threshold value, the associated event is generated.

Use the **no** form of this command to remove an rmon-alarm-id from the configuration.

**Parameters** *rmon-alarm-id* — The rmon-alarm-id is a numerical identifier for the alarm being configured. The number of alarms that can be created is limited to 1200.

**Default** None

**Values** 1 — 65535

**variable-oid** *oid-string* — The oid-string is the SNMP object identifier of the particular variable to be sampled. Only SNMP variables that resolve to an ASN.1 primitive type of integer (integer, Integer32, Counter32, Counter64, Gauge, or TimeTicks) may be sampled. The oid-string may be expressed using either the dotted string notation or as object name plus dotted instance identifier. For example, "1.3.6.1.2.1.2.2.1.10.184582144" or "ifInOctets.184582144".

The oid-string has a maximum length of 255 characters

**Default** None

**interval** *seconds* — The interval in seconds specifies the polling period over which the data is sampled and compared with the rising and falling thresholds. When setting this interval value, care should be taken in the case of 'delta' type sampling - the interval should be set short enough that the sampled variable is very unlikely to increase or decrease by more than 2147483647 - 1 during a single sampling interval. Care should also be taken not to set the interval value too low to avoid creating unnecessary processing overhead.

**Default** None

**Values** 1 — 2147483647

**sample-type** — Specifies the method of sampling the selected variable and calculating the value to be compared against the thresholds.

**Default**     **Absolute**

**Values**     **absolute** — Specifies that the value of the selected variable will be compared directly with the thresholds at the end of the sampling interval.

**delta** — Specifies that the value of the selected variable at the last sample will be subtracted from the current value, and the difference compared with the thresholds.

**startup-alarm** *alarm-type* — Specifies the alarm that may be sent when this alarm is first created.

If the first sample is greater than or equal to the rising threshold value and 'startup-alarm' is equal to 'rising' or 'either', then a single rising threshold crossing event is generated.

If the first sample is less than or equal to the falling threshold value and 'startup-alarm' is equal to 'falling' or 'either', a single falling threshold crossing event is generated.

**Default**     **either**

**Values**     **rising, falling, either**

**rising-event** *rmon-event-id* — The identifier of the the **rmon>event** that specifies the action to be taken when a rising threshold crossing event occurs.

If there is no corresponding 'event' configured for the specified rmon-event-id, then no association exists and no action is taken.

If the 'rising-event rmon-event-id' has a value of zero (0), no associated event exists.

If a 'rising event rmon-event' is configured, the CLI requires a 'rising-threshold' to also be configured.

**Default**     0

**Values**     0 — 65535

**rising-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated startup-alarm is equal to rising or either.

After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the 'falling-threshold' value.

**Default**     0

**Values**     -2147483648 — 2147483647

**falling-event** *rmon-event-id* — The identifier of the **rmon>event** that specifies the action to be taken when a falling threshold crossing event occurs. If there is no corresponding event configured for the specified rmon-event-id, then no association exists and no action is taken. If the falling-event has a value of zero (0), no associated event exists.

If a 'falling event' is configured, the CLI requires a 'falling-threshold' to also be configured.

**Default**     0

**Values**     0 — 65535

**falling-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than

## System Alarm Commands

this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated 'startup-alarm' is equal to 'falling' or 'either'.

After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.

**Default** 0

**Values** -2147483648 — 2147483647

**owner** *owner* — The owner identifies the creator of this alarm. It defaults to "TiMOS CLI". This parameter is defined primarily to allow entries that have been created in the RMON-MIB alarmTable by remote SNMP managers to be saved and reloaded in a CLI configuration file. The owner will not normally be configured by CLI users and can be a maximum of 80 characters long.

**Default** TiMOS CLI

Configuration example:

```
alarm 3 variable-oid ifInOctets.184582144 interval 20 sample-type delta start-alarm either
rising-event 5 rising-threshold 10000 falling-event 5 falling-threshold 9000 owner "TiMOS
CLI"
```

## cflash-cap-alarm

**Syntax** **cflash-cap-alarm** *cflash-id* **rising-threshold** *threshold* [**falling-threshold** *threshold*] **interval** *seconds* [*rmon-event-type*] [**startup-alarm** *alarm-type*]  
**no cflash-cap-alarm** *cflash-id*

**Context** config>system>thresholds

**Description** This command enables capacity monitoring of the compact flash specified in this command. The severity level is alarm. Both a rising and falling threshold can be specified.

The **no** form of this command removes the configured compact flash threshold alarm.

**Parameters** *cflash-id* — The cflash-id specifies the name of the cflash device to be monitored.

**Values** cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

**rising-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated 'startup-alarm' is equal to 'rising' or 'either'.

After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the 'falling-threshold' value.

The threshold value represents units of 512 bytes.

**Default** 0

**Values** -2147483648 — 2147483647

**falling-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated startup-alarm is equal to falling or either.

After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.

The threshold value represents units of 512 bytes.

**Default** 0

**Values** -2147483648 — 2147483647

**interval** *seconds* — Specifies the polling period, in seconds, over which the data is sampled and compared with the rising and falling thresholds.

**Values** 1 — 2147483647

**rmon-event-type** — Specifies the type of notification action to be taken when this event occurs.

**Values** log — An entry is made in the RMON-MIB log table for each event occurrence. This does not create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the **show>system>thresholds** CLI command.

trap — A TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session, memory log, cflash file, syslog, or SNMP trap destinations logs.

both — Both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.

none — No action is taken.

**Default** both

**startup-alarm** *alarm-type* — Specifies the alarm that may be sent when this alarm is first created.

If the first sample is greater than or equal to the rising threshold value and startup-alarm is equal to rising or either, then a single rising threshold crossing event is generated.

If the first sample is less than or equal to the falling threshold value and startup-alarm is equal to falling or either, a single falling threshold crossing event is generated.

**Default** either

**Values** rising, falling, either

Configuration example:

```
cflash-cap-alarm cf1-A: rising-threshold 50000000 falling-threshold 49999900 interval 120 rmon-
event-type both start-alarm rising.
```

cflash-cap-warn

## System Alarm Commands

**Syntax** **cflash-cap-warn** *cflash-id* **rising-threshold** *threshold* [**falling-threshold** *threshold*] **interval** *seconds* [*rmon-event-type*] [**startup-alarm** *alarm-type*]  
**no cflash-cap-warn** *cflash-id*

**Context** config>system>thresholds

**Description** This command enables capacity monitoring of the compact flash specified in this command. The severity level is warning. Both a rising and falling threshold can be specified. The no form of this command removes the configured compact flash threshold warning.

**Parameters** *cflash-id* — The cflash-id specifies the name of the cflash device to be monitored.

**Values** cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

**rising-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated startup-alarm is equal to rising or either.

After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the falling-threshold value.

The threshold value represents units of 512 bytes.

**Default** 0

**Values** -2147483648 — 2147483647

**falling-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated startup-alarm is equal to falling or either.

After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.

The threshold value represents units of 512 bytes.

**Default** 0

**Values** -2147483648 — 2147483647

**interval** *seconds* — Specifies the polling period over which the data is sampled and compared with the rising and falling thresholds.

**Values** 1 — 2147483647

**rmon-event-type** — Specifies the type of notification action to be taken when this event occurs.

**Values** log — In the case of log, an entry is made in the RMON-MIB log table for each event occurrence. This does not create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the show>system>thresholds CLI command.

trap — In the case of trap, a TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may

be CONSOLE, telnet session , memory log, cflash file, syslog, or SNMP trap destinations logs.

both — In the case of both, both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.

none — In the case of none, no action is taken.

**Default** both

**startup-alarm** *alarm-type* — Specifies the alarm that may be sent when this alarm is first created. If the first sample is greater than or equal to the rising threshold value and startup-alarm is equal to rising or either, then a single rising threshold crossing event is generated. If the first sample is less than or equal to the falling threshold value and startup-alarm is equal to falling or either, a single falling threshold crossing event is generated.

**Values** rising, falling, either

**Default** either

Configuration example:

```
cflash-cap-warn cf1-B: rising-threshold 2000000 falling-threshold 1999900 interval 240 rmon-event-type trap start-alarm either
```

## kb-memory-use-alarm

**Syntax** **kb-memory-use-alarm rising-threshold** *threshold* [**falling-threshold** *threshold*] **interval** *seconds* [*rmon-event-type*] [**startup-alarm** *alarm-type*]  
**no kb-memory-use-warn**

**Context** config>system>thresholds

**Description** This command configures memory use, in kilobytes, alarm thresholds.  
The **no** form of the command removes the parameters from the configuration.

**Default** none

**Parameters** **rising-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated startup-alarm is equal to rising or either.

After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the falling-threshold value.

The threshold value represents units of kilobytes.

**Default** 0

**Values** -2147483648 — 2147483647

## System Alarm Commands

**falling-threshold *threshold*** — Specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated startup-alarm is equal to falling or either.

After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.

The threshold value represents units of kilobytes.

**Default** 0

**Values** -2147483648 — 2147483647

**interval *seconds*** — Specifies the polling period over which the data is sampled and compared with the rising and falling thresholds.

**Values** 1 — 2147483647

**rmon-event-type** — Specifies the type of notification action to be taken when this event occurs.

**Values** log — In the case of log, an entry is made in the RMON-MIB log table for each event occurrence. This does not create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the show>system>thresholds CLI command.

trap — In the case of trap, a TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session, memory log, cflash file, syslog, or SNMP trap destinations logs.

both — In the case of both, both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.

none — In the case of none, no action is taken.

**Default** both

**startup-alarm *alarm-type*** — Specifies the alarm that may be sent when this alarm is first created. If the first sample is greater than or equal to the rising threshold value and startup-alarm is equal to rising or either, then a single rising threshold crossing event is generated. If the first sample is less than or equal to the falling threshold value and startup-alarm is equal to falling or either, a single falling threshold crossing event is generated.

**Values** rising, falling, either

**Default** either

## kb-memory-use-warn

**Syntax** **kb-memory-use-warn rising-threshold *threshold* [falling-threshold *threshold*] interval *seconds* [rmon-event-type] [startup-alarm *alarm-type*]**  
**no kb-memory-use-warn**

**Context** config>system>thresholds

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This command configures memory usage, in kilobytes, for warning thresholds                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Default</b>     | none                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Parameters</b>  | <p><b>rising-threshold</b> <i>threshold</i> — Specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated startup-alarm is equal to rising or either.</p> <p>After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the falling-threshold value.</p> <p>The threshold value represents units of kilobytes.</p> <p><b>Default</b> 0</p> <p><b>Values</b> -2147483648 — 2147483647</p> <p><b>falling-threshold</b> <i>threshold</i> — Specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated startup-alarm is equal to falling or either.</p> <p>After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.</p> <p>The threshold value represents units of kilobytes.</p> <p><b>Default</b> 0</p> <p><b>Values</b> -2147483648 — 2147483647</p> <p><b>interval</b> <i>seconds</i> — Specifies the polling period over which the data is sampled and compared with the rising and falling thresholds.</p> <p><b>Values</b> 1 — 2147483647</p> <p><b>rmon-event-type</b> — Specifies the type of notification action to be taken when this event occurs.</p> <p><b>Values</b></p> <ul style="list-style-type: none"> <li>log — In the case of log, an entry is made in the RMON-MIB log table for each event occurrence. This does not create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the show&gt;system&gt;thresholds CLI command.</li> <li>trap — In the case of trap, a TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session , memory log, cflash file, syslog, or SNMP trap destinations logs.</li> <li>both — In the case of both, both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.</li> <li>none — In the case of none, no action is taken.</li> </ul> <p><b>Default</b> both</p> <p><b>startup-alarm</b> <i>alarm-type</i> — Specifies the alarm that may be sent when this alarm is first created. If the first sample is greater than or equal to the rising threshold value and startup-alarm is equal to rising or</p> |

## System Alarm Commands

either, then a single rising threshold crossing event is generated. If the first sample is less than or equal to the falling threshold value and startup-alarm is equal to falling or either, a single falling threshold crossing event is generated.

**Values** rising, falling, either

**Default** either

### event

**Syntax** **event** *rmon-event-id* [*event-type*] [**description** *description-string*] [**owner** *owner-string*]  
**no event** *rmon-event-id*

**Context** config>system>thresholds>rmon

**Description** The event command configures an entry in the RMON-MIB event table. The event command controls the generation and notification of threshold crossing events configured with the alarm command. When a threshold crossing event is triggered, the **rmon>event** configuration optionally specifies if an entry in the RMON-MIB log table should be created to record the occurrence of the event. It may also specify that an SNMP notification (trap) should be generated for the event. The RMON-MIB defines two notifications for threshold crossing events: Rising Alarm and Falling Alarm.

Creating an event entry in the RMON-MIB log table does not create a corresponding entry in the TiMOS event logs. However, when the **event-type** is set to trap, the generation of a Rising Alarm or Falling Alarm notification creates an entry in the TiMOS event logs and that is distributed to whatever TiMOS log destinations are configured: CONSOLE, session, memory, file, syslog, or SNMP trap destination.

The TiMOS logger message includes a rising or falling threshold crossing event indicator, the sample type (absolute or delta), the sampled value, the threshold value, the RMON-alarm-id, the associated RMON-event-id and the sampled SNMP object identifier.

Use the **no** form of this command to remove an rmon-event-id from the configuration.

**Parameters** **rmon-event-type** — The rmon-event-type specifies the type of notification action to be taken when this event occurs.

**Values** log — In the case of log, an entry is made in the RMON-MIB log table for each event occurrence.

This does **not** create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the **show>system>thresholds** CLI command.

trap — In the case of trap, a TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session, memory log, cflash file, syslog, or SNMP trap destinations logs.

both — In the case of both, both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.

none — In the case of none, no action is taken.

**Default** both

**description** — The description is a user configurable string that can be used to identify the purpose of this event. This is an optional parameter and can be 80 characters long. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**Default** An empty string.

**owner** *owner* — The owner identifies the creator of this alarm. It defaults to "TiMOS CLI". This parameter is defined primarily to allow entries that have been created in the RMON-MIB alarmTable by remote SNMP managers to be saved and reloaded in a CLI configuration file. The owner will not normally be configured by CLI users and can be a maximum of 80 characters long.

**Default** TiMOS CLI

Configuration example:

**Default** event 5 rmon-event-type both description "alarm testing" owner "TiMOS CLI"

## memory-use-alarm

**Syntax** **memory-use-alarm rising-threshold** *threshold* [**falling-threshold** *threshold*] **interval** *seconds* [*rmon-event-type*] [**startup-alarm** *alarm-type*]  
**no memory-use-alarm**

**Context** config>system>thresholds

**Description** The memory thresholds are based on monitoring the TIMETRA-SYSTEM-MIB *sgiMemoryUsed* object. This object contains the amount of memory currently used by the system. The severity level is Alarm. The absolute sample type method is used.

The **no** form of this command removes the configured memory threshold warning.

**Parameters** **rising-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated startup-alarm is equal to rising or either.

After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the falling-threshold value.

The threshold value represents units of bytes.

**Default** 0

**Values** -2147483648 — 2147483647

**falling-threshold** *threshold* — Specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated startup-alarm is equal to falling or either.

After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.

## System Alarm Commands

The threshold value represents units of bytes.

**Default** 0

**Values** -2147483648 — 2147483647

**interval** *seconds* — Specifies the polling period over which the data is sampled and compared with the rising and falling thresholds.

The threshold value represents units of bytes.

**Values** 1 — 2147483647

**rmon-event-type** — Specifies the type of notification action to be taken when this event occurs.

**Values** log — In the case of log, an entry is made in the RMON-MIB log table for each event occurrence. This does not create an OS logger entry. The RMON-MIB log table entries can be viewed using the CLI command.

trap — In the case of trap, a TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session, memory log, cflash file, syslog, or SNMP trap destinations logs.

both — In the case of both, both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.

none — In the case of none, no action is taken.

**Default** both

**startup-alarm** *alarm-type* — Specifies the alarm that may be sent when this alarm is first created. If the first sample is greater than or equal to the rising threshold value and startup-alarm is equal to rising or either, then a single rising threshold crossing event is generated. If the first sample is less than or equal to the falling threshold value and startup-alarm is equal to falling or either, a single falling threshold crossing event is generated.

**Values** rising, falling, either

**Default** either

Configuration example:

```
memory-use-alarm rising-threshold 50000000 falling-threshold 45999999 interval 500 rmon-event-type both start-alarm either
```

## memory-use-warn

**Syntax** **memory-use-warn** **rising-threshold** *threshold* [**falling-threshold** *threshold*] **interval** *seconds* [*rmon-event-type*] [**startup-alarm** *alarm-type*]  
**no memory-use-warn**

**Context** config>system>thresholds

**Description** The memory thresholds are based on monitoring MemoryUsed object. This object contains the amount of memory currently used by the system. The severity level is Alarm.

The absolute sample type method is used.

The **no** form of this command removes the configured compact flash threshold warning.

**Parameters** **rising-threshold** *threshold* — The rising-threshold specifies a threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is greater than or equal to this threshold and the associated startup-alarm is equal to rising or either.

After a rising threshold crossing event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches less than or equal the falling-threshold value.

**Default** 0

**Values** -2147483648 — 2147483647

**falling-threshold** *threshold* — The falling-threshold specifies a threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single threshold crossing event will be generated. A single threshold crossing event will also be generated if the first sample taken is less than or equal to this threshold and the associated startup-alarm is equal to falling or either.

After a falling threshold crossing event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches greater than or equal the rising-threshold value.

**Default** 0

**Values** -2147483648 — 2147483647

**interval** *seconds* — The interval in seconds specifies the polling period over which the data is sampled and compared with the rising and falling thresholds.

**Values** 1 — 2147483647

**rmon-event-type** — Specifies the type of notification action to be taken when this event occurs.

**Values** log — In the case of log, an entry is made in the RMON-MIB log table for each event occurrence.

This does not create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the **show>system>thresholds** CLI command.

trap — In the case of trap, a TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session, memory log, cflash file, syslog, or SNMP trap destinations logs.

both — In the case of both, both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.

none — In the case of none, no action is taken.

**Default** both

## System Alarm Commands

**Values** log, trap, both, none

**startup-alarm** *alarm-type* — Specifies the alarm that may be sent when this alarm is first created. If the first sample is greater than or equal to the rising threshold value and startup-alarm is equal to rising or either, then a single rising threshold crossing event is generated. If the first sample is less than or equal to the falling threshold value and startup-alarm is equal to falling or either, a single falling threshold crossing event is generated.

**Default** either

**Values** rising, falling, either

Configuration example:

```
memory-use-warn rising-threshold 500000 falling-threshold 400000 interval 800 rmon-event-  
type log start-alarm falling
```

## rmon

**Syntax** rmon

**Context** config>system>thresholds

**Description** This command creates the context to configure generic RMON alarms and events.

Generic RMON alarms can be created on any SNMP object-ID that is valid for RMON monitoring (for example, an integer-based datatype).

The configuration of an event controls the generation and notification of threshold crossing events configured with the alarm command.

## thresholds

**Syntax** thresholds

**Context** config>system

**Description** This command enables the context to configure monitoring thresholds.

---

## Date and Time Commands

### set-time

**Syntax** `set-time [date] [time]`

**Context** admin

**Description** This command sets the local system time.

The time entered should be accurate for the time zone configured for the system. The system will convert the local time to UTC before saving to the system clock which is always set to UTC. This command does not take into account any daylight saving offset if defined.

If SNTP or NTP is enabled (no shutdown) then this command cannot be used.

**Parameters** *date* — The local date and time accurate to the minute in the YYYY/MM/DD format.

**Values** *YYYY* is the four-digit year  
*MM* is the two-digit month  
*DD* is the two-digit date

*time* — The time (accurate to the second) in the *hh:mm[:ss]* format. If no seconds value is entered, the seconds are reset to :00.

**Default** 0

**Values** *hh* is the two-digit hour in 24 hour format (00=midnight, 12=noon)  
*mm* is the two-digit minute

### time

**Syntax** `time`

**Context** config>system

**Description** This command enables the context to configure the system time zone and time synchronization parameters.

---

## Network Time Protocol Commands

### ntp

**Syntax** [no] ntp

**Context** config>system>time

**Description** This command enables the context to configure Network Time Protocol (NTP) and its operation. This protocol defines a method to accurately distribute and maintain time for network elements. Furthermore this capability allows for the synchronization of clocks between the various network elements. Use the no form of the command to stop the execution of NTP and remove its configuration.

**Default** none

### authentication-check

**Syntax** [no] authentication-check

**Context** config>system>time>ntp

**Description** This command provides the option to skip the rejection of NTP PDUs that do not match the authentication key-id, type or key requirements. The default behavior when authentication is configured is to reject all NTP protocol PDUs that have a mismatch in either the authentication key-id, type or key.

When **authentication-check** is enabled, NTP PDUs are authenticated on receipt. However, mismatches cause a counter to be increased, one counter for type and one for key-id, one for type, value mismatches. These counters are visible in a show command.

The **no** form of this command allows authentication mismatches to be accepted; the counters however are maintained.

**Default** authentication-check — Rejects authentication mismatches.

### authentication-key

**Syntax** **authentication-key** *key-id* {**key** *key*} [**hash** | **hash2**] **type** {**des** | **message-digest**}  
**no authentication-key** *key-id*

**Context** config>system>time>ntp

**Description** This command sets the authentication key-id, type and key used to authenticate NTP PDUs sent to or received by other network elements participating in the NTP protocol. For authentication to work, the authentication key-id, type and key value must match.

The **no** form of the command removes the authentication key.

**Default** none

- Parameters** *key-id* — Configure the authentication key-id that will be used by the node when transmitting or receiving Network Time Protocol packets.
- Entering the authentication-key command with a key-id value that matches an existing configuration key will result in overriding the existing entry.
- Recipients of the NTP packets must have the same authentication key-id, type, and key value in order to use the data transmitted by this node. This is an optional parameter.
- Default** None
- Values** 1 — 255
- key** — The authentication key associated with the configured key-id, the value configured in this parameter is the actual value used by other network elements to authenticate the NTP packet.
- The key can be any combination of ASCII characters up to 32 characters in length for message-digest (md5) or 8 characters in length for des (length limits are unencrypted lengths). If spaces are used in the string, enclose the entire string in quotation marks (“ ”).
- hash** — Specifies the key is entered in an encrypted form. If the hash or hash2 parameter is not used, the key is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted form in the configuration file with the hash or hash2 parameter specified.
- hash2** — Specifies the key is entered in a more complex encrypted form that involves more variables than the key value alone, this means that hash2 encrypted variable can't be copied and pasted. If the hash or hash2 parameter is not used, the key is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted form in the configuration file with the hash or hash2 parameter specified.
- type** — This parameter determines if DES or message-digest authentication is used.
- This is a required parameter; either DES or message-digest must be configured.
- Values** des — Specifies that DES authentication is used for this key  
 message-digest — Specifies that MD5 authentication in accordance with RFC 2104 is used for this key.
- Note:** des is not permitted in FIPS-140-2 mode.

## broadcast

- Syntax** **broadcast** [*router router-name*] {**interface** *ip-int-name*} [**key-id** *key-id*] [**version** *version*] [**tll** *tll*]  
**no broadcast** [*router router-name*] {**interface** *ip-int-name*}
- Context** config>system>time>ntp
- Description** This command configures the node to transmit NTP packets on a given interface. Broadcast and multicast messages can easily be spoofed, thus, authentication is strongly recommended.
- The **no** form of this command removes the address from the configuration.
- Parameters** *router* — Specifies the router name used to transmit NTP packets. Base is the default. Select management to use the management port (Ethernet port on the CPM)

## Network Time Protocol Commands

**Values** Base, management

**Default** Base

*ip-int-name* — Specifies the local interface on which to transmit NTP broadcast packets. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**Values** 32 character maximum

**key-id** *key-id* — Identifies the configured authentication key and authentication type used by this node to receive and transmit NTP packets to and from an NTP server and peers. If an NTP packet is received by this node both authentication key and authentication type must be valid otherwise the packet will be rejected and an event/trap generated.

**Values** 1 — 255

**Default** none

**version** *version* — Specifies the NTP version number that is generated by this node. This parameter does not need to be configured when in client mode in which case all versions will be accepted.

**Values** 1 — 4

**Default** 4

**ttl** *ttl* — Specifies the IP Time To Live (TTL) value.

**Values** 1 — 255

**Default** none

## broadcastclient

**Syntax** **broadcastclient** [**router** *router-name*] {**interface** *ip-int-name*} [**authenticate**]  
**no broadcastclient** [**router** *router-name*] {**interface** *ip-int-name*}

**Context** config>system>time>ntp

**Description** When configuring NTP, the node can be configured to receive broadcast packets on a given subnet. Broadcast and multicast messages can easily be spoofed, thus, authentication is strongly recommended. If broadcast is not configured then received NTP broadcast traffic will be ignored. Use the **show** command to view the state of the configuration.

The **no** form of this command removes the address from the configuration.

**Parameters** **router** *router-name* — Specifies the router name used to receive NTP packets.

**Values** Base, management

**Default** Base

**interface** *ip-int-name* — Specifies the local interface on which to receive NTP broadcast packets. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

**Values** 32 character maximum

**authenticate** — Specifies whether or not to require authentication of NTP PDUs. When enabled, NTP PDUs are authenticated upon receipt.

## multicast

**Syntax** **multicast** [**version** *version*] [**key-id** *key-id*]  
**no multicast**

**Context** config>system>time>ntp

**Description** This command configures NTP the node to transmit multicast packets on the CPMCCM MGMT port. Broadcast and multicast messages can easily be spoofed; authentication is strongly recommended. The **no** form of this command removes the multicast address from the configuration.

**Parameters** **version** *version* — Specifies the NTP version number that is generated by this node. This parameter does not need to be configured when in client mode in which case all three versions are accepted.

**Values** 2 — 4

**Default** 4

**key-id** *key-id* — Specifies the configured authentication key and authentication type used by this version to transmit NTP packets. If this command is omitted from the configuration, packets are sent un-encrypted.

**Values** 1 — 255

**Default** None

## multicastclient

**Syntax** **multicastclient** [**authenticate**]  
**no multicastclient**

**Context** config>system>time>ntp

**Description** This command configures the node to receive multicast NTP messages on the MGMT port. If **multicastclient** is not configured, received NTP multicast traffic will be ignored. Use the **show** command to view the state of the configuration.

The **no** construct of this message removes the multicast client for the specified interface from the configuration.

**Parameters** **authenticate** — This optional parameter makes authentication a requirement. If authentication is required, the authentication key-id received must have been configured in the “authentication-key” command, and that key-id’s type and key value must also match.

## ntp-server

## Network Time Protocol Commands

**Syntax** **ntp-server** [authenticate]  
**no ntp-server**

**Context** config>system>time>ntp

**Description** This command configures the node to assume the role of an NTP server. Unless the server command is used, this node will function as an NTP client only and will not distribute the time to downstream network elements.

**Default** no ntp-server

**Parameters** **authenticate** — If specified, makes authentication a requirement. If authentication is required, the authentication key-id received in a message must have been configured in the “authentication-key” command, and that key-id’s type and key value must also match.

The authentication key from the received messages will be used for the transmitted messages.

## peer

**Syntax** **peer** {ip-address | ipv6-address} [key-id key-id] [version version] [prefer]  
**no peer** ip-address

**Context** config>system>time>ntp

**Description** Configuration of an NTP peer configures symmetric active mode for the configured peer. Although any system can be configured to peer with any other NTP node it is recommended to configure authentication and to configure known time servers as their peers.

The **no** form of the command removes the configured peer.

**Parameters** *ipv6-address* — ipv6-address - Configure the IPv6 address of the peer that requires a peering relationship to be set up.

**Default** None

**Values** x:x:x:x:x:x:x (eight 16-bit pieces)  
x:x:x:x:x:d.d.d.d  
x [0 — FFFF]H  
d [0 — 255]D

*ip-address* — Configure the IP address of the peer that requires a peering relationship to be set up. This is a required parameter.

**Default** None

**Values** Any valid IP-address

**key-id** *key-id* — Successful authentication requires that both peers must have configured the same authentication key-id, type and key value.

Specify the *key-id* that identifies the configured authentication key and authentication type used by this node to transmit NTP packets to an NTP peer. If an NTP packet is received by this node, the

authentication key-id, type, and key value must be valid otherwise the packet will be rejected and an event/trap generated.

**Default** None

**Values** 1 — 255

**version** *version* — Specify the NTP version number that is generated by this node. This parameter does not need to be configured when in client mode in which case all three nodes are accepted.

**Default** 4

**Values** 2 — 4

**prefer** — When configuring more than one peer, one remote system can be configured as the preferred peer. When a second peer is configured as preferred, then the new entry overrides the old entry.

## server

**Syntax** **server** {*ip address* | *ipv6-address*}[**key-id** *key-id*] [**version** *version*] [**prefer**]  
**no server** *ip address*

**Context** config>system>time>ntp

**Description** This command is used when the node should operate in client mode with the ntp server specified in the address field of this command. The no construct of this command removes the server with the specified address from the configuration.

**Parameters** *ipv6-address* — Configure the IPv6 address of the node that acts as an NTP server to this network element.

**Default** None

**Values** x:x:x:x:x:x:x (eight 16-bit pieces)  
 x:x:x:x:x:d.d.d.d  
 x [0 — FFFF]H  
 d [0 — 255]D

*ip-address* — Configures the IP address of a node that acts as an NTP server to this network element. This is a required parameter.

**Values** Any valid IP address

**key-id** *key-id* — Enters the key-id that identifies the configured authentication key and authentication type used by this node to transmit NTP packets to an NTP server. If an NTP packet is received by this node, the authentication key-id, type, and key value must be valid otherwise the packet will be rejected and an event/trap generated. This is an optional parameter.

**Values** 1 — 255

**version** *version* — Configures the NTP version number that is expected by this node. This is an optional parameter

**Default** 4

**Values** 2 — 4

## Network Time Protocol Commands

**prefer** — When configuring more than one peer, one remote system can be configured as the preferred peer. When a second peer is configured as preferred, then the new entry overrides the old entry.

---

## SNTP Commands

### sntp

**Syntax** [no] sntp

**Context** config>system>time

**Description** This command creates the context to edit the Simple Network Time Protocol (SNTP).  
SNTP can be configured in either broadcast or unicast client mode. SNTP is a compact, client-only version of the NTP. SNTP can only receive the time from SNTP/NTP servers. It cannot be used to provide time services to other systems.  
The system clock is automatically adjusted at system initialization time or when the protocol first starts up. When the time differential between the SNTP/NTP server and the system is more than 2.5 seconds, the time on the system is gradually adjusted.  
SNTP is created in an administratively enabled state (**no shutdown**).  
The **no** form of the command removes the SNTP instance and configuration. SNTP does not need to be administratively disabled when removing the SNTP instance and configuration.

**Default** no sntp

### broadcast-client

**Syntax** [no] broadcast-client

**Context** config>system>time>sntp

**Description** This command enables listening to SNTP/NTP broadcast messages on interfaces with broadcast client enabled at global device level.  
When this global parameter is configured then the **ntp-broadcast** parameter must be configured on selected interfaces on which NTP broadcasts are transmitted.  
SNTP must be shutdown prior to changing either to or from broadcast mode.  
The **no** form of the command disables broadcast client mode.

**Default** no broadcast-client

### server-address

**Syntax** **server-address** *ip-address* [**version** *version-number*] [**normal** | **preferred**]  
[**interval** *seconds*]  
**no server-address**

## Network Time Protocol Commands

**Context** config>system>time>sntp

**Description** This command creates an SNTP server for unicast client mode.

**Parameters** *ip-address* — Specifies the IP address of the SNTP server.

**version** *version-number* — Specifies the SNTP version supported by this server.

**Values** 1 — 3

**Default** 3

**normal | preferred** — Specifies the preference value for this SNTP server. When more than one time-server is configured, one server can have preference over others. The value for that server should be set to **preferred**. Only one server in the table can be a preferred server.

**Default** normal

**interval** *seconds* — Specifies the frequency at which this server is queried.

**Values** 64 — 1024

**Default** 64

---

## CRON Commands

### cron

**Syntax** `cron`

**Context** `config`

**Description** This command creates the context to create scripts, script parameters and schedules which support the Service Assurance Agent (SAA) functions.

CRON features are saved to the configuration file on both primary and backup control modules. If a control module switchover occurs, CRON events are restored when the new configuration is loaded. If a control module switchover occurs during the execution of a cron script, the failover behavior will be determined by the contents of the script.

### schedule

**Syntax** `[no] schedule schedule-name [owner owner-name]`

**Context** `config>system>cron`

**Description** This command configures the type of schedule to run, including one-time only (oneshot), periodic or calendar-based runs. All runs are determined by month, day of month or weekday, hour, minute and interval (seconds).

The **no** form of the command removes the context from the configuration.

**Default** `none`

**Parameters** *schedule-name* — Name of the schedule.

**owner** *owner-name* — Owner name of the schedule.

### count

**Syntax** `count number`  
**no count**

**Context** `config>system>cron>sched`

**Description** This command configures the total number of times a CRON “interval” schedule is run. For example, if the interval is set to 600 and the count is set to 4, the schedule runs 4 times at 600 second intervals.

**Parameters** *number* — The number of times the schedule is run.

**Values** 1 — 65535

**Default** 65535

## day-of-month

**Syntax** **day-of-month** {*day-number* [*..day-number*] **all**}  
**no day-of-month**

**Context** config>system>cron>sched

**Description** This command specifies which days of the month that the schedule will occur. Multiple days of the month can be specified. When multiple days are configured, each of them will cause the schedule to trigger. If a day-of-month is configured without configuring **month**, **weekday**, **hour** and **minute**, the event will not execute.

Using the **weekday** command as well as the **day-of-month** command will cause the script to run twice. For example, consider that “today” is Monday January 1. If “Tuesday January 5” is configured, the script will run on Tuesday (tomorrow) as well as January 5 (Friday).

The **no** form of this command removes the specified day-of-month from the list.

**Parameters** *day-number* — The positive integers specify the day of the month counting from the first of the month. The negative integers specify the day of the month counting from the last day of the month. For example, configuring **day-of-month -5, 5** in a month that has 31 days will specify the schedule to occur on the 27th and 5th of that month.

Integer values must map to a valid day for the month in question. For example, February 30 is not a valid date.

**Values** 1 — 31, -31 — -1 (maximum 62 day-numbers)

**all** — Specifies all days of the month.

## end-time

**Syntax** **end-time** [*date* | *day-name*] *time*  
**no end-time**

**Context** config>system>cron>sched

**Description** This command is used concurrently with type **periodic** or **calendar**. Using the type of **periodic**, end-time determines at which interval the schedule will end. Using the type of **calendar**, end-time determines on which date the schedule will end.

When **no end-time** is specified, the schedule runs forever.

**Parameters** *date* — Specifies the date to schedule a command.

**Values** YYYY:MM:DD in year:month:day number format

*day-name* — Specifies the day of the week to schedule a command.

**Values** sunday|monday|tuesday|wednesday|thursday|friday|saturday

*time* — Specifies the time of day to schedule a command.

**Values** hh:mm in hour:minute format

## hour

**Syntax** **hour** {..*hour-number* [..*hour-number*]} **all**  
**no hour**

**Context** config>system>cron>sched

**Description** This command specifies which hour to schedule a command. Multiple hours of the day can be specified. When multiple hours are configured, each of them will cause the schedule to trigger. Day-of-month or weekday must also be specified. All days of the month or weekdays can be specified. If an hour is configured without configuring [month](#), [weekday](#), [day-of-month](#), and [minute](#), the event will not execute. The **no** form of this command removes the specified hour from the configuration.

**Parameters** *hour-number* — Specifies the hour to schedule a command.

**Values** 0 — 23 (maximum 24 hour-numbers)

**all** — Specifies all hours.

## interval

**Syntax** **interval** *seconds*  
**no interval**

**Context** config>system>cron>sched

**Description** This command specifies the interval between runs of an event.

**Parameters** *seconds* — The interval, in seconds, between runs of an event.

**Values** 30 — 4,294,967,295

## minute

**Syntax** **minute** {*minute-number* [..*minute-number*]} **all**  
**no minute**

**Context** config>system>cron>sched

**Description** This command specifies the minute to schedule a command. Multiple minutes of the hour can be specified. When multiple minutes are configured, each of them will cause the schedule to occur. If a minute is configured, but no hour or day is configured, the event will not execute. If a minute is configured without configuring [month](#), [weekday](#), [day-of-month](#), and [hour](#), the event will not execute.

The **no** form of this command removes the specified minute from the configuration.

**Parameters** *minute-number* — Specifies the minute to schedule a command.

**Values** 0 — 59 (maximum 60 minute-numbers)

**all** — Specifies all minutes.

## month

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>month</b> { <i>month-number</i> [ <i>..month-number</i> ]  <i>month-name</i> [ <i>..month-name</i> ]}<br><b>no month</b>                                                                                                                                                                                                                                                                                                                                            |
| <b>Context</b>     | config>system>cron>sched                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Description</b> | This command specifies the month when the event should be executed. Multiple months can be specified. When multiple months are configured, each of them will cause the schedule to trigger. If a month is configured without configuring <a href="#">weekday</a> , <a href="#">day-of-month</a> , <a href="#">hour</a> and <a href="#">minute</a> , the event will not execute. The <b>no</b> form of this command removes the specified month from the configuration. |
| <b>Parameters</b>  | <p><b>month-number</b> — Specifies a month number.</p> <p style="padding-left: 20px;"><b>Values</b> 1 —12 (maximum 12 month-numbers)</p> <p><b>all</b> — Specifies all months.</p> <p><b>month-name</b> — Specifies a month by name</p> <p style="padding-left: 20px;"><b>Values</b> january, february, march, april, may, june, july, august, september, october, november, december (maximum 12 month names).</p>                                                    |

## type

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>type</b> { <i>schedule-type</i> }                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Context</b>     | config>system>cron>sched                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Description</b> | This command specifies how the system should interpret the commands contained within the schedule node.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Parameters</b>  | <p><i>schedule-type</i> — Specify the type of schedule for the system to interpret the commands contained within the schedule node.</p> <p style="padding-left: 20px;"><b>Values</b></p> <ul style="list-style-type: none"> <li><b>periodic</b> — Specifies a schedule which runs at a given interval. <a href="#">interval</a> must be specified for this feature to run successfully.</li> <li><b>calendar</b> — Specifies a schedule which runs based on a calendar. <a href="#">weekday</a>, <a href="#">month</a>, <a href="#">day-of-month</a>, <a href="#">hour</a> and <a href="#">minute</a> must be specified for this feature to run successfully.</li> <li><b>oneshot</b> — Specifies a schedule which runs one time only. As soon as the first event specified in these parameters takes place and the associated event occurs, the schedule enters a shutdown state. <a href="#">month</a>, <a href="#">weekday</a>, <a href="#">day-of-month</a>, <a href="#">hour</a> and <a href="#">minute</a> must be specified for this feature to run successfully.</li> </ul> <p style="padding-left: 20px;"><b>Default</b> periodic</p> |

## weekday

|               |                                                                                                                                 |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b> | <b>weekday</b> { <i>weekday-number</i> [ <i>..weekday-number</i> ]  <i>day-name</i> [ <i>..day-name</i> ]}<br><b>no weekday</b> |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|

**Context** config>system>cron>sched

**Description** This command specifies which days of the week that the schedule will fire on. Multiple days of the week can be specified. When multiple days are configured, each of them will cause the schedule to occur. If a weekday is configured without configuring [month](#), [day-of-month](#), [hour](#) and [minute](#), the event will not execute.

Using the **weekday** command as well as the **day-of month** command will cause the script to run twice. For example, consider that “today” is Monday January 1. If “Tuesday January 5” is configured, the script will run on Tuesday (tomorrow) as well as January 5 (Friday).

The **no** form of this command removes the specified weekday from the configuration.

**Parameters** **day-number** — Specifies a weekday number.

**Values** 1 —7 (maximum 7 week-day-numbers)

**day-name** — Specifies a day by name

**Values** sunday, monday, tuesday, wednesday, thursday, friday, saturday (maximum 7 weekday names)

**all** — Specifies all days of the week.

## Time Range Commands

### time-range

**Syntax** [no] **time-range** *name*

**Context** config>system>cron

**Description** This command configures a time range.  
The **no** form of the command removes the *name* from the configuration.

**Default** none

**Parameters** *name* — Configures a name for the time range up to 32 characters in length.

### absolute

**Syntax** **absolute start** *start-absolute-time* **end** *end-absolute-time*  
**no absolute start** *absolute-time*

**Context** config>system>cron>time-range

**Description** This command configures an absolute time interval that will not repeat.  
The **no** form of the command removes the absolute time range from the configuration.

**Parameters** **start** *absolute-time* — Specifies starting parameters for the absolute time-range.

|               |                |                       |
|---------------|----------------|-----------------------|
| <b>Values</b> | absolute-time: | year/month/day, hh:mm |
|               | year:          | 2005 — 2099           |
|               | month:         | 1 — 12                |
|               | day:           | 1 — 31                |
|               | hh:            | 0 — 23                |
|               | mm: [          | 0 — 59                |

**end** *absolute-time* — Specifies end parameters for the absolute time-range.

|               |                |                       |
|---------------|----------------|-----------------------|
| <b>Values</b> | absolute-time: | year/month/day, hh:mm |
|               | year:          | 2005 — 2099           |
|               | month:         | 1 — 12                |
|               | day:           | 1 — 31                |
|               | hh:            | 0 — 23                |
|               | mm: [          | 0 — 59                |

## daily

**Syntax** **daily start** *start-time-of-day* **end** *end-time-of-day*  
**no daily start** *start-time-of-day*

**Context** config>system>cron>time-range

**Description** This command configures the start and end of a schedule for every day of the week. To configure a daily time-range across midnight, use a combination of two entries. An entry that starts at hour zero will take over from an entry that ends at hour 24.

The **no** form of the command removes the daily time parameters from the configuration.

**Parameters** *start-time-of-day* — Specifies the starting time for the time range.

**Values** Syntax: hh:mm  
hh 0 — 23  
mm 0 — 59

*end-time-of-day* — Specifies the ending time for the time range.

**Values** Syntax: hh:mm  
hh 0 — 24  
mm 0 — 59

## weekdays

**Syntax** **weekdays start** *start-time-of-day* **end** *end-time-of-day*  
**no weekdays start** *start-time-of-day*

**Context** config>system>cron>time-range

**Description** This command configures the start and end of a weekday schedule.

The **no** form of the command removes the weekday parameters from the configuration.

**Parameters** *start-time-of-day* — Specifies the starting time for the time range.

**Values** Syntax: hh:mm  
hh 0 — 23  
mm 0 — 59

*end-time-of-day* — Specifies the ending time for the time range.

**Values** Syntax: hh:mm  
hh 0 — 24  
mm 0 — 59

## weekend

**Syntax** **weekend start** *start-time-of-day* **end** *end-time-of-day*  
**no weekend start** *start-time-of-day*

## Network Time Protocol Commands

**Context** config>system>cron>time-range

**Description** This command configures a time interval for every weekend day in the time range.

The resolution must be at least one minute apart, for example, start at 11:00 and end at 11:01. An 11:00 start and end time is invalid. This example configures a start at 11:00 and an end at 11:01 on both Saturday and Sunday.

The **no** form of the command removes the weekend parameters from the configuration.

**Parameters** *start-time-of-day* — Specifies the starting time for the time range.

|               |         |           |
|---------------|---------|-----------|
| <b>Values</b> | Syntax: | hh:mm     |
|               |         | hh 0 — 23 |
|               |         | mm 0 — 59 |

*end-time-of-day* — Specifies the ending time for the time range.

|               |         |           |
|---------------|---------|-----------|
| <b>Values</b> | Syntax: | hh:mm     |
|               |         | hh 0 — 24 |
|               |         | mm 0 — 59 |

## weekly

**Syntax** **weekly start** *start-time-in-week* **end** *end-time-in-week*  
**no weekly start** *start-time-in-week*

**Context** config>system>cron>time-range

**Description** This command configures a weekly periodic interval in the time range.

The **no** form of the command removes the weekly parameters from the configuration.

**Parameters** *start-time-in-week* — Specifies the start day and time of the week.

|               |         |                                                                                                            |
|---------------|---------|------------------------------------------------------------------------------------------------------------|
| <b>Values</b> | Syntax: | day, hh:mm                                                                                                 |
|               |         | day sun, mon, tue, wed, thu, fri, sat<br>sunday, monday, tuesday, wednesday, thursday, friday,<br>saturday |
|               |         | hh 0 — 23                                                                                                  |
|               |         | mm 0 — 59                                                                                                  |

*end-time-in-week* — Specifies the end day and time of the week.

|               |         |                                                                                                            |
|---------------|---------|------------------------------------------------------------------------------------------------------------|
| <b>Values</b> | Syntax: | day, hh:mm                                                                                                 |
| <b>Values</b> |         | day sun, mon, tue, wed, thu, fri, sat<br>sunday, monday, tuesday, wednesday, thursday, friday,<br>saturday |
|               |         | hh 0 — 24                                                                                                  |
|               |         | mm 0 — 59                                                                                                  |

**weekly start** *time-in-week* **end** *time-in-week* — This parameter configures the start and end of a schedule for the same day every week, for example, every Friday. The start and end dates must be the same. The

resolution must be at least one minute apart, for example, start at 11:00 and end at 11:01. A start time and end time of 11:00 is invalid.

**Values** 00 — 23, 00 — 59

**Default** no time-range

## Time of Day Commands

### tod-suite

**Syntax** [no] **tod-suite** *tod-suite name create*

**Context** config>system>cron

**Description** This command creates the tod-suite context.

**Default** no tod-suite

### egress

**Syntax** **egress**

**Context** config>system>cron>tod-suite

**Description** This command enables the TOD suite egress parameters.

### ingress

**Syntax** **ingress**

**Context** config>system>cron>tod-suite

**Description** This command enables the TOD suite ingress parameters.

### filter

**Syntax** **filter ip** *ip-filter-id* [**time-range** *time-range-name*] [**priority** *priority*]  
**filter ipv6** *ipv6-filter-id* [**time-range** *time-range-name*] [**priority** *priority*]  
**filter mac** *mac-filter-id* [**time-range** *time-range-name*] [**priority** *priority*]  
**no ip** *ip-filter-id* [**time-range** *time-range-name*]  
**no filter ipv6** *ipv6-filter-id* [**time-range** *time-range-name*]  
**no filter mac** *mac-filter-id* [**time-range** *time-range-name*]

**Context** config>system>cron>tod-suite>egress  
config>system>cron>tod-suite>ingress

**Description** This command creates time-range based associations of previously created filter policies. Multiple policies may be included and each must be assigned a different priority; in case time-ranges overlap, the priority will be used to determine the prevailing policy. Only a single reference to a policy may be included without a time-range.

- Parameters**
- ip-filter** *ip-filter-id* — Specifies an IP filter for this tod-suite.  
**Values** 1 — 65535
  - ipv6-filter** *ipv6-filter-id* — Specifies an IPv6 filter for this tod-suite.  
**Values** 1 — 65535
  - time-range** *time-range-name* — Name for the specified time-range. If the time-range is not populated the system will assume the assignment to mean “all times”. Only one entry without a time-range is allowed for every type of policy. The system does not allow the user to specify more than one policy with the same time-range and priority.  
**Values** Up to 32 characters
  - priority** *priority* — Priority of the time-range. Only one time-range assignment of the same type and priority is allowed.  
**Values** 1 — 10
  - mac** *mac-filter-id* — Specifies a MAC filter for this tod-suite.  
**Values** 1 — 65535

## qos

- Syntax** **qos** *policy-id* [**time-range** *time-range-name*] [**priority** *priority*]  
**no qos** *policy-id* [**time-range** *time-range-name*] [
- Context** config>system>cron>tod-suite>egress  
config>system>cron>tod-suite>ingress
- Description** This command creates time-range based associations of previously created QoS policies. Multiple policies may be included and each must be assigned a different priority; in case time-ranges overlap, the priority will be used to determine the prevailing policy. Only a single reference to a policy may be included without a time-range.
- The no form of the command reverts to the
- Parameters**
- policy-id** — Specifies an egress QoS policy for this tod-suite.  
**Values** 1 — 65535
  - time-range** *time-range-name* — Name for the specified time-range. If the time-range is not populated the system will assume the assignment to mean “all times”. Only one entry without a time-range is allowed for every type of policy. The system does not allow the user to specify more than one policy with the same time-range and priority.  
**Values** Up to 32 characters  
**Default** "NO-TIME-RANGE" policy
  - priority** *priority* — Priority of the time-range. Only one time-range assignment of the same type and priority is allowed.

## Network Time Protocol Commands

**Values** 1 — 10

**Default** 5

### scheduler-policy

**Syntax** `[no] scheduler-policy scheduler-policy-name [time-range time-range-name] [priority priority]`

**Context** config>system>cron>tod-suite>egress  
config>system>cron>tod-suite>ingress

**Description** This command creates time-range based associations of previously created scheduler policies. Multiple policies may be included and each must be assigned a different priority; in case time-ranges overlap, the priority will be used to determine the prevailing policy. Only a single reference to a policy may be included without a time-range.

**Parameters** *scheduler-policy-name* — Specifies a scheduler policy for this tod-suite.

**Values** Up to 32 characters

**time-range** *time-range-name* — Specifies the name for a time-range. If the time-range is not populated the system will assume the assignment to mean “all times”. Only one entry without a time-range is allowed for every type of policy. The system does not allow the user to specify more than one policy and the same time-range and priority.

**Values** Up to 32 characters

**priority** *priority* — Specifies the time-range priority. Only one time-range assignment of the same type and priority is allowed.

**Values** 1 — 10

---

## Script Control Commands

### script-control

**Syntax** `script-control`

**Context** `config>system`

**Description** This command enables the context to configure command script parameters.

### script-policy

**Syntax** `script-policy policy-name [owner policy-owner]`

**Context** `config>system>script-control`  
`config>system>cron>schedule`

**Description** This command is used to configure the CLI script policy.

**Parameters** *policy-name* — Specifies the name of the policy. Can be up to 32 characters.  
*owner policy-owner* — Specifies the name of the policy owner. Can be up to 32 characters.

**Default** “TiMOS CLP”

### expire-time

**Syntax** `expire-time {seconds | forever}`

**Context** `config>system>script-control>script-policy`

**Description** This command is used to configure the maximum amount of time to keep the run history status entry from a script run.

**Parameters** *seconds* — Specifies the time to keep the run history status entry, in seconds.

**Values** 0 — 21474836

**Default** 3600

**forever** — Keyword to keep the run history status entry indefinitely.

### lifetime

**Syntax** `lifetime {seconds | forever}`

**Context** `config>system>script-control>script-policy`

## Network Time Protocol Commands

**Description** This command is used to configure the maximum amount of time that a script may run.

**Parameters** *seconds* — Specifies the maximum amount of time that a script may run, in seconds.

**Values** 0 — 21474836

**Default** 3600

**forever** — Keyword to allow a script to run indefinitely.

## max-completed

**Syntax** **max-completed unsigned**

**Context** config>system>script-control>script-policy

**Description** This command is used to configure the maximum number of script run history status entries to keep.

**Parameters** *unsigned* — Specifies the maximum number of script run history status entries to keep.

**Values** 1 — 255

**Default** 1

## results

**Syntax** **results file-url**  
**no results**

**Context** config>system>script-control>script-policy

**Description** This command is used to specify the location where the system writes the output of an event script's execution.

The **no** form of the command removes the file location from the configuration. Scripts will not execute if there is no result location defined.

**Parameters** *file-url* — Specifies the location to send CLI output from script runs. The *file-url* is a location, directory, and filename prefix to which a data and timestamp suffix is added when the results files are created during a script run, as follows:

*file-url\_YYYYMMDD-hhmmss.uuuuuu.out*

where: YYYYMMDD — date

hhmmss — hours, minutes, and seconds

uuuuuu — microseconds (padded to 6 characters with leading zeros)

**Values** *local-url* | *remote-url*

*local-url* — [*cflash-id*] [*file-path*]

200 chars max, including *cflash-id*

directory length 99 characters max each

*remote url* — [{ftp:// | tftp://}login:password@remote-location/][file-path]  
 255 characters max  
 directory length 99 characters max each

*remote-location* — [hostname | ipv4-address | ipv6-address]

*ipv4-address* — a.b.c.d

*ipv6-address* — x:x:x:x:x:x[-interface]  
 x:x:x:x:x:d.d.d.d[-interface]  
 x — [0..FFFF]H  
 d — [0..255]D  
*interface* — 32 characters max, for link local addresses

*cflash-id* — cf1: | cf1-A: | cf1-B: | cf2: | cf2-A: | cf2-B: | cf3: | cf3-A: | cf3-B:

## script

**Syntax** **script** *script-name* [**owner** *script-owner*]  
**no script**

**Context** config>system>script-control>script-policy  
 config>system>script-control

**Description** This command is used to configure a script to be run.  
 The **no** form of the command removes the script.

**Parameters** *script-name* — Specifies the name of the script. Can be up to 32 characters.  
*owner script-owner* — Specifies the name of the script owner. Can be up to 32 characters.

**Default** “TiMOS CLI”

## location

**Syntax** **location** *file-url*  
**no location**

**Context** config>system>script-control>script

**Description** This command is used to identify the location of a script to be scheduled.  
 The **no** form of the command removes the location.

**Parameters** *file-url* — Specifies the location to search for scripts.

**Values** *local-url* | *remote-url*

*local-url* — [*cflash-id*/] [*file-path*]  
 200 chars max, including *cflash-id*  
 directory length 99 characters max each

## Network Time Protocol Commands

*remote url* — [{ftp:// | tftp://}login:password@remote-location/][file-path]

255 characters max

directory length 99 characters max each

*remote-location* — [hostname | ipv4-address | ipv6-address]

*ipv4-address* — a.b.c.d

*ipv6-address* — x:x:x:x:x:x[-interface]

x:x:x:x:x:d.d.d.d[-interface]

x — [0..FFFF]H

d — [0..255]D

*interface* — 32 characters max, for link local addresses

*cflash-id* — cf1: | cf1-A: | cf1-B: | cf2: | cf2-A: | cf2-B: | cf3: | cf3-A: | cf3-B:

---

## System Time Commands

### dst-zone

**Syntax** [no] **dst-zone** [*std-zone-name* | *non-std-zone-name*]

**Context** config>system>time

**Description** This command configures the start and end dates and offset for summer time or daylight savings time to override system defaults or for user defined time zones.

When configured, the time is adjusted by adding the configured offset when summer time starts and subtracting the configured offset when summer time ends.

If the time zone configured is listed in [Table 22, System-defined Time Zones, on page 246](#), then the starting and ending parameters and offset do not need to be configured with this command unless it is necessary to override the system defaults. The command returns an error if the start and ending dates and times are not available either in [Table 22](#) or entered as optional parameters in this command.

Up to five summer time zones may be configured, for example, for five successive years or for five different time zones. Configuring a sixth entry will return an error message. If no summer (daylight savings) time is supplied, it is assumed no summer time adjustment is required.

The **no** form of the command removes a configured summer (daylight savings) time entry.

**Default** none — No summer time is configured.

**Parameters** *std-zone-name* — The standard time zone name. The standard name must be a system-defined zone in [Table 22](#). For zone names in the table that have an implicit summer time setting, for example MDT for Mountain Daylight Saving Time, the remaining **start-date**, **end-date** and **offset** parameters need to be provided unless it is necessary to override the system defaults for the time zone.

**Values** *std-zone-name* ADT, AKDT, CDT, CEST, EDT, EEST, MDT, PDT, WEST

*non-std-zone-name* — The non-standard time zone name. Create a user-defined name created using the [zone](#) command on page 399

**Values** 5 characters maximum

### end

**Syntax** **end** {*end-week*} {*end-day*} {*end-month*} [*hours-minutes*]

**Context** config>system>time>dst-zone

**Description** This command configures start of summer time settings.

**Parameters** *end-week* — Specifies the starting week of the month when the summer time will end.

**Values** first, second, third, fourth, last

**Default** first

## Network Time Protocol Commands

*end-day* — Specifies the starting day of the week when the summer time will end.

**Values**      sunday, monday, tuesday, wednesday, thursday, friday, saturday

**Default**     sunday

*end-month* — The starting month of the year when the summer time will take effect.

**Values**      january, february, march, april, may, june, july, august, september, october, november, december}

**Default**     january

*hours* — Specifies the hour at which the summer time will end.

**Values**      0 — 24

**Default**     0

*minutes* — Specifies the number of minutes, after the hours defined by the *hours* parameter, when the summer time will end.

**Values**      0 — 59

**Default**     0

### offset

**Syntax**      **offset** *offset*

**Context**      config>system>time>dst-zone

**Description**      This command specifies the number of minutes that will be added to the time when summer time takes effect. The same number of minutes will be subtracted from the time when the summer time ends.

**Parameters**      *offset* — The number of minutes added to the time at the beginning of summer time and subtracted at the end of summer time, expressed as an integer.

**Default**      60

**Values**      0 — 60

### start

**Syntax**      **start** {*start-week*} {*start-day*} {*start-month*} [*hours-minutes*]

**Context**      config>system>time>dst-zone

**Description**      This command configures start of summer time settings.

**Parameters**      **start-week** — Specifies the starting week of the month when the summer time will take effect.

**Values**      first, second, third, fourth, last

**Default**      first

*start-day* — Specifies the starting day of the week when the summer time will take effect.

**Default**     sunday

**Values**     sunday, monday, tuesday, wednesday, thursday, friday, saturday

*start-month* — The starting month of the year when the summer time will take effect.

**Values**     january, february, march, april, may, june, july, august, september, october, november, december

**Default**     january

*hours* — Specifies the hour at which the summer time will take effect.

**Default**     0

*minutes* — Specifies the number of minutes, after the hours defined by the *hours* parameter, when the summer time will take effect.

**Default**     0

## zone

**Syntax**     **zone** [*std-zone-name* | *non-std-zone-name*] [*hh* [:*mm*]]  
**no zone**

**Context**     config>system>time

**Description** This command sets the time zone and/or time zone offset for the device.

7950 XRS supports system-defined and user-defined time zones. The system-defined time zones are listed in [Table 22, System-defined Time Zones, on page 246](#).

For user-defined time zones, the zone and the UTC offset must be specified.

The **no** form of the command reverts to the default of Coordinated Universal Time (UTC). If the time zone in use was a user-defined time zone, the time zone will be deleted. If a **dst-zone** command has been configured that references the zone, the summer commands must be deleted before the zone can be reset to UTC.

**Default**     **zone utc** - The time zone is set for Coordinated Universal Time (UTC).

**Parameters** *std-zone-name* — The standard time zone name. The standard name must be a system-defined zone in [Table 22](#). For zone names in the table that have an implicit summer time setting, for example MDT for Mountain Daylight Saving Time, the remaining **start-date**, **end-date** and **offset** parameters need to be provided unless it is necessary to override the system defaults for the time zone.

For system-defined time zones, a different offset cannot be specified. If a new time zone is needed with a different offset, the user must create a new time zone. Note that some system-defined time zones have implicit summer time settings which causes the switchover to summer time to occur automatically; configuring the **dst-zone** parameter is not required.

A user-defined time zone name is case-sensitive and can be up to 5 characters in length.

## Network Time Protocol Commands

**Values** A user-defined value can be up to 4 characters or one of the following values:  
GMT, BST, IST, WET, WEST, CET, CEST, EET, EEST, MSK, MSD, AST, ADT, EST,  
EDT, ET, CST, CDT, CT, MST, MDT, MT, PST, PDT, PT, HST, AKST, AKDT, WAST,  
CAST, EAST

*non-std-zone-name* — The non-standard time zone name.

**Values** Up to 5 characters maximum.

*hh[:mm]* — The hours and minutes offset from UTC time, expressed as integers. Some time zones do not have an offset that is an integral number of hours. In these instances, the *minutes-offset* must be specified. For example, the time zone in Pirlanngimpi, Australia UTC + 9.5 hours.

**Default** hours: 0  
minutes: 0

**Values** hours: -11 — 11  
minutes: 0 — 59

---

## System Synchronization Configuration Commands

### sync-if-timing

**Syntax** `sync-if-timing`

**Context** `config>system`

**Description** This command creates or edits the context to create or modify timing reference parameters.

**Default** Disabled

### abort

**Syntax** `abort`

**Context** `config>system>sync-if-timing`

**Description** This command is required to discard changes that have been made to the synchronous interface timing configuration during a session.

**Default** No default

### begin

**Syntax** `begin`

**Context** `config>system>sync-if-timing`

**Description** This command is required in order to enter the mode to create or edit the system synchronous interface timing configuration.

**Default** No default

### bits

**Syntax** `bits`

**Context** `config>system>sync-if-timing`

**Description** This command enables the context to configure parameters for the Building Integrated Timing Supply (BITS). The settings specified under this context apply to both the BITS input and BITS output ports and to both the bits1 and bits2 ports.

## System Synchronization Configuration Commands

**Default.** disabled

### commit

**Syntax** **commit**

**Context** config>system>sync-if-timing

**Description** This command saves changes made to the system synchronous interface timing configuration.

**Default** No default

### interface-type

**Syntax** **interface-type {ds1 [{esf | sf}] | e1 [{pcm30crc | pcm31crc}] | 2048khz-g703}**  
**no interface-type**

**Context** config>system>sync-if-timing>bits

**Description** This command configures the Building Integrated Timing Source (BITS) timing reference. This command is not supported on the 7450 ESS-6, 7450 ESS-6v, 7450 ESS-1.

The **no** form of the command reverts to the default configuration.

**Default** ds1 esf

**Parameters** **ds1 esf** — Specifies Extended Super Frame (ESF). This is a framing type used on DS1 circuits that consists of 24 192-bit frames, The 193rd bit provides timing and other functions.

**ds1 sf** — Specifies Super Frame (SF), also called D4 framing. This is a common framing type used on DS1 circuits. SF consists of 12 192-bit frames. The 193rd bit provides error checking and other functions. ESF supersedes SF.

**e1 pcm30crc** — Specifies the pulse code modulation (PCM) type. PCM30CRC uses PCM to separate the signal into 30 user channels with CRC protection.

**e1 pcm31crc** — Specifies the pulse code modulation (PCM) type. PCM31CRC uses PCM to separate the signal into 31 user channels with CRC protection.

**2048khz-g703** — Specifies the 2048 kHz synchronization interface (T12) of ITU-T G.703.

### input

**Syntax** **input**

**Context** config>system>sync-if-timing>bits

**Description** This command provides a context to enable or disable the external BITS timing reference inputs to the XRS router. In redundant systems with BITS ports, there are two possible BITS-in interfaces, one for each CPM.

**Default** shutdown

## output

**Syntax** **output**

**Context** config>system>sync-if-timing>bits

**Description** This command provides a context to configure and enable or disable the external BITS timing reference output to the XRS router. On redundant systems, there are two possible BITS-out interfaces, one for each CPM.

**Default** shutdown

## line-length

**Syntax** **line-length** {110,220,330,440,550,660}

**Context** config>system>sync-if-timing>bits

**Description** This command configures the line-length parameter of the BITS output. This is the distance in feet between the network element and the office clock (BITS/SSU). There are two possible BITS-out interfaces, one for each CPM. They are configured together, but they are displayed separately in the show command. This command is only applicable when the interface-type is DS1.

**Default** 110

**Parameters**

- 110* — Distance is from 0 to 110 feet
- 220* — Distance is from 110 to 220 feet
- 330* — Distance is from 220 to 330 feet
- 440* — Distance is from 330 to 440 feet
- 550* — Distance is from 440 to 550 feet
- 660* — Distance is from 550 to 660 feet

## SOURCE

**Syntax** **source** {**line-ref** | **internal-clock**}

**Context** config>system>sync-if-timing>bits>output

**Description** This command configures the values used to identify the source of the BITS (Building Integrated Timing Supply) output. This is either the signal recovered directly from ref1, ref2 or it is the output of the node's central clock. The directly recovered signal would be used when the BITS output signal is feeding into an external stand alone timing distribution device (BITS/SASE). The specific directly recovered signal used is the best of the available signals based of the QL and/or the ref-order. The central clock output would be used

## System Synchronization Configuration Commands

when no BITS/SASE device is present and the BITS output signal is used to monitor the quality of the recovered clock within the system.

**Default** line-ref

**Parameters** **line-ref** — Specifies that the BITS output timing is selected from one of the input references, without any filtering.

**internal-clock** — Specifies that the BITS output timing is driven from the system timing.

### ssm-bit

**Syntax** **ssm-bit sa-bit**

**Context** config>system>sync-if-timing>bits  
config>system>sync-if-timing>ref1  
config>system>sync-if-timing>ref2

**Description** This command configures which sa-bit to use for conveying SSM information when the interface-type is E1.

**Default** 8

**Parameters** *sa-bit* — Specifies the sa-bit value.

**Values** 4–8

### ql-override

**Syntax** **ql-override {prs|stu|st2|tnc|st3e|st3|eec1|sec|prc|ssu-a|ssu-b|eec2}**  
**no ql-override**

**Context** config>system>sync-if-timing>bits  
config>system>sync-if-timing>ref1  
config>system>sync-if-timing>ref2

**Description** This command configures the QL value to be used for the reference for SETS input selection and BITS output. This value overrides any value received by that reference's SSM process.

**Default** no ql-overide

**Parameters** **prs** — SONET Primary Reference Source Traceable  
**stu** — SONET Synchronous Traceability Unknown  
**st2** — SONET Stratum 2 Traceable  
**tnc** — SONET Transit Node Clock Traceable  
**st3e** — SONET Stratum 3E Traceable  
**st3** — SONET Stratum 3 Traceable  
**eec1** — Ethernet Equipment Clock Option 1 Traceable (sdh)

**ecc2** — Ethernet Equipment Clock Option 2 Traceable (sonet)  
**prc** — SDH Primary Reference Clock Traceable  
**ssu-a** — SDH Primary Level Synchronization Supply Unit Traceable  
**ssu-b** — SDH Second Level Synchronization Supply Unit Traceable  
**sec** — SDH Synchronous Equipment Clock Traceable

## ql-selection

**Syntax** **[no] ql-selection**

**Context** config>system>sync-if-timing

**Description** When enabled the selection of system timing reference and BITS output timing reference takes into account quality level. This command turns -on or turns-off SSM encoding as a means of timing reference selection.

**Default** no ql-selection

## ref-order

**Syntax** **ref-order** *first second [third ]*  
**no ref-order**

**Context** config>system>sync-if-timing

**Description** The synchronous equipment timing subsystem can lock to different timing reference inputs, those specified in the **ref1**, **ref2**, **bits** command configuration. This command organizes the priority order of the timing references.

If a reference source is disabled, then the clock from the next reference source as defined by **ref-order** is used. If all reference sources are disabled, then clocking is derived from a local oscillator.

Note that if a **sync-if-timing** reference is linked to a source port that is operationally down, the port is no longer qualified as a valid reference.

Each BITS port is associated to one CCM and CPM. CPM A can only use the BITS input port on CCM A and CPM B can only use the BITS input port on CCM B.

The **no** form of the command resets the reference order to the default values.

**Default** **bits ref1 ref2**

*first* — Specifies the first timing reference to use in the reference order sequence.

**Values** ref1, ref2, bits

*second* — Specifies the second timing reference to use in the reference order sequence.

**Values** ref1, ref2, bits

*third* — Specifies the third timing reference to use in the reference order sequence.

## System Synchronization Configuration Commands

**Values** ref1, ref2, bits

### ref1

**Syntax** ref1

**Context** config>system>sync-if-timing

**Description** This command enables the context to configure parameters for the first timing reference. Note that source ports for ref1 and ref2 must be on different slots. On a 7950 XRS-40 system, the source ports for **ref1** and **ref2** must reside on the master chassis.

### ref2

**Syntax** ref2

**Context** config>system>sync-if-timing

**Description** This command enables the context to configure parameters for the second timing reference. Note that source ports for ref1 and ref2 must be on different slots. On a 7950 XRS-40 system, the source ports for **ref1** and **ref2** must reside on the master chassis.

### revert

**Syntax** [no] revert

**Context** config>system>sync-if-timing

**Description** This command allows the clock to revert to a higher priority reference if the current reference goes offline or becomes unstable. When the failed reference becomes operational, it is eligible for selection. When the mode is non-revertive, a failed clock source is not selected again.

**Default** no revert

### source-port

**Syntax** source-port *port-id*  
no source-port

**Context** config>system>sync-if-timing>ref1  
config>system>sync-if-timing>ref2

**Description** This command configures the source port for timing reference **ref1** or **ref2**. If the port is unavailable or the link is down, then the reference sources are re-evaluated according to the reference order configured in the **ref-order** command.

**Parameters** *port-id* — Identify the physical port in the *slot/mda/port* format.

---

## System Administration Commands

### admin

**Syntax**    **admin**

**Context**    <ROOT>

**Description**    The context to configure administrative system commands. Only authorized users can execute the commands in the **admin** context.

**Default**    none

### clear-policy-lock

**Syntax**    **clear-policy-lock**

**Context**

**Description**    This command allows an authorized administrator to clear an exclusive policy lock. This will reset the lock flag and end the policy editing session in progress, aborting any policy edits.

### debug-save

**Syntax**    **debug-save** *file-url*

**Context**    admin

**Description**    This command saves existing debug configuration (configuration done under the debug branch of CLI). Debug configurations are not preserved in configuration saves. SR OS automatically looks for and loads the saved debug config during startup.

**Default**    none

**Parameters**    *file-url* — The file URL location to save the debug configuration.

|               |             |                                                                                                                                                                                                                                                                                       |
|---------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Values</b> | file url:   | local-url   remote-url: 255 chars max                                                                                                                                                                                                                                                 |
|               | local-url:  | [ <i>cflash-id</i> ]/[ <i>file-path</i> ], 200 chars max, including the cflash-id directory length, 99 chars max each                                                                                                                                                                 |
|               | remote-url: | [{ftp://} login:pswd@remote-locn/][ <i>file-path</i> ]<br>remote-locn [ <i>hostname</i>   <i>ipv4-address</i>   [ <i>ipv6-address</i> ] ]<br>ipv4-address    a.b.c.d<br>ipv6-address    - x:x:x:x:x:x[-interface]<br>x:x:x:x:x:d.d.d.d[-interface]<br>x - [0..FFFF]H<br>d - [0..255]D |

interface - 32 chars max, for link local addresses  
 255 chars max, directory length 99 chars max each  
 cflash-id: cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:

## disconnect

**Syntax** **disconnect** [**address** *ip-address* | **username** *user-name* | **console** | **telnet** | **ftp** | **ssh** | **netconf**]

**Context** admin

**Description** This command disconnects a user from a session.

Disconnect without any parameters will disconnect the session in which the command was executed.

If any of the session type options (for example, console, telnet, FTP, SSH) are specified, then only the respective sessions are affected.

If no session type options are specified, then all sessions from the IP address or from the specified user are disconnected.

Any task that the user is executing is terminated. FTP files accessed by the user will not be removed.

A major severity security log event is created specifying what was terminated and by whom.

**Default** none — No disconnect options are configured.

**Parameters** **address** *ip-address* — The IP address to disconnect, specified in dotted decimal notation.

| Values | ipv4-address   | a.b.c.d                         |
|--------|----------------|---------------------------------|
|        | ipv6-address - | x:x:x:x:x:x:x[-interface]       |
|        |                | x:x:x:x:x:x.d.d.d.d[-interface] |
|        |                | x - [0..FFFF]H                  |
|        |                | d - [0..255]D                   |

**username** *user-name* — The name of the user.

**console** — Disconnects the console session.

**telnet** — Disconnects the Telnet session.

**ftp** — Disconnects the FTP session.

**ssh** — Disconnects the SSH session.

**netconf** — Disconnects the NETCONF session.

## display-config

**Syntax** **display-config** [**detail** | **index**]

**Context** admin

**Description** This command displays the system's running configuration.

By default, only non-default settings are displayed.

## System Administration Commands

Specifying the **detail** option displays all default and non-default configuration parameters.

**Parameters** **detail** — Displays default and non-default configuration parameters.  
**index** — Displays only persistent-indices.

### reboot

**Syntax** **reboot [active | standby ] [now]**

**Context** admin

**Description** This command reboots the router or one CPM and can also be used to force an upgrade of the system boot ROMs.

If no options are specified, the user is prompted to confirm the reboot operation. Answering yes ('y') will result in both CPMs and all IOMs rebooting.

```
ALA-1>admin# reboot
Are you sure you want to reboot (y/n)?
```

**Parameters** **active** — Keyword to reboot the active CPM

**Default** active

**standby** — Keyword to reboot the standby CPM

**Default** active

**upgrade** — Forces card firmware to be upgraded during chassis reboot. Normally, the 7950 XRS automatically performs firmware upgrades on CPMs and XCM cards without the need for the **upgrade** keyword. 7

When the **upgrade** keyword is specified, a chassis flag is set for the BOOT Loader (boot.ldr) and on the subsequent boot of the 7950 XRS on the chassis, firmware images on CPMs or XCMs will be upgraded automatically.

Any CPMs or XCM/IOMs that are installed in the chassis will be upgraded automatically. For example, if a card is inserted with down revision firmware as a result of a card hot swap with the latest OS version running, the firmware on the card will be automatically upgraded before the card is brought online.

If the card firmware is upgraded automatically, a chassis cardUpgraded (event 2032) log event is generated. The corresponding SNMP trap for this log event is tmnxEqCardFirmwareUpgraded.

During any firmware upgrade, automatic or manual, it is imperative that during the upgrade procedure:

- Power must NOT be switched off or interrupted.
- The system must NOT be reset.
- No cards are inserted or removed.

Any of the above conditions may render cards inoperable requiring a return of the card for resolution.

The time required to upgrade the firmware on the cards in the chassis depends on the number of cards to be upgraded. The progress of a firmware upgrade can be monitored at the console.

**now** — Forces a reboot of the router immediately without an interactive confirmation.

## save

**Syntax** `save [file-url] [detail] [index]`

**Context** admin

**Description** This command saves the running configuration to a configuration file. For example:

```
A:ALA-1>admin# save ftp://test:test@192.168.x.xx/./100.cfg
Saving configuration .....Completed.
```

An **admin save** operation initiated by a user is aborted if another user initiates another **admin save** from another session.

By default, the running configuration is saved to the primary configuration file.

**Parameters** *file-url* — The file URL location to save the configuration file.

**Default** The primary configuration file location.

**Values**

|                    |                                                                                                                                                       |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| file url:          | local-url   remote-url: 255 chars max                                                                                                                 |
| local-url:         | [ <i>cflash-id</i> ]/[ <i>file-path</i> ], 200 chars max, including the <i>cflash-id</i> directory length, 99 chars max each                          |
| remote-url:        | [ {ftp://} login:pswd@remote-locn/ ][ <i>file-path</i> ]                                                                                              |
| remote-locn        | [ <i>hostname</i>   <i>ipv4-address</i>   [ <i>ipv6-address</i> ] ]                                                                                   |
| ipv4-address       | a.b.c.d                                                                                                                                               |
| ipv6-address       | - x:x:x:x:x:x:x[-interface]<br>x:x:x:x:x:d.d.d.d[-interface]<br>x - [0..FFFF]H<br>d - [0..255]D<br>interface - 32 chars max, for link local addresses |
|                    | 255 chars max, directory length 99 chars max each                                                                                                     |
| <i>cflash-id</i> : | cf1:, cf1-A:,cf1-B:,cf2:,cf2-A:,cf2-B:,cf3:,cf3-A:,cf3-B:                                                                                             |

**detail** — Saves both default and non-default configuration parameters.

**index** — Forces a save of the persistent index file regardless of the persistent status in the BOF file. The index option can also be used to avoid an additional boot required while changing your system to use the persistence indices.

## enable-tech

**Syntax** `[no] enable-tech`

**Context** admin

**Description** This command enables the shell and kernel commands.

**NOTE:** This command should only be used with authorized direction from the Alcatel-Lucent Technical Assistance Center (TAC).

## radius-discovery

## System Administration Commands

**Syntax** **radius-discovery**

**Context** admin

**Description** This command performs RADIUS discovery operations.

### force-discover

**Syntax** **force-discover** [**svc-id** *service-id*]

**Context** admin>radius-discovery

**Description** When enabled, the server is immediately contacted to attempt discovery.

**Parameters** **svc-id** *service-id* — Specifies an existing service ID.

**Values** 1 — 2147483648 | *svc-name*, up to 64 char max

### tech-support

**Syntax** **tech-support** [*file-url*]

**Context** admin

**Description** This command creates a system core dump. If the *file-url* is omitted, and a *ts-location* is defined, then the tech support file will have an automatic SR OS generated file name based on the system name and the date and time and will be saved to the directory indicated by the configured *ts-location*.

The format of the auto-generated filename is *ts-XXXXXX.YYYYMMDD.HHMMUTC.dat* where:

- **XXXXXX**: system name with special characters expanded to avoid problems with file systems (for example, a '.' is expanded to %2E.)
- **YYYYMMDD**: Date with leading zeroes on year, month and day
- **HHMM**: Hours and Minutes in UTC time (24hr format, always 4 chars, with leading zeroes on hours and minutes)

**NOTE:** This command should only be used with authorized direction from the Alcatel-Lucent Technical Assistance Center (TAC).

**Parameters** *file-url* — The file URL location to save the binary file.

**Values** file url: local-url | remote-url: 255 chars max  
local-url: [*cflash-id*]/[*file-path*], 200 chars max, including the *cflash-id* directory length, 99 chars max each  
remote-url: [{ftp://} login:pswd@remote-locn/][*file-path*]  
remote-locn [ *hostname* | *ipv4-address* | [*ipv6-address*] ]  
ipv4-address a.b.c.d  
ipv6-address - x:x:x:x:x:x[-interface]  
x:x:x:x:x:d.d.d.d[-interface]  
x - [0..FFFF]H

d - [0..255]D  
 interface - 32 chars max, for link local addresses  
 255 chars max, directory length 99 chars max each  
 cflash-id: cf1:, cf1-A:, cf1-B:, cf2:, cf2-A:, cf2-B:, cf3:, cf3-A:, cf3-B:

## ts-location

**Syntax** **ts-location** *file-url*  
**no ts-location**

**Context** config>system>security

**Description** The **ts-location** command is used (along with an automatic system generated file name) when no *file-url* parameter is provided for the **admin tech-support** command. If **no ts-location** is defined then the operator must provide a file-url with the **admin tech-support** command itself.

The directory specified for the ts-location is not auto-created by SR OS. The operator must ensure that it exists.

Please see the 'admin tech-support' command for more details about the system generated file name.

**Parameters** *file-url* — Specifies the destination directory for auto-named tech-support files (when no file-url is specified with the 'admin tech-support' command). The *file-url* for the **ts-location** must be a directory (no filename or extension). The root directory (for example, cf1:\) is blocked for local compact flash destinations. A sub-directory (for example, cf2:\tech-support) must be used if local cf is the location.

|               |              |                                                                                                                     |
|---------------|--------------|---------------------------------------------------------------------------------------------------------------------|
| <b>Values</b> | <file-url>   | <local-url> <remote-url>                                                                                            |
|               | local-url    | [<cflash-id>/][<file-path>]<br>200 chars max, including cflash-id<br>directory length 99 chars max each             |
|               | remote-url   | [{ftp:// tftp://}<login>:<pswd>@<remote-locn>/][<file-path>]<br>255 chars max<br>directory length 99 chars max each |
|               | remote-locn  | [ <hostname>   <ipv4-address>  <ipv6-address> ]                                                                     |
|               | ipv4-address | a.b.c.d                                                                                                             |
|               | ipv6-address | x:x:x:x:x:x[-interface]<br>x:x:x:x:x:d.d.d.d[-interface]                                                            |
|               |              | x - [0..FFFF]H<br>d - [0..255]D<br>interface - 32 chars max, for link<br>local addresses                            |
|               | cflash-id    | cf1: cf1-A: cf1-B: cf2: cf2-A: cf2-B: cf3: cf3-A: cf3-B:                                                            |

## view

**Syntax** **view** {bootup-cfg|active-cfg|candidate-cfg|latest-rb| *checkpoint-id*|rescue}

**Context** <ROOT>

## System Administration Commands

**Description** The context to configure administrative system viewing parameters. Only authorized users can execute the commands in the **admin** context.

**Default** none

**Parameters** **bootup-cfg** — Specifies the bootup configuration.  
**active-cfg** — Specifies current running configuration.  
**candidate-cfg** — Specifies candidate configuration.  
**latest-rb** — Specifies the latest configuration.  
*checkpoint-id* — Specifies a specific checkpoint file configuration.

**Values** 1 — 9

**rescue** — Specifies a rescue checkpoint configuration.

pThe clock-type is restricted based on the profile. See the profile command description for the details of the restrictions.

**Values**

**Description**

**Description**

**Description**

---

## Redundancy Commands

### redundancy

**Syntax** `redundancy`

**Context** admin  
config

**Description** This command enters the context to allow the user to perform redundancy operations.

### mgmt-ethernet

**Syntax** `mgmt-ethernet [revert seconds]`  
`no mgmt-ethernet`

**Context** configure>

The **revert** option allows the administrator to control when to revert back to the management Ethernet port of the primary CPM once it comes up again.

The **no** form of the command disables redundancy, so that connectivity to the active CPM is lost if its Ethernet port goes down.

This feature is not supported on the 7750 SR-a, 7750 SR-c and the VSR platforms.

**Default** 5 seconds

**Parameters** *seconds* — Specifies the duration to wait (in seconds) before reverting back to the primary CPM's management Ethernet port.

**Values** 1 — 300

### rollback-sync

**Syntax** `rollback-sync`

**Context** admin>redundancy

**Description** This command copies the entire set of rollback checkpoint files from the active CPM CF to the inactive CPM CF.

**Default** None.

### synchronize

## Redundancy Commands

**Syntax**    **synchronize {boot-env|config}**  
**no synchronize**

**Context**    admin>redundancy

**Description**    This command performs a synchronization of the standby CPM's images and/or configuration files to the active CPM. Either the **boot-env** or **config** parameter must be specified.

In the **admin>redundancy** context, this command performs a manually triggered standby CPM synchronization. When the standby CPM takes over operation following a failure or reset of the active CPM, it is important to ensure that the active and standby CPM have identical operational parameters. This includes the saved configuration, CPM and XCM images.

The active CPM ensures that the active configuration is maintained on the standby CPM. However, to ensure smooth operation under all circumstances, runtime images and system initialization configurations must also be automatically synchronized between the active and standby CPM. If synchronization fails, alarms and log messages that indicate the type of error that caused the failure of the synchronization operation are generated. When the error condition ceases to exist, the alarm is cleared.

Only files stored on the router are synchronized. If a configuration file or image is stored in a location other than on a local compact flash, the file is not synchronized (for example, storing a configuration file on an FTP server).

The **no** form of the command removes the parameter from the configuration.

**Default**    none

**Parameters**    **boot-env** — Synchronizes all files required for the boot process (loader, BOF, images, and config).

**config** — Synchronizes only the primary, secondary, and tertiary configuration files.

## force-switchover

**Syntax**    **force-switchover [now] [ignore-status]**

**Context**    admin>redundancy

**Description**    This command forces a switchover to the standby CPM card. The primary CPM reloads its software image and becomes the secondary CPM.

**Parameters**    **now** — Forces the switchover to the redundant CPM card immediately.

**ignore-status** — Forces a switchover despite any diagnostics or conditions on the standby. This is true even if the standby cannot reach the extension CPMs on the extension chassis of an XRS-40 via its local CPM interconnect ports).

## bgp-multi-homing

**Syntax**    **bgp-multi-homing**

**Context**    config>redundancy

**Description** This command configures BGP multi-homing parameters.

## boot-timer

**Syntax** **boot-timer** *seconds*  
**no boot-timer**

**Context** config>redundancy>bgp-multi-homing

**Description** This command configures the time the service manager waits after a node reboot before running the DF election algorithm. The boot-timer value should be configured to allow for the BGP sessions to come up and for the NLRI information to be refreshed/exchanged.

The **no** form of the command reverts the default.

**Default** no boot-timer

**Parameters** *seconds* — Specifies the BGP multi-homing boot-timer in seconds.

**Values** 1 — 100

## site-activation-timer

**Syntax** **site-activation-timer** *seconds*  
**no site-activation-timer**

**Context** config>redundancy>bgp-multi-homing

**Description** This command defines the amount of time the service manager will keep the local sites in standby status, waiting for BGP updates from remote PEs before running the DF election algorithm to decide whether the site should be unblocked. The timer is started when one of the following events occurs if the site is operationally up:

- Manual site activation using the **no shutdown** command at site-id level or at member object(s) level (SAP(s) or PW(s))
- Site activation after a failure

**Default** no site-activation-timer

**Parameters** *seconds* — Specifies the standby status in seconds.

**Values** 1 — 100

**Default** 2

## site-min-down-timer

**Syntax** **site-min-down-timer** *min-down-time*  
**no site-min-down-timer**

## Redundancy Commands

**Context** config>redundancy>bgp-multi-homing

**Description** This command configures the BGP multi-homing site minimum down time. When set to a non-zero value, if the site goes operationally down it will remain operationally down for at least the length of time configured for the **site-min-down-timer**, regardless of whether other state changes would have caused it to go operationally up. This timer is restarted every time that the site transitions from up to down.

The above operation is optimized in the following circumstances:

- If the site goes down on the designated forwarder but there are no BGP multi-homing peers with the same site in an UP state, then the **site-min-down-timer** is not started and is not used.
- If the site goes down on the designated forwarder but there are no active BGP multi-homing peers, then the **site-min-down-timer** is not started and is not used.
- If the **site-min-down-timer** is active and a BGP multi-homing update is received from the designated forwarder indicating its site has gone down, the **site-min-down-timer** is immediately terminated and this PE becomes the designated forwarder if the BGP multi-homing algorithm determines it should be the designated forwarder.

The **no** form of the command reverts to default value.

**Default** no site-min-down-timer

**Parameters** *min-down-time* — Specifies the time, in seconds, that a BGP multi-homing site remains operationally down after a transition from up to down.

**Values** 1— 100 seconds

**Default** 0 seconds

## synchronize

**Syntax** synchronize {**boot-env** | **config**}

**Context** config>redundancy

**Description** This command performs a synchronization of the standby CPMs images and/or config files to the active CPM. Either the **boot-env** or **config** parameter must be specified.

In the **config>redundancy** context, this command performs an automatically triggered standby CPM synchronization. When the standby CPM takes over operation following a failure or reset of the active CPM, it is important to ensure that the active and standby CPMs have identical operational parameters. This includes the saved configuration, CPM and XCM images.

The active CPM ensures that the active configuration is maintained on the standby CPM. However, to ensure smooth operation under all circumstances, runtime images and system initialization configurations must also be automatically synchronized between the active and standby CPM. If synchronization fails, alarms and log messages that indicate the type of error that caused the failure of the synchronization operation are generated. When the error condition ceases to exist, the alarm is cleared.

Only files stored on the router are synchronized. If a configuration file or image is stored in a location other than on a local compact flash, the file is not synchronized (for example, storing a configuration file on an FTP server).

**Default** enabled

**Parameters** **boot-env** — Synchronizes all files required for the boot process (loader, BOF, images, and config).  
**config** — Synchronize only the primary, secondary, and tertiary configuration files.

**Default** **config**

## synchronize

**Syntax** **synchronize {boot-env | config}**

**Context** admin>redundancy

**Description** This command performs a synchronization of the standby CPM's images and/or config files to the active CPM. Either the **boot-env** or **config** parameter must be specified.

In the **admin>redundancy** context, this command performs a manually triggered standby CPM synchronization. When the standby CPM takes over operation following a failure or reset of the active CPM, it is important to ensure that the active and standby CPM have identical operational parameters. This includes the saved configuration, CPM and XCMimages. The active CPM ensures that the active configuration is maintained on the standby CPM. However, to ensure smooth operation under all circumstances, runtime images and system initialization configurations must also be automatically synchronized between the active and standby CPM.

If synchronization fails, alarms and log messages that indicate the type of error that caused the failure of the synchronization operation are generated. When the error condition ceases to exist, the alarm is cleared.

Only files stored on the router are synchronized. If a configuration file or image is stored in a location other than on a local compact flash, the file is not synchronized (for example, storing a configuration file on an FTP server).

**Default** none

**Parameters** **boot-env** — Synchronizes all files required for the boot process (loader, BOF, images, and configuration files).  
**config** — Synchronize only the primary, secondary, and tertiary configuration files.

## multi-chassis

**Syntax** **multi-chassis**

**Context** config>redundancy

**Description** This command enables the context to configure multi-chassis parameters.

## peer-name

## Redundancy Commands

**Syntax**    **peer-name** *name*  
              **no peer-name**

**Context**    config>redundancy>multi-chassis>peer

**Description**    This command specifies a peer name.

**Parameters**    *name* — The string may be up to 32 characters long. Any printable, seven-bit ASCII characters can be used within the string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## rollback-sync

**Syntax**    **[no] rollback-sync**

**Context**    config>redundancy

**Description**    The operator can enable automatic synchronization of rollback checkpoint files between the active CPM and inactive CPM. When this automatic synchronization is enabled, a rollback save will cause the new checkpoint file to be saved on both the active and standby CPMs. The suffixes of the old checkpoint files on both active and standby CPMs are incremented. Note that automatic sync only causes the ONE new checkpoint file to be copied to both CFs (the other 9 checkpoints are not automatically copied from active to standby but that can be done manually with "admin red rollback-sync").

Automatic synchronization of rollback checkpoint files across CPMs is only performed if the rollback-location is configured as a local file-url (for example, "cf3:/rollback-files/rollback). Synchronization is not done if the rollback-location is remote.

Note that "config red sync {boot-env|config}" and "admin red sync {boot-env|config}" do not apply to rollback checkpoint files. These commands do not manually or automatically sync rollback checkpoint files. The dedicated rollback-sync commands must be used to sync rollback checkpoint files.

## source-address

**Syntax**    **source-address** *ip-address*  
              **no source-address**

**Context**    config>redundancy>multi-chassis>peer

**Description**    This command specifies the source address used to communicate with the multi-chassis peer.

**Parameters**    *ip-address* — Specifies the source address used to communicate with the multi-chassis peer.

## sync

**Syntax**    **[no] sync**

**Context**    config>redundancy>multi-chassis>peer

**Description** This command enables the context to configure synchronization parameters.

## igmp

**Syntax** [no] igmp

**Context** config>redundancy>multi-chassis>peer>sync

**Description** This command specifies whether IGMP protocol information should be synchronized with the multi-chassis peer.

**Default** no igmp

## igmp-snooping

**Syntax** [no] igmp-snooping

**Context** config>redundancy>multi-chassis>peer>sync

**Description** This command specifies whether IGMP snooping information should be synchronized with the multi-chassis peer.

**Default** no igmp-snooping

## local-dhcp-server

**Syntax** [no] local-dhcp-server

**Context** config>redundancy>multi-chassis>peer>sync

**Description** This command synchronizes DHCP server information.

## mld-snooping

**Syntax** [no] mld-snooping

**Context** config>redundancy>multi-chassis>peer>sync

**Description** MCS synchronization of MLD snooping is not supported. This command is not blocked for backwards compatibility reasons but has no effect on the system if configured.

## port

**Syntax** port [*port-id* | *lag-id*] [**sync-tag** *sync-tag*]

## Redundancy Commands

**no port** [*port-id* | *lag-id*]

**Context** config>redundancy>multi-chassis>peer>sync

**Description** This command specifies the port to be synchronized with the multi-chassis peer and a synchronization tag to be used while synchronizing this port with the multi-chassis peer.

**Parameters** *port-id* — Specifies the port to be synchronized with the multi-chassis peer.  
*lag-id* — Specifies the LAG ID to be synchronized with the multi-chassis peer.

**sync-tag** *sync-tag* — Specifies a synchronization tag to be used while synchronizing this port with the multi-chassis peer.

## python

**Syntax** python

**Context** config>redundancy>multi-chassis>peer>sync

**Description** This command enables syncing of python-policy cached entries to the peer.  
Use the **mcs-peer** command in the python-policy to enable syncing for a specific python-policy.

**Default** no python

## range

**Syntax** **range** *encap-range* **sync-tag** *sync-tag*  
**no range** *encap-range*

**Context** config>redundancy>multi-chassis>peer>sync>port

**Description** This command configures a range of encapsulation values.

**Parameters** *encap-range* — Specifies a range of encapsulation values on a port to be synchronized with a multi-chassis peer.

|               |       |                                  |
|---------------|-------|----------------------------------|
| <b>Values</b> | Dot1Q | <i>start-vlan-end-vlan</i>       |
|               | QinQ  | <i>Q1.start-vlan-Q1.end-vlan</i> |

**sync-tag** *sync-tag* — Specifies a synchronization tag up to 32 characters in length to be used while synchronizing this encapsulation value range with the multi-chassis peer.

---

## Peer Commands

### peer

**Syntax** [no] peer *ip-address*

**Context** config>redundancy>multi-chassis

**Description** This command configures a multi-chassis redundancy peer.

**Parameters** *ip-address* — Specifies a peer IP address. Multicast address are not allowed.

### authentication-key

**Syntax** authentication-key [*authentication-key* | *hash-key*] [**hash** | **hash2**]  
no authentication-key

**Context** config>redundancy>multi-chassis>peer

**Description** This command configures the authentication key used between this node and the multi-chassis peer. The authentication key can be any combination of letters or numbers.

**Parameters** *authentication-key* — Specifies the authentication key. Allowed values are any string up to 20 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

*hash-key* — The hash key. The key can be any combination of ASCII characters up to 33 (hash1-key) or 55 (hash2-key) characters in length (encrypted). If spaces are used in the string, enclose the entire string in quotation marks (“ ”).

**hash** — Specifies the key is entered in an encrypted form. If the hash or hash2 parameter is not used, the key is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted form in the configuration file with the hash or hash2 parameter specified.

**hash2** — Specifies the key is entered in a more complex encrypted form that involves more variables than the key value alone, this means that hash2 encrypted variable cannot be copied and pasted. If the hash or hash2 parameter is not used, the key is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted form in the configuration file with the hash or hash2 parameter specified.

## MC Endpoint Commands

### mc-endpoint

- Syntax** `[no] mc-endpoint`
- Context** `config>redundancy>multi-chassis>peer`
- Description** This command specifies that the endpoint is multi-chassis. This value should be the same on both MC-EP peers for the pseudowires that must be part of the same group.  
The **no** form of this command removes the endpoint from the MC-EP. Single chassis behavior applies.

### bfd-enable

- Syntax** `[no] bfd-enable`
- Context** `config>redundancy>multi-chassis>peer>mc-ep`  
`config>router>rsvp`  
`config>router>bgp`  
`config>router>bgp>group`  
`config>router>bgp>group>neighbor`  
`config>redundancy>multi-chassis>peer>mc-ep`
- Description** This command enables the use of bi-directional forwarding (BFD) to control the state of the associated protocol interface. By enabling BFD on a given protocol interface, the state of the protocol interface is tied to the state of the BFD session between the local node and the remote node. The parameters used for the BFD are set via the BFD command under the IP interface.  
The **no** form of this command disables BFD.
- Default** `no bfd-enable`

### boot-timer

- Syntax** `boot-timer interval`  
`no boot-timer`
- Context** `config>redundancy>multi-chassis>peer>mc-ep`
- Description** This command configures the boot timer interval. This command applies only when the node reboots. It specifies the time the MC-EP protocol keeps trying to establish a connection before assuming a failure of the remote peer. This is different from the keep-alives mechanism which is used just after the peer-peer communication was established. After this time interval passed all the mc-endpoints configured under services will revert to single chassis behavior, activating the best local PW.  
The **no** form of this command sets the interval to default.

**Default** 300

**Parameters** *interval* — Specifies the boot timer interval.

**Values** 1 — 600

## hold-on-neighbor-failure

**Syntax** **hold-on-neighbor-failure** *multiplier*  
**no hold-on-neighbor-failure**

**Context** config>redundancy>multi-chassis>peer>mc-ep

**Description** This command specifies the number of keep-alive intervals that the local node will wait for packets from the MC-EP peer before assuming failure. After this time interval passed the all the mc-endpoints configured under services will revert to single chassis behavior, activating the best local pseudowire.

The **no** form of this command sets the multiplier to default value

**Default** 3

**Parameters** *multiplier* — Specifies the hold time applied on neighbor failure.

**Values** 2 — 25

## keep-alive-interval

**Syntax** **keep-alive-interval** *interval*  
**no keep-alive-interval**

**Context** config>redundancy>multi-chassis>peer>mc-ep

**Description** This command sets the interval at which keep-alive messages are exchanged between two systems participating in MC-EP when bfd is not enabled or is down. These fast keep-alive messages are used to determine remote-node failure and the interval is set in deci-seconds.

The **no** form of this command sets the interval to default value

**Default** 5 (0.5s)

**Parameters** *interval* — The time interval expressed in deci-seconds.

**Values** 5 — 500 (tenths of a second)

## Redundancy Commands

### passive-mode

**Syntax** [no] **passive-mode**

**Context** config>redundancy>multi-chassis>peer>mc-ep

**Description** This command configures the passive mode behavior for the MC-EP protocol. When in passive mode the MC-EP pair will be dormant until two of the pseudowires in a MC-EP will be signaled as active by the remote PEs, being assumed that the remote pair is configured with regular MC-EP. As soon as more than one pseudowire is active, dormant MC-EP pair will activate. It will use the regular exchange to select the best pseudowire between the active ones and it will block the Rx and Tx directions of the other pseudowires.

The **no** form of this command will disable the passive mode behavior.

**Default** no passive-mode

### system-priority

**Syntax** **system-priority** *value*  
**no system-priority**

**Context** config>redundancy>multi-chassis>peer>mc-ep

**Description** This command allows the operator to set the system priority. The peer configured with the lowest value is chosen to be the master. If system-priority are equal then the one with the highest system-id (chassis MAC address) is chosen as the master.

The **no** form of this command sets the system priority to default

**Default** no system-priority

**Parameters** *value* — Specifies the priority assigned to the local MC-EP peer.

**Values** 1 — 255

---

## MC-LAG Commands

### mc-lag

**Syntax** [no] mc-lag

**Context** config>redundancy>multi-chassis>peer>mc-lag

**Description** This command enables the context to configure multi-chassis LAG operations and related parameters. The **no** form of this command administratively disables multi-chassis LAG. MC-LAG can only be issued only when mc-lag is shutdown.

### hold-on-neighbor-failure

**Syntax** **hold-on-neighbor-failure** *multiplier*  
**no hold-on-neighbor-failure**

**Context** config>redundancy>multi-chassis>peer>mc-lag

**Description** This command specifies the interval that the standby node will wait for packets from the active node before assuming a redundant-neighbor node failure. This delay in switch-over operation is required to accommodate different factors influencing node failure detection rate, such as IGP convergence, or HA switch-over times and to prevent the standby node to take action prematurely. The **no** form of this command sets this parameter to default value.

**Default** 3

**Parameters** *multiplier* — The time interval that the standby node will wait for packets from the active node before assuming a redundant-neighbor node failure.

**Values** 2 — 25

### keep-alive-interval

**Syntax** **keep-alive-interval** *interval*  
**no keep-alive-interval**

**Context** config>redundancy>multi-chassis>peer>mc-lag

**Description** This command sets the interval at which keep-alive messages are exchanged between two systems participating in MC-LAG. These keep-alive messages are used to determine remote-node failure and the interval is set in deci-seconds.

The **no** form of this command sets the interval to default value

**Default** 1s (10 hundreds of milliseconds means interval value of 10)

## Redundancy Commands

**Parameters** *interval* — The time interval expressed in deci-seconds

**Values** 5 — 500

## lag

**Syntax** **lag** *lag-id* **lacp-key** *admin-key* **system-id** *system-id* [**remote-lag** *remote-lag-id*] **system-priority** *system-priority* **source-bmac-lsb** *use-lacp-key*  
**lag** *lag-id* **lacp-key** *admin-key* **system-id** *system-id* [**remote-lag** *remote-lag-id*] **system-priority** *system-priority* **source-bmac-lsb** *MAC-Lsb*  
**lag** *lag-id* **lacp-key** *admin-key* **system-id** *system-id* [**remote-lag** *remote-lag-id*] **system-priority** *system-priority*  
**lag** *lag-id* [**remote-lag** *remote-lag-id*]  
**no lag** *lag-id*

**Context** config>redundancy>multi-chassis>peer>mc-lag

**Description** This command defines a LAG which is forming a redundant-pair for MC-LAG with a LAG configured on the given peer. The same LAG group can be defined only in the scope of 1 peer. The same **lacp-key**, **system-id**, and **system-priority** must be configured on both nodes of the redundant pair in order to MC-LAG to become operational. In order MC-LAG to become operational, all parameters (**lacp-key**, **system-id**, **system-priority**) must be configured the same on both nodes of the same redundant pair. The partner system (the system connected to all links forming MC-LAG) will consider all ports using the same **lacp-key**, **system-id**, **system-priority** as the part of the same LAG. In order to achieve this in MC operation, both redundant-pair nodes have to be configured with the same values. In case of the mismatch, MC-LAG is kept operationally down.

**Default** none

**Parameters** *lag-id* — The LAG identifier, expressed as a decimal integer. Specifying the *lag-id* allows the mismatch between lag-id on redundant-pair. If no **lag-id** is specified it is assumed that neighbor system uses the same *lag-id* as a part of the given MC-LAG. If no matching MC-LAG group can be found between neighbor systems, the individual LAGs will operate as usual (no MC-LAG operation is established.).

**Values** 1 — 800

**lacp-key** *admin-key* — Specifies a 16 bit key that needs to be configured in the same manner on both sides of the MC-LAG in order for the MC-LAG to come up.

**Values** 1 — 65535

**system-id** *system-id* — Specifies a 6 byte value expressed in the same notation as MAC address

**Values** xx:xx:xx:xx:xx:xx - xx [00..FF]

**remote-lag** *lag-id* — Specifies the LAG ID on the remote system.

**Values** 1 — 800

**system-priority** *system-priority* — Specifies the system priority to be used in the context of the MC-LAG. The partner system will consider all ports using the same **lacp-key**, **system-id**, and **system-priority** as part of the same LAG.

**Values**     1 — 65535

---

## Multi-Chassis Mobile Commands

### mc-mobile

|                    |                                                                        |
|--------------------|------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>mc-mobile</b>                                                       |
| <b>Context</b>     | config>redundancy>mc>peer                                              |
| <b>Description</b> | This command enables to the context to configure mc-mobile parameters. |
| <b>Default</b>     | no mc-mobile                                                           |

### bfd-enable

|                    |                                                                                                                                                                                                                                                                                                            |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>bfd-enable [service <i>service-id</i>] interface <i>interface-name</i></b><br><b>no bfd-enable</b>                                                                                                                                                                                                      |
| <b>Context</b>     | config>redundancy>multi-chassis>peer>mc-mobile                                                                                                                                                                                                                                                             |
| <b>Description</b> | This command enables the use of Bi-directional Forwarding Detection (BFD) to be associated with the peer. The mc-mobile redundancy protocol will use the BFD state to determine liveness of its peer. The parameters for the BFD session are set via the BFD command under the IP interface configuration. |
| <b>Default</b>     | no bfd-enable                                                                                                                                                                                                                                                                                              |
| <b>Parameters</b>  | <i>service-id</i> — Specifies the service identifier string, maximum of 64 characters.<br><b>Values</b> 1—2147483648<br><i>interface-name</i> — Specifies the interface name, maximum of 32 characters.                                                                                                    |

### hold-on-neighbor-failure

|                    |                                                                                                                                                                                                                                                                 |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>hold-on-neighbor-failure <i>multiplier</i></b><br><b>no hold-on-neighbor-failure</b>                                                                                                                                                                         |
| <b>Context</b>     | config>redundancy>multi-chassis>peer>mc-mobile                                                                                                                                                                                                                  |
| <b>Description</b> | This command specifies the number of keep-alive-intervals that may expire before the local node decides that the peer has failed. A peer failure will be declared if no keep-alive responses are received after hold-on-neighbor-failure x keep-alive-interval. |
| <b>Default</b>     | 3                                                                                                                                                                                                                                                               |
| <b>Parameters</b>  | <i>multiplier</i> — Specifies the multiplier.<br><b>Values</b> 2—25                                                                                                                                                                                             |

## keep-alive-interval

**Syntax**    **keep-alive-interval** *interval*  
              **no keep-alive-interval**

**Context**    config>redundancy>multi-chassis>peer>mc-mobile

**Description**    This command sets the interval at which keep-alive messages are sent to the peer when bfd is not enabled or is down.

**Default**     10 (1 second)

**Parameters**    *interval* — The time interval expressed in deci-seconds.

**Values**     5—500 (tenths of a second)

## Multi-Chassis Ring Commands

### mc-ring

- Syntax** **mc-ring**
- Context** config>redundancy>mc>peer  
config>redundancy>multi-chassis>peer>sync
- Description** This command enables the context to configure the multi-chassis ring parameters.

### ring

- Syntax** **ring** *sync-tag*  
**no ring** *sync-tag*
- Context** config>redundancy>mc>peer>mcr
- Description** This command configures a multi-chassis ring.
- Parameters** *sync-tag* — Specifies a synchronization tag to be used while synchronizing this port with the multi-chassis peer.

### in-band-control-path

- Syntax** **in-band-control-path**
- Context** config>redundancy>mc>peer>mcr>ring
- Description** This command enables the context to configure multi-chassis ring inband control path parameters.

### dst-ip

- Syntax** **dst-ip** *ip-address*  
**no dst-ip**
- Context** config>redundancy>mc>peer>mcr>ring>in-band-control-path
- Description** This command specifies the destination IP address used in the inband control connection. If the address is not configured, the ring cannot become operational.
- Parameters** *ip-address* — Specifies the destination IP address.

## interface

**Syntax** **interface** *ip-int-name*  
**no interface**

**Context** config>redundancy>mc>peer>mcr>ring>in-band-control-path

**Description** This command specifies the name of the IP interface used for the inband control connection. If the name is not configured, the ring cannot become operational.

## service-id

**Syntax** **service-id** *service-id*  
**no service-id**

**Context** config>redundancy>mc>peer>mcr>ring>ibc

**Description** This command specifies the service ID if the interface used for the inband control connection belongs to a VPRN service. If not specified, the *service-id* is zero and the interface must belong to the Base router.

The **no** form of the command removes the service-id from the IBC configuration.

**Parameters** *service-id* — Specifies the service ID if the interface.

## path-b

**Syntax** [**no**] **path-b**

**Context** config>redundancy>mc>peer>mcr>ring

**Description** This command specifies the set of upper-VLAN IDs associated with the SAPs that belong to path B with respect to load-sharing. All other SAPs belong to path A.

**Default** If not specified, the default is an empty set.

## range

**Syntax** [**no**] **range** *vlan-range*

**Context** config>redundancy>mc>peer>mcr>ring>path-b  
 config>redundancy>mc>peer>mcr>ring>path-excl

**Description** This command configures a MCR b-path VLAN range.

**Parameters** *vla-range* — Specifies the VLAN range.

**Values** 1 to 4094 — 1 to 4094

## Redundancy Commands

### path-excl

|                    |                                                                                                                                           |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>[no] path-excl</b>                                                                                                                     |
| <b>Context</b>     | config>redundancy>mc>peer>mcr>ring                                                                                                        |
| <b>Description</b> | This command specifies the set of upper-VLAN IDs associated with the SAPs that are to be excluded from control by the multi-chassis ring. |
| <b>Default</b>     | If not specified, the default is an empty set.                                                                                            |

### ring-node

|                    |                                                                                                                                                                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>ring-node</b> <i>ring-node-name</i> [ <b>create</b> ]<br><b>no ring-node</b> <i>ring-node-name</i>                                                                                                                                                               |
| <b>Context</b>     | config>redundancy>mc>peer>mcr>ring                                                                                                                                                                                                                                  |
| <b>Description</b> | This command specifies the unique name of a multi-chassis ring access node.                                                                                                                                                                                         |
| <b>Parameters</b>  | <i>ring-node-name</i> — Specifies the unique name of a multi-chassis ring access node.<br><b>create</b> — Keyword used to create the ring node instance. The <b>create</b> keyword requirement can be enabled/disabled in the <b>environment&gt;create</b> context. |

### connectivity-verify

|                    |                                                                                   |
|--------------------|-----------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>connectivity-verify</b>                                                        |
| <b>Context</b>     | config>redundancy>mc>peer>mcr>ring>ring-node                                      |
| <b>Description</b> | This command enables the context to configure node connectivity check parameters. |

### dst-ip

|                    |                                                                                                 |
|--------------------|-------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>dst-ip</b> <i>ip-address</i><br><b>no dst-ip</b>                                             |
| <b>Context</b>     | config>redundancy>mc>peer>mcr>ring>ring-node>connectivity-verify                                |
| <b>Description</b> | This command configures the node cc destination IP address.                                     |
| <b>Default</b>     | no dst-ip                                                                                       |
| <b>Parameters</b>  | <i>ip-address</i> — Specifies the destination IP address used in the inband control connection. |

## interval

|                    |                                                                                                           |
|--------------------|-----------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>interval</b> <i>interval</i><br><b>no interval</b>                                                     |
| <b>Context</b>     | config>redundancy>mc>peer>mcr>ring>ring-node>connectivity-verify                                          |
| <b>Description</b> | This command specifies the polling interval of the ring-node connectivity verification of this ring node. |
| <b>Default</b>     | 5                                                                                                         |
| <b>Parameters</b>  | <i>interval</i> — Specifies the polling interval, in minutes.<br><b>Values</b> 1 — 6000                   |

## service-id

|                    |                                                                                                                      |
|--------------------|----------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>service-id</b> <i>service-id</i><br><b>no service-id</b>                                                          |
| <b>Context</b>     | config>redundancy>mc>peer>mcr>ring>ring-node>connectivity-verify                                                     |
| <b>Description</b> | This command specifies the service ID of the SAP used for the ring-node connectivity verification of this ring node. |
| <b>Default</b>     | no service-id                                                                                                        |
| <b>Parameters</b>  | <i>service-id</i> — Specifies the service ID of the SAP.<br><b>Values</b> 1 — 2147483647                             |

## src-ip

|                   |                                                                                                                                                                                     |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>     | <b>src-ip</b> <i>ip-address</i><br><b>no src-ip</b>                                                                                                                                 |
| <b>Context</b>    | config>redundancy>mc>peer>mcr>ring>ring-node>connectivity-verify<br>This command specifies the source IP address used in the ring-node connectivity verification of this ring node. |
| <b>Default</b>    | no src-ip                                                                                                                                                                           |
| <b>Parameters</b> | <i>ip-address</i> — Specifies the address of the multi-chassis peer.                                                                                                                |

## src-mac

|               |                                                         |
|---------------|---------------------------------------------------------|
| <b>Syntax</b> | <b>src-mac</b> <i>ieee-address</i><br><b>no src-mac</b> |
|---------------|---------------------------------------------------------|

## Redundancy Commands

**Context** config>redundancy>mc>peer>mcr>node>cv

**Description** This command specifies the source MAC address used for the Ring-Node Connectivity Verification of this ring node.

A value of all zeroes (000000000000 H (0:0:0:0:0:0)) specifies that the MAC address of the system management processor (CPM) is used.

**Default** no src-mac

**Parameters** *ieee-address* — Specifies the source MAC address.

## vlan

**Syntax** **vlan [0..4094]**  
**no vlan**

**Context** config>redundancy>mc>peer>mcr>node>cv

**Description** This command specifies the VLAN tag of the SAP used for the ring-node connectivity verification of this ring node. It is only meaningful if the value of service ID is not zero. A zero value means that no VLAN tag is configured.

**Default** no vlan

**Parameters** [0..4094] — Specifies the set of VLAN IDs associated with the SAPs that are to be controlled by the slave peer.

---

## LLDP System Commands

### lldp

**Syntax**    `lldp`

**Context**    `config>system`

**Description**    This command enables the context to configure system-wide Link Layer Discovery Protocol parameters.

### message-fast-tx

**Syntax**    `message-fast-tx time`  
`no message-fast-tx`

**Context**    `config>system>lldp`

**Description**    This command configures the duration of the fast transmission period.

**Parameters**    *time* — Specifies the fast transmission period in seconds.

**Values**        1 — 3600

**Default**       1

### message-fast-tx-init

**Syntax**    `message-fast-tx-init count`  
`no message-fast-tx-init`

**Context**    `config>system>lldp`

**Description**    This command configures the number of LLDPDUs to send during the fast transmission period.

**Parameters**    *count* — Specifies the number of LLDPDUs to send during the fast transmission period.

**Values**        1 — 8

**Default**       4

## notification-interval

**Syntax**     **notification-interval** *time*  
              **no notification-interval**

**Context**     config>system>lldp

**Description**   This command configures the minimum time between change notifications.

**Parameters**   *time* — Specifies the minimum time, in seconds, between change notifications.

**Values**     5 — 3600

**Default**    5

## reinit-delay

**Syntax**     **reinit-delay** *time*  
              **no reinit-delay**

**Context**     config>system>lldp

**Description**   This command configures the time before re-initializing LLDP on a port.

**Parameters**   *time* — Specifies the time, in seconds, before re-initializing LLDP on a port.

**Values**     1 — 10

**Default**    2

## tx-credit-max

**Syntax**     **tx-credit-max** *count*  
              **no tx-credit-max**

**Context**     config>system>lldp

**Description**   This command configures the maximum consecutive LLDPDUs transmitted.

**Parameters**   *count* — Specifies the maximum consecutive LLDPDUs transmitted.

**Values**     1 — 100

**Default**    5

## tx-hold-multiplier

**Syntax** **tx-hold-multiplier** *multiplier*  
**no tx-hold-multiplier**

**Context** config>system>lldp

**Description** This command configures the multiplier of the tx-interval.

**Parameters** *multiplier* — Specifies the multiplier of the tx-interval.

**Values** 2 — 10

**Default** 4

## tx-interval

**Syntax** **tx-interval** *interval*  
**no tx-interval**

**Context** config>system>lldp

**Description** This command configures the LLDP transmit interval time.

**Parameters** *interval* — Specifies the LLDP transmit interval time.

**Values** 1 — 100

**Default** 5

---

## LLDP Ethernet Port Commands

### lldp

|                    |                                                                                                                      |
|--------------------|----------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>lldp</b>                                                                                                          |
| <b>Context</b>     | config>port>ethernet                                                                                                 |
| <b>Description</b> | This command enables the context to configure Link Layer Discovery Protocol (LLDP) parameters on the specified port. |

### dest-mac

|                    |                                                                                                                                                                                                                                                                                                                          |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>dest-mac</b> { <i>bridge-mac</i> }                                                                                                                                                                                                                                                                                    |
| <b>Context</b>     | config>port>ethernet>lldp                                                                                                                                                                                                                                                                                                |
| <b>Description</b> | This command configures destination MAC address parameters.                                                                                                                                                                                                                                                              |
| <b>Parameters</b>  | <b>bridge-mac</b> — Specifies destination bridge MAC type to use by LLDP.<br><b>Values</b><br><b>nearest-bridge</b> — Specifies to use the nearest bridge.<br><b>nearest-non-tpmr</b> — Specifies to use the nearest non-Two-Port MAC Relay (TPMR) .<br><b>nearest-customer</b> — Specifies to use the nearest customer. |

### admin-status

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <b>admin-status</b> { <b>rx</b>   <b>tx</b>   <b>tx-rx</b>   <b>disabled</b> }                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Context</b>     | config>port>ethernet>lldp>dstmac                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Description</b> | This command specifies the administratively desired status of the local LLDP agent.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Parameters</b>  | <b>rx</b> — Specifies the LLDP agent will receive, but will not transmit LLDP frames on this port.<br><b>tx</b> — Specifies that the LLDP agent will transmit LLDP frames on this port and will not store any information about the remote systems connected.<br><b>tx-rx</b> — Specifies that the LLDP agent will transmit and receive LLDP frames on this port.<br><b>disabled</b> — Specifies that the LLDP agent will not transmit or receive LLDP frames on this port. If there is remote systems information which is received on this port and stored in other tables, before the port's admin status becomes disabled, then the information will naturally age out. |

## notification

**Syntax** [no] notification

**Context** config>port>ethernet>lldp>dstmac

**Description** This command enables LLDP notifications.  
The **no** form of the command disables LLDP notifications.

## tx-mgmt-address

**Syntax** tx-mgmt-address [system]  
no tx-mgmt-address

**Context** config>port>ethernet>lldp>dstmac

**Description** This command specifies which management address to transmit.  
The **no** form of the command resets value to the default.

**Default** no tx-mgmt-address

**Parameters** **system** — Specifies to use the system IP address. Note that the system address will only be transmitted once it has been configured if this parameter is specified

## tx-tlvs

**Syntax** tx-tlvs [port-desc] [sys-name] [sys-desc] [sys-cap]  
no tx-tlvs

**Context** config>port>ethernet>lldp>dstmac

**Description** This command specifies which LLDP TLVs to transmit.  
The **no** form of the command resets the value to the default.

**Default** no tx-tlvs

**Parameters** **port-desc** — Indicates that the LLDP agent should transmit port description TLVs.  
**sys-name** — Indicates that the LLDP agent should transmit system name TLVs.  
**sys-desc** — Indicates that the LLDP agent should transmit system description TLVs.  
**sys-cap** — Indicates that the LLDP agent should transmit system capabilities TLVs.



---

## Show Commands

---

### SYSTEM COMMANDS

#### card

**Syntax**    **card**

**Context**    show>system

**Description**    This command enables the context to display card information.

#### memory-pools

**Syntax**    **memory-pools**

**Context**    show>system>card

**Description**    This command displays the memory pools for the card.

#### connections

**Syntax**    **connections [address *ip-address*] [port *port-number*] [detail]**

**Context**    show>system

**Description**    This command displays UDP and TCP connection information.  
If no command line options are specified, a summary of the TCP and UDP connections displays.

**Parameters**    *ip-address* — Displays only the connection information for the specified IP address.

**Values**

|               |                                                            |
|---------------|------------------------------------------------------------|
| ipv4-address: | a.b.c.d (host bits must be 0)                              |
| ipv6-address: | x:x:x:x:x:x:x[-interface]<br>x:x:x:x:x:d.d.d.d[-interface] |
| x:            | [0 — FFFF]H                                                |
| d:            | [0 — 255]D                                                 |
| interface:    | 32 characters maximum, mandatory for link local addresses  |

*port-number* — Displays only the connection information for the specified port number.

**Values**    0 — 65535

**detail** — Appends TCP statistics to the display output.

**Output Standard Connection Output** — The following table describes the system connections output fields.

| Label          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Proto          | Displays the socket protocol, either TCP or UDP.                                                                                                                                                                                                                                                                                                                                                                                                               |
| RecvQ          | Displays the number of input packets received by the protocol.                                                                                                                                                                                                                                                                                                                                                                                                 |
| TxmtQ          | Displays the number of output packets sent by the application.                                                                                                                                                                                                                                                                                                                                                                                                 |
| Local Address  | Displays the local address of the socket. The socket port is separated by a period.                                                                                                                                                                                                                                                                                                                                                                            |
| Remote Address | Displays the remote address of the socket. The socket port is separated by a period.                                                                                                                                                                                                                                                                                                                                                                           |
| State          | <p>Listen — The protocol state is in the listen mode.</p> <p>Established — The protocol state is established.</p> <p>vRtrID — The virtual router identifier.</p> <ul style="list-style-type: none"> <li>vRtrID 0 — listens for connections in all routing instances including the Base and Management VRFs.</li> <li>vRtrID 1 — Base routing instance</li> <li>vRtrID 4095 — Management routing instance</li> </ul> <p>MSS — The TCP maximum segment size.</p> |

**Sample Output**

```
A:ALA-12# show system connections
=====
Connections
=====
Prot RecvQ  TxmtQ  Local Address          State
      MSS   Remote Address          vRtrID
-----
TCP      0      0 0.0.0.0.21            LISTEN
      1024 0.0.0.0.0              0
TCP      0      0 0.0.0.0.22            LISTEN
      1024 0.0.0.0.0              0
TCP      0      0 0.0.0.0.23            LISTEN
      1024 0.0.0.0.0              0
TCP      0      0 0.0.0.0.830           LISTEN
      1024 0.0.0.0.0              0
TCP      0      0 0.0.0.0.6068          LISTEN
      1024 0.0.0.0.0              0
TCP      0      0 0.0.0.0.47806         LISTEN
      1024 0.0.0.0.0              0
TCP      0      0 ::.21                 LISTEN
      1024 ::.0                    0
TCP      0      0 ::.22                 LISTEN
      1024 ::.0                    0
TCP      0      0 ::.830                LISTEN
      1024 ::.0                    0
```

## Show Commands

```

TCP      0      0  ::.47806                LISTEN
          1024  ::.0                      0
TCP      0      0  127.1.0.11.21          LISTEN
          1024  0.0.0.0.0                4095
TCP      0      0  127.1.0.11.21059      LISTEN
          1024  0.0.0.0.0                4095
TCP      0      0  135.121.129.98.22     LISTEN
          1024  0.0.0.0.0                4095
TCP      0      0  135.121.129.98.23     ESTABLISH
          1024  138.120.140.149.59042    4095
TCP      0      1149  135.121.129.98.23     ESTABLISH
          1024  138.120.140.244.58579    4095
TCP      0      0  135.121.129.98.830    LISTEN
          1024  0.0.0.0.0                4095
TCP      0      0  3000::8779:8163.22     LISTEN
          1024  ::.0                      4095
TCP      0      0  3000::8779:8163.830    LISTEN
          1024  ::.0                      4095
UDP      0      0  0.0.0.0.67            ---
          0.0.0.0.0                0
UDP      0      0  0.0.0.0.68            ---
          0.0.0.0.0                0
UDP      0      0  0.0.0.0.123           ---
          0.0.0.0.0                0
UDP      0      0  0.0.0.0.319           ---
          0.0.0.0.0                0
UDP      0      0  0.0.0.0.320           ---
          0.0.0.0.0                0
UDP      0      0  0.0.0.0.514           ---
          0.0.0.0.0                0
UDP      0      0  0.0.0.0.50055         ---
          0.0.0.0.0                0
UDP      0      0  ::.123                 ---
          ::.0                      0
UDP      0      0  ::.50056               ---
          ::.0                      0
UDP      0      0  0.0.0.0.1025          ---
          0.0.0.0.0                1
UDP      0      0  0.0.0.0.123           ---
          0.0.0.0.0                4095
UDP      0      0  0.0.0.0.49152

```

-----  
No. of Connections: 18

=====  
A:ALA-12#

### Sample Detailed Output

A:ALA-12# show system connections detail

-----  
TCP Statistics

```

-----
packets sent                : 659635
data packets                 : 338982 (7435146 bytes)
data packet retransmitted   : 73 (1368 bytes)
ack-only packets            : 320548 (140960 delayed)
URG only packet              : 0
window probe packet         : 0

```

## System Commands

```
window update packet          : 0
control packets               : 32
packets received              : 658893
acks                          : 338738 for (7435123 bytes)
duplicate acks                : 23
ack for unsent data           : 0
packets received in-sequence  : 334705 (5568368 bytes)
completely duplicate packet   : 2 (36 bytes)
packet with some dup. data    : 0 (0 bytes)
out-of-order packets          : 20 (0 bytes)
packet of data after window   : 0 (0 bytes)
window probe                   : 0
window update packet          : 3
packets received after close   : 0
discarded for bad checksum     : 0
discarded for bad header offset field : 0
discarded because packet too short : 0
connection request            : 4
connection accept             : 24
connections established (including accepts) : 27
connections closed            : 26 (including 2 drops)
embryonic connections dropped  : 0
segments updated rtt          : 338742 (of 338747 attempts)
retransmit timeouts           : 75
connections dropped by rexmit timeout : 0
persist timeouts              : 0
keepalive timeouts            : 26
keepalive probes sent         : 0
connections dropped by keepalive : 1
pcb cache lookups failed      : 0
connections dropped by bad md5 digest : 0
connections dropped by enhanced auth : 0
path mtu discovery backoff    : 0
=====
A:ALA-12#
```

## cpu

**Syntax**    **cpu** [**sample-period** *seconds*]

**Context**    show>system  
              show>card

**Description**    This command displays CPU utilization per task over a sample period.

**Parameters**    **sample-period** *seconds* — The number of seconds over which to sample CPU task utilization.

**Default**    1

**Values**     1 — 300

**Output System CPU Output** — The following table describes the system CPU output fields.

| Label           | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CPU Utilization | The total amount of CPU time.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Name            | The process or protocol name.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| CPU Time (uSec) | The CPU time each process or protocol has used in the specified time.                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| CPU Usage       | The sum of CPU usage of all the processes and protocols.                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Capacity Usage  | Displays the level the specified service is being utilized. When this number hits 100%, this part of the system is busied out. There may be extra CPU cycles still left for other processes, but this service is running at capacity. This column does not reflect the true CPU utilization value; that data is still available in the <b>CPU Usage</b> column. This column is the <b>busiest</b> task in each group, where <b>busiest</b> is defined as either actually running or blocked attempting to acquire a lock. |

### Sample Output

```
*A:cses-E11# show system cpu sample-period 2
=====
CPU Utilization (Sample period: 2 seconds)
=====
Name                               CPU Time      CPU Usage     Capacity
                                   (uSec)                               Usage
-----
BFD                                 10            ~0.00%       ~0.00%
BGP                                  0             0.00%        0.00%
CFLOWD                               61           ~0.00%       ~0.00%
Cards & Ports                        8,332         0.41%        0.08%
ICC                                   408           0.02%        0.01%
IGMP/MLD                             1,768         0.08%        0.08%
IOM                                  17,197        0.85%        0.31%
IP Stack                             4,080         0.20%        0.09%
IS-IS                                1,213         0.06%        0.06%
LDP                                    0             0.00%        0.00%
Logging                               32            ~0.00%       ~0.00%
MPLS/RSVP                            2,380         0.11%        0.08%
MSDP                                   0             0.00%        0.00%
Management                           5,969         0.29%        0.15%
OAM                                    907           0.04%        0.02%
OSPF                                   25           ~0.00%       ~0.00%
PIM                                   5,600         0.27%        0.27%
RIP                                    0             0.00%        0.00%
RTM/Policies                          0             0.00%        0.00%
Redundancy                           3,635         0.18%        0.13%
SIM                                   1,462         0.07%        0.04%
SNMP Daemon                          0             0.00%        0.00%
Services                             2,241         0.11%        0.05%
Stats                                  0             0.00%        0.00%
System                                8,802         0.43%        0.17%
Traffic Eng                           0             0.00%        0.00%
```

## System Commands

```

VRRP                                697                0.03%           0.02%
WEB Redirect                         125                ~0.00%          ~0.00%
-----
Total                               2,014,761         100.00%
  Idle                               1,945,113         96.54%
  Usage                               69,648            3.45%
Busiest Core Utilization             69,648            3.45%
=====
*A:cses-E11#

*A:ALA-1# show card 4 cpu

=====
Card 4 CPU Utilization (Sample period: 1 second)
=====
Name                                CPU Time          CPU Usage        Capacity
                                   (uSec)
                                   (uSec)
-----
HQoS Algorithm                       70                ~0.00%           ~0.00%
HQoS Statistics                      124                ~0.00%           0.83%
IOM                                  15,904            0.79%            0.94%
-----
Total                               2,003,678         100.00%
  Idle                               1,987,580         99.19%
  Usage                               16,098            0.80%
Busiest Core Utilization             8,192             0.81%
=====

```

## cron

**Syntax** **cron**

**Context** show>cron

**Description** This command enters the show CRON context.

## action

**Syntax** **action** [*action-name*] [**owner** *action-owner*] **run-history** *run-state*

**Context** show>cron#

**Description** This command displays cron action parameters.

**Parameters** **action** *action-name* — Specifies the action name.

**Values** maximum 32 characters

**owner** *action-owner* — Specifies the owner name.

**Default** TiMOS CLI

**run-history** *run-state* — Specifies the state of the test to be run.

**Values**      executing, initializing, terminated

**Output**      The following table describes the show cron action output fields.

| Label                       | Description                                                                                |
|-----------------------------|--------------------------------------------------------------------------------------------|
| Action                      | Displays the name of the action.                                                           |
| Action owner                | The name of the action owner.                                                              |
| Administrative status       | Enabled — Administrative status is enabled<br>Disabled — Administrative status is disabled |
| Script                      | The name of the script                                                                     |
| Script owner                | The name of the script owner.                                                              |
| Script source location      | Displays the location of scheduled script.                                                 |
| Max running allowed         | Displays the maximum number of allowed sessions.                                           |
| Max completed run histories | Displays the maximum number of sessions previously run.                                    |
| Max lifetime allowed        | Displays the maximum amount of time the script may run.                                    |
| Completed run histories     | Displays the number of completed sessions.                                                 |
| Executing run histories     | Displays the number of sessions in the process of executing.                               |
| Initializing run histories  | Displays the number of sessions ready to run/queued but not executed.                      |
| Max time run history saved  | Displays the maximum amount of time to keep the results from a script run.                 |
| Last change                 | Displays the system time a change was made to the configuration.                           |

**Sample Output**

```
*A:Redundancy# show cron action run-history terminated
=====
CRON Action Run History
=====
Action "test"
Owner "TiMOS CLI"
-----
Script Run #17
-----
Start time      : 2006/11/06 20:30:09      End time       : 2006/11/06 20:35:24
Elapsed time    : 0d 00:05:15             Lifetime      : 0d 00:00:00
State           : terminated              Run exit code : noError
```

## System Commands

```
Result time   : 2006/11/06 20:35:24      Keep history  : 0d 00:49:57
Error time    : never
Results file  : ftp://*:*@192.168.15.18/home/testlab_bgp/cron/_20061106-203008.
              out
Run exit      : Success
```

-----  
Script Run #18  
-----

```
Start time    : 2006/11/06 20:35:24      End time      : 2006/11/06 20:40:40
Elapsed time  : 0d 00:05:16              Lifetime     : 0d 00:00:00
State        : terminated                 Run exit code : noError
Result time   : 2006/11/06 20:40:40      Keep history  : 0d 00:55:13
Error time    : never
Results file  : ftp://*:*@192.168.15.18/home/testlab_bgp/cron/_20061106-203523.
              out
Run exit      : Success
```

-----  
\*A:Redundancy#

\*A:Redundancy# show cron action run-history executing

=====

```
CRON Action Run History
```

```
Action "test"
Owner "TiMOS CLI"
```

-----  
Script Run #20  
-----

```
Start time    : 2006/11/06 20:46:00      End time      : never
Elapsed time  : 0d 00:00:56              Lifetime     : 0d 00:59:04
State        : executing                  Run exit code : noError
Result time   : never                     Keep history  : 0d 01:00:00
Error time    : never
Results file  : ftp://*:*@192.168.15.18/home/testlab_bgp/cron/_20061106-204559.
              out
```

=====

```
*A:Redundancy#
```

\*A:Redundancy# show cron action run-history initializing

=====

```
CRON Action Run History
```

```
Action "test"
Owner "TiMOS CLI"
```

-----  
Script Run #21  
-----

```
Start time    : never                     End time      : never
Elapsed time  : 0d 00:00:00              Lifetime     : 0d 01:00:00
State        : initializing               Run exit code : noError
Result time   : never                     Keep history  : 0d 01:00:00
Error time    : never
Results file  : none
```

-----  
Script Run #22  
-----

```
Start time    : never                     End time      : never
```

```

Elapsed time : 0d 00:00:00           Lifetime      : 0d 01:00:00
State        : initializing          Run exit code : noError
Result time  : never                 Keep history  : 0d 01:00:00
Error time   : never
Results file : none
-----
Script Run #23
-----
Start time   : never                 End time      : never
Elapsed time : 0d 00:00:00           Lifetime      : 0d 01:00:00
State        : initializing          Run exit code : noError
Result time  : never                 Keep history  : 0d 01:00:00
Error time   : never
Results file : none
=====
*A:Redundancy#

```

## schedule

**Syntax** `schedule [schedule-name] [owner schedule-owner]`

**Context** `show>cron#`

**Description** This command displays cron schedule parameters.

**Parameters** *schedule-name* — Displays information for the specified scheduler name.  
*owner schedule-owner* — Displays information for the specified scheduler owner.

**Output** The following table describes the show cron schedule output fields.

| Label                 | Description                                                                              |
|-----------------------|------------------------------------------------------------------------------------------|
| Schedule name         | Displays the schedule name.                                                              |
| Schedule owner        | Displays the owner name of the action.                                                   |
| Description           | Displays the schedule's description.                                                     |
| Administrative status | Enabled — The administrative status is enabled.<br>Disabled — Administratively disabled. |
| Operational status    | Enabled — The operational status is enabled.<br>Disabled — Operationally disabled.       |
| Action                | Displays the action name                                                                 |
| Action owner          | Displays the name of action owner.                                                       |
| Script                | Displays the name of the script.                                                         |

## System Commands

| Label                        | Description (Continued)                                                                                                                                                                  |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Script owner                 | Displays the name of the script.                                                                                                                                                         |
| Script owner                 | Displays the name of the of script owner.                                                                                                                                                |
| Script source location       | Displays the location of scheduled script.                                                                                                                                               |
| Script results location      | Displays the location where the script results have been sent.                                                                                                                           |
| Schedule type                | Periodic – Displays a schedule which ran at a given interval.<br>Calendar – Displays a schedule which ran based on a calendar.<br>Oneshot – Displays a schedule which ran one time only. |
| Interval                     | Displays the interval between runs of an event.                                                                                                                                          |
| Next scheduled run           | Displays the time for the next scheduled run.                                                                                                                                            |
| Weekday                      | Displays the configured weekday.                                                                                                                                                         |
| Month                        | Displays the configured month.                                                                                                                                                           |
| Day of Month                 | Displays the configured day of month.                                                                                                                                                    |
| Hour                         | Displays the configured hour.                                                                                                                                                            |
| Minute                       | Displays the configured minute.                                                                                                                                                          |
| Number of scheduled runs     | Displays the number of scheduled sessions.                                                                                                                                               |
| Last scheduled run           | Displays the last scheduled session.                                                                                                                                                     |
| Number of scheduled failures | Displays the number of scheduled sessions that failed to execute.                                                                                                                        |
| Last scheduled failure       | Displays the last scheduled session that failed to execute.                                                                                                                              |
| Last failure time            | Displays the system time of the last failure.                                                                                                                                            |

```
A:sim1>show>cron schedule test
=====
CRON Schedule Information
=====
Schedule                : test
Schedule owner          : TiMOS CLI
Description              : none
Administrative status    : enabled
Operational status      : enabled
Action                  : test
Action owner            : TiMOS CLI
Script                  : test
Script Owner            : TiMOS CLI
Script source location   : ftp://*****:*****@192.168.15.1/home/testlab_bgp
                        /cron/test1.cfg
```

```

Script results location      : ftp://*****.*****@192.168.15.1/home/testlab_bgp
                             /cron/res
Schedule type               : periodic
Interval                   : 0d 00:01:00 (60 seconds)
Next scheduled run         : 0d 00:00:42
Weekday                    : tuesday
Month                      : none
Day of month               : none
Hour                      : none
Minute                    : none
Number of schedule runs    : 10
Last schedule run         : 2008/01/01 17:20:52
Number of schedule failures : 0
Last schedule failure     : no error
Last failure time         : never
=====
A:sim1>show>cron

```

## information

**Syntax** information

**Context** show>system

**Description** This command displays general system information including basic system, SNMP server, last boot and DNS client information.

**Output** **System Information Output** — The following table describes the system information output fields.

| Label                 | Description                                                                                                              |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------|
| System Name           | The configured system name.                                                                                              |
| System Contact        | A text string that describes the system contact information.                                                             |
| System Location       | A text string that describes the system location.                                                                        |
| System Coordinates    | A text string that describes the system coordinates.                                                                     |
| System Up Time        | The time since the last boot.                                                                                            |
| SNMP Port             | The port number used by this node to receive SNMP request messages and to send replies.                                  |
| SNMP Engine ID        | The SNMP engineID to uniquely identify the SNMPv3 node.                                                                  |
| SNMP Max Message Size | The maximum SNMP packet size generated by this node.                                                                     |
| SNMP Admin State      | Enabled — SNMP is administratively enabled and running.<br>Disabled — SNMP is administratively shutdown and not running. |
| SNMP Oper State       | Enabled — SNMP is operationally enabled.<br>Disabled — SNMP is operationally disabled.                                   |

## System Commands

| Label                   | Description (Continued)                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SNMP Index Boot Status  | <p><i>Persistent</i> – System indexes are saved between reboots.</p> <p><i>Not Persistent</i> – System indexes are not saved between reboots.</p>                                                                                                                                                                                                                                |
| Telnet/SSH/FTP Admin    | Displays the administrative state of the Telnet, SSH, and FTP sessions.                                                                                                                                                                                                                                                                                                          |
| Telnet/SSH/FTP Oper     | Displays the operational state of the Telnet, SSH, and FTP sessions.                                                                                                                                                                                                                                                                                                             |
| BOF Source              | The location of the BOF.                                                                                                                                                                                                                                                                                                                                                         |
| Image Source            | <p><i>Primary</i> – Indicates that the directory location for runtime image file was loaded from the primary source.</p> <p><i>Secondary</i> – Indicates that the directory location for runtime image file was loaded from the secondary source.</p> <p><i>Tertiary</i> – Indicates that the directory location for runtime image file was loaded from the tertiary source.</p> |
| Config Source           | <p><i>Primary</i> – Indicates that the directory location for configuration file was loaded from the primary source.</p> <p><i>Secondary</i> – Indicates that the directory location for configuration file was loaded from the secondary source.</p> <p><i>Tertiary</i> – Indicates that the directory location for configuration file was loaded from the tertiary source.</p> |
| DNS Resolve Preference  | <p><i>ipv4-only</i> – Dns-names are queried for A-records only.</p> <p><i>ipv6-first</i> – Dns-server will be queried for AAAA-records first and a successful reply is not received, the dns-server is queried for A-records.</p>                                                                                                                                                |
| Last Booted Config File | The URL and filename of the last loaded configuration file.                                                                                                                                                                                                                                                                                                                      |
| Last Boot Cfg Version   | The date and time of the last boot.                                                                                                                                                                                                                                                                                                                                              |
| Last Boot Config Header | Displays header information such as image version, date built, date generated.                                                                                                                                                                                                                                                                                                   |
| Last Boot Index Version | The version of the persistence index file read when this card was last rebooted.                                                                                                                                                                                                                                                                                                 |
| Last Boot Index Header  | The header of the persistence index file read when this card was last rebooted.                                                                                                                                                                                                                                                                                                  |
| Last Saved Config       | The location and filename of the last saved configuration file.                                                                                                                                                                                                                                                                                                                  |
| Time Last Saved         | The date and time of the last time configuration file was saved.                                                                                                                                                                                                                                                                                                                 |
| Changes Since Last Save | <p><i>Yes</i> – There are unsaved configuration file changes.</p> <p><i>No</i> – There are no unsaved configuration file changes.</p>                                                                                                                                                                                                                                            |
| Time Last Modified      | The date and time of the last modification.                                                                                                                                                                                                                                                                                                                                      |

| Label                  | Description (Continued)                                                                                                                                                                                                                   |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Max Cfg/BOF Backup Rev | The maximum number of backup revisions maintained for a configuration file. This value also applies to the number of revisions maintained for the BOF file.                                                                               |
| Cfg-OK Script          | URL — The location and name of the CLI script file executed following successful completion of the boot-up configuration file execution.                                                                                                  |
| Cfg-OK Script Status   | Successful/Failed — The results from the execution of the CLI script file specified in the Cfg-OK Script location.<br>Not used — No CLI script file was executed.                                                                         |
| Cfg-Fail Script        | URL — The location and name of the CLI script file executed following a failed boot-up configuration file execution.<br>Not used — No CLI script file was executed.                                                                       |
| Cfg-Fail Script Status | Successful/Failed — The results from the execution of the CLI script file specified in the Cfg-Fail Script location.<br>Not used — No CLI script file was executed.                                                                       |
| Management IP Addr     | The management IP address and mask.                                                                                                                                                                                                       |
| DNS Server             | The IP address of the DNS server.                                                                                                                                                                                                         |
| DNS Domain             | The DNS domain name of the node.                                                                                                                                                                                                          |
| BOF Static Routes      | To — The static route destination.<br><br>Next Hop — The next hop IP address used to reach the destination.<br>Metric — Displays the priority of this static route versus other static routes.<br>None — No static routes are configured. |

### Sample Output

```
A:Dut-F>show system information
...
Primary DNS Server      : 138.120.252.56
Secondary DNS Server   : 138.120.252.48
Tertiary DNS Server    : 138.120.252.49
DNS Domain             : labs.ca.alcatel-lucent.com
DNS Resolve Preference : ipv4-only
DNSSEC                 AD Validated      : False
DNSSEC Response Control: drop
BOF Static Routes      :
```

```
A:Dut-F# show system information
=====
System Information
=====
System Name           : Dut-F
System Type           : 7750 SR-7 7450 ESS-7
```

## System Commands

```
System Version      : B-6.0.B1-6
System Contact      :
System Location     :
System Coordinates  :
System Active Slot  : A
System Up Time      : 0 days, 03:42:01.29 (hr:min:sec)

SNMP Port           : 161
SNMP Engine ID      : 0000197f00008c6cff000000
SNMP Max Message Size : 1500
SNMP Admin State    : Enabled
SNMP Oper State     : Enabled
SNMP Index Boot Status : Not Persistent
SNMP Sync State     : OK

Tel/Tel6/SSH/FTP Admin : Enabled/Disabled/Enabled/Enabled
Tel/Tel6/SSH/FTP Oper  : Up/Down/Up/Up

BOF Source          : ftp://test:test@xxx.xxx.xx.xxx/./images
Image Source        : primary
Config Source       : primary
Last Booted Config File: ftp://*: *@xxx.xxx.xx.xxx/./images/dut-f.cfg
Last Boot Cfg Version : N/A
Last Boot Index Version: N/A
Last Saved Config   : N/A
Time Last Saved     : N/A
Changes Since Last Save: No
Max Cfg/BOF Backup Rev : 5
Cfg-OK Script       : ftp://*: @[3000::8acb:466d]/./images/env.cfg
Cfg-OK Script Status : failed
Cfg-Fail Script     : N/A
Cfg-Fail Script Status : not used
Management IP Addr  : xxx.xxx.xx.xxx/23
Primary DNS Server  : xxx.xxx.xx.xxx
Secondary DNS Server : xxx.xxx.xx.xxx
Tertiary DNS Server : N/A
DNS Domain          : sh.bel.alcatel.be
DNS Resolve Preference : ipv4-only
BOF Static Routes   :
  To                Next Hop
  138.203.0.0/16    xxx.xxx.xx.xxx
  172.0.0.0/8       xxx.xxx.xx.xxx
ICMP Vendor Enhancement: Disabled
=====
A:Dut-F#
```

## Ildp

**Syntax** **ildp neighbor**

**Context** show>system

**Description** This command displays neighbor information for all configured ports without having to specify each individual port ID.

**Parameters** **neighbor** — Displays LLDP neighbor information.

**Sample Output**

```
*A:Dut-C# show system lldp neighbor
Link Layer Discovery Protocol (LLDP) System Information
=====
NB = nearest-bridge   NTMPR = nearest-non-tpmr   NC = nearest-customer
=====
Port      Scope  Chassis ID          Index  Port ID  System Name
-----
1/1/1     NB     16:2f:ff:00:00:00   1      35717120  Dut-A
2/1/2     NB     16:34:ff:00:00:00   1      35782656  Dut-D
2/1/1     NB     16:36:ff:00:00:00   2      35684352  Dut-E
1/1/2     NB     16:30:ff:00:00:00   2      35749888  Dut-B
1/1/3     NB     16:30:ff:00:00:00   3      35782656  Dut-B
2/1/3     NB     16:30:ff:00:00:00   3      35815424  Dut-B
=====
Number of neighbors : 6
*A:Dut-C#
```

```
A:GHR-API# show system lldp neighbor
Link Layer Discovery Protocol (LLDP) System Information
=====
NB = nearest-bridge   NTMPR = nearest-non-tpmr   NC = nearest-customer
=====
Port      Scope  Chassis ID          Index  Port ID  System Name
-----
1/1/6     NTPMR  00:21:05:1b:bc:17   1      36044800  RXI-AMI
1/1/8     NTPMR  00:21:06:6d:bd:53   2      36110336  YOY-WOW
1/1/9     NTPMR  00:21:08:2b:ab:81   3      36143104  FRI-MON
=====
Number of neighbors : 3
```

**load-balancing-alg****Syntax** **load-balancing-alg [detail]****Context** show>system**Description** This command displays system load balancing settings.**Parameters** **detail** — Displays port settings.**Sample Output**

```
*A:ALA-49>show>system# load-balancing-alg
=====
System-wide Load Balancing Algorithms
=====
L4 - Load Balance          : exclude-L4
LSR - Load Balance         : lbl-only
=====
*A:ALA-49>show>system#
```

memory-pools

**Syntax**    **memory-pools**

**Context**    show>system

**Description**    This command displays system memory status.

**Output**        **Memory Pools Output** — The following table describes memory pool output fields.

| Label              | Description                                                               |
|--------------------|---------------------------------------------------------------------------|
| Name               | The name of the system or process.                                        |
| Max Allowed        | Integer — The maximum allocated memory size.<br>No Limit — No size limit. |
| Current Size       | The current size of the memory pool.                                      |
| Max So Far         | The largest amount of memory pool used.                                   |
| In Use             | The current amount of the memory pool currently in use.                   |
| Current Total Size | The sum of the Current Size column.                                       |
| Total In Use       | The sum of the In Use column.                                             |
| Available Memory   | The amount of available memory.                                           |

**Sample Output**

```
A:ALA-1# show system memory-pools
=====
Memory Pools
=====
Name                Max Allowed      Current Size      Max So Far        In Use
-----
System              No limit         24,117,248       24,117,248       16,974,832
Icc                  8,388,608        1,048,576        1,048,576         85,200
RTM/Policies        No limit         5,242,912        5,242,912        3,944,104
OSPF                 No limit         3,145,728        3,145,728        2,617,384
MPLS/RSVP           No limit         9,769,480        9,769,480        8,173,760
LDP                  No limit         0                 0                 0
IS-IS                No limit         0                 0                 0
RIP                  No limit         0                 0                 0
VRRP                 No limit         1,048,576        1,048,576         96
BGP                  No limit         2,097,152        2,097,152        1,624,800
BGP                  No limit         2,097,152        2,097,152        1,624,800
Services             No limit         2,097,152        2,097,152        1,589,824
IOM                  No limit         205,226,800     205,226,800     202,962,744
SIM                  No limit         1,048,576        1,048,576         392
CFLOWD               No limit         0                 1,048,576         0
CFLOWD               No limit         0                 1,048,576         0
IGMP                 No limit         0                 0                 0
```

```

PIM                No limit                0                0                0
PIM                No limit                0                0                0
MMPI               No limit                0                0                0
MFIB               No limit                0                0                0
PIP                No limit                79,943,024       79,943,024       78,895,248
Mbuf               67,108,864          5,837,328        5,837,328        4,834,280
-----
Current Total Size :   343,495,200 bytes
Total In Use       :   324,492,768 bytes
Available Memory   :   640,178,652 bytes
=====
A:ALA-1#

```

## ntp

**Syntax** ntp

**Context** show>system

**Description** This command displays NTP protocol configuration and state.

**Output** **Show NTP Output** — The following table describes NTP output fields.

| Label                | Description                                                                        |
|----------------------|------------------------------------------------------------------------------------|
| Enabled              | yes — NTP is enabled.<br>no — NTP is disabled.                                     |
| Admin Status         | yes — Administrative state is enabled.<br>no — Administrative state is disabled.   |
| NTP Server           | Displays NTP server state of this node.                                            |
| Stratum              | Displays stratum level of this node.                                               |
| Oper Status          | yes — The operational state is enabled.<br>no — The operational state is disabled. |
| Auth Check           | Displays the authentication requirement                                            |
| System Ref. ID       | IP address of this node or a 4-character ASCII code showing the state.             |
| Auth Error           | Displays the number of authentication errors.                                      |
| Auth Errors Ignored  | Displays the number of authentication errors ignored.                              |
| Auth key ID Errors   | Displays the number of key identification errors.                                  |
| Auth Key Type Errors | Displays the number of authentication key type errors.                             |

| Label        | Description (Continued)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Reject       | The peer is rejected and will not be used for synchronization. Rejection reasons could be the peer is unreachable, the peer is synchronized to this local server so synchronizing with it would create a sync loop, or the synchronization distance is too large. This is the normal startup state.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Invalid      | The peer is not maintaining an accurate clock. This peer will not be used for synchronization.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Excess       | The peer's synchronization distance is greater than ten other peers. This peer will not be used for synchronization.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Outlyer      | The peer is discarded as an outlyer. This peer will not be used for synchronization.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Candidate    | The peer is accepted as a possible source of synchronization.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Selected     | The peer is an acceptable source of synchronization, but its synchronization distance is greater than six other peers.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Chosen       | The peer is chosen as the source of synchronization.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| ChosenPPS    | The peer is chosen as the source of synchronization, but the actual synchronization is occurring from a pulse-per-second (PPS) signal.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Remote       | The IP address of the remote NTP server or peer with which this local host is exchanging NTP packets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Reference ID | <p>When stratum is between 0 and 15 this field shows the IP address of the remote NTP server or peer with which the remote is exchanging NTP packets. For reference clocks, this field shows the identification assigned to the clock, such as, ".GPS." For an NTP server or peer, if the client has not yet synchronized to a server/peer, the status cannot be determined and displays the following codes:</p> <p>Peer Codes:</p> <p>ACST — The association belongs to any cast server.</p> <p>AUTH — Server authentication failed. Please wait while the association is restarted.</p> <p>AUTO — Autokey sequence failed. Please wait while the association is restarted.</p> <p>BCST — The association belongs to a broadcast server.</p> <p>CRPT — Cryptographic authentication or identification failed. The details should be in the system log file or the cryptostats statistics file, if configured. No further messages will be sent to the server.</p> <p>DENY — Access denied by remote server. No further messages will be sent to the server.</p> |

| Label  | Description (Continued)                                                                                                                                                 |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | DROP — Lost peer in symmetric mode. Please wait while the association is restarted.                                                                                     |
|        | RSTR — Access denied due to local policy. No further messages will be sent to the server.                                                                               |
|        | INIT — The association has not yet synchronized for the first time.                                                                                                     |
|        | MCST — The association belongs to a manycast server.                                                                                                                    |
|        | NKEY — No key found. Either the key was never installed or is not trusted.                                                                                              |
|        | RATE — Rate exceeded. The server has temporarily denied access because the client exceeded the rate threshold.                                                          |
|        | RMOT — The association from a remote host running ntpdc has had unauthorized attempted access.                                                                          |
|        | STEP — A step change in system time has occurred, but the association has not yet resynchronized.                                                                       |
|        | System Codes                                                                                                                                                            |
|        | INIT — The system clock has not yet synchronized for the first time.                                                                                                    |
|        | STEP — A step change in system time has occurred, but the system clock has not yet resynchronized.                                                                      |
| St     | Stratum level of this node.                                                                                                                                             |
| Auth   | yes — Authentication is enabled.<br>no — Authentication is disabled.                                                                                                    |
| Poll   | Polling interval in seconds.                                                                                                                                            |
| R      | Yes — The NTP peer or server has been reached at least once in the last 8 polls.<br>No — The NTP peer or server has not been reached at least once in the last 8 polls. |
| Offset | The time between the local and remote UTC time, in milliseconds.                                                                                                        |

### Sample Output

```
*A:Dut-A# show system ntp
=====
NTP Status
=====
Configured           : Yes           Stratum             : 4
Admin Status        : up           Oper Status         : up
Server Enabled      : No           Server Authenticate : No
Clock Source        : 1111:2222:3333:4444:5555:10:100:2
Auth Check          : Yes
Current Date & Time: 2015/07/10 12:46:30 UTC
=====

*A:Dut-A# show system ntp all
=====
NTP Status
```

## System Commands

```
=====  
Configured      : Yes           Stratum           : 4  
Admin Status    : up           Oper Status       : up  
Server Enabled  : No           Server Authenticate : No  
Clock Source    : 1111:2222:3333:4444:5555:10:100:2  
Auth Check      : Yes  
Current Date & Time: 2015/07/10 12:46:32 UTC  
=====  
NTP Active Associations  
=====  
State           Reference ID   St Type  A  Poll Reach  Offset(ms)  
Remote  
-----  
candidate       252.242.213.211 3  srvr  -  64  YYYYYYYY  -5.829  
  10.10.1.2  
candidate       252.242.213.211 3  srvr  -  64  YYYYYYYY  -6.889  
  10.10.100.2  
chosen          252.242.213.211 3  srvr  -  64  ...YYYYY  -6.804  
  1111:2222:3333:4444:5555:10:100:2  
=====  
NTP Clients  
=====  
vRouter                Time Last Request Rx  
Address  
-----  
=====  
*A:Dut-A# show system ntp detail  
=====  
NTP Status  
=====  
Configured      : Yes           Stratum           : 4  
Admin Status    : up           Oper Status       : up  
Server Enabled  : No           Server Authenticate : No  
Clock Source    : 1111:2222:3333:4444:5555:10:100:2  
Auth Check      : Yes  
Auth Errors     : 0           Auth Errors Ignored : 0  
Auth Key Id Errors : 0           Auth Key Type Errors : 0  
Current Date & Time: 2015/07/10 12:46:34 UTC  
=====  
NTP Configured Broadcast/Multicast Interfaces  
=====  
vRouter          Interface      Address           Type  Auth  Poll  
-----  
=====  
*A:Dut-A# show system ntp detail all  
=====  
NTP Status  
=====  
Configured      : Yes           Stratum           : 4  
Admin Status    : up           Oper Status       : up  
Server Enabled  : No           Server Authenticate : No  
Clock Source    : 1111:2222:3333:4444:5555:10:100:2  
Auth Check      : Yes  
Auth Errors     : 0           Auth Errors Ignored : 0
```

```

Auth Key Id Errors : 0                      Auth Key Type Errors : 0
Current Date & Time: 2015/07/10 12:46:36 UTC
=====
NTP Configured Broadcast/Multicast Interfaces
=====
vRouter      Interface      Address          Type   Auth   Poll
-----
=====
NTP Active Associations
=====
State          Remote          Reference ID     St Type  A  Poll Reach   Offset(ms)
-----
candidate      10.10.1.2      252.242.213.211 3  srvr - 64  YYYYYYYY -5.829
candidate      10.10.100.2    252.242.213.211 3  srvr - 64  YYYYYYYY -6.889
chosen         1111:2222:3333:4444:5555:10:100:2 252.242.213.211 3  srvr - 64  ...YYYYY -6.804
=====
NTP Clients
=====
vRouter      Address          Time Last Request Rx
-----
=====
*A:Dut-A#

```

## rollback

**Syntax** rollback

**Context** show>system

**Description** This command displays rollback configuration and state.

### Sample Output

```

A:dut-a_a_a# show system rollback
=====
Rollback Information
=====
Rollback Location      : cf1:/Rollback
Save
  Last Rollback Save Result : In Progress, Successful or Failed
  Last Save Completion Time : 10/15/2010 21:24:06
Revert
  In Progress           : Yes, No
  Last Revert Initiated Time : 10/15/2010 21:26:23
  Last Revert Initiated User : xyz
  Last Initiated Checkpoint : cf1:/Rollback.rb.3
  Last Completed Revert Result : Successful or Failed

```

## System Commands

```

Last Revert Completion Time : 10/15/2010 21:27:19
=====
Rollback Files
=====
Idx      Suffix  Creation time      Release  User
      Comment
-----
latest  .rb      2010/10/15 21:24:02  9.0.R4   fred
        This checkpoint was saved after the 3 VPLS services were created
1       .rb.1    2010/10/15 21:23:58  9.0.R4   John
        John's checkpoint on Sunday
2       .rb.2    2010/10/15 21:23:52  9.0.R4   admin
        A long checkpoint comment that an operator is using to summarize
        various some of the changes that were made.  They may even have so
        much to say that they use the maximum comment size.  Notice that
        words are not chopped.
...
9       .rb.9    2010/10/14 22:00:01  9.0.R4   admin
        VPLS services 1000-2000 created
...
53      .rb.53   2010/10/14 22:10:10  9.0.R4   admin
-----
No. of Rollback Files: 10
=====

```

## sntp

**Syntax** sntp

**Context** show>system

**Description** This command displays SNTP protocol configuration and state.

**Output** **Show SNTP Output** — The following table describes SNTP output fields.

| Label       | Description                                                                                                                                                                                 |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SNTP Server | The SNTP server address for SNTP unicast client mode.                                                                                                                                       |
| Version     | The SNTP version number, expressed as an integer.                                                                                                                                           |
| Preference  | Normal — When more than one time server is configured, one server can be configured to have preference over another.<br>Preferred — Indicates that this server has preference over another. |
| Interval    | The frequency, in seconds, that the server is queried.                                                                                                                                      |

### Sample Output

```
A:ALA-1# show system sntp
```

```

SNTP
=====
SNTP Server          Version          Preference       Interval
-----
10.10.20.253        3                Preferred        64
=====
A:ALA-1#

```

## thresholds

**Syntax** thresholds

**Context** show>system

**Description** This command display system monitoring thresholds. The “Threshold Events Log” table will keep only the last 201 entries.

**Output** **Thresholds Output** — following table describes system threshold output fields.

| Label            | Description                                                                                                                    |
|------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Variable         | Displays the variable OID.                                                                                                     |
| Alarm Id         | Displays the numerical identifier for the alarm.                                                                               |
| Last Value       | Displays the last threshold value.                                                                                             |
| Rising Event Id  | Displays the identifier of the RMON rising event.                                                                              |
| Threshold        | Displays the identifier of the RMON rising threshold.                                                                          |
| Falling Event Id | Displays the identifier of the RMON falling event.                                                                             |
| Threshold        | Displays the identifier of the RMON falling threshold.                                                                         |
| Sample Interval  | Displays the polling interval, in seconds, over which the data is sampled and compared with the rising and falling thresholds. |
| Sample Type      | Displays the method of sampling the selected variable and calculating the value to be compared against the thresholds.         |
| Startup Alarm    | Displays the alarm that may be sent when this alarm is first created.                                                          |
| Owner            | Displays the owner of this alarm.                                                                                              |
| Description      | Displays the event cause.                                                                                                      |
| Event Id         | Displays the identifier of the threshold event.                                                                                |
| Last Sent        | Displays the date and time the alarm was sent.                                                                                 |

| Label       | Description (Continued)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Action Type | <p>log — An entry is made in the RMON-MIB log table for each event occurrence. This does not create a TiMOS logger entry. The RMON-MIB log table entries can be viewed using the <b>show&gt;system&gt;thresholds</b> CLI command.</p> <p>trap — A TiMOS logger event is generated. The TiMOS logger utility then distributes the notification of this event to its configured log destinations which may be CONSOLE, telnet session, memory log, cflash file, syslog, or SNMP trap destinations logs.</p> <p>both — Both a entry in the RMON-MIB logTable and a TiMOS logger event are generated.</p> <p>none — No action is taken</p> |
| Owner       | Displays the owner of the event.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

**Sample Output**

```
A:ALA-48# show system thresholds
=====
Threshold Alarms
=====
Variable: tmnxCpmFlashUsed.1.11.1
Alarm Id      : 1      Last Value : 835
Rising Event Id : 1      Threshold  : 5000
Falling Event Id : 2      Threshold  : 2500
Sample Interval : 2147483* SampleType : absolute
Startup Alarm  : either Owner      : TiMOS CLI
Variable: tmnxCpmFlashUsed.1.11.1
Alarm Id      : 2      Last Value : 835
Rising Event Id : 3      Threshold  : 10000
Falling Event Id : 4      Threshold  : 5000
Sample Interval : 2147483* SampleType : absolute
Startup Alarm  : rising Owner      : TiMOS CLI
Variable: sgiMemoryUsed.0
Alarm Id      : 3      Last Value : 42841056
Rising Event Id : 5      Threshold  : 4000
Falling Event Id : 6      Threshold  : 2000
Sample Interval : 2147836 SampleType : absolute
Startup Alarm  : either Owner      : TiMOS CLI
=====
* indicates that the corresponding row element may have been truncated.
=====
Threshold Events
=====
Description: TiMOS CLI - cflash capacity alarm rising event
Event Id      : 1      Last Sent  : 10/31/2006 08:47:59
Action Type   : both   Owner      : TiMOS CLI
Description: TiMOS CLI - cflash capacity alarm falling event
Event Id      : 2      Last Sent  : 10/31/2006 08:48:00
Action Type   : both   Owner      : TiMOS CLI
Description: TiMOS CLI - cflash capacity warning rising event
Event Id      : 3      Last Sent  : 10/31/2006 08:47:59
Action Type   : both   Owner      : TiMOS CLI
Description: TiMOS CLI - cflash capacity warning falling event
Event Id      : 4      Last Sent  : 10/31/2006 08:47:59
```

```

Action Type      : both      Owner       : TiMOS CLI
Description: TiMOS CLI - memory usage alarm rising event
Event Id        : 5          Last Sent   : 10/31/2006 08:48:00
Action Type      : both      Owner       : TiMOS CLI
Description: TiMOS CLI - memory usage alarm falling event
Event Id        : 6          Last Sent   : 10/31/2006 08:47:59
Action Type      : both      Owner       : TiMOS CLI
=====
Threshold Events Log
=====
Description      : TiMOS CLI - cflash capacity alarm falling event : value=835, <=2500 : alarm-index 1, event
                  -index 2 alarm-variable OID tmnxCpmFlashUsed.
                  1.11.1
Event Id         : 2          Time Sent    : 10/31/2006 08:48:00
Description      : TiMOS CLI - memory usage alarm rising event :
                  value=42841056, >=4000 : alarm-index 3, even
                  t-index 5 alarm-variable OID sgiMemoryUsed.0
Event Id         : 5          Time Sent    : 10/31/2006 08:48:00
=====
A:ALA-48#

```

## time

**Syntax** time

**Context** show>system

**Description** This command displays the system time and zone configuration parameters.

**Output** **System Time Output** — The following table describes system time output fields.

| Label             | Description                                                                                                    |
|-------------------|----------------------------------------------------------------------------------------------------------------|
| Date & Time       | The system date and time using the current time zone.                                                          |
| DST Active        | Yes — Daylight Savings Time is currently in effect.<br>No — Daylight Savings Time is not currently in effect.  |
| Zone              | The zone names for the current zone, the non-DST zone, and the DST zone if configured.                         |
| Current Time Zone | Indicates the process currently controlling the system time. SNTP, NTP or NONE.                                |
| Zone type         | Non-standard — The zone is user-defined.<br>Standard — The zone is system defined.                             |
| Offset from UTC   | The number of hours and minutes added to universal time for the zone, including the DST offset for a DST zone. |

## System Commands

| Label               | Description (Continued)                                                                                                                                      |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Offset from Non-DST | The number of hours (always 0) and minutes (0—60) added to the time at the beginning of Daylight Saving Time and subtracted at the end Daylight Saving Time. |
| Starts              | The date and time Daylight Saving Time begins.                                                                                                               |
| Ends                | The date and time Daylight Saving Time ends.                                                                                                                 |

### Sample Output

```
A:ALA-1# show system time
=====
Date & Time
=====
Current Date & Time : 2006/05/05 23:03:13   DST Active       : yes
Current Zone       : PDT                   Offset from UTC  : -7:00
-----
Non-DST Zone      : PST                   Offset from UTC  : -8:00
Zone type         : standard
-----
DST Zone          : PDT                   Offset from Non-DST : 0:60
Starts           : first sunday in april 02:00
Ends             : last sunday in october 02:00
=====
A:ALA-1#

A:ALA-1# show system time (with no DST zone configured)
=====
Date & Time
=====
Current Date & Time : 2006/05/12 11:12:05   DST Active       : no
Current Zone       : APA                   Offset from UTC  : -8:00
-----
Non-DST Zone      : APA                   Offset from UTC  : -8:00
Zone Type         : non-standard
-----
No DST zone configured
=====
A:ALA-1#
```

## time

**Syntax** time

**Context** show

**Description** This command displays the current day, date, time and time zone.

The time is displayed either in the local time zone or in UTC depending on the setting of the root level **time-display** command for the console session.

**Output Sample Output**

```
A:ALA-49# show time
Tue Oct 31 12:17:15 GMT 2006
```

**tod-suite**

**Syntax** **tod-suite [detail]**  
**tod-suite associations**  
**tod-suite failed-associations**

**Context** show>cron

**Description** This command displays information on the configured time-of-day suite.

**Output** **CRON TOD Suite Output** — The following table describes TOD suite output fields:

| Label               | Description                                                                                 |
|---------------------|---------------------------------------------------------------------------------------------|
| Associations        | Shows which SAPs this tod-suite is associated with.                                         |
| failed-associations | Shows the SAPs or Multiservice sites where the TOD Suite could not be applied successfully. |
| Detail              | Shows the details of this tod-suite.                                                        |

**Sample Output**

```
A:kerckhot_4# show cron tod-suite suite_sixteen detail
=====
Cron tod-suite details
=====
Name      : suite_sixteen
Type / Id      Time-range      Prio  State
-----
Ingress Qos Policy
  1160          day              5     Inact
  1190          night            6     Activ
Ingress Scheduler Policy
  SchedPolCust1_Day      day              5     Inact
  SchedPolCust1_Night   night            6     Activ
Egress Qos Policy
  1160          day              5     Inact
  1190          night            6     Activ
Egress Scheduler Policy
  SchedPolCust1Egress_Day  day              5     Inact
=====
A:kerckhot_4#
```

## System Commands

The following example shows output for TOD suite associations.

```
A:kerckhot_4# show cron tod-suite suite_sixteen associations
=====
Cron tod-suite associations for suite suite_sixteen
=====
Service associations
-----
Service Id   : 1                               Type    : VPLS
SAP 1/1/1:1
SAP 1/1/1:2
SAP 1/1/1:3
SAP 1/1/1:4
SAP 1/1/1:5
SAP 1/1/1:6
SAP 1/1/1:20
-----
Number of SAP's : 7
Customer Multi-Service Site associations
-----
Multi Service Site: mss_1_1
-----
Number of MSS's: 1
=====
A:kerckhot_4#
```

The following example shows output for TOD suite failed-associations.

```
A:kerckhot_4# show cron tod-suite suite_sixteen failed-associations
=====
Cron tod-suite associations failed
=====
tod-suite suite_sixteen : failed association for SAP
-----
Service Id   : 1                               Type    : VPLS
SAP 1/1/1:2
SAP 1/1/1:3
SAP 1/1/1:4
SAP 1/1/1:5
SAP 1/1/1:6
SAP 1/1/1:20
-----
tod-suite suite_sixteen : failed association for Customer MSS
-----
None
-----
Number of tod-suites failed/total : 1/1
=====
A:kerckhot_4#
```

Zooming in on one of the failed SAPs, the assignments of QoS and scheduler policies are shown as not as intended:

```
A:kerckhot_4# show service id 1 sap 1/1/1:2
=====
Service Access Points(SAP)
=====
Service Id           : 1
```

## Show Commands

```

SAP : 1/1/1:2 Encap : q-tag
Dot1Q Ethertype : 0x8100 QinQ Ethertype : 0x8100
Admin State : Up Oper State : Up
Flags : None
Last Status Change : 10/05/2006 18:11:34
Last Mgmt Change : 10/05/2006 22:27:48
Max Nbr of MAC Addr: No Limit Total MAC Addr : 0
Learned MAC Addr : 0 Static MAC Addr : 0
Admin MTU : 1518 Oper MTU : 1518
Ingress qos-policy : 1130 Egress qos-policy : 1130
Intend Ing qos-pol* : 1190 Intend Egr qos-po* : 1190
Shared Q plcy : n/a Multipoint shared : Disabled
Ingr IP Fltr-Id : n/a Egr IP Fltr-Id : n/a
Ingr Mac Fltr-Id : n/a Egr Mac Fltr-Id : n/a
Ingr IPv6 Fltr-Id : n/a Egr IPv6 Fltr-Id : n/a
tod-suite : suite_sixteen qinq-pbit-marking : both
Egr Agg Rate Limit : max
ARP Reply Agent : Unknown Host Conn Verify : Disabled
Mac Learning : Enabled Discard Unkwn Srce: Disabled
Mac Aging : Enabled Mac Pinning : Disabled
L2PT Termination : Disabled BPDU Translation : Disabled

Multi Svc Site : None
I. Sched Pol : SchedPolCust1
Intend I Sched Pol : SchedPolCust1_Night
E. Sched Pol : SchedPolCust1Egress
Intend E Sched Pol : SchedPolCust1Egress_Night
Acct. Pol : None Collect Stats : Disabled
Anti Spoofing : None Nbr Static Hosts : 0
=====
A:kerckhot_4#

```

If a time-range is specified for a filter entry, use the **show filter** command to view results:

```

A:kerckhot_4# show filter ip 10
=====
IP Filter
=====
Filter Id : 10 Applied : No
Scope : Template Def. Action : Drop
Entries : 2
-----
Filter Match Criteria : IP
-----
Entry : 1010
time-range : day Cur. Status : Inactive
Log Id : n/a
Src. IP : 0.0.0.0/0 Src. Port : None
Dest. IP : 10.10.100.1/24 Dest. Port : None
Protocol : Undefined Dscp : Undefined
ICMP Type : Undefined ICMP Code : Undefined
Fragment : Off Option-present : Off
Sampling : Off Int. Sampling : On
IP-Option : 0/0 Multiple Option: Off
TCP-syn : Off TCP-ack : Off
Match action : Forward
Next Hop : 138.203.228.28
Ing. Matches : 0 Egr. Matches : 0
Entry : 1020

```

## System Commands

```
time-range      : night                               Cur. Status    : Active
Log Id         : n/a
Src. IP        : 0.0.0.0/0                             Src. Port       : None
Dest. IP       : 10.10.1.1/16                         Dest. Port      : None
Protocol       : Undefined                             Dscp            : Undefined
ICMP Type      : Undefined                             ICMP Code       : Undefined
Fragment       : Off                                  Option-present  : Off
Sampling       : Off                                  Int. Sampling   : On
IP-Option      : 0/0                                  Multiple Option: Off
TCP-syn        : Off                                  TCP-ack        : Off
Match action   : Forward
Next Hop       : 172.22.184.101
Ing. Matches   : 0                                    Egr. Matches   : 0
```

```
=====
A:kerckhot_4#
```

If a filter is referred to in a TOD Suite assignment, use the show filter associations command to view the output:

```
A:kerckhot_4# show filter ip 160 associations
```

```
=====
IP Filter
```

```
=====
Filter Id      : 160                                  Applied        : No
Scope         : Template                             Def. Action    : Drop
Entries       : 0
```

```
-----
Filter Association : IP
```

```
-----
Tod-suite "english_suite"
- ingress, time-range "day" (priority 5)
```

```
=====
A:kerckhot_4#
```

## redundancy

**Syntax** redundancy

**Context** show

**Description** This command enables the context to show redundancy information.

## mgmt-ethernet

**Syntax** mgmt-ethernet

**Context** show>redundancy

**Description** This command shows the management Ethernet port redundancy status. The **show router "management" interface** command also shows the CPM Ethernet port used by the management interface. If the primary CPM's port is active, then it shows "A/1" under the Port field. If the secondary CPM's port is active, then it shows "B/1 -> A/1" in the Port field.

This feature is not supported on 7750 SR-a, 7750 SR-c or VSR platforms.

**Output Show Redundancy Mgmt-Ethernet Output** — The following table describes the Redundancy Mgmt-Ethernet fields:

| Label        | Description                                                                          |
|--------------|--------------------------------------------------------------------------------------|
| Admin Status | Enabled — Administrative status is enabled.<br>Disabled — Administratively disabled. |
| Oper Status  | Displays the CPM on which the management Ethernet port is operating.                 |
| Revert Time  | Displays the revert time.                                                            |

**Sample Output**

```
A:SR12# show redundancy mgmt-ethernet

=====
Management Ethernet Redundancy
=====
Admin Status   : Enabled
Oper Status    : Management port operating on active CPM
Revert Time    : 5 seconds
=====
```

**Show Router “Management” Interface Detail Output** — The following is a sample output that shows “A/1” when the primary CPM’s Ethernet port is active and “B/1 ->A/1” if the secondary CPM’s port is active.

```
*B:Dut-A# show router "management" interface

=====
Interface Table (Router: management)
=====
Interface-Name      Adm      Opr (v4/v6)  Mode      Port/SapId
IP-Address          PfxState
-----
management          Up       Up/Up        Network  B/1 -> A/1
138.120.186.219/24  n/a
3000::8a78:badb/96  PREFERRED
fe80::221:5ff:fece:df49/64  PREFERRED
-----
Interfaces : 1
=====
```

```
*B:Dut-A# show router "management" interface detail

=====
Interface Table (Router: management)
=====

-----
Interface
-----
If Name           : management
Admin State       : Up
Oper (v4/v6)     : Up/Up
Protocols         : None
```

## System Commands

```
IP Addr/mask      : 138.120.186.219/24   Address Type      : Primary
IGP Inhibit       : Disabled              Broadcast Address : Host-ones
HoldUp-Time       : 0                     Track Srrp Inst   : 0
IPv6 Address      : 3000::8a78:badb/96
IPv6 Addr State   : PREFERRED
CGA modifier      : (Not Specified)
HoldUp-Time       : 0                     Track Srrp Inst   : 0
Link Lcl Address  : fe80::221:5ff:fece:df49/64
Link Lcl State    : PREFERRED
```

### ----- Details

```
-----
Description       : (Not Specified)
If Index          : 1280                   Virt. If Index    : 1280
Last Oper Chg    : 06/16/2015 21:01:07   Global If Index   : 16384
Lag Link Map Prof: none
Port Id          : B/1 -> A/1
TOS Marking      : Trusted                 If Type           : Network
Egress Filter    : none                    Ingress Filter    : none
Egr IPv6 Flt     : none                    Ingr IPv6 Flt     : none
BGP IP FlowSpec  : Disabled
BGP IPv6 FlowSpec: Disabled
SNTP B.Cast      : True                    Network QoS Policy: 1
MAC Address       : 00:21:05:ce:df:49      Mac Accounting    : Disabled
```

## multi-chassis

**Syntax** multi-chassis

**Context** show>redundancy

**Description** This command enables the context to show multi-chassis redundancy information.

## all

**Syntax** all [detail]

**Context** show>redundancy>multi-chassis

**Description** This command displays brief multi-chassis redundancy information.

**Parameters** detail — Shows detailed multi-chassis redundancy information.

**Output** **Show Redundancy Multi-Chassis All Output** — The following table describes Redundancy Multi-Chassis All fields:

| Label           | Description                                 |
|-----------------|---------------------------------------------|
| Peer IP Address | Displays the multi-chassis redundancy peer. |
| Description     | The text string describing the peer.        |

| Label             | Description                                                                            |
|-------------------|----------------------------------------------------------------------------------------|
| Authentication    | If configured, displays the authentication key used between this node and the MC peer. |
| Source IP Address | Displays the source address used to communicate with the MC peer.                      |
| Admin State       | Displays the administrative state of the peer.                                         |

### Sample Output

```
B:Dut-B# show redundancy multi-chassis all
=====
Multi-chassis Peer Table
=====
Peer
-----
Peer IP Address      : 10.10.10.2
Description          : Mc-Lag peer 10.10.10.2
Authentication      : Disabled
Source IP Address    : 0.0.0.0
Admin State         : Enabled
=====
B:Dut-B#
```

```
B:Dut-B# show lag detail
=====
LAG Details
=====
LAG 1
-----
Description: Description For LAG Number 1
-----
Details
-----
Lag-id           : 1                Mode           : access
Adm              : up                Opr            : up
Thres. Exceeded Cnt : 9                Port Threshold : 0
Thres. Last Cleared : 05/20/2006 00:12:35  Threshold Action : down
Dynamic Cost     : false            Encap Type     : null
Configured Address : 1c:71:ff:00:01:41             Lag-IfIndex    : 1342177281
Hardware Address  : 1c:71:ff:00:01:41             Adapt Qos     : distribute
Hold-time Down   : 0.0 sec
LACP             : enabled           Mode           : active
LACP Transmit Intvl : fast                LACP xmit stdby : enabled
Selection Criteria : highest-count       Slave-to-partner : disabled
Number of sub-groups: 1                Forced         : -
System Id        : 1c:71:ff:00:00:00             System Priority : 32768
Admin Key        : 32768                       Oper Key       : 32666
Prtr System Id   : 20:f4:ff:00:00:00             Prtr System Priority : 32768
Prtr Oper Key    : 32768

MC Peer Address   : 10.10.10.2                MC Peer Lag-id : 1
MC System Id     : 00:00:00:33:33:33             MC System Priority : 32888
MC Admin Key     : 32666                       MC Active/Standby : active
MC Lacp ID in use : true                            MC extended timeout : false
```

## System Commands

```

MC Selection Logic : peer decided
MC Config Mismatch : no mismatch
-----
Port-id           Adm    Act/Stdby Opr    Primary  Sub-group  Forced  Prio
-----
331/2/1           up    active  up    yes      1          -      32768
331/2/2           up    active  up           1          -      32768
331/2/3           up    active  up           1          -      32768
331/2/4           up    active  up           1          -      32768
-----
Port-id           Role     Exp  Def  Dist  Col  Syn  Aggr  Timeout  Activity
-----
331/2/1           actor   No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/1           partner No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/2           actor   No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/2           partner No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/3           actor   No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/3           partner No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/4           actor   No   No   Yes  Yes  Yes  Yes  Yes     Yes
331/2/4           partner No   No   Yes  Yes  Yes  Yes  Yes     Yes
=====
B:Dut-B#

```

## mc-endpoint

**Syntax** **mc-endpoint statistics**  
**mc-endpoint peer [ip-address] statistics**  
**mc-endpoint endpoint [mcep-id] statistics**  
**mc-endpoint peer [ip-address]**

**Context** show>redundancy>multi-chassis

**Description** This command displays multi-chassis endpoint information.

**Parameters** **statistics** — Displays the global statistics for the MC endpoint.  
**peer ip-address** — Specifies the IP address of multi-chassis end-point peer.  
**endpoint mcep-id** — Specifies the multi-chassis endpoint.

**Values** 1 — 4294967295

### Sample Output

```

*A:Dut-B# show redundancy multi-chassis mc-endpoint statistics
=====
Multi-Chassis Endpoint Global Statistics
=====
Packets Rx                               : 533
Packets Rx Keepalive                     : 522
Packets Rx Config                         : 3
Packets Rx Peer Config                   : 1
Packets Rx State                         : 7
Packets Dropped Keep-Alive Task         : 7
Packets Dropped Too Short                : 0

```

```

Packets Dropped Verify Failed           : 0
Packets Dropped Tlv Invalid Size       : 0
Packets Dropped Out Of Seq             : 0
Packets Dropped Unknown Tlv           : 0
Packets Dropped Tlv Invalid MC-Endpoint Id : 0
Packets Dropped MD5                    : 0
Packets Dropped Unknown Peer           : 0
Packets Dropped MC Endpoint No Peer    : 0
Packets Tx                              : 26099
Packets Tx Keepalive                    : 8221
Packets Tx Config                       : 2
Packets Tx Peer Config                  : 17872
Packets Tx State                        : 4
Packets Tx Failed                       : 0
=====
*A:Dut-B#

*A:Dut-B# show redundancy multi-chassis mc-endpoint peer 3.1.1.3 statistics
=====
Multi-Chassis MC-Endpoint Statistics
=====
Peer Addr                               : 3.1.1.3
-----
Packets Rx                              : 597
Packets Rx Keepalive                    : 586
Packets Rx Config                       : 3
Packets Rx Peer Config                  : 1
Packets Rx State                        : 7
Packets Dropped State Disabled          : 0
Packets Dropped Packets Too Short      : 0
Packets Dropped Tlv Invalid Size       : 0
Packets Dropped Tlv Invalid LagId      : 0
Packets Dropped Out of Seq             : 0
Packets Dropped Unknown Tlv           : 0
Packets Dropped MD5                    : 0
Packets Tx                              : 636
Packets Tx Keepalive                    : 600
Packets Tx Peer Config                  : 30
Packets Tx Failed                       : 0
Packets Dropped No Peer                 : 0
=====
*A:Dut-B#

*A:Dut-B# show redundancy multi-chassis mc-endpoint endpoint 1 statistics
=====
Multi-Chassis Endpoint Statistics
=====
MC-Endpoint Id 1
=====
Packets Rx Config                       : 3
Packets Rx State                        : 7
Packets Tx Config                       : 2
Packets Tx State                        : 4
Packets Tx Failed                       : 0
=====
Number of Entries 1
=====

```

## System Commands

### mc-lag

- Syntax** `mc-lag [lag lag-id]`
- Context** `show>redundancy>multi-chassis`
- Description** This command displays multi-chassis LAG information.
- Parameters** `lag lag-id` — Shows information for the specified LAG identifier.
- Values** 1 — 800

### mc-mobile

- Syntax** `mc-mobile peer {ip-address | ip6-address}`
- Context** `show>redundancy>multi-chassis`
- Description** This command displays multi-chassis LAG information.
- Parameters** `ip-address` — Shows information for the specified IPv4 peer.  
`ip6-address` — Shows information for the specified IPv6 peer.

#### Sample Output

```
*A:Dut-A# show redundancy multi-chassis mc-mobile peer 10.90.1.2
=====
Multi-chassis Peer Mc-Mobile Table
=====
Peer                : 10.90.1.2
Last State Change   : 12/04/2012 23:23:43
Admin State         : Up/Down           Oper State         : Up/Down/ISSU
Peer Version        : 5.0Rx
Keep Alive          : 10 deci-sec       Hold On Nbr Fail    : 3
BFD Svc ID         : 0                BFD Interface Name  : mc_intloopback
-----
Gateway Id         : 2
-----
Admin Role         : Primary           Oper Role           : Master
Peer Admin Role    : Secondary        Peer Oper Role      : Slave
Admin State        : Up                Oper State          : Up
Last Time Peer Connected : 12/04/2012 23:23:43

Last State Change   : 12/04/2012 23:23:43
Last State Chg Reason: Traffic Evnt
Geo-Redundancy State : Hot

CPM                : 0                Geo Redundancy      : Hot
MSCP Group         : 1                Geo Redundancy      : Hot
=====
*A:Dut-A#
```

peer

**Syntax** `peer ip-address [lag lag-id]`

**Context** `show>redundancy>multi-chassis>mc-lag`

**Description** This command enables the context to display mc-lag peer-related redundancy information.

**Parameters** *ip-address* — Shows peer information about the specified IP address.

*lag lag-id* — Shows information for the specified LAG identifier.

**Values** 1 — 800

**Output** **Show Redundancy Multi-chassis MC-Lag Peer Output** — The following table describes show redundancy multi-chassis mc-lag peer output fields:

| Label                | Description                                                                                                                                           |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Last Changed         | Displays date and time of the last mc-lag peer.                                                                                                       |
| Admin State          | Displays the administrative state of the mc-lag peer.                                                                                                 |
| Oper State           | Displays the operation state of the mc-lag peer.                                                                                                      |
| KeepAlive            | Displays the length of time to keep alive the mc-lag peer.                                                                                            |
| Hold On Ngbr Failure | Specifies how many “keepalive” intervals the standby SR will wait for packets from the active node before assuming a redundant-neighbor node failure. |

**Sample Output**

```
A:subscr_mgt# show redundancy multi-chassis mc-lag peer 10.10.10.30
=====
Multi-Chassis MC-Lag Peer 10.10.10.30
=====
Last Changed      : 01/23/2007 18:20:13
Admin State      : Up
Oper State       : Up
KeepAlive        : 10 deci-seconds
Hold On Ngbr Failure : 3
-----
Lag Id LACP Key Remote Lag Id System Id          Sys Prio Last Changed
-----
1      1      1          00:00:00:00:00:01  1          01/23/2007 18:20:13
2      2      2          00:00:00:00:00:02  2          01/24/2007 08:53:48
-----
Number of LAGs : 2
=====
A:subscr_mgt#
```

```
A:subscr_mgt# show redundancy multi-chassis mc-lag peer 10.10.10.30 lag 1
=====
Multi-Chassis MC-Lag Peer 10.10.10.30
=====
Last Changed      : 01/23/2007 18:20:13
```

## System Commands

```

Admin State      : Up                Oper State       : Up
KeepAlive       : 10 deci-seconds   Hold On Ngbr Failure : 3
-----
Lag Id LACP Key Remote Lag Id System Id          Sys Prio Last Changed
-----
1      1      1                00:00:00:00:00:01  1          01/23/2007 18:20:13
-----
Number of LAGs : 1
=====
A:subscr_mgt#

```

## statistics

**Syntax** **statistics mc-lag** [**peer** *ip-address* [**lag** *lag-id*]]

**Context** show>redundancy>multi-chassis>mc-lag

**Description** This command displays multi-chassis statistics.

**Parameters** **mc-lag** — Displays multi-chassis LAG statistics.

**peer** *ip-address* — Shows the specified address of the multi-chassis peer.

**lag** *lag-id* — Shows information for the specified LAG identifier.

**Values** 1 — 800

**Output** **Show Redundancy Multi-chassis MC-Lag Peer Statistics Output** — The following table describes show redundancy multi-chassis mc-lag peer output fields:

| Label                             | Description                                                                                       |
|-----------------------------------|---------------------------------------------------------------------------------------------------|
| Packets Rx                        | Indicates the number of MC-Lag packets received from the peer.                                    |
| Packets Rx Keepalive              | Indicates the number of MC-Lag keepalive packets received from the peer.                          |
| Packets Rx Config                 | Indicates the number of received MC-Lag configured packets from the peer.                         |
| Packets Rx Peer Config            | Indicates the number of received MC-Lag packets configured by the peer.                           |
| Packets Rx State                  | Indicates the number of MC-Lag “lag” state packets received from the peer.                        |
| Packets Dropped State Disabled    | Indicates the number of packets that were dropped because the peer was administratively disabled. |
| Packets Dropped Packets Too Short | Indicates the number of packets that were dropped because the packet was too short.               |
| Packets Dropped Tlv Invalid Size  | Indicates the number of packets that were dropped because the packet size was invalid.            |

| Label                                | Description (Continued)                                                                                               |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Packets Dropped<br>Tlv Invalid LagId | Indicates the number of packets that were dropped because the packet referred to an invalid or non multi-chassis lag. |
| Packets Dropped<br>Out of Seq        | Indicates the number of packets that were dropped because the packet size was out of sequence.                        |
| Packets Dropped<br>Unknown Tlv       | Indicates the number of packets that were dropped because the packet contained an unknown TLV.                        |
| Packets Dropped<br>MD5               | Indicates the number of packets that were dropped because the packet failed MD5 authentication.                       |
| Packets Tx                           | Indicates the number of packets transmitted from this system to the peer.                                             |
| Packets Tx<br>Keepalive              | Indicates the number of keepalive packets transmitted from this system to the peer.                                   |
| Packets Tx Peer<br>Config            | Indicates the number of configured packets transmitted from this system to the peer.                                  |
| Packets Tx Failed                    | Indicates the number of packets that failed to be transmitted from this system to the peer.                           |

**Sample Output**

```
A:subscr_mgt# show redundancy multi-chassis mc-lag statistics
=====
Multi-Chassis Statistics
=====
Packets Rx                               : 52535
Packets Rx Keepalive                      : 52518
Packets Rx Config                         : 2
Packets Rx Peer Config                    : 4
Packets Rx State                          : 6
Packets Dropped KeepaliveTask             : 0
Packets Dropped Packet Too Short          : 0
Packets Dropped Verify Failed             : 0
Packets Dropped Tlv Invalid Size          : 0
Packets Dropped Out of Seq                : 0
Packets Dropped Unknown Tlv              : 0
Packets Dropped Tlv Invalid LagId         : 0
Packets Dropped MD5                       : 0
Packets Dropped Unknown Peer              : 0
Packets Tx                                 : 52583
Packets Tx Keepalive                      : 52519
Packets Tx Config                         : 2
Packets Tx Peer Config                    : 54
Packets Tx State                          : 8
Packets Tx Failed                         : 0
=====
A:subscr_mgt#
```

## System Commands

```
B:Dut-B# show redundancy multi-chassis mc-lag peer 10.10.10.2 statistics
=====
Multi-Chassis Statistics, Peer 10.10.10.2
=====
Packets Rx                               : 231
Packets Rx Keepalive                     : 216
Packets Rx Config                         : 1
Packets Rx Peer Config                   : 2
Packets Rx State                         : 12
Packets Dropped State Disabled           : 0
Packets Dropped Packets Too Short        : 0
Packets Dropped Tlv Invalid Size         : 0
Packets Dropped Tlv Invalid LagID        : 0
Packets Dropped Out of Seq               : 0
Packets Dropped Unknown Tlv              : 0
Packets Dropped MD5                      : 0
Packets Tx                               : 235
Packets Tx Keepalive                     : 216
Packets Tx Peer Config                   : 3
Packets Tx Failed                        : 0
=====
B:Dut-B#
```

## mc-ring

**Syntax** **mc-ring peer** *ip-address* **statistics**  
**mc-ring peer** *ip-address* [**ring** *sync-tag* [**detail|statistics**] ]  
**mc-ring peer** *ip-address* **ring** *sync-tag* **ring-node** [*ring-node-name* [**detail|statistics**] ]  
**mc-ring global-statistics**

**Context** show>redundancy>multi-chassis

**Description** This command displays multi-chassis ring information.

**Parameters** *ip-address* — Specifies the address of the multi-chassis peer to display.  
**ring** *sync-tag* — Specifies a synchronization tag to be displayed that was used while synchronizing this port with the multi-chassis peer.  
**node** *ring-node-name* — Specifies a ring-node name.  
**global-statistics** — Displays global statistics for the multi-chassis ring.  
**detail** — Displays detailed peer information for the multi-chassis ring.

**Output** **Show mc-ring peer ip-address ring Output** — The following table describes mc-ring peer ip-address ring output fields.

| Label      | Description                                                                                               |
|------------|-----------------------------------------------------------------------------------------------------------|
| Sync Tag   | Displays the synchronization tag that was used while synchronizing this port with the multi-chassis peer. |
| Oper State | noPeer — The peer has no corresponding ring configured.                                                   |

| Label                  | Description                                                                                                                                                                                                                                                                                                                                  |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                        | connected — The in-band control connection with the peer is operational.                                                                                                                                                                                                                                                                     |
|                        | broken — The in-band control connection with the peer has timed out.                                                                                                                                                                                                                                                                         |
|                        | conflict — The in-band control connection with the peer has timed out but the physical connection is still OK; the failure of the in-band signaling connection is caused by a misconfiguration. For example, a conflict between the configuration of this system and its peer, or a misconfiguration on one of the ring access node systems. |
|                        | testingRing — The in-band control connection with the peer is being set up. Waiting for result.                                                                                                                                                                                                                                              |
|                        | waitingForPeer — Verifying if this ring is configured on the peer.                                                                                                                                                                                                                                                                           |
|                        | configErr — The ring is administratively up, but a configuration error prevents it from operating properly.                                                                                                                                                                                                                                  |
|                        | halfBroken — The in-band control connection indicates that the ring is broken in one direction (towards the peer).                                                                                                                                                                                                                           |
|                        | localBroken — The in-band control connection with the peer is known to be broken due to local failure or local administrative action.                                                                                                                                                                                                        |
|                        | shutdown — The ring is shutdown.                                                                                                                                                                                                                                                                                                             |
| Failure Reason         | Displays the reason of the failure of the operational state of a MC ring.                                                                                                                                                                                                                                                                    |
| No. of MC Ring entries | Displays the number of MC ring entries.                                                                                                                                                                                                                                                                                                      |

### Sample Output

```
*A:ALA-48>show>redundancy>multi-chassis# mc-ring peer 10.0.0.2 ring ring11 detail
=====
Multi-Chassis MC-Ring Detailed Information
=====
Peer          : 10.0.0.2
Sync Tag      : ring11
Port ID       : 1/1/3
Admin State   : inService
Oper State    : connected
Admin Change  : 01/07/2008 21:40:07
Oper Change   : 01/07/2008 21:40:24
Failure Reason : None
-----
In Band Control Path
-----
Service ID    : 10
Interface Name : to_an1
Oper State    : connected
Dest IP       : 10.10.0.2
Src IP        : 10.10.0.1
```

## System Commands

```
-----
VLAN Map B Path Provisioned
-----
range 13-13
range 17-17
-----
VLAN Map Excluded Path Provisioned
-----
range 18-18
-----
VLAN Map B Path Operational
-----
range 13-13
range 17-17
-----
VLAN Map Excluded Path Operational
-----
range 18-18
=====
*A:ALA-48>show>redundancy>multi-chassis#

*A:ALA-48>show>redundancy>multi-chassis# mc-ring peer 192.251.10.104
=====
MC Ring entries
=====
Sync Tag                Oper State      Failure Reason
-----
No. of MC Ring entries: 0
=====
*A:ALA-48>show>redundancy>multi-chassis#

*A:ALA-48>show>redundancy>multi-chassis# mc-ring peer 10.0.0.2
=====
MC Ring entries
=====
Sync Tag                Oper State      Failure Reason
-----
ring11                 connected       None
ring12                 shutdown        None
-----
No. of MC Ring entries: 4
=====
*A:ALA-48>show>redundancy>multi-chassis#

*A:ALA-48>show>redundancy>multi-chassis# mc-ring peer 10.0.0.2 ring ring11 ring-node an1
detail
=====
Multi-Chassis MC-Ring Node Detailed Information
=====
Peer          : 10.0.0.2
Sync Tag      : ring11
Node Name     : an1
Oper State Loc : connected
Oper State Rem : notTested
In Use        : True
Admin Change  : 01/07/2008 21:40:07
```

```

Oper Change      : 01/07/2008 21:40:25
Failure Reason   : None
-----
Ring Node Connectivity Verification
-----
Admin State      : inService
Service ID       : 11
VLAN Tag         : 11
Dest IP          : 10.11.3.1
Src IP           : None
Interval         : 1 minutes
Src MAC          : None
=====
*A:ALA-48>show>redundancy>multi-chassis#

*A:ALA-48>show>redundancy>multi-chassis# mc-ring peer 10.0.0.2 ring ring11 ring-node
=====
MC Ring Node entries
=====
Name              Loc Oper St.      Failure Reason
  In Use          Rem Oper St.
-----
an1               connected         None
  Yes             notTested
an2               connected         None
  Yes             notTested
-----
No. of MC Ring Node entries: 2
=====
*A:ALA-48>show>redundancy>multi-chassis#

```

**Show Redundancy Multi-Chassis Ring Peer Statistics Output** — The following table describes multi-chassis ring peer output fields.

| Label               | Description                                                                          |
|---------------------|--------------------------------------------------------------------------------------|
| Message             | Displays the message type.                                                           |
| Received            | Indicates the number of valid MC-ring signalling messages received from the peer.    |
| Transmitted         | Indicates the number of valid MC-ring signalling messages transmitted from the peer. |
| MCS ID Request      | Displays the number of valid MCS ID requests were received from the peer.            |
| MCS ID Response     | Displays the number of valid MCS ID responses were received from the peer.           |
| Ring Exists Request | Displays the number of valid 'ring exists' requests were received from the peer.     |

## System Commands

| Label                | Description (Continued)                                                                               |
|----------------------|-------------------------------------------------------------------------------------------------------|
| Ring Exists Response | Displays the number of valid ring exists' responses were received from the peer.                      |
| Keepalive            | Displays the number of valid MC-ring control packets of type 'keepalive' were received from the peer. |

### Sample Output

```
*A:ALA-48>show>redundancy>multi-chassis# mc-ring peer 192.251.10.104 statistics
=====
MC Ring statistics for peer 192.251.10.104
=====
Message                               Received      Transmitted
-----
MCS ID Request                         0             0
MCS ID Response                        0             0
Ring Exists Request                    0             0
Ring Exists Response                    0             0
Keepalive                               0             0
-----
Total                                  0             0
=====
*A:ALA-48>show>redundancy>multi-chassis#
```

**Show mc-ring ring-node Command Output**

| Label      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Oper State | Displays the state of the connection verification (both local and remote).<br><br>notProvisioned – Connection verification is not provisioned.<br><br>configErr – Connection verification is provisioned but a configuration error prevents it from operating properly.<br><br>notTested – Connection verification is administratively disabled or is not possible in the current situation.<br><br>testing – Connection Verification is active, but no results are yet available.<br><br>connected – The ring node is reachable.<br><br>disconnected – Connection verification has timed out. |
| In Use     | Displays “True” if the ring node is referenced on an e-pipe or as an inter-dest-id on a static host or dynamic lease.                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

**Show mc-ring global-statistics Command Output**

| Label                   | Description                                                                                                          |
|-------------------------|----------------------------------------------------------------------------------------------------------------------|
| Rx                      | Displays the number of MC-ring signalling packets were received by this system.                                      |
| Rx Too Short            | Displays the number of MC-ring signalling packets were received by this system that were too short.                  |
| Rx Wrong Authentication | Displays the number of MC-ring signalling packets were received by this system with invalid authentication.          |
| Rx Invalid TLV          | Displays the number of MC-ring signalling packets were received by this system with invalid TLV.                     |
| Rx Incomplete           | Displays the number of MC-ring signalling packets were received by this system that were incomplete.                 |
| Rx Unknown Type         | Displays the number of MC-ring signalling packets were received by this system that were of unknown type.            |
| Rx Unknown Peer         | Displays the number of MC-ring signalling packets were received by this system that were related to an unknown peer. |
| Rx Unknown Ring         | Displays the number of MC-ring signalling packets were received by this system that were related to an unknown ring. |

## System Commands

| Label                       | Description                                                                                                                |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------|
| Rx Unknown Ring Node        | Displays the number of MC-ring signalling packets were received by this system that were related to an unknown ring node.  |
| Tx                          | Displays the number of MC-ring signalling packets were transmitted by this system.                                         |
| Tx No Buffer                | Displays the number of MC-ring signalling packets could not be transmitted by this system due to a lack of packet buffers. |
| Tx Transmission Failed      | Displays the number of MC-ring signalling packets could not be transmitted by this system due to a transmission failure.   |
| Tx Unknown Destination      | Displays the number of MC-ring 'unknown destination' signalling packets were transmitted by this system.                   |
| Missed Configuration Events | Displays the number of missed configuration events on this system.                                                         |
| Missed BFD Events           | Displays the number of missed BFD events on this system.                                                                   |

```
*A:ALA-48>show>redundancy>multi-chassis# mc-ring global-statistics
=====
Global MC Ring statistics
=====
Rx                               : 0
Rx Too Short                     : 0
Rx Wrong Authentication          : 0
Rx Invalid TLV                  : 0
Rx Incomplete                   : 0
Rx Unknown Type                 : 0
Rx Unknown Peer                 : 0
Rx Unknown Ring                 : 0
Rx Unknown Ring Node           : 0
Tx                               : 36763
Tx No Buffer                     : 0
Tx Transmission Failed          : 0
Tx Unknown Destination          : 0
Missed Configuration Events     : 0
Missed BFD Events               : 0
=====
*A:ALA-48>show>redundancy>multi-chassis#
```

## sync

**Syntax** `sync [port port-id | lag-id]`

**Context** `show>redundancy>multi-chassis`

**Description** This command displays synchronization information.

**Parameters** `port port-id` — Shows the specified port ID of the multi-chassis peer.

**lag** *lag-id* — Shows information for the specified LAG identifier.

**Values** 1 — 800

**Output** **Show Redundancy Multi-chassis Sync Output** — The following table describes show redundancy multi-chassis sync output fields:

| Label                   | Description                                                                                       |
|-------------------------|---------------------------------------------------------------------------------------------------|
| Peer IP Address         | Displays the multi-chassis redundancy peer.                                                       |
| Description             | The text string describing the peer.                                                              |
| Authentication          | If configured, displays the authentication key used between this node and the multi-chassis peer. |
| Source IP Address       | Displays the source address used to communicate with the multi-chassis peer.                      |
| Admin State             | Displays the administrative state of the peer.                                                    |
| Client Applications     | Displays the list of client applications synchronized between SRs.                                |
| Sync Admin State        | Displays the administrative state of the synchronization.                                         |
| Sync Oper State         | Displays the operation state of the synchronization.                                              |
| DB Sync State           | Displays the database state of the synchronization.                                               |
| Num Entries             | Displays the number of entries on local router.                                                   |
| Lcl Deleted Entries     | Displays the number of deleted entries made at the local router.                                  |
| Alarm Entries           | Displays the alarm entries on the local router.                                                   |
| Rem Num Entries         | Displays the number of entries on the remote router.                                              |
| Rem Lcl Deleted Entries | Displays the number of locally deleting entries made by the remote router.                        |
| Rem Alarm Entries       | Displays alarm entries on the remote router.                                                      |

### Sample Output

```
*A:subscr_mgt_2# show redundancy multi-chassis sync
=====
Multi-chassis Peer Table
=====
Peer
-----
Peer IP Address      : 10.10.10.20
Description          : MC-Lag peer 10.10.10.20
Authentication      : Disabled
Source IP Address    : 0.0.0.0
```

## System Commands

```
Admin State           : Enabled
-----
Sync-status
-----
Client Applications   : SUBMGMT
Sync Admin State     : Up
Sync Oper State      : Up
DB Sync State        : inSync
Num Entries          : 1
Lcl Deleted Entries  : 0
Alarm Entries        : 0
Rem Num Entries      : 1
Rem Lcl Deleted Entries : 0
Rem Alarm Entries    : 0
=====
A:subscr_mgt_2#
```

## peer

**Syntax** `peer ip-address`

**Context** `show>redundancy>multi-chassis>sync`

**Description** This command enables the context to display peer-related redundancy information.

**Parameters** *ip-address* — Shows peer information about the specified IP address.

**Output** **Show Redundancy Multi-chassis Sync Peer Output** — The following table describes show redundancy multi-chassis sync output fields:

| Label               | Description                                                                                       |
|---------------------|---------------------------------------------------------------------------------------------------|
| Peer IP Address     | Displays the multi-chassis redundancy peer.                                                       |
| Description         | The text string describing the peer.                                                              |
| Authentication      | If configured, displays the authentication key used between this node and the multi-chassis peer. |
| Source IP Address   | Displays the source address used to communicate with the multi-chassis peer.                      |
| Admin State         | Displays the administrative state of the peer.                                                    |
| Client Applications | Displays the list of client applications synchronized between SRs.                                |
| Sync Admin State    | Displays the administrative state of the synchronization.                                         |
| Sync Oper State     | Displays the operation state of the synchronization.                                              |
| DB Sync State       | Displays the database state of the synchronization.                                               |
| Num Entries         | Displays the number of entries on local router.                                                   |

|                         |                                                                            |
|-------------------------|----------------------------------------------------------------------------|
| Lcl Deleted Entries     | Displays the number of deleted entries made at the local router.           |
| Alarm Entries           | Displays the alarm entries on the local router.                            |
| Rem Num Entries         | Displays the number of entries on the remote router.                       |
| Rem Lcl Deleted Entries | Displays the number of locally deleting entries made by the remote router. |
| Rem Alarm Entries       | Displays alarm entries on the remote router.                               |

### Sample Output

```
*A:subscr_mgt_2# show redundancy multi-chassis sync peer 10.10.10.20
=====
Multi-chassis Peer Table
=====
Peer
-----
Peer IP Address       : 10.10.10.20
Description           : Mc-Lag peer 10.10.10.20
Authentication       : Disabled
Source IP Address    : 0.0.0.0
Admin State          : Enabled
-----
Sync-status
-----
Client Applications   : SUBMGMT
Sync Admin State     : Up
Sync Oper State      : Up
DB Sync State        : inSync
Num Entries          : 1
Lcl Deleted Entries  : 0
Alarm Entries        : 0
Rem Num Entries      : 1
Rem Lcl Deleted Entries : 0
Rem Alarm Entries    : 0
=====
MCS Application Stats
=====
Application          : igmp
Num Entries          : 0
Lcl Deleted Entries  : 0
Alarm Entries        : 0
-----
Rem Num Entries      : 0
Rem Lcl Deleted Entries : 0
Rem Alarm Entries    : 0
-----
Application          : igmpSnooping
Num Entries          : 0
Lcl Deleted Entries  : 0
Alarm Entries        : 0
-----
Rem Num Entries      : 0
Rem Lcl Deleted Entries : 0
```

## System Commands

```

Rem Alarm Entries      : 0
-----
Application           : subMgmt
Num Entries           : 1
Lcl Deleted Entries   : 0
Alarm Entries         : 0
-----
Rem Num Entries       : 1
Rem Lcl Deleted Entries : 0
Rem Alarm Entries     : 0
-----
Application           : srrp
Num Entries           : 0
Lcl Deleted Entries   : 0
Alarm Entries         : 0
-----
Rem Num Entries       : 0
Rem Lcl Deleted Entries : 0
Rem Alarm Entries     : 0
=====
*A:subscr_mgt_2#

```

### detail

**Syntax** detail

**Context** show>redundancy>multi-chassis>peer

**Description** This command displays detailed peer information.

**Output** **Show Redundancy Multi-chassis Sync Peer Detail Output** — The following table describes show redundancy multi-chassis sync detail output fields:

| Label               | Description                                                                                       |
|---------------------|---------------------------------------------------------------------------------------------------|
| Peer IP Address     | Displays the multi-chassis redundancy peer.                                                       |
| Description         | The text string describing the peer.                                                              |
| Authentication      | If configured, displays the authentication key used between this node and the multi-chassis peer. |
| Source IP Address   | Displays the source address used to communicate with the multi-chassis peer.                      |
| Admin State         | Displays the administrative state of the peer.                                                    |
| Client Applications | Displays the list of client applications synchronized between routers.                            |
| Sync Admin State    | Displays the administrative state of the synchronization.                                         |
| Sync Oper State     | Displays the operation state of the synchronization.                                              |

| Label                   | Description (Continued)                                                    |
|-------------------------|----------------------------------------------------------------------------|
| DB Sync State           | Displays the database state of the synchronization.                        |
| Num Entries             | Displays the number of entries on local router.                            |
| Lcl Deleted Entries     | Displays the number of deleted entries made at the local router.           |
| Alarm Entries           | Displays the alarm entries on the local router.                            |
| Rem Num Entries         | Displays the number of entries on the remote router.                       |
| Rem Lcl Deleted Entries | Displays the number of locally deleting entries made by the remote router. |
| Rem Alarm Entries       | Displays alarm entries on the remote router.                               |

### Sample Output

```
*A:subscr_mgt_2# show redundancy multi-chassis sync peer 10.10.10.20 detail
=====
Multi-chassis Peer Table
=====
Peer
-----
Peer IP Address      : 10.10.10.20
Description          : Mc-Lag peer 10.10.10.20
Authentication      : Disabled
Source IP Address   : 0.0.0.0
Admin State         : Enabled
-----
Sync-status
-----
Client Applications  : SUBMGMT
Sync Admin State    : Up
Sync Oper State     : Up
DB Sync State       : inSync
Num Entries         : 1
Lcl Deleted Entries : 0
Alarm Entries       : 0
Rem Num Entries     : 1
Rem Lcl Deleted Entries : 0
Rem Alarm Entries   : 0
=====
MCS Application Stats
=====
Application          : igmp
Num Entries          : 0
Lcl Deleted Entries  : 0
Alarm Entries        : 0
-----
Rem Num Entries      : 0
Rem Lcl Deleted Entries : 0
Rem Alarm Entries    : 0
```

## System Commands

```
-----  
Application           : igmpSnooping  
Num Entries           : 0  
Lcl Deleted Entries   : 0  
Alarm Entries         : 0  
-----  
Rem Num Entries       : 0  
Rem Lcl Deleted Entries : 0  
Rem Alarm Entries     : 0  
-----  
Application           : subMgmt  
Num Entries           : 1  
Lcl Deleted Entries   : 0  
Alarm Entries         : 0  
-----  
Rem Num Entries       : 1  
Rem Lcl Deleted Entries : 0  
Rem Alarm Entries     : 0  
-----  
Application           : srrp  
Num Entries           : 0  
Lcl Deleted Entries   : 0  
Alarm Entries         : 0  
-----  
Rem Num Entries       : 0  
Rem Lcl Deleted Entries : 0  
Rem Alarm Entries     : 0  
=====
```

Ports synced on peer 10.10.10.20

```
=====
```

| Port/Encap | Tag     |
|------------|---------|
| lag-1      | test123 |

```
=====
```

\*A:subscr\_mgt\_2#

## synchronization

**Syntax**    **synchronization**

**Context**    show>redundancy

**Description**    This command displays redundancy synchronization times.

### Sample Output

```
A:ALA-48>show>redundancy# synchronization  
=====
```

Synchronization Information

```
=====
```

|                      |            |
|----------------------|------------|
| Standby Status       | : disabled |
| Last Standby Failure | : N/A      |
| Standby Up Time      | : N/A      |
| Failover Time        | : N/A      |
| Failover Reason      | : N/A      |

```

Boot/Config Sync Mode      : None
Boot/Config Sync Status   : No synchronization
Last Config File Sync Time : Never
Last Boot Env Sync Time   : Never
=====
A:ALA-48>show>redundancy#

```

## time-range

**Syntax** `time-range name associations [detail]`

**Context** `show>cron`

**Description** This command displays information on the configured time ranges.

**Output** **Time Range Output** — The following table displays system time range output fields:

| Label        | Description                                                                                                  |
|--------------|--------------------------------------------------------------------------------------------------------------|
| Associations | Shows the time-range as it is associated with the TOD suites and ACL entries as well as the SAPs using them. |
| Detail       | Shows the details of this time-range.                                                                        |

### Sample Output

The following example shows time-range detail output.

```

A:ala# show cron time-range time-range2 detail
=====
Cron time-range
=====
Name      : time-range1
Periodic  : Start * * * * End * * * *
Absolute  : Start * * * * End * * * *

```

The following example shows output for time-range associations with previously created IP and MAC filters.

```

A:ala# show cron time-range day associations
=====
Cron time-range associations
=====
Name      : day                               State : Inactive
-----
IP Filter associations
-----
IP filter Id : 10, entry 1010
-----
MAC Filter associations
-----
None
-----

```

## System Commands

```
Tod-suite associations
-----
Tod-suite : suite_sixteen, for Ingress Qos Policy "1160"
Tod-suite : suite_sixteen, for Ingress Scheduler Policy "SchedPolCust1_Day"
Tod-suite : suite_sixteen, for Egress Qos Policy "1160"
Tod-suite : suite_sixteen, for Egress Scheduler Policy "SchedPolCust1Egress_Day"
=====
```

### script-control

**Syntax** **script-control**

**Context** show>system

**Description** This command enables the context to display script information.

### script

**Syntax** **script** [*script-name*] [*owner script-owner*]

**Context** show>system>script-control

**Description** This command displays script parameters.

**Parameters** *script-name* — Displays information for the specified script.  
*owner script-owner* — Displays information for the specified script owner.

**Output** The following table describes the show script output fields.

| Label                  | Description                                                                          |
|------------------------|--------------------------------------------------------------------------------------|
| Script                 | Displays the name of the script.                                                     |
| Script owner           | Displays the owner name of script.                                                   |
| Administrative status  | Enabled — Administrative status is enabled.<br>Disabled — Administratively disabled. |
| Operational status     | Enabled — Operational status is enabled.<br>Disabled — Operationally disabled.       |
| Script source location | Displays the location of scheduled script.                                           |
| Last script error      | Displays the system time of the last error.                                          |
| Last change            | Displays the system time of the last change.                                         |

**Sample Output**

```
A:sim1>show>system>script-control# script
=====
Script Information
=====
Script                : test
Owner name            : TiMOS CLI
Description           : asd
Administrative status : enabled
Operational status   : enabled
Script source location : ftp://*****:*****@100.100.100.1/home/testlab_bgp
                       /test1.cfg
Last script error     : none
Last change           : 2015/01/07 17:10:03
=====
A:sim1>show>cron#
```

**script-policy**

**Syntax** **script-policy** *script-policy-name* [**owner** *owner-name*]  
**script-policy run-history** [*run-state*]

**Context** show>system>script-control

**Description** This command displays script policy information.

**Parameters** *script-policy-name* — Displays policy information for the specified script.  
**owner** *owner-name* — Displays information for the specified script owner.

**Default** “TiMOS CLI”

*run-state* — Displays information for script policies in the specified state.

**Values** executing | initializing | terminated

**Output** **Script Policy Output** — The following table describes script policy output fields.

| Label                 | Description                                                                                  |
|-----------------------|----------------------------------------------------------------------------------------------|
| Script policy         | Displays the name of the script policy.                                                      |
| Script policy owner   | The name of the script policy owner.                                                         |
| Administrative status | Enabled — Administrative status is enabled.<br>Disabled — Administrative status is disabled. |
| Script                | The name of the script.                                                                      |
| Script owner          | The name of the script owner.                                                                |

## System Commands

| Label                       | Description (Continued)                                                    |
|-----------------------------|----------------------------------------------------------------------------|
| Script source location      | Displays the location of scheduled script.                                 |
| Max running allowed         | Displays the maximum number of allowed sessions.                           |
| Max completed run histories | Displays the maximum number of sessions previously run.                    |
| Max lifetime allowed        | Displays the maximum amount of time the script may run.                    |
| Completed run histories     | Displays the number of completed sessions.                                 |
| Executing run histories     | Displays the number of sessions in the process of executing.               |
| Initializing run histories  | Displays the number of sessions ready to run/queued but not executed.      |
| Max time tun history saved  | Displays the maximum amount of time to keep the results from a script run. |
| Last change                 | Displays the system time a change was made to the configuration.           |

### Sample Output

```
*A:Redundancy# show system script-control script-policy run-history terminated
=====
Script-policy Run History
=====
Script policy "test"
Owner "TiMOS CLI"
-----
Script Run #17
-----
Start time : 2006/11/06 20:30:09 End time : 2006/11/06 20:35:24
Elapsed time : 0d 00:05:15 Lifetime : 0d 00:00:00
State : terminated Run exit code : noError
Result time : 2006/11/06 20:35:24 Keep history : 0d 00:49:57
Error time : never
Results file : ftp://*:*@192.168.15.18/home/testlab_bgp/cron/_20061106-203008.
out
Run exit : Success
-----
Script Run #18
-----
Start time : 2006/11/06 20:35:24 End time : 2006/11/06 20:40:40
Elapsed time : 0d 00:05:16 Lifetime : 0d 00:00:00
State : terminated Run exit code : noError
Result time : 2006/11/06 20:40:40 Keep history : 0d 00:55:13
Error time : never
Results file : ftp://*:*@192.168.15.18/home/testlab_bgp/cron/_20061106-203523.
```

```

out
Run exit : Success
-----
*A:Redundancy#

*A:Redundancy# show system script-control script-policy run-history executing
=====
Script-policy Run History
=====
Script policy "test"
Owner "TiMOS CLI"
-----
Script Run #20
-----
Start time : 2006/11/06 20:46:00 End time : never
Elapsed time : 0d 00:00:56 Lifetime : 0d 00:59:04
State : executing Run exit code : noError
Result time : never Keep history : 0d 01:00:00
Error time : never
Results file : ftp://*:*@192.168.15.18/home/testlab_bgp/cron/_20061106-204559.
out
=====
*A:Redundancy#

*A:Redundancy# show system script-control script-policy run-history initializing
=====
Script-policy Run History
=====
Script policy "test"
Owner "TiMOS CLI"
-----
Script Run #21
-----
Start time : never End time : never
Elapsed time : 0d 00:00:00 Lifetime : 0d 01:00:00
State : initializing Run exit code : noError
Result time : never Keep history : 0d 01:00:00
Error time : never
Results file : none
-----
Script Run #22
-----
Start time : never End time : never
Elapsed time : 0d 00:00:00 Lifetime : 0d 01:00:00
State : initializing Run exit code : noError
Result time : never Keep history : 0d 01:00:00
Error time : never
Results file : none
-----
Script Run #23
-----
Start time : never End time : never
Elapsed time : 0d 00:00:00 Lifetime : 0d 01:00:00
State : initializing Run exit code : noError
Result time : never Keep history : 0d 01:00:00
Error time : never
Results file : none
=====
*A:Redundancy#

```

## System Commands

### uptime

**Syntax**    **uptime**

**Context**    show

**Description**    This command displays the time since the system started.

**Output**    **Uptime Output** — The following table describes uptime output fields.

| Label          | Description                                                                    |
|----------------|--------------------------------------------------------------------------------|
| System Up Time | Displays the length of time the system has been up in days, hr:min:sec format. |

#### Sample Output

```
A:ALA-1# show uptime
System Up Time      : 11 days, 18:32:02.22 (hr:min:sec)

A:ALA-1#
```

### switch-fabric

**Syntax**    **switch-fabric**

**Context**    show>system

**Description**    This command displays switch fabric information.

**Output**    **Switch fabric output** — The following table describes switch-fabric output fields:

| Label                    | Description                                                                                                                                           |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Slot/MDA                 | Displays the fabric slot within a chassis in the system. The CPM cards and XCM cards cannot be physically inserted into the switch fabric card slots. |
| Min. Forwarding Capacity | Displays the minimum forwarding capacity of the slot and XMA/MDA as a percentage.                                                                     |
| Max. Forwarding Capacity | Displays the maximum forwarding capacity of the slot and XMA/MDA as a percentage.                                                                     |

#### Sample Output

```
A:ALA-7# show system switch-fabric
=====
Switch Fabric
=====
Slot/Mda Min. Forwarding Capacity Max. Forwarding Capacity
```

```

-----
1/1 100%    100%
1/2 100%    100%
2/1 100%    100%
2/2 100%    100%
3/1 100%    100%
3/2 100%    100%
4/1 100%    100%
4/2 100%    100%
5/1 100%    100%
5/2 100%    100%
A   100%    100%
B   100%    100%
=====
A:ALA-7#

A:ALA-12# show system switch-fabric
=====
Switch Fabric
=====
Slot/Mda Min. Forwarding Capacity Max. Forwarding Capacity
-----
1/1 100%    100%
1/2 100%    100%
2/1 100%    100%
2/2 100%    100%
3/1 100%    100%
3/2 100%    100%
4/1 100%    100%
4/2 100%    100%
5/1 100%    100%
5/2 100%    100%
6/1 100%    100%
6/2 100%    100%
7/1 100%    100%
7/2 100%    100%
8/1 100%    100%
8/2 100%    100%
A   100%    100%
B   100%    100%
=====
A:ALA-12

```

## sync-if-timing

**Syntax**    **sync-if-timing**

**Context**    show>system

**Description**    This command displays synchronous interface timing operational information.

**Output**    **System Timing Output** — The following table describes sync-if-timing output fields.

## System Commands

| Label                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| System Status CPM<br>A/B    | <p>Indicates the present status of the synchronous timing equipment subsystem (SETS).</p> <p>Not Present — Only shown on systems without central clocks (7450 ESS-1)</p> <p>Master Freerun — The clock is in free-run because it hasn't had a qualified input reference to lock to</p> <p>Master Holdover — The clock was locked to an input reference but has lost all qualified input references and is in holdover.</p> <p>Master Locked — The clock is locked to an input reference</p> <p>Acquiring — The clock is training to a qualified input reference.</p> |
| Reference Input<br>Mode     | <p>Revertive — Indicates that for a re-validated or a newly validated reference source which has a higher priority than the currently selected reference has reverted to the new reference source.</p> <p>Non-revertive — The clock cannot revert to a higher priority clock if the current clock goes offline.</p>                                                                                                                                                                                                                                                  |
| Quality Level<br>Selection  | Indicates whether the ql-selection command has been enabled or disabled. If this command is enabled, then the reference is selected first using the QL value, then by the priority reference order. If this command is not enabled, then the reference is selected by the priority reference order.                                                                                                                                                                                                                                                                  |
| Reference<br>Selected       | <p>Indicates which reference has been selected:</p> <ul style="list-style-type: none"> <li>• ref1, ref2 - (for all chassis)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                               |
| System Quality<br>Level     | Indicates the quality level being generated by the system clock.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Current Frequency<br>Offset | (value) — The frequency offset of the currently selected timing reference in parts per million.                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Reference Order             | ref1, ref2 — Indicates that the priority order of the timing references.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Reference Mate CPM          | Data within this block represents the status of the timing reference provided by the Mate CPM. This will be the BITS input from the standby CPM.                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Admin Status                | <p>down — The <b>ref1</b> or <b>ref2</b> configuration is administratively shutdown.</p> <p>up — The <b>ref1</b> or <b>ref2</b> configuration is administratively enabled.</p> <p>diag — Indicates the reference has been forced using the force-reference command.</p>                                                                                                                                                                                                                                                                                              |
| Quality Level<br>Override   | Indicates whether the QL value used to determine the reference was configured directly by the user.                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| Label                     | Description (Continued)                                                                                                                                                                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Rx Quality Level          | Indicates the QL value received on the interface. <ul style="list-style-type: none"> <li>• inv - SSM received on the interface indicates an invalid code for the interface type.</li> <li>• unknown - No QL value was received on the interface.</li> </ul>               |
| Qualified for Use         | Indicates whether the reference has been qualified to be used as a source of timing for the node.                                                                                                                                                                         |
| Not Qualified Due To      | Indicates the reason why the reference has not been qualified: <ul style="list-style-type: none"> <li>- disabled</li> <li>- LOS</li> <li>- OOPIR</li> <li>- OOF</li> </ul>                                                                                                |
| Selected for Use          | Indicates whether the method is presently selected.                                                                                                                                                                                                                       |
| Not Selected Due To       | Indicates the reason why the method is not selected: <ul style="list-style-type: none"> <li>- disabled</li> <li>- not qualified</li> <li>- previous failure</li> <li>- LOF</li> <li>- AIS-L</li> <li>- validating</li> <li>- on standby</li> <li>- ssm quality</li> </ul> |
| Source Port               | Identifies the Source port for the reference.                                                                                                                                                                                                                             |
| Interface Type            | The interface type configured for the BITS port.                                                                                                                                                                                                                          |
| Framing                   | The framing configured for the BITS port.                                                                                                                                                                                                                                 |
| Line Coding               | The line coding configured for the BITS port.                                                                                                                                                                                                                             |
| Line Length               | The line length value of the BITS output.                                                                                                                                                                                                                                 |
| Output Admin Status       | down – The BITS output is administratively shutdown.<br><br>up – The BITS output is administratively enabled.<br><br>diag – Indicates the BITS output has been forced using the force-reference command.                                                                  |
| Output Source             | The source to be used to provide the signal on the BITS output port.<br>line reference – unfiltered recovered line reference.<br>internal clock – filtered node clock output.                                                                                             |
| Output Reference Selected | The reference selected as the source for the BITS output signal (ref1 or ref2).                                                                                                                                                                                           |
| TX Quality Level          | QL value for BITS output signal.                                                                                                                                                                                                                                          |

## System Commands

The following example is for a node locked to the active BITS input and directing the signal on ref1 to the BITS output:

### Sample Output

```
*A:SR7# show system sync-if-timing
=====
System Interface Timing Operational Info
=====
System Status CPM A           : Master Locked
  Reference Input Mode         : Non-revertive
  Quality Level Selection      : Disabled
  Reference Selected           : BITS A
  System Quality Level         : prs
  Current Frequency Offset (ppm) : +0

Reference Order                : bits ref1 ref2

Reference Mate CPM
  Qualified For Use             : Yes
  Selected For Use              : No
  Not Selected Due To          :      on standby

Reference Input 1
  Admin Status                  : up
  Rx Quality Level              : prs
  Qualified Level Override      : none
  Qualified For Use             : Yes
  Selected For Use              : No
  Not Selected Due To          :      on standby
  Source Port                   : 3/1/2

Reference Input 2
  Admin Status                  : down
  Rx Quality Level              : unknown
  Qualified Level Override      : none
  Qualified For Use             : No
  Not Qualified Due To         :      disabled
  Selected For Use              : No
  Not Selected Due To          :      disabled
  Source Port                   : None

Reference BITS A
  Admin Status                  : up
  Rx Quality Level              : prs
  Qualified Level Override      : none
  Qualified For Use             : Yes
  Selected For Use              : Yes
  Interface Type                : DS1
  Framing                       : ESF
  Line Coding                    : B8ZS
  Line Length                    : 550-660ft
  Output Admin Status           : up
  Output Source                  : line reference
  Output Reference Selected     : ref1
  Tx Quality Level              : prs
=====
```

```
*A:SR7#
```

The following example is for a node locked to the standby CPM BITS input and directing the ref1 signal to the BITS output port:

```
*A:Dut-B# show system sync-if-timing
```

```
=====
System Interface Timing Operational Info
=====
```

```
System Status CPM A           : Master Locked
Reference Input Mode          : Non-revertive
Quality Level Selection       : Disabled
Reference Selected            : Mate CPM (BITS B)
System Quality Level          : prs
Current Frequency Offset (ppm) : +0
```

```
Reference Order                : bits ref1 ref2
```

```
Reference Mate CPM
```

```
Qualified For Use              : Yes
Selected For Use               : Yes
```

```
Reference Input 1
```

```
Admin Status                   : up
Rx Quality Level               : prs
Quality Level Override         : none
Qualified For Use              : Yes
Selected For Use               : No
    Not Selected Due To       : on standby
Source Port                    : 3/1/2
```

```
Reference Input 2
```

```
Admin Status                   : down
Rx Quality Level               : unknown
Quality Level Override         : none
Qualified For Use              : No
    Not Qualified Due To       : disabled
Selected For Use               : No
    Not Selected Due To       : disabled
Source Port                    : None
```

```
Reference BITS A
```

```
Admin Status                   : up
Rx Quality Level               : unknown
Quality Level Override         : none
Qualified For Use              : No
    Not Qualified Due To       : LOS
Selected For Use               : No
    Not Selected Due To       : not qualified
Interface Type                 : DS1
Framing                        : ESF
Line Coding                    : B8ZS
Line Length                    : 550-660ft
Output Admin Status           : up
Output Source                  : line reference
Output Reference Selected     : ref1
Tx Quality Level              : prs
```

## System Commands

The following example is for a node whose standby CPM is locked to its local BITS port and the signal from ref1 is directed to the BITS output port:

```
A:SR7# show system sync-if-timing standby
=====
System Interface Timing Operational Info
=====
System Status CPM B           : Master Locked
  Reference Input Mode        : Non-revertive
  Quality Level Selection     : Disabled
  Reference Selected          : BITS B
  System Quality Level        : prs
  Current Frequency Offset (ppm) : +0

Reference Order                : bits ref1 ref2

Reference Mate CPM
  Qualified For Use            : Yes
  Selected For Use             : No
  Not Selected Due To         : on standby

Reference Input 1
  Admin Status                 : down
  Rx Quality Level             : unknown
  Quality Level Override       : none
  Qualified For Use            : No
  Not Qualified Due To         : disabled
  Selected For Use             : No
  Not Selected Due To         : disabled
  Source Port                  : None

Reference Input 2
  Rx Quality Level             : unknown
  Quality Level Override       : none
  Qualified For Use            : No
  Not Qualified Due To         : disabled
  Selected For Use             : No
  Not Selected Due To         : disabled
  Source Port                  : None

Reference BITS B
  Admin Status                 : up
  Rx Quality Level             : prs
  Quality Level Override       : none
  Qualified For Use            : Yes
  Selected For Use             : Yes
  Interface Type               : DS1
  Framing                      : ESF
  Line Coding                  : B8ZS
  Line Length                  : 550-660ft
  Output Admin Status          : up
  Output Source                : line reference
  Output Reference Selected    : ref1
  Tx Quality Level             : prs
=====
*A:SR7#
```

## synchronization

**Syntax** `synchronization`

**Context** `show>redundancy>synchronization`

**Description** This command displays redundancy synchronization times.

**Output** **Synchronization Output** — The following table describes redundancy synchronization output fields.

| Label                      | Description                                                                                                                                                                                                                                 |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Standby Status             | Displays the status of the standby .                                                                                                                                                                                                        |
| Last Standby Failure       | Displays the timestamp of the last standby failure.                                                                                                                                                                                         |
| Standby Up Time            | Displays the length of time the standby has been up.                                                                                                                                                                                        |
| Failover Time              | Displays the timestamp when the last redundancy failover occurred causing a switchover from active to standby . If there is no redundant card in this system or no failover has occurred since the system last booted, the value will be 0. |
| Failover Reason            | Displays a text string giving an explanation of the cause of the last redundancy failover. If no failover has occurred, an empty string displays.                                                                                           |
| Boot/Config Sync Mode      | Displays the type of synchronization operation to perform between the primary and secondary s after a change has been made to the configuration files or the boot environment information contained in the boot options file (BOF).         |
| Boot/Config Sync Status    | Displays the results of the last synchronization operation between the primary and secondary s.                                                                                                                                             |
| Last Config File Sync Time | Displays the timestamp of the last successful synchronization of the configuration files.                                                                                                                                                   |
| Last Boot Env Sync Time    | Displays the timestamp of the last successful synchronization of the boot environment files.                                                                                                                                                |

**Sample Output**

```
A:ALA-1>show>redundancy# synchronization
=====
Synchronization Information
=====
Standby Status           : disabled
Last Standby Failure     : N/A
Standby Up Time          : N/A
Failover Time            : N/A
Failover Reason          : N/A
Boot/Config Sync Mode    : None
Boot/Config Sync Status  : No synchronization
Last Config File Sync Time : Never
Last Boot Env Sync Time  : Never
```

# System Commands

```
=====
A:ALA-1>show>redundancy#
```

---

## Debug Commands

### sync-if-timing

**Syntax**    **sync-if-timing**

**Context**    debug

**Description**    The context to debug synchronous interface timing references.

### force-reference

**Syntax**    **force-reference {ref1 | ref2 | bits}**  
**no force-reference**

**Context**    debug>sync-if-timing

**Description**    This command allows an operator to force the system synchronous timing output to use a specific reference.

**Note:** The debug sync-if-timing force-reference command should only be used to test and debug problems. Network synchronization problems may appear if network elements are left with this manual override setting. Once the system timing reference input has been forced, it may be cleared using the no force-reference command.

The CPM clock can be forced to use a specific input reference using the force-reference command.

When the command is executed, the CPM clock on the active CPM immediately switches its input reference to that specified by the command. If the specified input is not available (shutdown), or in a disqualified state, the CPM clock shall use the next qualified input reference based on the selection rules.

This command also affects the BITS output port on the active CPM. If the BITS output port selection is set to line-reference and the reference being forced is not the BITS input port, then the system uses the forced reference to generate the signal out the BITS output port. If the BITS output port selection is set to internal-clock, then the system uses the output of the CPM clock to generate the signal for the BITS output port.

On a CPM activity switch, the force command is cleared and normal reference selection is determined.

Debug configurations are not saved between reboots.

**Note:** The 7750 SR-c4 has two BITS input ports on the CFM. The force reference command on this system allows the selection of the specific port.

7750 SR-c4 CLI Syntax: **debug>sync-if-timing>force-reference {ref1 | ref2 | bits1 | bits2}**

**Parameters**

- ref1** — The clock will use the first timing reference.
- ref2** — The clock will use the second timing reference.
- bits** — The clock will use the external network interface on the active CPM to be the highest priority input.
- bits1** — (7750 SR-c4) The clock will use the bits1 timing reference.
- bits2** — (7750 SR-c4) The clock will use the bits2 timing reference.

## Debug Commands

### system

**Syntax** [no] system

**Context** debug

**Description** This command displays system debug information.

### http-connections

**Syntax** http-connections [*host-ip-address/mask*]  
http-connections

**Context** debug>system

**Description** This command displays HTTP connections debug information.

**Parameters** *host-ip-address/mask* — Displays information for the specified host IP address and mask.

### ntp

**Syntax** [no] router *router-name* interface *ip-int-name*

**Context** debug>system

**Description** This command enables and configures debugging for NTP.  
The **no** form of the command disables debugging for NTP.

**Parameters** *router-name* — Base, management

**Default** Base

*ip-int-name* — maximum 32 characters; must begin with a letter. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

### persistence

**Syntax** [no] persistence

**Context** debug>system

**Description** This command displays persistence debug information.

---

## Tools Commands

### redundancy

**Syntax**    **redundancy**

**Context**    tools>dump

**Description**    This command enables the context to dump redundancy parameters.

### multi-chassis

**Syntax**    **multi-chassis**

**Context**    tools>dump>redundancy

**Description**    This command enables the context to dump multi-chassis parameters.

### mc-endpoint

**Syntax**    **mc-endpoint peer *ip-address***

**Context**    tools>dump>redundancy>multi-chassis

**Description**    This command dumps multi-chassis endpoint information.

**Parameters**    **peer *ip-address*** — Specifies the peer's IP address.

#### Sample Output

```
*A:Dut-B# tools dump redundancy multi-chassis mc-endpoint peer 3.1.1.3
MC Endpoint Peer Info
  peer addr           : 3.1.1.3
  peer name           : Dut-C
  peer name refs      : 1
  src addr conf       : Yes
  source addr         : 2.1.1.2
  num of mcep         : 1
  num of non-mcep     : 0
  own sess num        : 58ba0d39
  mc admin state      : Up
  tlv own mc admin state : Up
  tlv peer mc admin state : Up
  reachable           : Yes

  own sys priority    : 50
  own sys id          : 00:03:fa:72:c3:c0
  peer sys priority   : 21
```

## Debug Commands

```
peer sys id           : 00:03:fa:c6:31:f8
master               : No

conf boot timer      : 300
boot timer active    : No
conf ka intv         : 10
conf hold on num of fail : 3
tlv own ka intv      : 10
tlv peer ka intv     : 10
ka timeout tmr active : Yes
ka timeout tmr intvl : 20
ka timeout tmr time left : 4
peer ka intv         : 10
mc peer timed out    : No

initial peer conf rx : Yes
peer-mc disabled     : No
initial peer conf sync : Yes
peer conf sync       : Yes

own passive mode     : Disable
peer passive mode    : No

retransmit pending   : No
non-mcep retransmit pending : No
retransmit intvl     : 5
last tx time         : 1437130
last rx time         : 1437156

own bfd              : Enable
peer bfd             : Enable
bfd vrtr if         : 2
bfd handle           : 1
bfd state            : 3
bfd code             : 0

*A:Dut-B#
```

## mc-ring

**Syntax** **mc-ring**  
**mc-ring peer** *ip-address* [**ring sync-tag**]

**Context** tools>dump>redundancy>multi-chassis

**Description** This command dumps multi-chassis ring information.

**peer** *ip-address* — Specifies the peer's IP address.

**ring sync-tag** — Specifies the ring's sync-tag created in the **config>redundancy>mc>peer>mcr> ring** context.

## sync-database

**Syntax** **sync-database** [**peer** *ip-address*] [**port** *port-id* | *lag-id*] [**sync-tag** *sync-tag*] [**application** *application*] [**detail**] [**type** *type*]

**Context** tools>dump>redundancy>multi-chassis

**Description** This command dumps MCS database information.

**peer** *ip-address* — Specifies the peer's IP address.

**port** *port-id* | *lag-id* — Indicates the port or LAG ID to be synchronized with the multi-chassis peer.  
*slot/mda/port* or *lag-lag-id*

**sync-tag** *sync-tag* — Specifies a synchronization tag to be used while synchronizing this port with the multi-chassis peer.

**application** *application* — Specifies a particular multi-chassis peer synchronization protocol application.

**Values**

|                |                                       |
|----------------|---------------------------------------|
| dhcp-server:   | local dhcp server                     |
| igmp:          | Internet group management protocol    |
| igmp-snooping: | igmp-snooping                         |
| mc-ring:       | multi-chassis ring                    |
| mld-snooping:  | multicast listener discovery-snooping |
| srrp:          | simple router redundancy protocol     |
| sub-host-trk:  | subscriber host tracking              |
| sub-mgmt:      | subscriber management                 |

**type** *type* — Indicates the locally deleted or alarmed deleted entries in the MCS database per multi-chassis peer.

**Values** alarm-deleted, local-deleted

**detail** — Displays detailed information.

## set-role

**Syntax** **set-role** {**standalone** | **master** | **extension**}

**Context** tools>perform>chassis

**Description** This command sets the role of the chassis from which the command is invoked.

- When run on a standalone chassis this will update the EEPROM on the (one) Chassis backplane.
- Master and Extension chassis are blocked if any SFMs are configured as type **sfm-x20** (must be **sfm-x20-b**). The following message displays:
- When the **extension** option is specified, the chassis will immediately reboot as part of the command. The following warning and prompt will be provided:

```
WARNING: You are about to provision the chassis as an XRS-40 Extension chassis.
This chassis will immediately reboot after the command is executed. No CLI shell
is available directly on an Extension chassis. An Extension chassis will not com
pletely boot up unless it is properly cabled to and controlled by an XRS-40 Master
```

## Debug Commands

```
chassis. Do you wish to proceed (yes/no) ?
```

- When the **master** option is specified, the chassis will immediately reboot as part of the command. The Operational mode is not changed until a reboot is performed. The following warning and prompt will be provided:

```
WARNING: You are about to provision the chassis as an XRS-40 Master chassis. This chassis will immediately reboot after the command is executed.
```

```
Do you wish to proceed (yes/no) ?
```

- When the **master** or **extension** options are specified and the chassis has any SFM slots with a configured type of sfm-x20, then the command will fail with the following message:

```
Configured sfm-type of sfm-x20 is not compatible with XRS-40 mode operation.
```

If you want to change the role of the chassis anyways, you can deconfigure the SFMs and then change the role.

## mgmt-ethernet

**Syntax** `mgmt-ethernet`

**Context** `tools>perform>redundancy>mgmt-ethernet`

**Description** This command triggers redundancy mode, just as if the management Ethernet port of the primary CPM has gone down. The router will revert if the management Ethernet port of the primary CPM has been up for the revert duration.

## sfm-interco-test

**Syntax** `sfm-interco-test [sfm x]`

**Context** `tools>perform>system>inter-chassis>`

**Description** Use this command to run inter-chassis SFM loopback tests.

Run on an out-of-service standalone chassis that will later become the Extension chassis of an XRS-40 system. The out of service chassis (Chassis 1 – future Master chassis) must be connected by means of SFM interconnect links (cable bundles) before this test is run. This test operates without requiring any XCMs in either chassis, but they can be present.

The test should not be initiated from Chassis 1.

The following conditions must be satisfied for the test to be permitted:

- The system must be in standalone mode; error message:

```
The test can only be performed on a standalone system
```

- The system must have only XRS-40 compatible SFMs provisioned; error message:

```
The chassis can not have SFMs with a configured type of sfm-x20s-b when performing the test
```

- All provisioned SFMs must be operational; error message:  
     All provisioned SFMs must be operational before performing the test
- The same test cannot be running in another session (i.e. only one test can be executed at a time); error message:  
     The test is already in-progress in another session

Other notes (which are also relayed to the operator when the test is attempted):

- All provisioned XCMs will be reset at the start of the test and will be held in the *booting* state until the test has completed.
- All SFMs will be cleared when the operator exits the test. This will trigger a reset of the XCMs and the standby CPM.

### Sample Output

```
*A:Dut-A# tools perform system inter-chassis sfm-interco-test
WARNING: This test is intended for an out-of-service standalone chassis that is
going to later become the extension chassis of an XRS-40 system.
```

At the start of the test, all provisioned IOMs will be reset and will be held in the 'booting' state until the test has completed.

While the test is running avoid altering this system or the attached system (e.g. do not shutdown, clear, or remove the CPMs/SFMs/IOMs and do not issue CPM switchovers)

Once testing has completed all SFMs in this system will be cleared.

```
Do you wish to proceed (y/n)? y
Clearing provisioned IOMs ...
Test executing ...
Displaying results
```

```
=====
SFm Interconnect Port Summary
=====
```

| SFM | SFM Oper State | IcPort Num | IcPort Oper State | Module Inserted | Degrade State | Miscon SFM | Info IcPort |
|-----|----------------|------------|-------------------|-----------------|---------------|------------|-------------|
| 1   | up             | 1          | up                | yes             | none          |            |             |
| 1   | up             | 2          | up                | yes             | none          |            |             |
| 1   | up             | 3          | up                | yes             | none          |            |             |
| 1   | up             | 4          | up                | yes             | none          |            |             |
| 1   | up             | 5          | up                | yes             | none          |            |             |
| 1   | up             | 6          | up                | yes             | none          |            |             |
| 1   | up             | 7          | up                | yes             | none          |            |             |
| 1   | up             | 8          | up                | yes             | none          |            |             |
| 1   | up             | 9          | up                | yes             | none          |            |             |
| 1   | up             | 10         | up                | yes             | none          |            |             |
| 1   | up             | 11         | up                | yes             | none          |            |             |
| 1   | up             | 12         | up                | yes             | none          |            |             |
| 1   | up             | 13         | up                | yes             | none          |            |             |
| 1   | up             | 14         | up                | yes             | none          |            |             |
| 2   | up             | 1          | up                | yes             | none          |            |             |

## Debug Commands

|   |    |    |    |     |      |
|---|----|----|----|-----|------|
| 2 | up | 2  | up | yes | none |
| 2 | up | 3  | up | yes | none |
| 2 | up | 4  | up | yes | none |
| 2 | up | 5  | up | yes | none |
| 2 | up | 6  | up | yes | none |
| 2 | up | 7  | up | yes | none |
| 2 | up | 8  | up | yes | none |
| 2 | up | 9  | up | yes | none |
| 2 | up | 10 | up | yes | none |
| 2 | up | 11 | up | yes | none |
| 2 | up | 12 | up | yes | none |
| 2 | up | 13 | up | yes | none |
| 2 | up | 14 | up | yes | none |
| 3 | up | 1  | up | yes | none |
| 3 | up | 2  | up | yes | none |
| 3 | up | 3  | up | yes | none |
| 3 | up | 4  | up | yes | none |
| 3 | up | 5  | up | yes | none |
| 3 | up | 6  | up | yes | none |
| 3 | up | 7  | up | yes | none |
| 3 | up | 8  | up | yes | none |
| 3 | up | 9  | up | yes | none |
| 3 | up | 10 | up | yes | none |
| 3 | up | 11 | up | yes | none |
| 3 | up | 12 | up | yes | none |
| 3 | up | 13 | up | yes | none |
| 3 | up | 14 | up | yes | none |
| 4 | up | 1  | up | yes | none |
| 4 | up | 2  | up | yes | none |
| 4 | up | 3  | up | yes | none |
| 4 | up | 4  | up | yes | none |
| 4 | up | 5  | up | yes | none |
| 4 | up | 6  | up | yes | none |
| 4 | up | 7  | up | yes | none |
| 4 | up | 8  | up | yes | none |
| 4 | up | 9  | up | yes | none |
| 4 | up | 10 | up | yes | none |
| 4 | up | 11 | up | yes | none |
| 4 | up | 12 | up | yes | none |
| 4 | up | 13 | up | yes | none |
| 4 | up | 14 | up | yes | none |
| 5 | up | 1  | up | yes | none |
| 5 | up | 2  | up | yes | none |
| 5 | up | 3  | up | yes | none |
| 5 | up | 4  | up | yes | none |
| 5 | up | 5  | up | yes | none |
| 5 | up | 6  | up | yes | none |
| 5 | up | 7  | up | yes | none |
| 5 | up | 8  | up | yes | none |
| 5 | up | 9  | up | yes | none |
| 5 | up | 10 | up | yes | none |
| 5 | up | 11 | up | yes | none |
| 5 | up | 12 | up | yes | none |
| 5 | up | 13 | up | yes | none |
| 5 | up | 14 | up | yes | none |
| 6 | up | 1  | up | yes | none |
| 6 | up | 2  | up | yes | none |
| 6 | up | 3  | up | yes | none |
| 6 | up | 4  | up | yes | none |

|   |    |    |    |     |      |
|---|----|----|----|-----|------|
| 6 | up | 5  | up | yes | none |
| 6 | up | 6  | up | yes | none |
| 6 | up | 7  | up | yes | none |
| 6 | up | 8  | up | yes | none |
| 6 | up | 9  | up | yes | none |
| 6 | up | 10 | up | yes | none |
| 6 | up | 11 | up | yes | none |
| 6 | up | 12 | up | yes | none |
| 6 | up | 13 | up | yes | none |
| 6 | up | 14 | up | yes | none |
| 7 | up | 1  | up | yes | none |
| 7 | up | 2  | up | yes | none |
| 7 | up | 3  | up | yes | none |
| 7 | up | 4  | up | yes | none |
| 7 | up | 5  | up | yes | none |
| 7 | up | 6  | up | yes | none |
| 7 | up | 7  | up | yes | none |
| 7 | up | 8  | up | yes | none |
| 7 | up | 9  | up | yes | none |
| 7 | up | 10 | up | yes | none |
| 7 | up | 11 | up | yes | none |
| 7 | up | 12 | up | yes | none |
| 7 | up | 13 | up | yes | none |
| 7 | up | 14 | up | yes | none |
| 8 | up | 1  | up | yes | none |
| 8 | up | 2  | up | yes | none |
| 8 | up | 3  | up | yes | none |
| 8 | up | 4  | up | yes | none |
| 8 | up | 5  | up | yes | none |
| 8 | up | 6  | up | yes | none |
| 8 | up | 7  | up | yes | none |
| 8 | up | 8  | up | yes | none |
| 8 | up | 9  | up | yes | none |
| 8 | up | 10 | up | yes | none |
| 8 | up | 11 | up | yes | none |
| 8 | up | 12 | up | yes | none |
| 8 | up | 13 | up | yes | none |
| 8 | up | 14 | up | yes | none |

=====  
 Correct any mis-cabling and replace any suspected faulty equipment. Press Q to quit the test or any other key to run the test again. q  
 Test complete, clearing the SFMs to return them to normal operational state.  
 Done. Exiting test.

## stop

**Syntax** `stop [script-policy-name] [owner script-policy-owner] [all]`

**Context** `tools>perform>system>script-control>script-policy`

**Description** This command stops the execution of scripts.

**Parameters** *script-policy-name* — Only stop scripts with the specified script-policy.

## Debug Commands

**owner** *script-policy-owner* — Only stop scripts that are associated with script-policies with the specified owner.

**Default** “TiMOS CLI”

**all** — Keyword to stop all running scripts.

## customer

**Syntax** **customer** *customer-id* [**site** *customer-site-name*]

**Context** tools>perform>system>cron>tod>re-evaluate

**Description** This command is used to re-evaluate the time-of-day state of a multi-service site.

**Parameters** *customer-id* — Re-evaluate time-of-day state of a specific customer.

**Values** 1 to 2147483647

*customer-site-name* — Re-evaluate time-of-day state of a specific customer site. 32 characters max.

## filter

**Syntax** **filter** {**ip-filter** | **ipv6-filter** | **mac-filter**}

**Context** tools>perform>system>cron>tod>re-evaluate

**Description** This command is used to re-evaluate the time-of-day state of a filter entry.

**Parameters** **ip-filter** — Re-evaluate time-of-day state of an IP filter entry.

**ipv6-filter** — Re-evaluate time-of-day state of an IPv6 filter entry.

**mac-filter** — Re-evaluate time-of-day state of a MAC filter entry.

## service

**Syntax** **service** *service-id* [**sap** *sap-id*]

**Context** tools>perform>system>cron>tod>re-evaluate

**Description** This command is used to re-evaluate the time-of-day state of a SAP.

**Parameters** *service-id* — Re-evaluate time-of-day state of a specific service.

**Values** 1 to 2148007978 | *svc-name*: 64 characters max

*sap-id* — Re-evaluate time-of-day state of a specific SAP.

**Values** *sap-id* null port-id|bundle-id|bpgrp-id|lag-id|aps-id>  
dot1q port-id|bundle-id|bpgrp-id|lag-id|aps-id|pw-id>:qtag1  
qinq port-id|bundle-id|bpgrp-id|lag-id|pw-id>:qtag1.qtag2

```

atm      <port-id|aps-id>[:vpi/vci|vpi|vpi1.vpi2|cp.conn-prof-id]
         cp                      keyword
         conn-prof-id           1..8000
frame    port-id|aps-id:dldci
cisco-hdlc slot/mda/port.channel
cem      slot/mda/port.channel
ima-grp  bundle-id[:vpi/vci|vpi|vpi1.vpi2|cp.conn-prof-id]
         cp                      keyword
         conn-prof-id           1..8000
port-id  slot/mda/port[.channel]
bundle-id bundle-<type>-slot/mda.bundle-num
         bundle                  keyword
         type                    ima, fr, ppp
         bundle-num              1..336
bpgrp-id bpgrp-<type>-<bpgrp-num>
         bpgrp                  keyword
         type                    ima, ppp
         bpgrp-num              1..2000
aps-id   aps-<group-id>[.channel]
         aps                    keyword
         group-id                1..64
ccag-id  ccag-id.path-id[cc-type]<cc-id>
         ccag                   keyword
         id                      1..8
         path-id                 a, b
         cc-type                 .sap-net, .net-sap
         cc-id                   0..4094
eth-tunnel eth-tunnel-id[:eth-tun-sap-id]
         id                      1..1024
         eth-tun-sap-id         0..4094
lag-id   lag-id
         lag                    keyword
         id                      1..800
pw-id    pw-id
         pw                    keyword
         id                      1..10239
qtag1    *, 0..4094
qtag2    *|0..4094
vpi      0..4095 (NNI)
         0..255 (UNI)
vci      1, 2, 5..65535
dldci    16..1022
tunnel-id tunnel-id.private|public:tag
         tunnel                  keyword
         id                      1..16
         tag                    0..4094

```

tod-suite

## Debug Commands

**Syntax** `tod-suite [tod-suite-name]`

**Context** `tools>perform>system>cron>tod>re-evaluate`

**Description** This command is used to re-evaluate the time-of-day state for objects referring to a tod-suite.

**Parameters** *tod-suite-name* — Re-evaluate time-of-day state for all objects referring to a specific tod-suite. 32 characters maximum.

---

## Clear Commands

### redundancy

**Syntax** `redundancy`

**Context** `clear`

**Description** This command enables the context to clear redundancy parameters.

### multi-chassis

**Syntax** `multi-chassis`

**Context** `clear>redundancy`

**Description** This command enables the context to clear multi-chassis parameters.

### mc-mobile

**Syntax** `mc-mobile statistics peer {ip-address | ipv6-address}`

**Context** `clear>redundancy`

**Description** This command enables the context to clear multi-chassis parameters.

### mc-endpoint

**Syntax** `mc-endpoint endpoint [mcep-id] statistics`  
`mc-endpoint statistics`  
`mc-endpoint peer [ip-address] statistics`

**Context** `clear>redundancy>multi-chassis`

**Description** This command clears multi-chassis endpoint statistics.

**endpoint** *mcep-id* — Clears information for the specified multi-chassis endpoint ID.

**Values** 1 — 4294967295

**peer** *ip-address* — Clears information for the specified peer IP address.

**statistics** — Clears statistics for this multi-chassis endpoint.

## Clear Commands

### mc-lag

**Syntax** **mc-lag** [**peer** *ip-address* [**lag** *lag-id*]]

**Context** clear>redundancy>multi-chassis

**Description** This command clears multi-chassis Link Aggregation Group (LAG) information.

**Parameters** **peer** *ip-address* — Clears the specified address of the multi-chassis peer.

**lag** *lag-id* — Clears the specified LAG on this system.

**Values** 1 — 100

### mc-ring

**Syntax** **mc-ring**

**Context** clear>redundancy>multi-chassis

**Description** This command clears multi-chassis ring data.

### debounce

**Syntax** **debounce peer** *ip-address* **ring** *sync-tag*

**Context** clear>redundancy>multi-chassis

**Description** This command clears multi-chassis ring operational state debounce history.

**Parameters** *ip-address* — Clears debounce history for the specified IP address.

**ring** *sync-tag* — Clears debounce history for the specified sync tag.

### ring-nodes

**Syntax** **ring-nodes peer** *ip-address* **ring** *sync-tag*

**Context** clear>redundancy>multi-chassis>mcr

**Description** This command clears multi-chassis ring unreferenced ring nodes.

**Parameters** *ip-address* — Clears ring statistics for the specified IP address.

**ring** *sync-tag* — Clears ring statistics for the specified sync tag.

### statistics

**Syntax** **statistics**

**Context** clear>redundancy>multi-chassis>mcr

**Description** This command clears multi-chassis ring

## global

**Syntax** **global**

**Context** clear>redundancy>multi-chassis>mcr>statistics

**Description** This command clears multi-chassis ring global statistics.

## peer

**Syntax** **peer** *ip-address*

**Context** clear>redundancy>multi-chassis>mcr>statistics

**Description** This command clears multi-chassis ring peer statistics.

**Parameters** *ip-address* — Clears ring peer statistics for the specified IP address.

## ring

**Syntax** **ring peer** *ip-address* **ring** *sync-tag*

**Context** clear>redundancy>multi-chassis>mcr>statistics

**Description** This command clears multi-chassis ring statistics.

**Parameters** *ip-address* — Clears ring statistics for the specified IP address.

**ring** *sync-tag* — Clears ring statistics for the specified sync tag.

## ring-node

**Syntax** **ring-node peer** *ip-address* **ring** *sync-tag* **node** *ring-node-name*

**Context** clear>redundancy>multi-chassis>mcr>statistics

**Description** This command clears multi-chassis ring statistics.

**Parameters** **peer** *ip-address* — Clears ring-node peer statistics for the specified IP address.

**ring** *sync-tag* — Clears ring-node peer statistics for the specified sync-tag.

## Clear Commands

**node** *ring-node-name* — Clears ring-node peer statistics for the specified ring node name.

## sync-database

**Syntax** **sync-database peer** *ip-address* **all application** *application*  
**sync-database peer** *ip-address* {**port** *port-id* | **lag-id** | **sync-tag** *sync-tag* } **application** *application*  
**sync-database peer** *ip-address* **port** *port-id* | **lag-id** **sync-tag** *sync-tag* **application** *application*

**Context** clear>redundancy>multi-chassis

**Description** This command clears multi-chassis sync database information.

**Parameters** **peer** *ip-address* — Clears the specified address of the multi-chassis peer.

**port** *port-id* — Clears the specified port ID of the multi-chassis peer.

**port** *lag-id* — Clears the specified Link Aggregation Group (LAG) on this system.

**all** — Clears all ports and/or sync tags.

**sync-tag** *sync-tag* — Clears the synchronization tag used while synchronizing this port with the multi-chassis peer.

**application** — Clears the specified application information that was synchronized with the multi-chassis peer.

|               |                       |                                       |
|---------------|-----------------------|---------------------------------------|
| <b>Values</b> | <b>all:</b>           | All supported applications            |
|               | <b>igmp:</b>          | internet group management protocol    |
|               | <b>igmp-snooping:</b> | igmp-snooping                         |
|               | <b>mc-ring:</b>       | multi-chassis ring                    |
|               | <b>mld-snooping:</b>  | multicast listener discovery-snooping |

## screen

**Syntax** **screen**

**Context** clear

**Description** This command allows an operator to clear the Telnet or console screen.

## system

**Syntax** **system sync-if-timing** {**ref1** | **ref2** | **bits**}

**Context** clear

**Description** This command allows an operator to individually clear (re-enable) a previously failed reference. As long as the reference is one of the valid options, this command is always executed. An inherent behavior enables the revertive mode which causes a re-evaluation of all available references.

## statistics

**Syntax** **statistics**

**Context** clear>system

**Description** This command clears system specific statistics.

## xmpp

**Syntax** **xmpp server** *xmpp-server-name*

**Context** clear>system>statistics

**Description** This command clears XMPP server statistics.

## script-control

**Syntax** **script-control**

**Context** clear>system

**Description** This command enables the context to clear script information.

## script-policy

**Syntax** **script-policy**

**Context** clear>system>script-control

**Description** This command enables the context to clear script policy information.

## completed

**Syntax** **completed** [*script-policy-name*] [**owner** *owner-name*]

**Context** clear>system>script-control>script-policy

**Description** This command clears completed script run history entries.

**Parameters** *script-policy-name* — Only clear history entries for the specified script-policy.

**owner** *owner-name* — Only clear history entries for script-policies with the specified owner.

**Default** “TiMOS CLI”

## Clear Commands

### sync-if-timing

**Syntax** `system sync-if-timing {ref1 | ref2| bits}`

**Context** clear

**Description** This command allows an operator to individually clear (re-enable) a previously failed reference. As long as the reference is one of the valid options, this command is always executed. An inherent behavior enables the revertive mode which causes a re-evaluation of all available references.

**Parameters**

- ref1** — clears the first timing reference.
- ref2** — clears the second timing reference.
- bits** — Clears the bits timing reference.

### trace

**Syntax** `trace`

**Context** clear

**Description** This command clears commands for traces

### log

**Syntax** `log`

**Context** clear>trace

**Description** This command allows an operator to clear the trace log.

# Standards and Protocol Support



**Note:** The information presented is subject to change without notice.

Alcatel-Lucent assumes no responsibility for inaccuracies contained herein.

## ANCP/L2CP

RFC 5851, *Framework and Requirements for an Access Node Control Mechanism in Broadband Multi-Service Networks*

draft-ietf-ancp-protocol-02, *Protocol for Access Node Control Mechanism in Broadband Networks*

## ATM

AF-ILMI-0065.000, *Integrated Local Management Interface (ILMI) Version 4.0*

AF-PHY-0086.001, *Inverse Multiplexing for ATM (IMA) Specification Version 1.1*

AF-TM-0121.000, *Traffic Management Specification Version 4.1*

AF-TM-0150.00, *Addendum to Traffic Management v4.1 optional minimum desired cell rate indication for UBR*

GR-1113-CORE, *Asynchronous Transfer Mode (ATM) and ATM Adaptation Layer (AAL) Protocols Generic Requirements, Issue 1*

GR-1248-CORE, *Generic Requirements for Operations of ATM Network Elements (NEs), Issue 3*

ITU-T I.432.1, *B-ISDN user-network interface - Physical layer specification: General characteristics (02/99)*

ITU-T I.610, *B-ISDN operation and maintenance principles and functions (11/95)*

RFC 1626, *Default IP MTU for use over ATM AAL5*

RFC 2684, *Multiprotocol Encapsulation over ATM Adaptation Layer 5*

## BGP

RFC 1772, *Application of the Border Gateway Protocol in the Internet*

RFC 1997, *BGP Communities Attribute*

RFC 2385, *Protection of BGP Sessions via the TCP MD5 Signature Option*

RFC 2439, *BGP Route Flap Damping*

RFC 2545, *Use of BGP-4 Multiprotocol Extensions for IPv6 Inter-Domain Routing*

RFC 2858, *Multiprotocol Extensions for BGP-4*

RFC 2918, *Route Refresh Capability for BGP-4*

RFC 3107, *Carrying Label Information in BGP-4*

RFC 3392, *Capabilities Advertisement with BGP-4*

RFC 4271, *A Border Gateway Protocol 4 (BGP-4)*

RFC 4360, *BGP Extended Communities Attribute*

RFC 4364, *BGP/MPLS IP Virtual Private Networks (VPNs)*

RFC 4456, *BGP Route Reflection: An Alternative to Full Mesh Internal BGP (IBGP)*

RFC 4486, *Subcodes for BGP Cease Notification Message*

RFC 4659, *BGP/MPLS IP Virtual Private Network (VPN) Extension for IPv6 VPN*

- RFC 4684, *Constrained Route Distribution for Border Gateway Protocol/MultiProtocol Label Switching (BGP/MPLS) Internet Protocol (IP) Virtual Private Networks (VPNs)*
- RFC 4724, *Graceful Restart Mechanism for BGP (Helper Mode)*
- RFC 4760, *Multiprotocol Extensions for BGP-4*
- RFC 4798, *Connecting IPv6 Islands over IPv4 MPLS Using IPv6 Provider Edge Routers (6PE)*
- RFC 4893, *BGP Support for Four-octet AS Number Space*
- RFC 5004, *Avoid BGP Best Path Transitions from One External to Another*
- RFC 5065, *Autonomous System Confederations for BGP*
- RFC 5291, *Outbound Route Filtering Capability for BGP-4*
- RFC 5575, *Dissemination of Flow Specification Rules*
- RFC 5668, *4-Octet AS Specific BGP Extended Community*
- draft-ietf-idr-add-paths-04, *Advertisement of Multiple Paths in BGP*
- draft-ietf-idr-best-external-03, *Advertisement of the best external route in BGP*

### Circuit Emulation

- MEF-8, *Implementation Agreement for the Emulation of PDH Circuits over Metro Ethernet Networks, October 2004*
- RFC 4553, *Structure-Agnostic Time Division Multiplexing (TDM) over Packet (SAToP)*
- RFC 5086, *Structure-Aware Time Division Multiplexed (TDM) Circuit Emulation Service over Packet Switched Network (CESoPSN)*
- RFC 5287, *Control Protocol Extensions for the Setup of Time-Division Multiplexing (TDM) Pseudowires in MPLS Networks*

### Ethernet

- IEEE 802.1AB, *Station and Media Access Control Connectivity Discovery*
- IEEE 802.1ad, *Provider Bridges*
- IEEE 802.1ag, *Connectivity Fault Management*
- IEEE 802.1ah, *Provider Backbone Bridges*
- IEEE 802.1ak, *Multiple Registration Protocol*
- IEEE 802.1aq, *Shortest Path Bridging*
- IEEE 802.1ax, *Link Aggregation*
- IEEE 802.1D, *MAC Bridges*
- IEEE 802.1p, *Traffic Class Expediting*
- IEEE 802.1Q, *Virtual LANs*
- IEEE 802.1s, *Multiple Spanning Trees*
- IEEE 802.1w, *Rapid Reconfiguration of Spanning Tree*
- IEEE 802.1X, *Port Based Network Access Control*
- IEEE 802.3ab, *1000BASE-T*
- IEEE 802.3ac, *VLAN Tag*
- IEEE 802.3ad, *Link Aggregation*
- IEEE 802.3ae, *10 Gb/s Ethernet*
- IEEE 802.3ah, *Ethernet in the First Mile*
- IEEE 802.3ba, *40 Gb/s and 100 Gb/s Ethernet*
- IEEE 802.3i, *Ethernet*
- IEEE 802.3u, *Fast Ethernet*
- IEEE 802.3x, *Ethernet Flow Control*
- IEEE 802.3z, *Gigabit Ethernet*
- ITU-T G.8031, *Ethernet Linear Protection Switching*
- ITU-T G.8032, *Ethernet Ring Protection Switching*
- ITU-T Y.1731, *OAM functions and mechanisms for Ethernet based networks*

### EVPN

- RFC7432, *BGP MPLS-Based Ethernet VPN*
- draft-ietf-bess-evpn-overlay-01, *A Network Virtualization Overlay Solution using EVPN*
- draft-ietf-bess-evpn-prefix-advertisement-01, *IP Prefix Advertisement in EVPN*

draft-ietf-bess-evpn-vpls-seamless-integ-00, *(PBB-)EVPN Seamless Integration with (PBB-)VPLS*  
 draft-ietf-l2vpn-pbb-evpn-10, *Provider Backbone Bridging Combined with Ethernet VPN (PBB-EVPN)*  
 draft-snr-bess-evpn-proxy-arp-nd-00, *Proxy-ARP/ND function in EVPN networks*

## Fast Reroute

RFC 5286, *Basic Specification for IP Fast Reroute: Loop-Free Alternates*  
 RFC 7490, *Remote Loop-Free Alternate (LFA) Fast Reroute (FRR)*  
 draft-ietf-rtgwg-lfa-manageability-08, *Operational management of Loop Free Alternates*  
 draft-kastran-mofir-02, *Multicast only Fast Re-Route*

## Frame Relay

ANSI T1.617 Annex D, *DSS1 - Signalling Specification For Frame Relay Bearer Service*  
 FRF.1.2, *PVC User-to-Network Interface (UNI) Implementation Agreement*  
 FRF.12, *Frame Relay Fragmentation Implementation Agreement*  
 FRF.16.1, *Multilink Frame Relay UNI/NNI Implementation Agreement*  
 FRF.5, *Frame Relay/ATM PVC Network Interworking Implementation*  
 FRF2.2, *PVC Network-to-Network Interface (NNI) Implementation Agreement*  
 ITU-T Q.933 Annex A, *Additional procedures for Permanent Virtual Connection (PVC) status management*

## IP — General

RFC 768, *User Datagram Protocol*  
 RFC 793, *Transmission Control Protocol*  
 RFC 854, *TELNET Protocol Specifications*

RFC 951, *Bootstrap Protocol (BOOTP)*  
 RFC 1034, *Domain Names - Concepts and Facilities*  
 RFC 1035, *Domain Names - Implementation and Specification*  
 RFC 1350, *The TFTP Protocol (revision 2)*  
 RFC 1534, *Interoperation between DHCP and BOOTP*  
 RFC 1542, *Clarifications and Extensions for the Bootstrap Protocol*  
 RFC 2131, *Dynamic Host Configuration Protocol*  
 RFC 2347, *TFTP Option Extension*  
 RFC 2348, *TFTP Blocksize Option*  
 RFC 2349, *TFTP Timeout Interval and Transfer Size Options*  
 RFC 2428, *FTP Extensions for IPv6 and NATs*  
 RFC 2865, *Remote Authentication Dial In User Service (RADIUS)*  
 RFC 2866, *RADIUS Accounting*  
 RFC 2867, *RADIUS Accounting Modifications for Tunnel Protocol Support*  
 RFC 2868, *RADIUS Attributes for Tunnel Protocol Support*  
 RFC 3046, *DHCP Relay Agent Information Option (Option 82)*  
 RFC 3315, *Dynamic Host Configuration Protocol for IPv6 (DHCPv6)*  
 RFC 3596, *DNS Extensions to Support IP version 6*  
 RFC 3768, *Virtual Router Redundancy Protocol (VRRP)*  
 RFC 4250, *The Secure Shell (SSH) Protocol Assigned Numbers*  
 RFC 4251, *The Secure Shell (SSH) Protocol Architecture*  
 RFC 4254, *The Secure Shell (SSH) Connection Protocol*  
 RFC 5880, *Bidirectional Forwarding Detection (BFD)*  
 RFC 5881, *Bidirectional Forwarding Detection (BFD) IPv4 and IPv6 (Single Hop)*  
 RFC 5883, *Bidirectional Forwarding Detection (BFD) for Multihop Paths*

RFC 7130, *Bidirectional Forwarding Detection (BFD) on Link Aggregation Group (LAG) Interfaces*  
draft-grant-tacacs-02, *The TACACS+ Protocol*  
draft-ietf-vrrp-unified-spec-02, *Virtual Router Redundancy Protocol Version 3 for IPv4 and IPv6*

### IP — Multicast

RFC 1112, *Host Extensions for IP Multicasting*  
RFC 2236, *Internet Group Management Protocol, Version 2*  
RFC 2375, *IPv6 Multicast Address Assignments*  
RFC 2710, *Multicast Listener Discovery (MLD) for IPv6*  
RFC 3306, *Unicast-Prefix-based IPv6 Multicast Addresses*  
RFC 3376, *Internet Group Management Protocol, Version 3*  
RFC 3446, *Anycast Rendezvous Point (RP) mechanism using Protocol Independent Multicast (PIM) and Multicast Source Discovery Protocol (MSDP)*  
RFC 3590, *Source Address Selection for the Multicast Listener Discovery (MLD) Protocol*  
RFC 3618, *Multicast Source Discovery Protocol (MSDP)*  
RFC 3810, *Multicast Listener Discovery Version 2 (MLDv2) for IPv6*  
RFC 3956, *Embedding the Rendezvous Point (RP) Address in an IPv6 Multicast Address*  
RFC 4601, *Protocol Independent Multicast - Sparse Mode (PIM-SM): Protocol Specification (Revised)*  
RFC 4604, *Using Internet Group Management Protocol Version 3 (IGMPv3) and Multicast Listener Discovery Protocol Version 2 (MLDv2) for Source-Specific Multicast*  
RFC 4607, *Source-Specific Multicast for IP*  
RFC 4608, *Source-Specific Protocol Independent Multicast in 232/8*

RFC 4610, *Anycast-RP Using Protocol Independent Multicast (PIM)*  
RFC 5059, *Bootstrap Router (BSR) Mechanism for Protocol Independent Multicast (PIM)*  
RFC 5384, *The Protocol Independent Multicast (PIM) Join Attribute Format*  
RFC 5496, *The Reverse Path Forwarding (RPF) Vector TLV*  
RFC 6037, *Cisco Systems' Solution for Multicast in MPLS/BGP IP VPNs*  
RFC 6513, *Multicast in MPLS/BGP IP VPNs*  
RFC 6514, *BGP Encodings and Procedures for Multicast in MPLS/IP VPNs*  
RFC 6515, *IPv4 and IPv6 Infrastructure Addresses in BGP Updates for Multicast VPNs*  
RFC 6516, *IPv6 Multicast VPN (MVPN) Support Using PIM Control Plane and Selective Provider Multicast Service Interface (S-PMSI) Join Messages*  
RFC 6625, *Wildcards in Multicast VPN Auto-Discover Routes*  
RFC 6826, *Multipoint LDP In-Band Signaling for Point-to-Multipoint and Multipoint-to-Multipoint Label Switched Path*  
RFC 7246, *Multipoint Label Distribution Protocol In-Band Signaling in a Virtual Routing and Forwarding (VRF) Table Context*  
RFC 7385, *IANA Registry for P-Multicast Service Interface (PMSI) Tunnel Type Code Points*  
draft-dolganow-l3vpn-mvpn-expl-track-00, *Explicit tracking in MPLS/BGP IP VPNs*

### IP — Version 4

RFC 791, *Internet Protocol*  
RFC 792, *Internet Control Message Protocol*  
RFC 826, *An Ethernet Address Resolution Protocol*  
RFC 1519, *Classless Inter-Domain Routing (CIDR): an Address Assignment and Aggregation Strategy*  
RFC 1812, *Requirements for IPv4 Routers*  
RFC 2401, *Security Architecture for Internet Protocol*

RFC 3021, *Using 31-Bit Prefixes on IPv4 Point-to-Point Links*

## IP — Version 6

RFC 1981, *Path MTU Discovery for IP version 6*

RFC 2460, *Internet Protocol, Version 6 (IPv6) Specification*

RFC 2464, *Transmission of IPv6 Packets over Ethernet Networks*

RFC 2529, *Transmission of IPv6 over IPv4 Domains without Explicit Tunnels*

RFC 3587, *IPv6 Global Unicast Address Format*

RFC 3633, *IPv6 Prefix Options for Dynamic Host Configuration Protocol (DHCP) version 6*

RFC 3646, *DNS Configuration options for Dynamic Host Configuration Protocol for IPv6 (DHCPv6)*

RFC 3736, *Stateless Dynamic Host Configuration Protocol (DHCP) Service for IPv6*

RFC 3971, *SEcure Neighbor Discovery (SEND)*

RFC 3972, *Cryptographically Generated Addresses (CGA)*

RFC 4007, *IPv6 Scoped Address Architecture*

RFC 4193, *Unique Local IPv6 Unicast Addresses*

RFC 4291, *Internet Protocol Version 6 (IPv6) Addressing Architecture*

RFC 4443, *Internet Control Message Protocol (ICMPv6) for the Internet Protocol Version 6 (IPv6) Specification*

RFC 4861, *Neighbor Discovery for IP version 6 (IPv6)*

RFC 4862, *IPv6 Stateless Address Autoconfiguration (Router Only)*

RFC 4941, *Privacy Extensions for Stateless Address Autoconfiguration in IPv6*

RFC 5007, *DHCPv6 Leasequery*

RFC 5095, *Deprecation of Type 0 Routing Headers in IPv6*

RFC 5952, *A Recommendation for IPv6 Address Text Representation*

RFC 6106, *IPv6 Router Advertisement Options for DNS Configuration*

RFC 6164, *Using 127-Bit IPv6 Prefixes on Inter-Router Links*

## IPsec

RFC 2401, *Security Architecture for the Internet Protocol*

RFC 2406, *IP Encapsulating Security Payload (ESP)*

RFC 2409, *The Internet Key Exchange (IKE)*

RFC 2560, *X.509 Internet Public Key Infrastructure Online Certificate Status Protocol - OCSP*

RFC 3706, *A Traffic-Based Method of Detecting Dead Internet Key Exchange (IKE) Peers*

RFC 3947, *Negotiation of NAT-Traversal in the IKE*

RFC 3948, *UDP Encapsulation of IPsec ESP Packets*

RFC 4210, *Internet X.509 Public Key Infrastructure Certificate Management Protocol (CMP)*

RFC 4211, *Internet X.509 Public Key Infrastructure Certificate Request Message Format (CRMF)*

RFC 5996, *Internet Key Exchange Protocol Version 2 (IKEv2)*

RFC 5998, *An Extension for EAP-Only Authentication in IKEv2*

draft-ietf-ipsec-isakmp-mode-cfg-05, *The ISAKMP Configuration Method*

draft-ietf-ipsec-isakmp-xauth-06, *Extended Authentication within ISAKMP/Oakley (XAUTH)*

## IS-IS

ISO/IEC 10589:2002, Second Edition, Nov. 2002, *Intermediate system to Intermediate system intra-domain routeing information exchange protocol for use in conjunction with the protocol for providing the connectionless-mode Network Service (ISO 8473)*

RFC 1195, *Use of OSI IS-IS for Routing in TCP/IP and Dual Environments*

## Standards and Protocol Support

RFC 2973, *IS-IS Mesh Groups*  
RFC 3359, *Reserved Type, Length and Value (TLV) Codepoints in Intermediate System to Intermediate System*  
RFC 3719, *Recommendations for Interoperable Networks using Intermediate System to Intermediate System (IS-IS)*  
RFC 3787, *Recommendations for Interoperable IP Networks using Intermediate System to Intermediate System (IS-IS)*  
RFC 4971, *Intermediate System to Intermediate System (IS-IS) Extensions for Advertising Router Information*  
RFC 5120, *M-ISIS: Multi Topology (MT) Routing in IS-IS*  
RFC 5130, *A Policy Control Mechanism in IS-IS Using Administrative Tags*  
RFC 5301, *Dynamic Hostname Exchange Mechanism for IS-IS*  
RFC 5302, *Domain-wide Prefix Distribution with Two-Level IS-IS*  
RFC 5303, *Three-Way Handshake for IS-IS Point-to-Point Adjacencies*  
RFC 5304, *IS-IS Cryptographic Authentication*  
RFC 5305, *IS-IS Extensions for Traffic Engineering TE*  
RFC 5306, *Restart Signaling for IS-IS (Helper Mode)*  
RFC 5307, *IS-IS Extensions in Support of Generalized Multi-Protocol Label Switching (GMPLS)*  
RFC 5308, *Routing IPv6 with IS-IS*  
RFC 5309, *Point-to-Point Operation over LAN in Link State Routing Protocols*  
RFC 5310, *IS-IS Generic Cryptographic Authentication*  
RFC 6213, *IS-IS BFD-Enabled TLV*  
RFC 6232, *Purge Originator Identification TLV for IS-IS*  
RFC 6233, *IS-IS Registry Extension for Purges*  
RFC 6329, *IS-IS Extensions Supporting IEEE 802.1aq Shortest Path Bridging*  
draft-ietf-isis-mi-02, *IS-IS Multi-Instance*

draft-ietf-isis-segment-routing-extensions-04, *IS-IS Extensions for Segment Routing*  
draft-kaplan-isis-ext-eth-02, *Extended Ethernet Frame Size Support*

## Management

ianaaddressfamilynumbers-mib, *IANA-ADDRESS-FAMILY-NUMBERS-MIB*  
ianagmplstc-mib, *IANA-GMPLS-TC-MIB*  
ianaiftype-mib, *IANAifType-MIB*  
ianaiprouteprotocol-mib, *IANA-RTPROTO-MIB*  
IEEE8021-CFM-MIB, *IEEE P802.1ag(TM) CFM MIB*  
IEEE8021-PAE-MIB, *IEEE 802.1X MIB*  
IEEE8023-LAG-MIB, *IEEE 802.3ad MIB*  
LLDP-MIB, *IEEE P802.1AB(TM) LLDP MIB*  
SFLOW-MIB, *sFlow MIB Version 1.3 (Draft 5)*  
RFC 1157, *A Simple Network Management Protocol (SNMP)*  
RFC 1215, *A Convention for Defining Traps for use with the SNMP*  
RFC 1724, *RIP Version 2 MIB Extension*  
RFC 2021, *Remote Network Monitoring Management Information Base Version 2 using SMIPv2*  
RFC 2115, *Management Information Base for Frame Relay DTEs Using SMIPv2*  
RFC 2138, *Remote Authentication Dial In User Service (RADIUS)*  
RFC 2206, *RSVP Management Information Base using SMIPv2*  
RFC 2213, *Integrated Services Management Information Base using SMIPv2*  
RFC 2494, *Definitions of Managed Objects for the DS0 and DS0 Bundle Interface Type*  
RFC 2514, *Definitions of Textual Conventions and OBJECT-IDENTITIES for ATM Management*  
RFC 2515, *Definitions of Managed Objects for ATM Management*  
RFC 2571, *An Architecture for Describing SNMP Management Frameworks*

- RFC 2572, *Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)*
- RFC 2573, *SNMP Applications*
- RFC 2574, *User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)*
- RFC 2575, *View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)*
- RFC 2578, *Structure of Management Information Version 2 (SMIv2)*
- RFC 2579, *Textual Conventions for SMIv2*
- RFC 2787, *Definitions of Managed Objects for the Virtual Router Redundancy Protocol*
- RFC 2819, *Remote Network Monitoring Management Information Base*
- RFC 2856, *Textual Conventions for Additional High Capacity Data Types*
- RFC 2863, *The Interfaces Group MIB*
- RFC 2864, *The Inverted Stack Table Extension to the Interfaces Group MIB*
- RFC 2933, *Internet Group Management Protocol MIB*
- RFC 3014, *Notification Log MIB*
- RFC 3164, *The BSD syslog Protocol*
- RFC 3165, *Definitions of Managed Objects for the Delegation of Management Scripts*
- RFC 3231, *Definitions of Managed Objects for Scheduling Management Operations*
- RFC 3273, *Remote Network Monitoring Management Information Base for High Capacity Networks*
- RFC 3419, *Textual Conventions for Transport Addresses*
- RFC 3498, *Definitions of Managed Objects for Synchronous Optical Network (SONET) Linear Automatic Protection Switching (APS) Architectures*
- RFC 3584, *Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework*
- RFC 3592, *Definitions of Managed Objects for the Synchronous Optical Network/Synchronous Digital Hierarchy (SONET/SDH) Interface Type*
- RFC 3593, *Textual Conventions for MIB Modules Using Performance History Based on 15 Minute Intervals*
- RFC 3635, *Definitions of Managed Objects for the Ethernet-like Interface Types*
- RFC 3637, *Definitions of Managed Objects for the Ethernet WAN Interface Sublayer*
- RFC 3826, *The Advanced Encryption Standard (AES) Cipher Algorithm in the SNMP User-based Security Model*
- RFC 3877, *Alarm Management Information Base (MIB)*
- RFC 3895, *Definitions of Managed Objects for the DS1, E1, DS2, and E2 Interface Types*
- RFC 3896, *Definitions of Managed Objects for the DS3/E3 Interface Type*
- RFC 4001, *Textual Conventions for Internet Network Addresses*
- RFC 4022, *Management Information Base for the Transmission Control Protocol (TCP)*
- RFC 4113, *Management Information Base for the User Datagram Protocol (UDP)*
- RFC 4220, *Traffic Engineering Link Management Information Base*
- RFC 4292, *IP Forwarding Table MIB*
- RFC 4293, *Management Information Base for the Internet Protocol (IP)*
- RFC 4631, *Link Management Protocol (LMP) Management Information Base (MIB)*
- RFC 4878, *Definitions and Managed Objects for Operations, Administration, and Maintenance (OAM) Functions on Ethernet-Like Interfaces*
- RFC 5101, *Specification of the IP Flow Information Export (IPFIX) Protocol for the Exchange of IP Traffic Flow Information*
- RFC 6241, *Network Configuration Protocol (NETCONF)*

- RFC 6242, *Using the NETCONF Protocol over Secure Shell (SSH)*
- draft-ietf-snmpv3-update-mib-05, *Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)*
- draft-ietf-idr-bgp4-mib-05, *Definitions of Managed Objects for the Fourth Version of Border Gateway Protocol (BGP-4)*
- draft-ietf-isis-wg-mib-06, *Management Information Base for Intermediate System to Intermediate System (IS-IS)*
- draft-ietf-mboned-msdp-mib-01, *Multicast Source Discovery protocol MIB*
- draft-ietf-mppls-ldp-mib-07, *Definitions of Managed Objects for the Multiprotocol Label Switching, Label Distribution Protocol (LDP)*
- draft-ietf-mppls-lsr-mib-06, *Multiprotocol Label Switching (MPLS) Label Switching Router (LSR) Management Information Base Using SMIPv2*
- draft-ietf-mppls-te-mib-04, *Multiprotocol Label Switching (MPLS) Traffic Engineering Management Information Base*
- draft-ietf-ospf-mib-update-08, *OSPF Version 2 Management Information Base*

### MPLS — General

- RFC 3031, *Multiprotocol Label Switching Architecture*
- RFC 3032, *MPLS Label Stack Encoding*
- RFC 3443, *Time To Live (TTL) Processing in Multiprotocol Label Switching (MPLS) Networks*
- RFC 4023, *Encapsulating MPLS in IP or Generic Routing Encapsulation (GRE)*
- RFC 4182, *Removing a Restriction on the use of MPLS Explicit NULL*
- RFC 5332, *MPLS Multicast Encapsulations*

### MPLS — GMPLS

- RFC 3471, *Generalized Multi-Protocol Label Switching (GMPLS) Signaling Functional Description*
- RFC 3473, *Generalized Multi-Protocol Label Switching (GMPLS) Signaling Resource ReserVation Protocol-Traffic Engineering (RSVP-TE) Extensions*
- RFC 4204, *Link Management Protocol (LMP)*
- RFC 4208, *Generalized Multiprotocol Label Switching (GMPLS) User-Network Interface (UNI): Resource ReserVation Protocol-Traffic Engineering (RSVP-TE) Support for the Overlay Model*
- RFC 4872, *RSVP-TE Extensions in Support of End-to-End Generalized Multi-Protocol Label Switching (GMPLS) Recovery*
- draft-ietf-ccamp-rsvp-te-srlg-collect-04, *RSVP-TE Extensions for Collecting SRLG Information*

### MPLS — LDP

- RFC 3037, *LDP Applicability*
- RFC 3478, *Graceful Restart Mechanism for Label Distribution Protocol (Helper Mode)*
- RFC 5036, *LDP Specification*
- RFC 5283, *LDP Extension for Inter-Area Label Switched Paths (LSPs)*
- RFC 5443, *LDP IGP Synchronization*
- RFC 5561, *LDP Capabilities*
- RFC 6388, *Label Distribution Protocol Extensions for Point-to-Multipoint and Multipoint-to-Multipoint Label Switched Paths*
- RFC 6826, *Multipoint LDP in-band signaling for Point-to-Multipoint and Multipoint-to-Multipoint Label Switched Paths*
- draft-ietf-mppls-ldp-ip-pw-capability-09, *Controlling State Advertisements Of Non-negotiated LDP Applications*
- draft-ietf-mppls-ldp-ipv6-15, *Updates to LDP for IPv6*

draft-pdutta-mpls-ldp-adj-capability-00, *LDP Adjacency Capabilities*  
 draft-pdutta-mpls-ldp-v2-00, *LDP Version 2*  
 draft-pdutta-mpls-multi-ldp-instance-00, *Multiple LDP Instances*  
 draft-pdutta-mpls-tldp-hello-reduce-04, *Targeted LDP Hello Reduction*

## MPLS — MPLS-TP

RFC 5586, *MPLS Generic Associated Channel*  
 RFC 5921, *A Framework for MPLS in Transport Networks*  
 RFC 5960, *MPLS Transport Profile Data Plane Architecture*  
 RFC 6370, *MPLS Transport Profile (MPLS-TP) Identifiers*  
 RFC 6378, *MPLS Transport Profile (MPLS-TP) Linear Protection*  
 RFC 6426, *MPLS On-Demand Connectivity and Route Tracing*  
 RFC 6428, *Proactive Connectivity Verification, Continuity Check and Remote Defect indication for MPLS Transport Profile*  
 RFC 6478, *Pseudowire Status for Static Pseudowires*  
 RFC 7213, *MPLS Transport Profile (MPLS-TP) Next-Hop Ethernet Addressing*

## MPLS — OAM

RFC 4379, *Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures*  
 RFC 6424, *Mechanism for Performing Label Switched Path Ping (LSP Ping) over MPLS Tunnels*  
 RFC 6425, *Detecting Data Plane Failures in Point-to-Multipoint Multiprotocol Label Switching (MPLS) - Extensions to LSP Ping*

## MPLS — RSVP-TE

RFC 2702, *Requirements for Traffic Engineering over MPLS*

RFC 2747, *RSVP Cryptographic Authentication*  
 RFC 2961, *RSVP Refresh Overhead Reduction Extensions*  
 RFC 3097, *RSVP Cryptographic Authentication -- Updated Message Type Value*  
 RFC 3209, *RSVP-TE: Extensions to RSVP for LSP Tunnels*  
 RFC 3473, *Generalized Multi-Protocol Label Switching (GMPLS) Signaling Resource ReserVation Protocol-Traffic Engineering (RSVP-TE) Extensions (IF\_ID RSVP\_HOP Object With Unnumbered Interfaces and RSVP-TE Graceful Restart Helper Procedures)*  
 RFC 3477, *Signalling Unnumbered Links in Resource ReSerVation Protocol - Traffic Engineering (RSVP-TE)*  
 RFC 3564, *Requirements for Support of Differentiated Services-aware MPLS Traffic Engineering*  
 RFC 3906, *Calculating Interior Gateway Protocol (IGP) Routes Over Traffic Engineering Tunnels*  
 RFC 4090, *Fast Reroute Extensions to RSVP-TE for LSP Tunnels*  
 RFC 4124, *Protocol Extensions for Support of DiffServ-aware MPLS Traffic Engineering*  
 RFC 4125, *Maximum Allocation Bandwidth Constraints Model for DiffServ-aware MPLS Traffic Engineering*  
 RFC 4127, *Russian Dolls Bandwidth Constraints Model for DiffServ-aware MPLS Traffic Engineering*  
 RFC 4561, *Definition of a Record Route Object (RRO) Node-Id Sub-Object*  
 RFC 4875, *Extensions to Resource Reservation Protocol - Traffic Engineering (RSVP-TE) for Point-to-Multipoint TE Label Switched Paths (LSPs)*  
 RFC 4950, *ICMP Extensions for Multiprotocol Label Switching*  
 RFC 5151, *Inter-Domain MPLS and GMPLS Traffic Engineering -- Resource Reservation Protocol-Traffic Engineering (RSVP-TE) Extensions*  
 RFC 5712, *MPLS Traffic Engineering Soft Preemption*

## Standards and Protocol Support

RFC 5817, *Graceful Shutdown in MPLS and Generalized MPLS Traffic Engineering Networks*

draft-newton-mpls-te-dynamic-overbooking-00, *A Diffserv-TE Implementation Model to dynamically change booking factors during failure events*

### NAT

RFC 5382, *NAT Behavioral Requirements for TCP*

RFC 5508, *NAT Behavioral Requirements for ICMP*

RFC 6146, *Stateful NAT64: Network Address and Protocol Translation from IPv6 Clients to IPv4 Servers*

RFC 6333, *Dual-Stack Lite Broadband Deployments Following IPv4 Exhaustion*

RFC 6334, *Dynamic Host Configuration Protocol for IPv6 (DHCPv6) Option for Dual-Stack Lite*

RFC 6888, *Common Requirements For Carrier-Grade NATs (CGNs)*

### OpenFlow

ONF *OpenFlow Switch Specification Version 1.3.1* (OpenFlow-hybrid switches)

### OSPF

RFC 1586, *Guidelines for Running OSPF Over Frame Relay Networks*

RFC 1765, *OSPF Database Overflow*

RFC 2328, *OSPF Version 2*

RFC 3101, *The OSPF Not-So-Stubby Area (NSSA) Option*

RFC 3509, *Alternative Implementations of OSPF Area Border Routers*

RFC 3623, *Graceful OSPF Restart Graceful OSPF Restart (Helper Mode)*

RFC 3630, *Traffic Engineering (TE) Extensions to OSPF Version 2*

RFC 4203, *OSPF Extensions in Support of Generalized Multi-Protocol Label Switching (GMPLS)*

RFC 4222, *Prioritized Treatment of Specific OSPF Version 2 Packets and Congestion Avoidance*

RFC 4552, *Authentication/Confidentiality for OSPFv3*

RFC 4576, *Using a Link State Advertisement (LSA) Options Bit to Prevent Looping in BGP/MPLS IP Virtual Private Networks (VPNs)*

RFC 4577, *OSPF as the Provider/Customer Edge Protocol for BGP/MPLS IP Virtual Private Networks (VPNs)*

RFC 4970, *Extensions to OSPF for Advertising Optional Router Capabilities*

RFC 5185, *OSPF Multi-Area Adjacency*

RFC 5187, *OSPFv3 Graceful Restart (Helper Mode)*

RFC 5243, *OSPF Database Exchange Summary List Optimization*

RFC 5250, *The OSPF Opaque LSA Option*

RFC 5309, *Point-to-Point Operation over LAN in Link State Routing Protocols*

RFC 5340, *OSPF for IPv6*

RFC 5709, *OSPFv2 HMAC-SHA Cryptographic Authentication*

RFC 5838, *Support of Address Families in OSPFv3*

RFC 6987, *OSPF Stub Router Advertisement*

draft-ietf-ospf-prefix-link-attr-06, *OSPFv2 Prefix/Link Attribute Advertisement*

draft-ietf-ospf-segment-routing-extensions-04, *OSPF Extensions for Segment Routing*

### Policy Management and Credit Control

3GPP TS 29.212, *Policy and Charging Control (PCC) over Gx/Sd Reference Point (Release 11 and Release 12) Gx support as it applies to wireline environment (BNG)*

RFC 3588, *Diameter Base Protocol*

RFC 4006, *Diameter Credit-Control Application*

**PPP**

- RFC 1332, *The PPP Internet Protocol Control Protocol (IPCP)*
- RFC 1377, *The PPP OSI Network Layer Control Protocol (OSINLCP)*
- RFC 1661, *The Point-to-Point Protocol (PPP)*
- RFC 1662, *PPP in HDLC-like Framing*
- RFC 1877, *PPP Internet Protocol Control Protocol Extensions for Name Server Addresses*
- RFC 1989, *PPP Link Quality Monitoring*
- RFC 1990, *The PPP Multilink Protocol (MP)*
- RFC 1994, *PPP Challenge Handshake Authentication Protocol (CHAP)*
- RFC 2153, *PPP Vendor Extensions*
- RFC 2516, *A Method for Transmitting PPP Over Ethernet (PPPoE)*
- RFC 2615, *PPP over SONET/SDH*
- RFC 2661, *Layer Two Tunneling Protocol "L2TP"*
- RFC 2686, *The Multi-Class Extension to Multi-Link PPP*
- RFC 2878, *PPP Bridging Control Protocol (BCP)*
- RFC 4951, *Fail Over Extensions for Layer 2 Tunneling Protocol (L2TP) "failover"*
- RFC 5072, *IP Version 6 over PPP*

**Pseudowire**

- MFA Forum 9.0.0, *The Use of Virtual trunks for ATM/MPLS Control Plane Interworking*
- MFA Forum 12.0.0, *Multiservice Interworking - Ethernet over MPLS*
- MFA Forum 13.0.0, *Fault Management for Multiservice Interworking v1.0*
- MFA Forum 16.0.0, *Multiservice Interworking - IP over MPLS*
- RFC 3916, *Requirements for Pseudo- Wire Emulation Edge-to-Edge (PWE3)*
- RFC 3985, *Pseudo Wire Emulation Edge-to-Edge (PWE3)*

- RFC 4385, *Pseudo Wire Emulation Edge-to-Edge (PWE3) Control Word for Use over an MPLS PSN*
- RFC 4446, *IANA Allocations for Pseudowire Edge to Edge Emulation (PWE3)*
- RFC 4447, *Pseudowire Setup and Maintenance Using the Label Distribution Protocol (LDP)*
- RFC 4448, *Encapsulation Methods for Transport of Ethernet over MPLS Networks*
- RFC 4619, *Encapsulation Methods for Transport of Frame Relay over Multiprotocol Label Switching (MPLS) Networks*
- RFC 4717, *Encapsulation Methods for Transport Asynchronous Transfer Mode (ATM) over MPLS Networks*
- RFC 4816, *Pseudowire Emulation Edge-to-Edge (PWE3) Asynchronous Transfer Mode (ATM) Transparent Cell Transport Service*
- RFC 5085, *Pseudowire Virtual Circuit Connectivity Verification (VCCV): A Control Channel for Pseudowires*
- RFC 5659, *An Architecture for Multi-Segment Pseudowire Emulation Edge-to-Edge*
- RFC 5885, *Bidirectional Forwarding Detection (BFD) for the Pseudowire Virtual Circuit Connectivity Verification (VCCV)*
- RFC 6073, *Segmented Pseudowire*
- RFC 6310, *Pseudowire (PW) Operations, Administration, and Maintenance (OAM) Message Mapping*
- RFC 6391, *Flow-Aware Transport of Pseudowires over an MPLS Packet Switched Network*
- RFC 6575, *Address Resolution Protocol (ARP) Mediation for IP Interworking of Layer 2 VPNs*
- RFC 6718, *Pseudowire Redundancy*
- RFC 6829, *Label Switched Path (LSP) Ping for Pseudowire Forwarding Equivalence Classes (FECs) Advertised over IPv6*
- RFC 6870, *Pseudowire Preferential Forwarding Status bit*

- RFC 7023, *MPLS and Ethernet Operations, Administration, and Maintenance (OAM) Interworking*
- RFC 7267, *Dynamic Placement of Multi-Segment Pseudowires*
- draft-ietf-l2vpn-vpws-iw-oam-04, *OAM Procedures for VPWS Interworking*

### Quality of Service

- RFC 2430, *A Provider Architecture for Differentiated Services and Traffic Engineering (PASTE)*
- RFC 2474, *Definition of the Differentiated Services Field (DS Field) in the IPv4 and IPv6 Headers*
- RFC 3260, *New Terminology and Clarifications for Diffserv*
- RFC 2598, *An Expedited Forwarding PHB*
- RFC 3140, *Per Hop Behavior Identification Codes*

### RIP

- RFC 1058, *Routing Information Protocol*
- RFC 2080, *RIPng for IPv6*
- RFC 2082, *RIP-2 MD5 Authentication*
- RFC 2453, *RIP Version 2*

### SONET/SDH

- ITU-G.841, *Types and Characteristics of SDH Networks Protection Architecture, issued in October 1998 and as augmented by Corrigendum 1, issued in July 2002*

### Timing

- GR-1244-CORE, *Clocks for the Synchronized Network: Common Generic Criteria, Issue 3, May 2005*
- GR-253-CORE, *SONET Transport Systems: Common Generic Criteria. Issue 3, September 2000*
- ITU-T G.781, *Synchronization layer functions, issued 09/2008*

- ITU-T G.813, *Timing characteristics of SDH equipment slave clocks (SEC), issued 03/2003*
- ITU-T G.8261, *Timing and synchronization aspects in packet networks, issued 04/2008*
- ITU-T G.8262, *Timing characteristics of synchronous Ethernet equipment slave clock (EEC), issued 08/2007*
- ITU-T G.8264, *Distribution of timing information through packet networks, issued 10/2008*
- ITU-T G.8265.1, *Precision time protocol telecom profile for frequency synchronization, issued 10/2010*
- ITU-T G.8275.1, *Precision time protocol telecom profile for phase/time synchronization with full timing support from the network, issued 07/2014*
- RFC 5905, *Network Time Protocol Version 4: Protocol and Algorithms Specification*

### Voice and Video Performance

- ETSI TS 101 329-5 Annex E, *QoS Measurement for VoIP - Method for determining an Equipment Impairment Factor using Passive Monitoring*
- ITU-T G.1020 Appendix I, *Performance Parameter Definitions for Quality of Speech and other Voiceband Applications Utilizing IP Networks - Mean Absolute Packet Delay Variation & Markov Models*
- ITU-T G.107, *The E Model - A computational model for use in planning*
- ITU-T P.564, *Conformance testing for voice over IP transmission quality assessment models*
- RFC 3550 Appendix A.8, *RTP: A Transport Protocol for Real-Time Applications (Estimating the Interarrival Jitter)*

### VPLS

- RFC 4761, *Virtual Private LAN Service (VPLS) Using BGP for Auto-Discovery and Signaling*
- RFC 4762, *Virtual Private LAN Service (VPLS) Using Label Distribution Protocol (LDP) Signaling*

RFC 5501, *Requirements for Multicast Support in Virtual Private LAN Services*

RFC 6074, *Provisioning, Auto-Discovery, and Signaling in Layer 2 Virtual Private Networks (L2VPNs)*

RFC 7041, *Extensions to the Virtual Private LAN Service (VPLS) Provider Edge (PE) Model for Provider Backbone Bridging*

RFC 7117, *Multicast in Virtual Private LAN Service (VPLS)*



# Customer Documentation and Product Support



## Customer Documentation

<http://documentation.alcatel-lucent.com>



## Technical Support

<http://support.alcatel-lucent.com>



## Documentation Feedback

[documentation.feedback@alcatel-lucent.com](mailto:documentation.feedback@alcatel-lucent.com)

