

---

# MLPPP Command Reference

---

## Command Hierarchies

### Configuration Commands

```

config
  — qos
    — mlppp-profile-egress profile-id [create]
    — no mlppp-profile-egress profile-id
      — class class-id
        — max-queue-size queue-size
        — no max-queue-size
        — mir mir-value
        — no mir
        — weight weight-value
        — no weight
        — description description-string
        — no description
        — fc fc-class mlppp-class class-id
        — no fc fc-class
    — mlppp-profile-ingress profile-id [create]
    — no mlppp-profile-ingress profile-id
      — class class-id
        — reassemble-timeout timeout-value
        — no reassemble-timeout
        — description description-string
        — no description

```

