

Network Queue QoS Policy Command Reference

Command Hierarchies

- [Configuration Commands on page 141](#)
- [Operational Commands on page 142](#)
- [Show Commands on page 142](#)

Configuration Commands

```
config
  — qos
    — network-queue policy-name
      — description description-string
      — no description
      — egress-hsmda
        — [no] wrr-policy {add add-bytes | subtract sub-bytes}
        — [no] packet-byte-offset
        — [no] queue queue-id
          — [no] adaptation-rule [pir {min | max | closest}]
          — percent-rate percentage
          — wrr-weight value
          — mbs {size [bytes | kilobytes] | default}
          — slope-policy hsmda-slope-policy-name
        — [no] fc fc-name
          — multicast-queue queue-id
          — no multicast-queue
          — queue queue-id
          — no queue
          — egress-hsmda
            — [no] queue
        — queue queue-id [multipoint] [queue-type] [create]
        — no queue queue-id
          — adaptation-rule [pir adaptation-rule] [cir adaptation-rule]
          — no adaptation-rule
          — avg-frame-overhead percent
          — no avg-frame-overhead
          — cbs percent
          — no cbs
          — high-prio-only percent
          — no high-prio-only
          — mbs percent
          — no mbs
          — [no] pool pool-name
          — port-parent [weight weight] [level level] [cir-weight cir-weight] [cir-level cir-level] [cir-level level] [cir-weight weight]
          — no port-parent
          — rate percent [cir percent]
          — no rate
```

Operational Commands

```
config
  — qos
    — copy network-queue src-name dst-name [overwrite]
```

Show Commands

```
show
  — qos
    — network-queue [network-queue-policy-name] [detail]
```