
Basic CLI Commands

Global Commands

enable-admin

Syntax **enable-admin**

Context <global>

Description **NOTE:** See the description for the **admin-password** command. If the **admin-password** is configured in the **config>system>security>password** context, then any user can enter a special administrative mode by entering the **enable-admin** command.

enable-admin is in the default profile. By default, all users are given access to this command.

Once the **enable-admin** command is entered, the user is prompted for a password. If the password matches, the user is given unrestricted access to all the commands.

The minimum length of the password is determined by the **minimum-length** command. The complexity requirements for the password is determined by the **complexity** command.

The following displays a password configuration example:

```
A:ALA-1>config>system>security# info
-----
...
    password
    aging 365
    minimum-length 8
    attempts 5 time 5 lockout 20
    admin-password "rUYUz9XM06I" hash
    exit
...
-----
A:ALA-1>config>system>security#
```

There are two ways to verify that a user is in the enable-admin mode:

- `show users` – Administrator can know which users are in this mode.
- Enter the `enable-admin` command again at the root prompt and an error message will be returned.

```
A:ALA-1# show users
=====
User Type From Login time Idle time
=====
admin Console -- 10AUG2006 13:55:24 0d 19:42:22
admin Telnet 10.20.30.93 09AUG2004 08:35:23 0d 00:00:00 A
=====
Number of users : 2
'A' indicates user is in admin mode
=====
A:ALA-1#
A:ALA-1# enable-admin
MINOR: CLI Already in admin mode.
A:ALA-1#
```

back

Syntax `back`

Context <GLOBAL>

Description This command moves the context back one level of the command hierarchy. For example, if the current level is the `config router ospf` context, the `back` command moves the cursor to the `config router` context level.

clear

Syntax `clear`

Context <GLOBAL>

Description This command clears statistics for a specified entity or clears and resets the entity.

Parameters

- `card` — Reinitializes a I/O module in the specified slot.
- `cflowd` — Clears cflowd.
- `cpm-filter` — Clears IP filter entry IDs.
- `cron` — Clears CRON history.
- `filter` — Clears IP, MAC, and log filter counters.
- `lag` — Clears LAG-related entities.
- `log` — Closes and reinitializes the log specified by log-id.
- `mda` — Reinitializes the specified MDA in a particular slot.
- `port` — Clears port statistics.

qos — Clears QoS statistics.

radius — Clears the RADIUS server state.

router — Clears router commands affecting the router instance in which they are entered.

Values arp, authentication, bgp, bfd, dhcp, dhcp6, forwarding-table, icmp-redirect-route, icmp6, igmp, interface, isis, ldp, mpls, neighbor, ospf, ospf3, pim, rip, router-advertisement, rsvp

saa — Clears the SAA test results.

screen — Clears the console or telnet screen.

service — Clears service ID and statistical entities.

subscriber-mgmt — Clears subscriber management data.

system — Clears (re-enables) a previously failed reference.

tacplus — Clears the TACACS+ server state.

trace — Clears the trace log.

vrrp — Clears and resets the VRRP interface and statistical entities.

echo

Syntax **echo** [*text-to-echo*] [*extra-text-to-echo*] [*more-text*]

Context <GLOBAL>

Description This command echoes arguments on the command line. The primary use of this command is to allow messages to be displayed to the screen in files executed with the **exec** command.

Parameters *text-to-echo* — Specifies a text string to be echoed up to 256 characters.

extra-text-to-echo — Specifies more text to be echoed up to 256 characters.

more-text — Specifies more text to be echoed up to 256 characters.

exec

Syntax **exec** [-**echo**] [-**syntax**] {*filename* | <<[*eof_string*]}

Context <GLOBAL>

Description This command executes the contents of a text file as if they were CLI commands entered at the console. Exec commands do not have **no** versions.

Parameters -**echo** — Echo the contents of the **exec** file to the session screen as it executes.

Default Echo disabled.

-**syntax** — Perform a syntax check of the file without executing the commands. Syntax checking will be able to find invalid commands and keywords, but it will not be able to validate erroneous user-supplied parameters.

Default Execute file commands.

filename — The text file with CLI commands to execute.

<< — Stdin can be used as the source of commands for the exec command. When stdin is used as the exec command input, the command list is terminated with <Ctrl-C>, “EOF<Return>” or “*eof_string*<Return>”.

If an error occurs entering an exec file sourced from stdin, all commands after the command returning the error will be silently ignored. The exec command will indicate the command error line number when the stdin input is terminated with an end-of-file input.

eof_string — The ASCII printable string used to indicate the end of the exec file when stdin is used as the exec file source. <Ctrl-C> and “EOF” can always be used to terminate an exec file sourced from stdin.

Default <Ctrl-C>, EOF

Related Commands

boot-bad-exec command on page 323 — Use this command to configure a URL for a CLI script to exec following a failed configuration boot.

boot-good-exec command on page 323 — Use this command to configure a URL for a CLI script to exec following a successful configuration boot.

exit

Syntax **exit [all]**

Context <GLOBAL>

Description

This command returns to the context from which the current level was entered. For example, if you navigated to the current level on a context by context basis, then the **exit** command only moves the cursor back one level.

```
A:ALA-1# configure
A:ALA-1>config# router
A:ALA-1>config>router# ospf
A:ALA-1>config>router>ospf# exit
A:ALA-1>config>router# exit
A:ALA-1>config# exit
```

If you navigated to the current level by entering a command string, then the **exit** command returns the cursor to the context in which the command was initially entered.

```
A:ALA-1# configure router ospf
A:ALA-1>config>router>ospf# exit
A:ALA-1#
```

The **exit all** command moves the cursor all the way back to the root level.

```
A:ALA-1# configure
A:ALA-1>config# router
A:ALA-1>config>router# ospf
A:ALA-1>config>router>ospf# exit all
A:ALA-1#
```

Parameters

all — Exits back to the root CLI context.

help

Syntax **help**
help edit
help global
help special-characters
 <GLOBAL>

Description This command provides a brief description of the help system. The following information displays:

Help may be requested at any point by hitting a question mark '?'.
 In case of an executable node, the syntax for that node will be displayed with an explanation of all parameters.
 In case of sub-commands, a brief description is provided.
 Global Commands:
 Help on global commands can be observed by issuing "help globals" at any time.
 Editing Commands:
 Help on editing commands can be observed by issuing "help edit" at any time.

Parameters **help** — Displays a brief description of the help system.

help edit — Displays help on editing.

Available editing keystrokes:

```
Delete current character.....Ctrl-d
Delete text up to cursor.....Ctrl-u
Delete text after cursor.....Ctrl-k
Move to beginning of line.....Ctrl-a
Move to end of line.....Ctrl-e
Get prior command from history.....Ctrl-p
Get next command from history.....Ctrl-n
Move cursor left.....Ctrl-b
Move cursor right.....Ctrl-f
Move back one word.....Esc-b
Move forward one word.....Esc-f
Convert rest of word to uppercase.....Esc-c
Convert rest of word to lowercase.....Esc-l
Delete remainder of word.....Esc-d
Delete word up to cursor.....Ctrl-w
Transpose current and previous character....Ctrl-t
Enter command and return to root prompt.....Ctrl-z
Refresh input line.....Ctrl-l
```

help global — Displays help on global commands.

Available global commands:

```
back            - Go back a level in the command tree
echo            - Echo the text that is typed in
exec            - Execute a file - use -echo to show the commands and
                 prompts on the screen
exit            - Exit to intermediate mode - use option all to exit to
                 root prompt
help            - Display help
history         - Show command history
info            - Display configuration for the present node
logout         - Log off this system
oam             + OAM Test Suite
ping            - Verify the reachability of a remote host
pwc            - Show the present working context
```

```

sleep          - Sleep for specified number of seconds
ssh           - SSH to a host
telnet        - Telnet to a host
traceroute    - Determine the route to a destination address
tree          - Display command tree structure from the context of
               execution
write         - Write text to another user

```

help special-characters — Displays help on special characters.

Use the following CLI commands to display more information about commands and command syntax:

? — Lists all commands in the current context.

string? — Lists all commands available in the current context that start with the string.

command ? — Display command's syntax and associated keywords.

string<Tab> or **string<Space>** — Complete a partial command name (auto-completion) or list available commands that match the string.

history

Syntax **history**

Context <GLOBAL>

Description This command lists the last 30 commands entered in this session.

Re-execute a command in the history with the **!**n**** command, where **n** is the line number associated with the command in the history output.

For example:

```

A:ALA-1# history
 68 info
 69 exit
 70 info
 71 filter
 72 exit all
 73 configure
 74 router
 75 info
 76 interface "test"
 77 exit
 78 reduced-prompt
 79 info
 80 interface "test"
 81 icmp unreachable exit all
 82 exit all
 83 reduced-prompt
 84 configure router
 85 interface
 86 info
 87 interface "test"
 88 info
 89 reduced-prompt
 90 exit all
 91 configure
 92 card 1

```

```

93 card-type
94 exit
95 router
96 exit
97 history
A:ALA-1# !91
A:ALA-1# configure
A:ALA-1>config#

```

info

Syntax `info [detail]`

Context <GLOBAL>

Description This command displays the running configuration for the configuration context.

The output of this command is similar to the output of a **show config** command. This command, however, lists the configuration of the context where it is entered and all branches below that context level.

By default, the command only enters the configuration parameters that vary from the default values. The **detail** keyword causes all configuration parameters to be displayed.

For example,

```

A:ALA-48>config>router>mpls# info
-----
admin-group "green" 15
admin-group "red" 25
admin-group "yellow" 20
interface "system"
exit
interface "to-104"
    admin-group "green"
    admin-group "red"
    admin-group "yellow"
    label-map 35
        swap 36 nexthop 10.10.10.91
        no shutdown
    exit
exit
path "secondary-path"
    hop 1 10.10.0.111 strict
    hop 2 10.10.0.222 strict
    hop 3 10.10.0.123 strict
    no shutdown
exit
path "to-NYC"
    hop 1 10.10.10.104 strict
    hop 2 10.10.0.210 strict
    no shutdown
exit
path "to-104"
    no shutdown
exit
lsp "to-104"
    to 10.10.10.104
    from 10.10.10.103
    rsvp-resv-style ff

```

```

cspf
...
-----
A:ALA-48>config>router>mpls#
A:ALA-48>config>router>mpls# info detail
-----
frr-object
no resignal-timer
admin-group "green" 15
admin-group "red" 25
admin-group "yellow" 20
interface "system"
    no admin-group
    no shutdown
exit
interface "to-104"
    admin-group "green"
    admin-group "red"
    admin-group "yellow"
    label-map 35
        swap 36 nexthop 10.10.10.91
    no shutdown
    exit
    no shutdown
exit
path "secondary-path"
    hop 1 10.10.0.111 strict
    hop 2 10.10.0.222 strict
    hop 3 10.10.0.123 strict
    no shutdown
exit
path "to-NYC"
    hop 1 10.10.10.104 strict
    hop 2 10.10.0.210 strict
    no shutdown
exit
path "to-104"
    no shutdown
exit
lsp "to-104"
to 10.10.10.104
from 10.10.10.103
rsvp-resv-style ff
adaptive
cspf
include "red"
exclude "green"
adspec
fast-reroute one-to-one
    no bandwidth
    no hop-limit
    node-protect
exit
hop-limit 10
retry-limit 0
retry-timer 30
secondary "secondary-path"
    no standby
    no hop-limit
    adaptive
    no include

```



```

        no exclude
        record
        record-label
        bandwidth 50000
        no shutdown
    exit
    primary "to-NYC"
        hop-limit 50
        adaptive
        no include
        no exclude
        record
        record-label
        no bandwidth
        no shutdown
    exit
    no shutdown
exit
...
-----
A:ALA-48>config>router>mpls#

```

Parameters **detail** — Displays all configuration parameters including parameters at their default values.

logout

Syntax **logout**

Context <GLOBAL>

Description This command logs out of the router session.

When the **logout** command is issued from the console, the login prompt is displayed, and any log IDs directed to the console are discarded. When the console session resumes (regardless of the user), the log output to the console resumes.

When a Telnet session is terminated from a **logout** command, all log IDs directed to the session are removed. When a user logs back in, the log IDs must be re-created.

mrinfo

Syntax `mrinfo [ip-address | dns-name] [router router-instance]`

Context <GLOBAL>

Description This command is used to print relevant multicast information from the target multicast router. Information displayed includes adjacency information, protocol, metrics, thresholds, and flags from the target multicast route

Parameters *ip-address* — Specify the ip-address of the multicast capable target router.
dns-name — Specify the DNS name (if DNS name resolution is configured).

Values 63 characters maximum

router *router-instance* — Specify the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647

Default Base

mstat

Syntax `mstat source [ip-address | dns-name] [group grp-ip-address] [destination dst-ip-address] [hop hop] [router router-instance] [wait-time wait-time]`

Context <GLOBAL>

Description This command traces a multicast path from a source to a receiver and displays multicast packet rate and loss information.

Parameters *source ip-address* — Specify the IP address of the multicast-capable source.
ip-address — Specify the ip-address of the multicast capable target router.
dns-name — Specify the DNS name (if DNS name resolution is configured).

Values 63 characters maximum

group *group-ip-address* — Specify the multicast address of the group to be displayed.

destination *dst-ip-address* — Specify the unicast destination address.

hop count — Specify the maximum number of hops that will be traced from the receiver back toward the source.

Values 1 — 255

Default 32 hops (infinity for the DVMRP routing protocol).

router *router-instance* — Specify the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647

Default Base

wait-time *wait-time* — Specify the number of seconds to wait for the response.

Values 1 — 60

mtrace

Syntax **mtrace source** [*ip-address* | *dns-name*] [**group** *grp-ip-address*] [**destination** *dst-ip-address*] [**hop** *hop*] [**router** *router-instance*] [**wait-time** *wait-time*]

Context <GLOBAL>

Description This command traces a multicast path from a source to a receiver.

Parameters *ip-address* — Specify the ip-address of the multicast capable target router.

dns-name — Specify the DNS name (if DNS name resolution is configured).

Values 63 characters maximum

group *group-ip-address* — Specify the multicast address or DNS name of the group that resolves to the multicast group address that will be used. If the group is not specified, address 224.2.0.1 (the Mbone audio) will be used. This will suffice if packet loss statistics for a particular multicast group are not needed.

destination *dst-p-address* — Specify either the IP address or the DNS name of the unicast destination. If this parameter is omitted the IP address of the system where the command is entered will be used. The receiver parameter can also be used to specify a local interface address as the destination address for sending the trace query. The response will also be returned to the address specified as the receiver.

hop *hop* — Specify the maximum number of hops that will be traced from the receiver back toward the source.

Values 1 — 255

Default 32 hops (infinity for the DVMRP routing protocol).

router-instance — Specify the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647

Default Base

wait-time *wait-time* — Specify the number of seconds to wait for the response.

Values 1 — 60

password

Syntax **password**

Context <ROOT>

Description This command changes a user CLI login password.

When a user logs in after the administrator forces a **new-password-at-login**, or the password has expired (**aging**), then this command is automatically invoked.

When invoked, the user is prompted to enter the old password, the new password, and then the new password again to verify the correct input.

If a user fails to create a new password after the administrator forces a **new-password-at-login** or after the password has expired, the user is not allowed access to the CLI.

ping

Syntax **ping** *{ip-address| ipv6-address | dns-name}* [**rapid** | **detail**] [**ttl** *time-to-live*] [**tos** *type-of-service*] [**size** *bytes*] [**pattern** *pattern*] [**source** *ip-address*] [**interval** *seconds*] [**{next-hop ip-address}** | **{interface interface-name}**] [**bypass-routing**] [**count** *requests*] [**do-not-fragment**] [**router** *[router-instance]*] [**timeout** *timeout*]

Context <GLOBAL>

Description This command is the TCP/IP utility to verify IP reachability.

Parameters *ip-address | dns-name* — The remote host to ping. The IP address or the DNS name (if DNS name resolution is configured) can be specified.

ipv6-address — The IPv6 IP address.

Values x:x:x:x:x:x:x:x (eight 16-bit pieces)
x:x:x:x:x:d.d.d.d
x: 0 — FFFF H
d: 0 — 255 D

rapid | **detail** — The **rapid** parameter specifies to send ping requests rapidly. The results are reported in a single message, not in individual messages for each ping request. By default, five ping requests are sent before the results are reported. To change the number of requests, include the **count** option.

The **detail** parameter includes in the output the interface on which the ping reply was received.

Example output:

```
A:ALA-1# ping 192.168.xx.xx4 detail
PING 192.168.xx.xx4: 56 data bytes
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=0 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=1 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=2 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=3 ttl=64 time=0.000 ms.
64 bytes from 192.168.xx.xx4 via fei0: icmp_seq=4 ttl=64 time=0.000 ms.

---- 192.168.xx.xx4 PING Statistics ----
5 packets transmitted, 5 packets received, 0.00% packet loss
round-trip min/avg/max/stddev = 0.000/0.000/0.000/0.000 ms
A:ALA-1#
```

ttl *time-to-live* — The IP Time To Live (TTL) value to include in the ping request, expressed as a decimal integer.

Values 0 — 128

tos *type-of-service* — The type-of-service (TOS) bits in the IP header of the ping packets, expressed as a decimal integer.

Values 0 — 255

size *bytes* — The size in bytes of the ping request packets.

Default 56 bytes (actually 64 bytes because 8 bytes of ICMP header data are added to the packet)

Values 0 — 65507

pattern *pattern* — A 16-bit pattern string to include in the ping packet, expressed as a decimal integer.

Values 0 — 65535

source *ip-address* — The source IP address to use in the ping requests in dotted decimal notation.

Default The IP address of the egress IP interface.

Values 0.0.0.0 — 255.255.255.255

interval *seconds* — The interval in seconds between consecutive ping requests, expressed as a decimal integer.

Default 1

Values 1 — 10000

next-hop *ip-address* — This option disregards the routing table and will send this packet to the specified next hop address. This address must be on an adjacent router that is attached to a subnet that is common between this and the next-hop router.

Default Per the routing table.

Values A valid IP next hop IP address.

interface *interface-name* — Specify the interface name.

bypass-routing — Send the ping request to a host on a directly attached network bypassing the routing table. The host must be on a directly attached network or an error is returned.

count *requests* — The number of ping requests to send to the remote host, expressed as a decimal integer.

Default 5

Values 1 — 10000

do-not-fragment — Specifies that the request frame should not be fragmented. This option is particularly useful in combination with the size parameter for maximum MTU determination.

router *router-instance* — Specify the router name or service ID.

Default Base

Values *router-name:* Base, management
service-id: 1 — 2147483647

timeout *timeout* — Specify the timeout in seconds.

Default 5

Values 1 — 10

pwc

Syntax **pwc [previous]**

Context <GLOBAL>

Description This command displays the present or previous working context of the CLI session. The **pwc** command provides a user who is in the process of dynamically configuring a chassis a way to display the current or previous working context of the CLI session. The **pwc** command displays a list of the CLI nodes that hierarchically define the current context of the CLI instance of the user.

For example,

```
A:ALA-1>config>router>bgp>group# pwc
-----
Present Working Context :
-----
<root>
  configure
  router Base
  bgp
  group test
  ospf
  area 1
-----
A:ALA-1>config>router>bgp>group#
```

For example,

When the **previous** keyword is specified, the previous context displays. This is the context entered by the CLI parser upon execution of the **exit** command. The current context of the CLI is not affected by the **pwc** command.

For example,

```
A:ALA-1>config>router>bgp>group# pwc previous
-----
Previous Working Context :
-----
<root>
  configure
  router Base
  bgp
  ospf
-----
A:ALA-1>config>router>bgp>group#
```

Parameters **previous** — Specifies to display the previous present working context.

sleep

Syntax **sleep [seconds]**

Context <GLOBAL>

Description This command causes the console session to pause operation (sleep) for 1 second (default) or for the specified number of seconds.

Parameters *seconds* — The number of seconds for the console session to sleep, expressed as a decimal integer.

Default 1
Values 1 — 100

ssh

Syntax **ssh** [*ip-addr* | *dns-name* [*username@ip-addr*] [-*I* *username*] [-*v* *SSH-version*] [**router** *router-instance*] **service-name** *service-name*]

Context <GLOBAL>

Description This command initiates a client SSH session with the remote host and is independent from the administrative or operational state of the SSH server. However, to be the target of an SSH session, the SSH server must be operational.

Quitting SSH while in the process of authentication is accomplished by either executing a ctrl-c or "~." (tilde and dot) assuming the "~" is the default escape character for SSH session.

Parameters *ip-address* | *host-name* — The remote host to which to open an SSH session. The IP address or the DNS name (providing DNS name resolution is configured) can be specified.

-I *user* — The user name to use when opening the SSH session.

router *router-instance* — Specify the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647

Default Base

telnet

Syntax **telnet** [*ip-address* | *dns-name*] [*port*] [**router** *router-instance*]

Context <GLOBAL>

Description This command opens a Telnet session to a remote host. Telnet servers in 7750 SRnetworks limit a Telnet clients to three retries to login. The Telnet server disconnects the Telnet client session after three retries. The number of retry attempts for a Telnet client session is not user-configurable.

Parameters *ip-address* — The IP address or the DNS name (providing DNS name resolution is configured) can be specified.

Values *ipv4-address* a.b.c.d
ipv6-address x:x:x:x:x:x:x[-interface]
x:x:x:x:x:d.d.d[-interface]
x: [0 — FFFF]H
d: [0 — 255]D
ipv6-address

dns-name — Specify the DNS name (if DNS name resolution is configured).

Values 128 characters maximum

port — The TCP port number to use to Telnet to the remote host, expressed as a decimal integer.

Default 23
Values 1 — 65535

router *router-instance* — Specify the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647
Default Base

traceroute

Syntax **traceroute** {*ip-address* | *dns-name*} [**tll** *tll*] [**wait** *milliseconds*] [**no-dns**] [**source** *ip-address*] [**tos** *type-of-service*] [**router** *router-instance*]

Context <GLOBAL>

Description The TCP/IP traceroute utility determines the route to a destination address. Note that aborting a traceroute with the <Ctrl-C> command could require issuing a second <Ctrl-C> command before the prompt is returned.

```
A:ALA-1# traceroute 192.168.xx.xx4
traceroute to 192.168.xx.xx4, 30 hops max, 40 byte packets
 1 192.168.xx.xx4 0.000 ms 0.000 ms 0.000 ms
A:ALA-1#
```

Parameters *ip-address* | *dns-name* — The remote address to traceroute. The IP address or the DNS name (if DNS name resolution is configured) can be specified.

Values *ipv4-address* a.b.c.d
ipv6-address x:x:x:x:x:x:x[-interface]
x:x:x:x:x:d.d.d.d[-interface]
x: [0 — FFFF]H
d: [0 — 255]D
dns-name 128 characters maximum

tll *tll* — The maximum Time-To-Live (TTL) value to include in the traceroute request, expressed as a decimal integer.

Values 1 — 255

wait *milliseconds* — The time in milliseconds to wait for a response to a probe, expressed as a decimal integer.

Default 5000

Values 1 — 60000

no-dns — When the **no-dns** keyword is specified, a DNS lookup for the specified host name will not be performed.

Default DNS lookups are performed

source *ip-address* — The source IP address to use as the source of the probe packets in dotted decimal notation. If the IP address is not one of the device's interfaces, an error is returned.

tos *type-of-service* — The type-of-service (TOS) bits in the IP header of the probe packets, expressed as a decimal integer.

Values 0 — 255

router *router-instance* — Specifies the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647

Default Base

tree

Syntax **tree** [**detail**]

Context <GLOBAL>

Description This command displays the command hierarchy structure from the present working context.

Parameters **detail** — Includes parameter information for each command displayed in the tree output.

write

Syntax **write** {*user* | **broadcast**} *message-string*

Context <GLOBAL>

Description This command sends a console message to a specific user or to all users with active console sessions.

Parameters *user* — The name of a user with an active console session to which to send a console message.

Values Any valid CLI username

broadcast — Specifies that the *message-string* is to be sent to all users logged into the router.

message-string — The message string to send. Allowed values are any string up to 250 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

CLI Environment Commands

alias

Syntax **alias** *alias-name* *alias-command-line*
no alias *alias-name*

Context environment

Description This command enables the substitution of a command line by an alias. Use the **alias** command to create alternative or easier to remember/understand names for an entity or command string. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. Only a single command can be present in the command string. The **alias** command can be entered in any context but must be created in the **root>environment** context.

For example, to create an alias named **soi** to display OSPF interfaces, enter:

alias soi "show router ospf interface"

Parameters *alias-name* — The alias name. Do not use a valid command string for the alias. If the alias specified is an actual command, this causes the command to be replaced by the alias.

alias-command-line — The command line to be associated.

create

Syntax [**no**] **create**

Context environment

Description By default, the **create** command is required to create a new OS entity.
The **no** form of the command disables requiring the **create** keyword.

Default **create** — The create keyword is required.

more

Syntax [**no**] **more**

Context environment

Description This command enables per-screen CLI output, meaning that the output is displayed on a screen-by- screen basis. The terminal screen length can be modified with the **terminal** command.
The following prompt appears at the end of each screen of paginated output:

Press any key to continue (Q to quit)

The **no** form of the command displays the output all at once. If the output length is longer than one screen, the entire output will be displayed, which may scroll the screen.

Default **more** — CLI output pauses at the end of each screen waiting for the user input to continue.

reduced-prompt

Syntax **reduced-prompt** [*number of nodes in prompt*]
no reduced-prompt

Context environment

Description This command configures the maximum number of higher CLI context levels to display in the CLI prompt for the current CLI session. This command is useful when configuring features that are several node levels deep, causing the CLI prompt to become too long.

By default, the CLI prompt displays the system name and the complete context in the CLI.

The number of *nodes* specified indicates the number of higher-level contexts that can be displayed in the prompt. For example, if reduced prompt is set to 2, the two highest contexts from the present working context are displayed by name with the hidden (reduced) contexts compressed into an ellipsis (“...”).

```
A:ALA-1>environment# reduced-prompt 2
A:ALA-1>vonfig>router# interface to-103
A:ALA-1>...router>if#
```

Note that the setting is not saved in the configuration. It must be reset for each CLI session or stored in an **exec** script file.

The **no** form of the command reverts to the default.

Default **no reduced-prompt** — Displays all context nodes in the CLI prompt.

Parameters *number of nodes in prompt* — The maximum number of higher-level nodes displayed by name in the prompt, expressed as a decimal integer.

Default 2

Values 0 — 15

saved-ind-prompt

Syntax [**no**] **saved-ind-prompt**

Context environment

Description This command enables saved indicator in the prompt. When changes are made to the configuration file a “*” appears in the prompt string indicating that the changes have not been saved. When an admin save command is executed the “*” disappears.

```
*A:ALA-48# admin save
Writing file to ftp://128.251.10.43/./sim48/sim48-config.cfg
Saving configuration .... Completed.
A:ALA-48#
```

suggest-internal-objects

Syntax [no] **suggest-internal-objects**

Context environment

Description This command enables suggesting of internally created objects while auto completing. The **no** form of the command disables the command.

terminal

Syntax **terminal**
no terminal

Context environment

Description This command enables the context to configure the terminal screen length for the current CLI session.

length

Syntax **length** *lines*

Context environment>terminal

Description This command sets the number of lines on a screen.

Default 24 — Terminal dimensions are set to 24 lines long by 80 characters wide.

Parameters *lines* — The number of lines for the terminal screen length, expressed as a decimal integer.

Values 1 — 512

width

Syntax **width** *width*

Context environment>terminal

Description This command determines display terminal width.

Default 80 — Terminal dimensions are set to 24 lines long by 80 characters wide.

Parameters *width* — Sets the width of the display terminal.

Values 1 — 512

time-display

Syntax `time-display {local | utc}`

Context environment

Description This command displays time stamps in the CLI session based on local time or Coordinated Universal Time (UTC).

The system keeps time internally in UTC and is capable of displaying the time in either UTC or local time based on the time zone configured.

This configuration command is only valid for times displayed in the current CLI session. This includes displays of event logs, traps and all other places where a time stamp is displayed.

In general all time stamps are shown in the time selected. This includes log entries destined for console/session, memory, or SNMP logs. Log files on compact flash are maintained and displayed in UTC format.

Default `time-display local` — Displays time stamps based on the local time.

Monitor CLI Commands

ccag

Syntax `ccag ccag-id [path {a | b}] [type {sap-sap | sap-net | net-sap}] [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor

Description Displays monitor command output of traffic statistics for Cross Connect Aggregation Groups (CCAGs) ports.

Parameters *ccag-id* — Specifies the CCAG instance to monitor.

path — Specifies the CCA path nodal context where the CCA path bandwidth, buffer and accounting parameters are maintained. The path context must be specified with either the **a** or **b** keyword specifying the CCA path context to be entered.

type — Specify cross connect type.

Values `sap-sap, sap-net, net-sap`

interval — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

cpm-filter

Syntax `cpm-filter`

Context monitor

Description Displays monitor command output for CPM filters.

ip

Syntax `ip entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>cpm-filter

Description This command displays monitor command statistics for IP filter entries.

Parameters `entry entry-id` — Displays information on the specified filter entry ID for the specified filter ID only.

Values 1 — 65535

`interval seconds` — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

ipv6

Syntax `ip entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>cpm-filter

Description This command displays monitor command statistics for IPv6 filter entries.

Parameters `entry entry-id` — Displays information on the specified filter entry ID for the specified filter ID only.

Values 1 — 65535

`interval seconds` — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

mac

Syntax `mac entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>cpm-filter

Description This command displays monitor command statistics for MAC filter entries.

Parameters `entry entry-id` — Displays information on the specified filter entry ID for the specified filter ID only.

Values 1 — 65535

`interval seconds` — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

filter

Syntax `filter`

Context monitor

Description This command enables the context to configure criteria to monitor IP and MAC filter statistics.

ip

Syntax `ip ip-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>filter

Description This command enables IP filter monitoring. The statistical information for the specified IP filter entry displays at the configured interval until the configured count is reached. The first screen displays the current statistics related to the specified IP filter. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta. Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters

ip-filter-id — Displays detailed information for the specified filter ID and its filter entries.

Values 1 — 65535

entry entry-id — Displays information on the specified filter entry ID for the specified filter ID only.

Values 1 — 65535

interval seconds — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-1>monitor# filter ip 10 entry 1 interval 3 repeat 3 absolute
=====
Monitor statistics for IP filter 10 entry 1
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====
A:ALA-1>monitor#

A:ALA-1>monitor# filter ip 10 entry 1 interval 3 repeat 3 rate
=====
Monitor statistics for IP filter 10 entry 1
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 3 sec (Mode: Rate)
-----
```

```

Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====
A:ALA-1>monitor#

```

ipv6

Syntax `ipv6 ipv6-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>filter

Description This command enables IPv6 filter monitoring. The statistical information for the specified IPv6 filter entry displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified IPv6 filter. The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *ipv6-filter-id* — Displays detailed information for the specified IPv6 filter ID and its filter entries.

Values 1 — 65535

entry *entry-id* — Displays information on the specified IPv6 filter entry ID for the specified filter ID only.

Values 1 — 65535

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-48# monitor filter ipv6 100 entry 10 interval 3 repeat 3 absolute
```

```

=====
Monitor statistics for IPv6 filter 100 entry 10
-----
At time t = 0 sec (Base Statistics)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 3 sec (Mode: Absolute)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 6 sec (Mode: Absolute)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 9 sec (Mode: Absolute)
-----
Ing. Matches : 0                               Egr. Matches : 01
=====
A:ALA-48#

```

```
A:ALA-48# monitor filter ipv6 100 entry 10 interval 3 repeat 3 rate
```

```

=====
Monitor statistics for IPv6 filter 100 entry 10
-----
At time t = 0 sec (Base Statistics)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 3 sec (Mode: Rate)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 6 sec (Mode: Rate)
-----
Ing. Matches : 0                               Egr. Matches : 1
-----
At time t = 9 sec (Mode: Rate)
-----
Ing. Matches : 0                               Egr. Matches : 1
=====
A:ALA-48#

```

mac

Syntax `mac mac-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>filter

Description This command enables MAC filter monitoring. The statistical information for the specified MAC filter entry displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified MAC filter. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters

mac-filter-id — The MAC filter policy ID.

Values 1 — 65535

entry *entry-id* — Displays information on the specified filter entry ID for the specified filter ID only.

Values 1 — 65535

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-1>monitor>filter# mac 50 entry 10 interval 3 repeat 3 absolute
=====
Monitor statistics for Mac filter 50 entry 10
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====
```

```
A:ALA-1>monitor>filter# mac 50 entry 10 interval 3 repeat 3 rate
=====
Monitor statistics for Mac filter 50 entry 10
=====
At time t = 0 sec (Base Statistics)
-----
Ing. Matches: 0                               Egr. Matches   : 0
```

```

-----
At time t = 3 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 6 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
-----
At time t = 9 sec (Mode: Rate)
-----
Ing. Matches: 0                               Egr. Matches   : 0
=====
A:ALA-1>monitor>filter#

```

lag

Syntax `lag lag-id [lag-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor

Description This command monitors traffic statistics for Link Aggregation Group (LAG) ports. Statistical information for the specified LAG ID(s) displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified LAG ID. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the “rate per second” for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *lag-id* — The number of the LAG.

Default none — The LAG ID value must be specified.

Values 1 — 200

interval seconds — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```

A:ALA-12# monitor lag 12
=====
Monitor statistics for LAG ID 12
=====

```

```

Port-id      Input      Input      Output      Output      Input      Output
             Bytes      Packets    Bytes      Packets     Errors    Errors
-----
At time t = 0 sec (Base Statistics)
-----
1/1/1        2168900   26450      64          1           0          0
1/1/2        10677318 125610     2273750    26439       0          0
1/1/3        2168490   26445      0           0           0          0
-----
Totals       15014708 178505     2273814    26440       0          0
-----
At time t = 5 sec (Mode: Delta)
-----
1/1/1        0          0          0           0           0          0
1/1/2        258        3          86          1           0          0
1/1/3        82         1          0           0           0          0
-----
Totals       340        4          86          1           0          0
=====
A:ALA-12#

```

lsp-egress-stats

Syntax **lsp-egress-stats**
lsp-egress-stats *lsp-name*

Context show>router>mpls

Description This command displays MPLS LSP egress statistics information.

lsp-ingress-stats

Syntax **lsp-ingress-stats**
lsp-ingress-stats *ip-address* **lsp** *lsp-name*

Context show>router>mpls

Description This command displays MPLS LSP ingress statistics information.

management-access-filter

Syntax **management-access-filter**

Context monitor

Description This command enables the context to monitor management-access filters. These filters are configured in the **config>system>security>mgmt-access-filter** context.

ip

Syntax `ip entry entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>management-access-filter

Description This command monitors statistics for the MAF IP filter entry.

Parameters `entry entry-id` — Specifies an existing IP MAF entry ID.

Values 1 — 9999

`interval seconds` — Configures the interval for each display in seconds.

Default 10

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

ipv6

Syntax `ipv6 entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>management-access-filter

Description This command monitors statistics for the MAF IPv6 filter entry.

Parameters `entry entry-id` — Specifies an existing IP MAF entry ID.

Values 1 — 9999

`interval seconds` — Configures the interval for each display in seconds.

Default 10

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

mac

Syntax `mac entry-id [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>management-access-filter

Description This command monitors statistics for the MAF MAC filter entry.

Parameters `entry entry-id` — Specifies an existing IP MAF entry ID.

Values 1 — 9999

`interval seconds` — Configures the interval for each display in seconds.

Default 10

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

port

Syntax `port port-id [port-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor

Description This command enables port traffic monitoring. The specified port(s) statistical information displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified port(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters `port port-id` — Specify up to 5 port IDs.

Syntax: `port-id` slot/mda/port[.channel]
aps-id aps-group-id[.channel]
aps keyword
group-id 1 — 64
bundle ID bundle-type-slot/mda.bundle-num
bundle keyword
type ima, ppp
bundle-num 1 — 128

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-12>monitor# port 2/1/4 interval 3 repeat 3 absolute
=====
Monitor statistics for Port 2/1/4
=====
```

	Input	Output

At time t = 0 sec (Base Statistics)		

Octets	0	0
Packets	39	175
Errors	0	0

At time t = 3 sec (Mode: Absolute)		

Octets	0	0
Packets	39	175
Errors	0	0

At time t = 6 sec (Mode: Absolute)		

Octets	0	0
Packets	39	175
Errors	0	0

At time t = 9 sec (Mode: Absolute)		

Octets	0	0
Packets	39	175
Errors	0	0
=====		

```
A:ALA-12>monitor#

A:ALA-12>monitor# port 2/1/4 interval 3 repeat 3 rate
=====
Monitor statistics for Port 2/1/4
=====
```

	Input	Output

At time t = 0 sec (Base Statistics)		

```

-----
Octets                                0                                0
Packets                               39                               175
Errors                                0                                0
-----
At time t = 3 sec (Mode: Rate)
-----
Octets                                0                                0
Packets                               0                                0
Errors                                0                                0
-----
At time t = 6 sec (Mode: Rate)
-----
Octets                                0                                0
Packets                               0                                0
Errors                                0                                0
-----
At time t = 9 sec (Mode: Rate)
-----
Octets                                0                                0
Packets                               0                                0
Errors                                0                                0
=====
A:ALA-12>monitor#

```

atm

Syntax `atm [interval seconds] [repeat repeat] [absolute|rate]`

Context monitor>port

Description This command enables ATM port traffic monitoring.

Parameters `interval seconds` — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

port

Syntax **port** *port-id* **atm** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
port *port-id* **atm aal-5** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
port *port-id* **atm ilmi** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
port *port-id* **atm interface-connection** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
port *port-id* **atm pvc** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
port *port-id* **atm pvp** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
port *port-id* **atm pvt** [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor

Description This command monitors ATM port traffic statistics.

Parameters *port-id* — Specify up to 5 port IDs.

Syntax: *port-id* slot/mda/port[.channel]
 aps-id aps-group-id[.channel]
 aps keyword
 group-id 1 — 64
 bundle ID bundle-type-slot/mda.bundle-num
 bundle keyword
 type ima, ppp
 bundle-num 1 — 128

atm — keyword specifying ATM information.

interface-connection — Monitors ATM interface statistics.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

Default Default mode delta

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Default Default mode delta

aal-5 — Displays ATM Adaptation Layer 5 (AAL5) information.

ilmi — Monitors ATM ILMI statistics.

pvc — Identifies the port by the PVC identifier (vpi/vci).

- pvp** — Identifies the port by the permanent virtual path.
- pvt** — Identifies the port by the permanent virtual tunnel.
- oam** — Identifies the port by the OAM test suite ID.

qos

- Syntax** **qos**
- Context** monitor
- Description** This command enables the context to configure criteria to monitor QoS scheduler statistics for specific customers and SAPs.

arbiter-stats

- Syntax** **arbiter-stats**
- Context** monitor>qos
- Description** This command enables the context to configure monitor commands for arbiter statistics.

sap

- Syntax** **sap** *sap-id* [**arbiter** *name* | *root*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
- Context** monitor>qos>arbiter-stats
- Description** This command monitors arbiter statistics for a SAP.
- Parameters**
 - sap-id* — Specify the physical port identifier portion of the SAP definition.
 - arbiter** *name* — Specify the name of the policer control policy arbiter.
 - Values** An existing *scheduler-name* in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.
 - root** — Specify the scheduler to which this queue would be feeding.
 - ingress** — Displays *scheduler-name* statistics applied on the ingress SAP.
 - egress** — Displays *scheduler-name* statistics applied on the egress SAP.
 - interval** *seconds* — Configures the interval for each display in seconds.
 - Default** 11 seconds
 - Values** 11 — 60
 - repeat** *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

subscriber

Syntax **subscriber** *sub-ident-string* [**arbiter** *name* | *root*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>qos>arbiter-stats

Description This command monitors arbiter statistics for a subscriber.

Parameters *sub-ident-string* — Specifies an existing subscriber a identification policy name.

arbiter *name* — Specify the name of the policer control policy arbiter.

Values An existing *scheduler-name* in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

root — Specify the scheduler to which this queue would be feeding.

ingress — Displays *scheduler-name* statistics applied on the ingress SAP.

egress — Displays *scheduler-name* statistics applied on the egress SAP.

interval *seconds* — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

customer

Syntax **customer** *customer-id* **site** *customer-site-name* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>qos>scheduler-stats

Description Use this command to monitor scheduler statistics per customer multi-service-site. The first screen displays the current statistics related to the specified customer ID and customer site name. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta. Monitor commands are similar to **show** commands but only statistical information displays. These commands display selected statistics per the configured number of times at the interval specified.

Parameters *customer-id* — Specifies the ID number to be associated with the customer, expressed as an integer.

Values 1 — 2147483647

site *customer-site-name* — Specify the customer site which is an anchor point for ingress and egress virtual scheduler hierarchy.

scheduler *scheduler-name* — Specify an existing *scheduler-name*. Scheduler names are configured in the **config>qos>scheduler-policy>tier level** context.

Values An existing *scheduler-name* is in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

ingress — Displays the customer's multi-service-site ingress scheduler policy.

egress — Displays the customer's multi-service-site egress scheduler policy.

interval *seconds* — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

sap

Syntax **sap** *sap-id* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>qos>scheduler-stats

Description Use this command to monitor scheduler statistics for a SAP at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified SAP. The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *sap-id* — Specifies the physical port identifier portion of the SAP definition.

scheduler *scheduler-name* — Specify an existing *scheduler-name*. Scheduler names are configured in the `config>qos>scheduler-policy>tier level` context.

Values An existing *scheduler-name* in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

ingress — Displays *scheduler-name* statistics applied on the ingress SAP.

egress — Displays *scheduler-name* statistics applied on the egress SAP.

interval *seconds* — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

subscriber

Syntax **subscriber** *sub-ident-string* [**scheduler** *scheduler-name*] [**ingress** | **egress**] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>qos>scheduler-stats

Description This command monitors scheduler statistics for a subscriber.

Parameters *sub-ident-string* — Specifies an existing subscriber a identification policy name.

scheduler *scheduler-name* — Specify an existing QoS scheduler policy name. Scheduler names are configured in the `config>qos>scheduler-policy>tier level` context.

Values An existing *scheduler-name* in the form of a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

ingress — Displays *scheduler-name* statistics applied on the ingress SAP.

egress — Displays *scheduler-name* statistics applied on the egress SAP.

interval *seconds* — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

router

Syntax **router** *router-instance*

Context monitor

Description This command enables the context to configure criteria to monitor statistical information for BGP, LDP, MPLS, OSPF, OSPF3, PIM,RIP, and RSVP protocols.

Parameters *router-instance* — Specify the router name or service ID.

Values *router-name:* Base, management
service-id: 1 — 2147483647

Default Base

neighbor

Syntax **neighbor** *ip-address [ip-address...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]*

Context monitor>router>bgp

Description This command displays statistical BGP neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters **neighbor** *ip-address* — Displays damping information for entries received from the BGP neighbor. Up to 5 IP addresses can be specified.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-12>monitor>router>bgp# neighbor 180.0.0.10 interval 3 repeat 3 absolute
=====
Monitor statistics for BGP Neighbor 180.0.0.10
=====
At time t = 0 sec
-----
Recd. Prefixes   : 2                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages    : 916              o/p Messages    : 916
i/p Octets       : 17510           o/p Octets      : 17386
i/p Updates     : 2                o/p Updates     : 0
-----
At time t = 3 sec
-----
Recd. Prefixes   : 0                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages    : 0                o/p Messages    : 0
i/p Octets       : 0                o/p Octets      : 0
i/p Updates     : 0                o/p Updates     : 0
-----
At time t = 6 sec
-----
Recd. Prefixes   : 0                Sent Prefixes   : 0
Recd. Paths      : 0                Suppressed Paths : 0
Num of Flaps     : 0
i/p Messages    : 0                o/p Messages    : 0
```

```

i/p Octets      : 0                o/p Octets      : 0
i/p Updates    : 0                o/p Updates    : 0
-----
At time t = 9 sec
-----
Recd. Prefixes : 0                Sent Prefixes  : 0
Recd. Paths    : 0                Suppressed Paths : 0
Num of Flaps   : 0
i/p Messages   : 0                o/p Messages   : 0
i/p Octets     : 6                o/p Octets     : 0
i/p Updates    : 0                o/p Updates    : 0
=====
A:ALA-12>monitor>router>bgp#

```

statistics

Syntax **statistics** [*interval seconds*] [*repeat repeat*] [*absolute* | *rate*]

Context monitor>router>isis

Description This command displays statistical IS-IS traffic information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified router statistics. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters **interval** *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```

A:ALA-12>monitor>router>isis# statistics interval 3 repeat 2 absolute
=====
ISIS Statistics
=====
At time t = 0 sec (Base Statistics)
-----

```

```
ISIS Instance      : 1          SPF Runs          : 2
Purge Initiated   : 0          LSP Regens.      : 11
```

CSPF Statistics

```
Requests          : 0          Request Drops    : 0
Paths Found       : 0          Paths Not Found  : 0
```

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	74	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

At time t = 3 sec (Mode: Absolute)

```
ISIS Instance      : 1          SPF Runs          : 2
Purge Initiated   : 0          LSP Regens.      : 11
```

CSPF Statistics

```
Requests          : 0          Request Drops    : 0
Paths Found       : 0          Paths Not Found  : 0
```

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	74	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

At time t = 6 sec (Mode: Absolute)

```
ISIS Instance      : 1          SPF Runs          : 2
Purge Initiated   : 0          LSP Regens.      : 11
```

CSPF Statistics

```
Requests          : 0          Request Drops    : 0
Paths Found       : 0          Paths Not Found  : 0
```

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	74	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

```
A:ALA-12>monitor>router>isis# statistics interval 3 repeat 2 rate
```

ISIS Statistics

At time t = 0 sec (Base Statistics)

```
ISIS Instance      : 1          SPF Runs          : 2
```

Purge Initiated : 0 LSP Regens. : 11

CSPF Statistics

Requests : 0 Request Drops : 0
Paths Found : 0 Paths Not Found: 0

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	76	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

At time t = 3 sec (Mode: Rate)

ISIS Instance : 1 SPF Runs : 0
Purge Initiated : 0 LSP Regens. : 0

CSPF Statistics

Requests : 0 Request Drops : 0
Paths Found : 0 Paths Not Found: 0

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	0	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

At time t = 6 sec (Mode: Rate)

ISIS Instance : 1 SPF Runs : 0
Purge Initiated : 0 LSP Regens. : 0

CSPF Statistics

Requests : 0 Request Drops : 0
Paths Found : 0 Paths Not Found: 0

PDU Type	Received	Processed	Dropped	Sent	Retransmitted
LSP	0	0	0	0	0
IIH	0	0	0	1	0
CSNP	0	0	0	0	0
PSNP	0	0	0	0	0
Unknown	0	0	0	0	0

A:ALA-12>monitor>router>isis#

session

Syntax `session ldp-id [ldp-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>router>ldp

Description This command displays statistical information for LDP sessions at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified LDP session(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *ldp-id* — Specify the IP address of the LDP session to display.

Values *ip-address[:label-space]*
ip-address — a.b.c.d
label-space — [0..65535]

interval seconds — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-103>monitor>router>ldp# session 10.10.10.104 interval 3 repeat 3 absolute
=====
Monitor statistics for LDP Session 10.10.10.104
=====
-----
                        Sent                Received
-----
At time t = 0 sec (Base Statistics)
-----
FECs                    1                    2
Hello                   5288                5289
Keepalive               8225                8225
Init                    1                    1
Label Mapping           1                    4
Label Request           0                    0
Label Release           0                    0
Label Withdraw          0                    0
```

```

Label Abort                0                0
Notification               0                0
Address                    1                1
Address Withdraw           0                0
-----
At time t = 3 sec (Mode: Absolute)
-----
FECs                       1                2
Hello                     5288            5289
Keepalive                  8226            8226
Init                       1                1
Label Mapping              1                4
Label Request              0                0
Label Release              0                0
Label Withdraw             0                0
Label Abort                0                0
Notification               0                0
Address                    1                1
Address Withdraw           0                0
-----
At time t = 6 sec (Mode: Absolute)
-----
FECs                       1                2
Hello                     5288            5290
Keepalive                  8226            8226
Init                       1                1
Label Mapping              1                4
Label Request              0                0
Label Release              0                0
Label Withdraw             0                0
Label Abort                0                0
Notification               0                0
Address                    1                1
Address Withdraw           0                0
-----
At time t = 9 sec (Mode: Absolute)
-----
FECs                       1                2
Hello                     5288            5290
Keepalive                  8226            8226
Init                       1                1
Label Mapping              1                4
Label Request              0                0
Label Release              0                0
Label Withdraw             0                0
Label Abort                0                0
Notification               0                0
Address                    1                1
Address Withdraw           0                0
=====
A:ALA-12>monitor>router>ldp#

A:ALA-12>monitor>router>ldp# session 10.10.10.104 interval 3 repeat 3 rate
=====
Monitor statistics for LDP Session 10.10.10.104
=====
                                Sent                Received
-----
At time t = 0 sec (Base Statistics)
-----

```

```

FECs                1                2
Hello               5289             5290
Keepalive          8227             8227
Init               1                1
Label Mapping      1                4
Label Request      0                0
Label Release      0                0
Label Withdraw    0                0
Label Abort       0                0
Notification      0                0
Address           1                1
Address Withdraw  0                0
-----
At time t = 3 sec (Mode: Rate)
-----
FECs                0                0
Hello               0                0
Keepalive          0                0
Init               0                0
Label Mapping      0                0
Label Request      0                0
Label Release      0                0
Label Withdraw    0                0
Label Abort       0                0
Notification      0                0
Address           0                0
Address Withdraw  0                0
-----
At time t = 6 sec (Mode: Rate)
-----
FECs                0                0
Hello               0                0
Keepalive          0                0
Init               0                0
Label Mapping      0                0
Label Request      0                0
Label Release      0                0
Label Withdraw    0                0
Label Abort       0                0
Notification      0                0
Address           0                0
Address Withdraw  0                0
-----
At time t = 9 sec (Mode: Rate)
-----
FECs                0                0
Hello               0                0
Keepalive          0                0
Init               0                0
Label Mapping      0                0
Label Request      0                0
Label Release      0                0
Label Withdraw    0                0
Label Abort       0                0
Notification      0                0
Address           0                0
Address Withdraw  0                0
=====
A:ALA-12>monitor>router>ldp#

```

statistics

Syntax `statistics [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>router>ldp

Description Monitor statistics for LDP instance at the configured interval until the configured count is reached. The first screen displays the current statistics related to the LDP statistics. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters **interval** *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-12>monitor>router>ldp# statistics interval 3 repeat 3 absolute
=====
Monitor statistics for LDP instance
=====
At time t = 0 sec (Base Statistics)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 3 sec (Mode: Absolute)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 6 sec (Mode: Absolute)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 9 sec (Mode: Absolute)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
```



```

=====
A:ALA-12>monitor>router>ldp#

A:ALA-12>monitor>router>ldp# statistics interval 3 repeat 3 rate
=====
Monitor statistics for LDP instance
=====
At time t = 0 sec (Base Statistics)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 1                Serv FECs Recv      : 2
-----
At time t = 3 sec (Mode: Rate)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 0                Serv FECs Recv      : 0
-----
At time t = 6 sec (Mode: Rate)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 0                Serv FECs Recv      : 0
-----
At time t = 9 sec (Mode: Rate)
-----
Addr FECs Sent      : 0                Addr FECs Recv      : 0
Serv FECs Sent      : 0                Serv FECs Recv      : 0
=====
A:ALA-12>monitor>router>ldp#

```

interface

Syntax `interface interface [interface...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>router>mpls

Description This command displays statistics for MPLS interfaces at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the MPLS interface(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *interface* — Specify the interface's IP address (*ip-address*) or interface name (*ip-int-name*). Up to 5 interfaces can be specified. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

interval seconds — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10
Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-12>monitor>router>mpls# interface system interval 3 repeat 3 absolute
=====
Monitor statistics for MPLS Interface "system"
=====
At time t = 0 sec (Base Statistics)
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
-----
At time t = 3 sec (Mode: Absolute)
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
-----
At time t = 6 sec (Mode: Absolute)
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
-----
At time t = 9 sec (Mode: Absolute)
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
=====
A:ALA-12>monitor>router>mpls#

A:ALA-12>monitor>router>mpls# interface system interval 3 repeat 3 rate
=====
Monitor statistics for MPLS Interface "system"
=====
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
-----
At time t = 3 sec (Mode: Rate)
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
-----
At time t = 6 sec (Mode: Rate)
-----
Transmitted : Pkts - 0          Octets - 0
Received    : Pkts - 0          Octets - 0
-----
At time t = 9 sec (Mode: Rate)
-----
Transmitted : Pkts - 0          Octets - 0
```

```

Received      : Pkts - 0                      Octets - 0
=====
A:ALA-12>monitor>router>mpls#

```

lsp-egress-statistics

Syntax **lsp-egress-stats** *lsp-name* [**interval seconds**] [**repeat repeat**] [**absolute | rate**]

Context monitor>router>mpls

Description This command displays egress statistics for LSP interfaces at the configured interval until the configured count is reached.

Default **no lsp-egress-statistics**

Parameters **repeat repeat** — Specifies how many times the command is repeated.

Values 10

Values 1 — 999

interval seconds — Specifies the interval for each display, in seconds.

Values 10

Values 3 — 60

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample

```

B:Dut-C-cpm2# monitor router mpls lsp-egress-stats sample repeat 3 interval 10 absolute
=====
Monitor egress statistics for MPLS LSP "sample"
-----
At time t = 0 sec (Base Statistics)
-----
LSP Name      : sample
-----
Collect Stats : Enabled          Accting Plcy. : 5
Adm State     : Up                PSB Match     : True
FC BE
InProf Pkts   : 0                  OutProf Pkts  : 551
InProf Octets : 0                  OutProf Octets: 560918
FC L2
InProf Pkts   : 0                  OutProf Pkts  : 551
InProf Octets : 0                  OutProf Octets: 560918
FC AF
InProf Pkts   : 551                OutProf Pkts  : 0
InProf Octets : 560918             OutProf Octets: 0
FC L1
InProf Pkts   : 551                OutProf Pkts  : 0
InProf Octets : 560918             OutProf Octets: 0
FC H2

```

```

InProf Pkts : 0
InProf Octets : 0
FC EF
InProf Pkts : 0
InProf Octets : 0
FC H1
InProf Pkts : 0
InProf Octets : 0
FC NC
InProf Pkts : 551
InProf Octets : 560918
OutProf Pkts : 551
OutProf Octets: 560918
OutProf Pkts : 551
OutProf Octets: 560918
OutProf Pkts : 551
OutProf Octets: 560918
OutProf Pkts : 0
OutProf Octets: 0

```

At time t = 10 sec (Mode: Absolute)

LSP Name : sample

```

Collect Stats : Enabled
Adm State : Up
FC BE
InProf Pkts : 0
InProf Octets : 0
FC L2
InProf Pkts : 0
InProf Octets : 0
FC AF
InProf Pkts : 580
InProf Octets : 590440
FC L1
InProf Pkts : 580
InProf Octets : 590440
FC H2
InProf Pkts : 0
InProf Octets : 0
FC EF
InProf Pkts : 0
InProf Octets : 0
FC H1
InProf Pkts : 0
InProf Octets : 0
FC NC
InProf Pkts : 580
InProf Octets : 590440
Accting Plcy. : 5
PSB Match : True
OutProf Pkts : 580
OutProf Octets: 590440
OutProf Pkts : 580
OutProf Octets: 590440
OutProf Pkts : 0
OutProf Octets: 0
OutProf Pkts : 0
OutProf Octets: 0
OutProf Pkts : 580
OutProf Octets: 590440
OutProf Pkts : 580
OutProf Octets: 590440
OutProf Pkts : 580
OutProf Octets: 590440
OutProf Pkts : 0
OutProf Octets: 0

```

At time t = 20 sec (Mode: Absolute)

LSP Name : sample

```

Collect Stats : Enabled
Adm State : Up
FC BE
InProf Pkts : 0
InProf Octets : 0
FC L2
InProf Pkts : 0
InProf Octets : 0
FC AF
InProf Pkts : 609
InProf Octets : 619962
FC L1
InProf Pkts : 609
InProf Octets : 619962
Accting Plcy. : 5
PSB Match : True
OutProf Pkts : 609
OutProf Octets: 619962
OutProf Pkts : 609
OutProf Octets: 619962
OutProf Pkts : 0
OutProf Octets: 0
OutProf Pkts : 0
OutProf Octets: 0

```

```

FC H2
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 609
OutProf Octets: 619962
FC EF
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 609
OutProf Octets: 619962
FC H1
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 609
OutProf Octets: 619962
FC NC
InProf Pkts   : 609
InProf Octets : 619962
OutProf Pkts  : 0
OutProf Octets: 0
-----
At time t = 30 sec (Mode: Absolute)
-----
LSP Name      : sample
-----
Collect Stats : Enabled
Adm State     : Up
Accting Plcy. : 5
PSB Match     : True
FC BE
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 638
OutProf Octets: 649484
FC L2
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 638
OutProf Octets: 649484
FC AF
InProf Pkts   : 638
InProf Octets : 649484
OutProf Pkts  : 0
OutProf Octets: 0
FC L1
InProf Pkts   : 638
InProf Octets : 649484
OutProf Pkts  : 0
OutProf Octets: 0
FC H2
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 638
OutProf Octets: 649484
FC EF
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 638
OutProf Octets: 649484
FC H1
InProf Pkts   : 0
InProf Octets : 0
OutProf Pkts  : 638
OutProf Octets: 649484
FC NC
InProf Pkts   : 638
InProf Octets : 649484
OutProf Pkts  : 0
OutProf Octets: 0
=====
B:Dut-C-cpm2#

```

lsp-ingress-statistics

Syntax `lsp-ingress-stats lsp lsp-name sender sender-address [interval seconds] [repeat repeat] [absolute | rate]`

Context monitor>router>mpls

Description This command displays ingress statistics for LSP interfaces at the configured interval until the configured count is reached.

Parameters

repeat *repeat* — Specifies how many times the command is repeated.

Values 10

Values 1 — 999

interval *seconds* — Specifies the interval for each display, in seconds.

Values 10

Values 3 — 60

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
B:Dut-C-cpm2# monitor router mpls lsp-ingress-stats lsp sample 1.1.1.1 repeat 3 interval 10
absolute
```

```
=====
Monitor ingress statistics for MPLS LSP "sample"
-----
```

```
At time t = 0 sec (Base Statistics)
-----
```

```
LSP Name      : sample
Sender        : 1.1.1.1
-----
```

```
Collect Stats : Enabled          Accting Plcy. : None
Adm State     : Up              PSB Match    : True
FC BE
InProf Pkts  : 539              OutProf Pkts : 0
InProf Octets : 548702          OutProf Octets : 0
FC L2
InProf Pkts  : 0                OutProf Pkts : 539
InProf Octets : 0                OutProf Octets : 548702
FC AF
InProf Pkts  : 0                OutProf Pkts : 0
InProf Octets : 0                OutProf Octets : 0
FC L1
InProf Pkts  : 1078             OutProf Pkts : 0
InProf Octets : 1097404         OutProf Octets : 0
FC H2
InProf Pkts  : 0                OutProf Pkts : 539
InProf Octets : 0                OutProf Octets : 548702
FC EF
InProf Pkts  : 539              OutProf Pkts : 0
InProf Octets : 548702          OutProf Octets : 0
FC H1
InProf Pkts  : 539              OutProf Pkts : 0
InProf Octets : 548702          OutProf Octets : 0
FC NC
InProf Pkts  : 0                OutProf Pkts : 539
InProf Octets : 0                OutProf Octets : 548702
-----
```

```
At time t = 10 sec (Mode: Absolute)
-----
```

```
LSP Name      : sample
```

Sender : 1.1.1.1

```

-----
Collect Stats : Enabled          Accting Plcy. : None
Adm State    : Up              PSB Match    : True
FC BE
InProf Pkts  : 568             OutProf Pkts : 0
InProf Octets : 578224         OutProf Octets : 0
FC L2
InProf Pkts  : 0              OutProf Pkts  : 568
InProf Octets : 0              OutProf Octets : 578224
FC AF
InProf Pkts  : 0              OutProf Pkts  : 0
InProf Octets : 0              OutProf Octets : 0
FC L1
InProf Pkts  : 1136           OutProf Pkts  : 0
InProf Octets : 1156448       OutProf Octets : 0
FC H2
InProf Pkts  : 0              OutProf Pkts  : 568
InProf Octets : 0              OutProf Octets : 578224
FC EF
InProf Pkts  : 568             OutProf Pkts  : 0
InProf Octets : 578224         OutProf Octets : 0
FC H1
InProf Pkts  : 568             OutProf Pkts  : 0
InProf Octets : 578224         OutProf Octets : 0
FC NC
InProf Pkts  : 0              OutProf Pkts  : 568
InProf Octets : 0              OutProf Octets : 578224
-----

```

At time t = 20 sec (Mode: Absolute)

LSP Name : sample
Sender : 1.1.1.1

```

-----
Collect Stats : Enabled          Accting Plcy. : None
Adm State    : Up              PSB Match    : True
FC BE
InProf Pkts  : 597             OutProf Pkts : 0
InProf Octets : 607746         OutProf Octets : 0
FC L2
InProf Pkts  : 0              OutProf Pkts  : 597
InProf Octets : 0              OutProf Octets : 607746
FC AF
InProf Pkts  : 0              OutProf Pkts  : 0
InProf Octets : 0              OutProf Octets : 0
FC L1
InProf Pkts  : 1194           OutProf Pkts  : 0
InProf Octets : 1215492       OutProf Octets : 0
FC H2
InProf Pkts  : 0              OutProf Pkts  : 597
InProf Octets : 0              OutProf Octets : 607746
FC EF
InProf Pkts  : 597             OutProf Pkts  : 0
InProf Octets : 607746         OutProf Octets : 0
FC H1
InProf Pkts  : 597             OutProf Pkts  : 0
InProf Octets : 607746         OutProf Octets : 0
FC NC
InProf Pkts  : 0              OutProf Pkts  : 597
InProf Octets : 0              OutProf Octets : 607746
-----

```

At time t = 30 sec (Mode: Absolute)

```
-----  
LSP Name      : sample  
Sender        : 1.1.1.1  
-----  
Collect Stats : Enabled                Accting Plcy. : None  
Adm State     : Up                    PSB Match    : True  
FC BE  
InProf Pkts  : 627                    OutProf Pkts : 0  
InProf Octets : 638286                OutProf Octets : 0  
FC L2  
InProf Pkts  : 0                      OutProf Pkts : 627  
InProf Octets : 0                    OutProf Octets : 638286  
FC AF  
InProf Pkts  : 0                      OutProf Pkts : 0  
InProf Octets : 0                    OutProf Octets : 0  
FC L1  
InProf Pkts  : 1254                   OutProf Pkts : 0  
InProf Octets : 1276572               OutProf Octets : 0  
FC H2  
InProf Pkts  : 0                      OutProf Pkts : 627  
InProf Octets : 0                    OutProf Octets : 638286  
FC EF  
InProf Pkts  : 627                    OutProf Pkts : 0  
InProf Octets : 638286                OutProf Octets : 0  
FC H1  
InProf Pkts  : 627                    OutProf Pkts : 0  
InProf Octets : 638286                OutProf Octets : 0  
FC NC  
InProf Pkts  : 0                      OutProf Pkts : 627  
InProf Octets : 0                    OutProf Octets : 638286  
=====
```

B:Dut-C-cpm2#

ospf

Syntax `ospf [ospf-instance]`

Context `monitor>router>ospf`

Description This command enables the context to configure monitor commands for the OSPF instance.

Parameters *ospf-instance* — Specifies the OSPF instance.

Values 1 — 31

ospf3

Syntax `ospf3`

Context `monitor>router`

Description This command enables the context to configure monitor commands for the OSPF3 instance.

interface

Syntax `interface interface [interface...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

Context
 monitor>router>ospf
 monitor>router>ospf3

Description This command displays statistics for OSPF interfaces at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the OSPF interface(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the “rate per second” for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *interface* — Specify the interface's IP address (*ip-address*) or interface name (*ip-int-name*). Up to 5 interfaces can be specified. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

interval seconds — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
A:ALA-12>monitor>router>ospf# interface to-104 interval 3 repeat 3 absolute
=====
Monitor statistics for OSPF Interface "to-104"
=====
At time t = 0 sec (Base Statistics)
-----
Tot Rx Packets : 8379          Tot Tx Packets : 8528
Rx Hellos      : 8225          Tx Hellos      : 8368
Rx DBDs        : 6             Tx DBDs        : 12
Rx LSRs        : 2             Tx LSRs        : 1
Rx LSUs        : 55           Tx LSUs        : 95
Rx LS Acks     : 91           Tx LS Acks     : 52
Retransmits    : 2            Discards       : 0
Bad Networks   : 0            Bad Virt Links : 0
Bad Areas      : 0            Bad Dest Adrs  : 0
Bad Auth Types : 0            Auth Failures  : 0
```

```

Bad Neighbors : 0
Bad Lengths : 0
Bad Dead Int. : 0
Bad Versions : 0
Bad Pkt Types : 0
Bad Hello Int. : 0
Bad Options : 0

```

```
-----
At time t = 3 sec (Mode: Absolute)
-----
```

```

Tot Rx Packets : 8379
Rx Hellos : 8225
Rx DBDs : 6
Rx LSRs : 2
Rx LSUs : 55
Rx LS Acks : 91
Retransmits : 2
Bad Networks : 0
Bad Areas : 0
Bad Auth Types : 0
Bad Neighbors : 0
Bad Lengths : 0
Bad Dead Int. : 0
Bad Versions : 0
Tot Tx Packets : 8528
Tx Hellos : 8368
Tx DBDs : 12
Tx LSRs : 1
Tx LSUs : 95
Tx LS Acks : 52
Discards : 0
Bad Virt Links : 0
Bad Dest Addrs : 0
Auth Failures : 0
Bad Pkt Types : 0
Bad Hello Int. : 0
Bad Options : 0

```

```
-----
At time t = 6 sec (Mode: Absolute)
-----
```

```

Tot Rx Packets : 8380
Rx Hellos : 8226
Rx DBDs : 6
Rx LSRs : 2
Rx LSUs : 55
Rx LS Acks : 91
Retransmits : 2
Bad Networks : 0
Bad Areas : 0
Bad Auth Types : 0
Bad Neighbors : 0
Bad Lengths : 0
Bad Dead Int. : 0
Bad Versions : 0
Tot Tx Packets : 8529
Tx Hellos : 8369
Tx DBDs : 12
Tx LSRs : 1
Tx LSUs : 95
Tx LS Acks : 52
Discards : 0
Bad Virt Links : 0
Bad Dest Addrs : 0
Auth Failures : 0
Bad Pkt Types : 0
Bad Hello Int. : 0
Bad Options : 0

```

```
-----
At time t = 9 sec (Mode: Absolute)
-----
```

```

Tot Rx Packets : 8380
Rx Hellos : 8226
Rx DBDs : 6
Rx LSRs : 2
Rx LSUs : 55
Rx LS Acks : 91
Retransmits : 2
Bad Networks : 0
Bad Areas : 0
Bad Auth Types : 0
Bad Neighbors : 0
Bad Lengths : 0
Bad Dead Int. : 0
Bad Versions : 0
Tot Tx Packets : 8529
Tx Hellos : 8369
Tx DBDs : 12
Tx LSRs : 1
Tx LSUs : 95
Tx LS Acks : 52
Discards : 0
Bad Virt Links : 0
Bad Dest Addrs : 0
Auth Failures : 0
Bad Pkt Types : 0
Bad Hello Int. : 0
Bad Options : 0

```

```
=====
A:ALA-12>monitor>router>ospf#
```

```
A:ALA-12>monitor>router>ospf# interface to-104 interval 3 repeat 3 rate
=====
```

Monitor statistics for OSPF Interface "to-104"

=====
 At time t = 0 sec (Base Statistics)

```
-----
Tot Rx Packets : 8381                Tot Tx Packets : 8530
Rx Hellos      : 8227                Tx Hellos      : 8370
Rx DBDs       : 6                    Tx DBDs       : 12
Rx LSRs       : 2                    Tx LSRs       : 1
Rx LSUs       : 55                   Tx LSUs       : 95
Rx LS Acks    : 91                   Tx LS Acks    : 52
Retransmits   : 2                    Discards      : 0
Bad Networks  : 0                    Bad Virt Links : 0
Bad Areas     : 0                    Bad Dest Adrs : 0
Bad Auth Types : 0                   Auth Failures : 0
Bad Neighbors : 0                    Bad Pkt Types : 0
Bad Lengths   : 0                    Bad Hello Int. : 0
Bad Dead Int. : 0                    Bad Options   : 0
Bad Versions  : 0
-----
```

At time t = 3 sec (Mode: Rate)

```
-----
Tot Rx Packets : 0                    Tot Tx Packets : 0
Rx Hellos      : 0                    Tx Hellos      : 0
Rx DBDs       : 0                    Tx DBDs       : 0
Rx LSRs       : 0                    Tx LSRs       : 0
Rx LSUs       : 0                    Tx LSUs       : 0
Rx LS Acks    : 0                    Tx LS Acks    : 0
Retransmits   : 0                    Discards      : 0
Bad Networks  : 0                    Bad Virt Links : 0
Bad Areas     : 0                    Bad Dest Adrs : 0
Bad Auth Types : 0                   Auth Failures : 0
Bad Neighbors : 0                    Bad Pkt Types : 0
Bad Lengths   : 0                    Bad Hello Int. : 0
Bad Dead Int. : 0                    Bad Options   : 0
Bad Versions  : 0
-----
```

At time t = 6 sec (Mode: Rate)

```
-----
Tot Rx Packets : 0                    Tot Tx Packets : 0
Rx Hellos      : 0                    Tx Hellos      : 0
Rx DBDs       : 0                    Tx DBDs       : 0
Rx LSRs       : 0                    Tx LSRs       : 0
Rx LSUs       : 0                    Tx LSUs       : 0
Rx LS Acks    : 0                    Tx LS Acks    : 0
Retransmits   : 0                    Discards      : 0
Bad Networks  : 0                    Bad Virt Links : 0
Bad Areas     : 0                    Bad Dest Adrs : 0
Bad Auth Types : 0                   Auth Failures : 0
Bad Neighbors : 0                    Bad Pkt Types : 0
Bad Lengths   : 0                    Bad Hello Int. : 0
Bad Dead Int. : 0                    Bad Options   : 0
Bad Versions  : 0
-----
```

At time t = 9 sec (Mode: Rate)

```
-----
Tot Rx Packets : 0                    Tot Tx Packets : 0
Rx Hellos      : 0                    Tx Hellos      : 0
Rx DBDs       : 0                    Tx DBDs       : 0
Rx LSRs       : 0                    Tx LSRs       : 0
Rx LSUs       : 0                    Tx LSUs       : 0
Rx LS Acks    : 0                    Tx LS Acks    : 0
-----
```

```

Retransmits      : 0
Bad Networks     : 0
Bad Areas        : 0
Bad Auth Types   : 0
Bad Neighbors    : 0
Bad Lengths      : 0
Bad Dead Int.    : 0
Bad Versions     : 0
Discards         : 0
Bad Virt Links   : 0
Bad Dest Adrs   : 0
Auth Failures    : 0
Bad Pkt Types    : 0
Bad Hello Int.   : 0
Bad Options      : 0
=====
A:ALA-12>monitor>router>ospf#

```

neighbor

Syntax **neighbor** *ip-address* [*ip-address...*(up to 5 max)] [*interval seconds*] [*repeat repeat*] [*absolute | rate*]

Context monitor>router>ospf

Description This command displays statistical OSPF or OSPF3 neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified OSPF neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters **neighbor** *ip-address* — The IP address to display information for entries received from the specified OSPF neighbor. Up to 5 IP addresses can be specified.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```

A:ALA-12>monitor>router# ospf neighbor 10.0.0.104 interval 3 repeat 3 absolute
=====
Monitor statistics for OSPF Neighbor 10.0.0.104
=====
At time t = 0 sec (Base Statistics)

```

```

-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
-----

At time t = 3 sec (Mode: Absolute)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
-----

At time t = 6 sec (Mode: Absolute)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
-----

At time t = 9 sec (Mode: Absolute)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
=====
A:ALA-12>monitor>router#

A:ALA-12>monitor>router# ospf neighbor 10.0.0.104 interval 3 repeat 3 absolute
=====
Monitor statistics for OSPF Neighbor 10.0.0.104
=====
-----
At time t = 0 sec (Base Statistics)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
-----

At time t = 3 sec (Mode: Rate)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
-----

At time t = 6 sec (Mode: Rate)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0
Option Mismatches : 0                Nbr Duplicates  : 0
-----

At time t = 9 sec (Mode: Rate)
-----
Bad Nbr States      : 0                LSA Inst fails   : 0
Bad Seq Num        : 0                Bad MTUs         : 0
Bad Packets        : 0                LSA not in LSDB : 0

```

```

Option Mismatches: 0                               Nbr Duplicates : 0
=====
A:ALA-12>monitor>router#

```

neighbor

Syntax **neighbor** [*router-id*] [*interface-name*] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>router>ospf3

Description This command displays statistical OSPF or OSPF3 neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified OSPF neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters **neighbor** *ip-address* — The IP address to display information for entries received from the specified OSPF neighbor. Up to 5 IP addresses can be specified.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

router-id — The router ID for an existing IP interface.

virtual-link

Syntax **virtual-link** *nbr-rtr-id* **area** *area-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>router>ospf
monitor>router>ospf3

Description This command displays statistical OSPF virtual link information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters

nbr-rtr-id — The IP address to uniquely identify a neighboring router in the autonomous system.

area *area-id* — The OSPF area ID, expressed in dotted decimal notation or as a 32-bit decimal integer.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

virtual-neighbor

Syntax **virtual-neighbor** *nbr-rtr-id* **area** *area-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>router>ospf
monitor>router>ospf3

Description

This command displays statistical OSPF virtual neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified OSPF virtual neighbor router. The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters

nbr-rtr-id — The IP address to uniquely identify a neighboring router in the autonomous system.

area *area-id* — The OSPF area ID, expressed in dotted decimal notation or as a 32-bit decimal integer.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

group

Syntax **group** *grp-ip-address* [**source** *ip-address*] [**interval** *interval*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>router>pim

Description This command monitors statistics for a PIM source group.

Parameters *grp-ip-address* — The IP address of an multicast group that identifies a set of recipients that are interested in a particular data stream.

source *ip-address* — The source IP address to use in the ping requests in dotted decimal notation.

Default The IP address of the egress IP interface.

Values 0.0.0.0 — 255.255.255.255

interval *interval* — Configures the interval for each display in seconds.

Default 10 seconds

Values 10|20|30|40|50|60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

neighbor

Syntax **neighbor** *neighbor* [*neighbor...*(up to 5 max)] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>router>rip

Description This command displays statistical RIP neighbor information at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified RIP neighbor(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

- Parameters**
- neighbor** *ip-address* — The IP address to display information for entries received from the specified RIP neighbor. Up to 5 IP addresses can be displayed.
 - interval** *seconds* — Configures the interval for each display in seconds.
 - Default** 5 seconds
 - Values** 3 — 60
 - repeat** *repeat* — Configures how many times the command is repeated.
 - Default** 10
 - Values** 1 — 999
 - absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.
 - rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

interface

- Syntax** **interface** *interface* [*interface...*(up to 5 max)][**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]
- Context** monitor>router>rsvp
- Description**

This command displays statistics for RSVP interfaces at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the RSVP interface(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.
- Parameters**
 - interface** — Specify the interface's IP address (*ip-address*) or interface name (*ip-int-name*). Up to 5 interfaces can be specified. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.
 - interval** *seconds* — Configures the interval for each display in seconds.
 - Default** 5 seconds
 - Values** 3 — 60
 - repeat** *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

service

Syntax **service**

Context monitor

Description This command enables the context to configure criteria to monitor specific service SAP criteria.

id

Syntax **id** *service-id*

Context monitor>service

Description This command displays statistics for a specific service, specified by the *service-id*, at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the *service-id*. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters *service-id* — The unique service identification number which identifies the service in the service domain.

sap

Syntax **sap** *sap-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>service>id *service-id*

Description This command monitors statistics for a SAP associated with this service.

This command displays statistics for a specific SAP, identified by the *port-id* and encapsulation value, at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the SAP. The subsequent statistical information listed for each interval is displayed as a delta to the previous display. When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

Parameters

sap-id — Specifies the physical port identifier portion of the SAP definition.

Values	<i>sap-id</i> :	null [port-id bundle-id bpgrp-id lag-id aps-id] dot1q [port-id bundle-id bpgrp-id lag-id aps-id]:qtag1 QinQ [port-id bundle-id bpgrp-id lag-id]:qtag1.qtag2 atm [port-id aps-id bundle-id bpgrp-id][:vpi/vci vpi vpi1.vpi2] frame [port-id bundle-id]:dlci cisco-hdlc slot/mda/port.channel
	port-id	slot/mda/port[.channel]
	aps-id	aps-group-id[.channel]
	aps	keyword
	group-id	1 — 64
	bundle-type-slot/mda.bundle-num	
	bundle	keyword
	type	ima, fr, ppp
	bundle-num	1 — 128
	bpgrp-id:	bpgrp-type-bpgrp-num
	bpgrp	keyword
	type	ima
	bpgrp-num	1 — 1280
	ccag-id	ccag-id.path-id[cc-type]:cc-id
	ccag	keyword
	id	1 — 8
	path-id	a, b
	cc-type	.sap-net, .net-sap
	cc-id	0 — 4094
	lag-id	lag-id
	lag	keyword
	id	1 — 200
	qtag1	0 — 4094
	qtag2	*, 0 — 4094
	vpi	NNI 0 — 4095 UNI 0 — 255
	vci	1, 2, 5 — 65535
	dlci	16 — 1022

port-id — Specifies the physical port ID in the *slot/mda/port* format.

If the card in the slot has MDAs installed, the *port-id* must be in the slot_number/MDA_number/port_number format. For example 6/2/3 specifies port 3 on MDA 2 in slot 6.

The *port-id* must reference a valid port type. When the *port-id* parameter represents SONET/SDH and TDM channels, the port ID must include the channel ID. A period “.” separates the physical port from the *channel-id*. The port must be configured as an access port.

If the SONET/SDH port is configured as clear-channel then only the port is specified.

bundle-id — Specifies the multilink bundle to be associated with this IP interface. The **bundle** keyword must be entered at the beginning of the parameter.

The command syntax must be configured as follows:

bundle-id: **bundle-type-slot-id/mda-slot.bundle-num**
bundle-id value range: 1 — 128

For example:

```
*A:ALA-12>config# port bundle-ppp-5/1.1
*A:ALA-12>config>port# multilink-bundle
```

bggrp-id — Specifies the bundle protection group ID to be associated with this IP interface. The **bggrp** keyword must be entered at the beginning of the parameter.

The command syntax must be configured as follows:

bggrp-id: **bggrp-type-bggrp-num**
type: ima
bggrp-num value range: 1 — 1280

For example:

```
*A:ALA-12>config# port bggrp-ima-1
*A:ALA-12>config>service>vpls$ sap bggrp-ima-1
```

qtag1, *qtag2* — Specifies the encapsulation value used to identify the SAP on the port or sub-port. If this parameter is not specifically defined, the default value is 0.

Values *qtag1:* 0 — 4094
qtag2: * | 0 — 4094

The values depends on the encapsulation type configured for the interface. The following table describes the allowed values for the port and encapsulation types.

Port Type	Encap-Type	Allowed Values	Comments
Ethernet	Null	0	The SAP is identified by the port.
Ethernet	Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the port. Note that a 0 <i>qtag1</i> value also accepts untagged packets on the dot1q port.
Ethernet	QinQ	<i>qtag1:</i> 0 — 4094 <i>qtag2:</i> 0 — 4094	The SAP is identified by two 802.1Q tags on the port. Note that a 0 <i>qtag1</i> value also accepts untagged packets on the dot1q port.
SONET/SDH	IPCP	-	The SAP is identified by the channel. No BCP is deployed and all traffic is IP.
SONET/SDH TDM	BCP-Null	0	The SAP is identified with a single service on the channel. Tags are assumed to be part of the customer packet and not a service delimiter.

SONET/SDH TDM	BCP-Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the channel.
SONET/SDH TDM	Frame Relay	16 — 991	The SAP is identified by the data link connection identifier (DLCI).
SONET/SDH ATM	ATM	vpi (NNI) 0 — 4095 vpi (UNI) 0 — 255 vci 1, 2, 5 — 65535 -	The SAP is identified by port or by PVPC or PVCC identifier (vpi, vpi/vci, or vpi range)

interval *seconds* — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the absolute rate-per-second value for each statistic is displayed.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```
*A:cses-A13# monitor service id 88 sap 1/1/2:0
=====
Monitor statistics for Service 88 SAP 1/1/2:0
=====
-----
At time t = 0 sec (Base Statistics)
-----
-----
Sap Statistics
-----
Last Cleared Time      : N/A
                        Packets          Octets
Forwarding Engine Stats
Dropped                : 0                0
Off. HiPrio            : 0                0
Off. LowPrio           : 0                0
Off. Uncolor           : 0                0

Queueing Stats (Ingress QoS Policy 1)
Dro. HiPrio            : 0                0
Dro. LowPrio           : 0                0
For. InProf            : 0                0
For. OutProf           : 0                0

Queueing Stats (Egress QoS Policy 1)
Dro. InProf            : 0                0
Dro. OutProf           : 0                0
```

```

For. InProf          : 0                0
For. OutProf         : 0                0
-----
Sap per Queue Stats
-----
                Packets                Octets

Ingress Queue 1 (Unicast) (Priority)
Off. HiPrio         : 0                0
Off. LoPrio         : 0                0
Dro. HiPrio         : 0                0
Dro. LoPrio         : 0                0
For. InProf         : 0                0
For. OutProf        : 0                0

```

sdp

Syntax `sdp {sdp-id | far-end ip-address} [interval seconds] [repeat repeat] [absolute | rate]`

Context `monitor>service>id service-id`

Description This command monitors statistics for a SDP binding associated with this service.

Parameters *sdp-id* — Specify the SDP identifier.

Values 1 — 17407

far-end ip-address — The system address of the far-end SR OS router for the SDP in dotted decimal notation.

interval seconds — Configures the interval for each display in seconds.

Default 11 seconds

Values 11 — 60

repeat repeat — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the absolute rate-per-second value for each statistic is displayed.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Sample Output

```

A:ALA-12# monitor service id 100 sdp 10 repeat 3
=====
Monitor statistics for Service 100 SDP binding 10
=====
At time t = 0 sec (Base Statistics)
-----
I. Fwd. Pkts.      : 0                I. Dro. Pkts.      : 0

```

```

E. Fwd. Pkts.      : 0                      E. Fwd. Octets   : 0
-----
At time t = 11 sec (Mode: Delta)
-----
I. Fwd. Pkts.      : 0                      I. Dro. Pkts.    : 0
E. Fwd. Pkts.      : 0                      E. Fwd. Octets   : 0
-----
At time t = 22 sec (Mode: Delta)
-----
I. Fwd. Pkts.      : 0                      I. Dro. Pkts.    : 0
E. Fwd. Pkts.      : 0                      E. Fwd. Octets   : 0
-----
At time t = 33 sec (Mode: Delta)
-----
I. Fwd. Pkts.      : 0                      I. Dro. Pkts.    : 0
E. Fwd. Pkts.      : 0                      E. Fwd. Octets   : 0
=====
A:ALA-12#

```

vrrp

Syntax vrrp

Context monitor>router

Description This command enables the context to configure criteria to monitor VRRP statistical information for a VRRP enabled on a specific interface.

instance

Syntax instance interface *interface-name* **vr-id** *virtual-router-id* [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>router>vrrp

Description Monitor statistics for a VRRP instance.

Parameters *interface-name* — The name of the existing IP interface on which VRRP is configured.
vr-id *virtual-router-id* — The virtual router ID for the existing IP interface, expressed as a decimal integer.

interval *seconds* — Configures the interval for each display in seconds.

Default 5 seconds

Values 3 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

subscriber

Syntax **subscriber** *sub-ident-string* **sap** *sap-id* **sla-profile** *sla-profile-name* [**base** | **ingress-queue-id** *ingress-queue-id* | **egress-queue-id** *egress-queue-id*] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

Context monitor>service

Description This command monitors statistics for a subscriber.

Parameters **sub-ident-string** — Specifies an existing subscriber identification profile to monitor.

sap *sap-id* — Specifies the physical port identifier portion of the SAP definition.

Values dlc1 16 — 1022

sla-profile *sla-profile-name* — Specifies an existing SLA profile.

interval *seconds* — Configures the interval for each display in seconds

Default 11

Values 11 — 60

repeat *repeat* — Configures how many times the command is repeated.

Default 10

Values 1 — 999

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

Default mode delta

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

base — Monitor base statistics.

ingress-queue-id *ingress-queue-id* — Monitors statistics for this queue.

Values 1 — 32

egress-queue-id *egress-queue-id* — Monitors statistics for this queue.

Values 1 — 8

Sample Output

```
A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default
=====
Monitor statistics for Subscriber alcatel_100
=====
At time t = 0 sec (Base Statistics)
-----
```


SLA Profile Instance statistics

```
-----
                Packets                Octets
Off. HiPrio      : 0                    0
Off. LowPrio     : 94531                30704535
Off. Uncolor     : 0                    0
```

Queueing Stats (Ingress QoS Policy 1000)

```
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 7332                2510859
For. InProf      : 0                    0
For. OutProf     : 87067               28152288
```

Queueing Stats (Egress QoS Policy 1000)

```
Dro. InProf      : 880                  127660
Dro. OutProf     : 0                    0
For. InProf      : 90862               12995616
For. OutProf     : 0                    0
```

SLA Profile Instance per Queue statistics

```
-----
                Packets                Octets
Ingress Queue 1 (Unicast) (Priority)
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0
```

Ingress Queue 2 (Unicast) (Priority)

```
Off. HiPrio      : 0                    0
Off. LowPrio     : 94531                30704535
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 7332                2510859
For. InProf      : 0                    0
For. OutProf     : 87067               28152288
```

Ingress Queue 3 (Unicast) (Priority)

```
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0
```

Ingress Queue 11 (Multipoint) (Priority)

```
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0
```

Egress Queue 1

```
Dro. InProf      : 880                  127660
Dro. OutProf     : 0                    0
```

```

For. InProf      : 90862          12995616
For. OutProf     : 0              0

```

Egress Queue 2

```

Dro. InProf      : 0              0
Dro. OutProf     : 0              0
For. InProf      : 0              0
For. OutProf     : 0              0

```

Egress Queue 3

```

Dro. InProf      : 0              0
Dro. OutProf     : 0              0
For. InProf      : 0              0
For. OutProf     : 0              0

```

=====
A:Dut-A#

A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default base rate

=====
Monitor statistics for Subscriber alcatel_100
=====

At time t = 0 sec (Base Statistics)

SLA Profile Instance statistics

	Packets	Octets
Off. HiPrio	: 0	0
Off. LowPrio	: 109099	35427060
Off. Uncolor	: 0	0
Queueing Stats (Ingress QoS Policy 1000)		
Dro. HiPrio	: 0	0
Dro. LowPrio	: 8449	2894798
For. InProf	: 0	0
For. OutProf	: 100523	32489663
Queueing Stats (Egress QoS Policy 1000)		
Dro. InProf	: 880	127660
Dro. OutProf	: 0	0
For. InProf	: 105578	15104553
For. OutProf	: 0	0

At time t = 11 sec (Mode: Rate)

SLA Profile Instance statistics

	Packets	Octets	% Port Util.
Off. HiPrio	: 0	0	0.00
Off. LowPrio	: 1469	477795	0.38
Off. Uncolor	: 0	0	0.00
Queueing Stats (Ingress QoS Policy 1000)			
Dro. HiPrio	: 0	0	0.00
Dro. LowPrio	: 119	40691	0.03
For. InProf	: 0	0	0.00
For. OutProf	: 1349	437350	0.34
Queueing Stats (Egress QoS Policy 1000)			
Dro. InProf	: 0	0	0.00
Dro. OutProf	: 0	0	0.00
For. InProf	: 1469	209129	0.16
For. OutProf	: 0	0	0.00

```

=====
A:Dut-A#

A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default
ingress-queue-id 1
=====
Monitor statistics for Subscriber alcatel_100
=====
At time t = 0 sec (Base Statistics)
-----
                Packets                Octets
Ingress Queue 1 (Unicast) (Priority)
Off. HiPrio      : 0                    0
Off. LowPrio     : 0                    0
Off. Uncolor     : 0                    0
Dro. HiPrio      : 0                    0
Dro. LowPrio     : 0                    0
For. InProf      : 0                    0
For. OutProf     : 0                    0
=====
A:Dut-A#

```

```

A:Dut-A# monitor service subscriber alcatel_100 sap 1/2/1:101 sla-profile sla_default
egress-queue-id 1
=====
Monitor statistics for Subscriber alcatel_100
-----
At time t = 0 sec (Base Statistics)
-----
                Packets                Octets
Egress Queue 1
Dro. InProf      : 880                  127660
Dro. OutProf     : 0                    0
For. InProf      : 164366               23506178
For. OutProf     : 0                    0
=====
A:Dut-A#

```

Show Commands

alias

Syntax alias

Context <root>

Description This command displays a list of existing aliases.

Output **Show Alias Fields** — The following table describes alias output fields.

Table 18: Show Alias Output Fields

Label	Description
Alias-Name	Displays the name of the alias.
Alias-command-name	The command and parameter syntax that define the alias.
Number of aliases	The total number of aliases configured on the router.

Sample Output

```
A:ALA-103>config>system# show alias
=====
Alias-Name                Alias-command-name
=====
sri                        show router interface
sse                        show service service-using epipe
ssvpls                     show service service-using vpls
ssvprn                     show service service-using vprn
ssi                        show service service-using ies
-----
Number of aliases : 5
=====
A:ALA-103>config>system#
```